



Bricsys®

Справочник системных переменных (V23)

Документация по продукту





Содержание

1.	System variable reference	58
1.1	System variable data types	58
1.2	System variables save location	58
1.3	Editing system variables	59
1.4	Searching for variables	59
2.		60
2.1	_QUADTABFLAGS system variable	60
2.1.1	Quad tab flags	60
2.2	_VERNUM system variable	60
2.2.1	Version number	60
3.	3	61
3.1	3DCOMPAREMODE system variable	61
3.1.1	Compare visualization mode	61
3.2	3DOSMODE system variable	61
3.2.1	3D entity snap mode	61
3.3	3DSNAPMARKERCOLOR system variable	62
3.3.1	3d snap marker color	62
4.	A	63
4.1	ACADLSPASDOC system variable	63
4.1.1	on_start.lsp for each doc	63
4.2	ACADPREFIX system variable	63
4.2.1	Program folder path	63
4.3	ACADVER system variable	63
4.3.1	AutoCAD version	63
4.4	ACISHLRRESOLUTION system variable	64
4.4.1	Hidden line removal resolution	64
4.5	ACISOUTVER system variable	64
4.5.1	Acisout version	64
4.6	ADAPTIVEGRIDSTEPSIZE system variable	64
4.6.1	Adaptive grid step size	64
4.7	AFLAGS system variable	65
4.7.1	Attribute options	65
4.8	ALLOWBREAKLINECROSSINGS system variable	65
4.8.1	Allow breakline crossings	65
4.9	ALLOWEDBENDANGLES system variable	65
4.9.1	Allowed bend angles	65
4.10	ALLOWTABEXTERNALMOVE system variable	66
4.10.1	Move tabs externally (Mac & Linux)	66
4.11	ALLOWTABMOVE system variable	66
4.11.1	Move tabs (Mac & Linux)	66
4.12	ALLOWTABSPLIT system variable	67
4.12.1	Split tabs (Mac & Linux)	67
4.13	ANGBASE system variable	67
4.13.1	Angle base	67
4.14	ANGDIR system variable	67
4.14.1	Angle direction	67
4.15	ANGLESAMPLINGINTERVAL system variable	68



Содержание

4.15.1	Angle sampling interval	68
4.16	ANNOALLVISIBLE system variable	68
4.16.1	Annotation visibility	68
4.17	Системная переменная ANNOAUTOSCALE	68
4.17.1	Масштабирование аннотаций	68
4.18	ANNOTATEDWG system variable	69
4.18.1	Annotative drawing	69
4.19	ANTIALIASRENDER system variable	70
4.19.1	Anti-alias amount for render	70
4.20	ANTALIASSCREEN system variable	70
4.20.1	Anti-alias amount for screen	70
4.21	APBOX system variable	71
4.21.1	Entity snap aperture box	71
4.22	APERTURE system variable	71
4.22.1	Entity snap aperture	71
4.23	ARCTESSELLATION system variable	72
4.23.1	Arc approximation mid-ordinate distance	72
4.24	ARCTESSELLATIONGRADING system variable	72
4.24.1	Arc approximation mid-ordinate distance	72
4.25	ARCTESSELLATIONTEMPLATEELEMENT system variable	72
4.25.1	Template Element arc approximation mid-ordinate distance	72
4.26	AREA system variable	73
4.26.1	Calculated area	73
4.27	AREAPREC system variable	73
4.27.1	Area precision	73
4.28	AREAUNITS system variable	74
4.28.1	Area units	74
4.29	ARRAYASSOCIATIVITY system variable	74
4.29.1	Associative arrays	74
4.30	ARRAYEDITSTATE system variable	74
4.30.1	Array editing state	74
4.31	ARRAYTYPE system variable	75
4.31.1	Array type	75
4.32	CIVILASSOCIATIVITY system variable	75
4.32.1	Associativity	75
4.33	ATTDIA system variable	75
4.33.1	Attribute dialog	75
4.34	ATTMODE system variable	76
4.34.1	Attribute display mode	76
4.35	ATTRACTONDISTANCE system variable	76
4.35.1	Grips attraction distance	76
4.36	ATTREQ system variable	76
4.36.1	Insertion default settings	76
4.37	AUDITCTL system variable	77
4.37.1	Audit control	77
4.38	AUDITERRORCOUNT system variable	77
4.38.1	Audit Error Count	77
4.39	AUNITS system variable	77



Содержание

4.39.1	Angular unit type	77
4.40	AUPREC system variable	78
4.40.1	Angular unit precision	78
4.41	AUTOCOMPLETEDELAY system variable	78
4.41.1	Auto complete delay	78
4.42	AUTOCOMPLETEMODE system variable	79
4.42.1	Auto complete mode	79
4.43	AUTOMATICCONNECTION system variable	79
4.43.1	Automatic connection	79
4.44	AUTOMATICSTAIRSECTIONBEHAVIOR system variable	79
4.44.1	Automatic stair section behavior	79
4.45	AUTOMATICTEES system variable	80
4.45.1	Automatic tees	80
4.46	AUTOMENULOAD system variable	80
4.46.1	Auto menu load	80
4.47	AUTORESETSCALES system variable	81
4.47.1	Purge unused scales	81
4.48	AUTOSAVECHECKSONLYFIRSTBITDBMOD system variable	81
4.48.1	Ignore all but first bit of DBMOD for autosave	81
4.49	AUTOSNAP system variable	82
4.49.1	AutoSnap	82
4.50	AUTOTRACKINGVECCOLOR system variable	82
4.50.1	Auto tracking vector color	82
4.51	AUTOVPFITTING system variable	83
4.51.1	Automatically fit viewport borders	83
5.	B	84
5.1	BACKGROUNDPLOT system variable	84
5.1.1	Background plotting	84
5.2	BACKZ system variable	84
5.2.1	Back clipping plane offset	84
5.3	BASEFILE system variable	84
5.3.1	Template	84
5.4	BCFSOURCEURL system variable	85
5.4.1	BCF source url	85
5.5	BILLOFMATERIALSSETTINGS system variable	85
5.5.1	Bill of materials defaults	85
5.6	BIMACTIVATEPYTHON system variable	85
5.6.1	Activate Python	85
5.7	BIMDEFAULTPROPERTIESPATH system variable	86
5.7.1	Default properties path	86
5.8	BIMMATCHPROP system variable	86
5.8.1	Match BIM Properties	86
5.9	BIMOSMODE system variable	86
5.9.1	BIM snap mode	86
5.10	BIMPROFILESTANDARDS system variable	87
5.10.1	Profile's standards	87
5.11	BINDTYPE system variable	87
5.11.1	Xref bind type	87



Содержание

5.12	BKGCOLOR system variable	88
5.12.1	Background color	88
5.13	BKGCOLORPS system variable	88
5.13.1	Paper space background color	88
5.14	BLIPMODE system variable	88
5.14.1	Blip mode	88
5.15	BLOCKEDITLOCK system variable	89
5.15.1	Block editor lock	89
5.16	BLOCKEDITOR system variable	89
5.16.1	Block editor	89
5.17	BLOCKIFYMODE system variable	89
5.17.1	Blockify settings	89
5.18	BLOCKIFYTOLERANCE system variable	90
5.18.1	Blockify tolerance	90
5.19	BLOCKLEVELOFDETAIL system variable	90
5.19.1	Block Level of detail	90
5.20	BLOCKSPATH system variable	91
5.20.1	Blocks path	91
5.21	BMAUTOUUPDATE system variable	91
5.21.1	Update external components	91
5.22	BMFORMTEMPLATEPATH system variable	91
5.22.1	BMFORM template path	91
5.23	BMUPDATEMODE system variable	92
5.23.1	Assembly components updating mode	92
5.24	BOMFILTERSETTINGS system variable	92
5.24.1	Default BOM filter settings	92
5.25	BOMPROPERTYSET system variable	93
5.25.1	Default BOM property set	93
5.26	BOMTEMPLATE system variable	93
5.26.1	Default template	93
5.27	BOMTHUMBNAILHEIGHT system variable	93
5.27.1	Default thumbnail height, px	93
5.28	BOMTHUMBNAILWIDTH system variable	94
5.28.1	Default thumbnail width, px	94
5.29	BOUNDARYCOLOR system variable	94
5.29.1	Detected Boundary Color	94
5.30	BSYSLIBCOPYOVERWRITE system variable	94
5.30.1	Bsystlib copy overwrite	94
5.31	BVMODE system variable	95
5.31.1	Block Visibility Mode	95
6.	C	96
6.1	CACHELAYOUT system variable	96
6.1.1	Cache layout	96
6.2	CAMERADISPLAY system variable	96
6.2.1	Camera display	96
6.3	CAMERAHEIGHT system variable	96
6.3.1	Camera height	96
6.4	CANNOSCALE system variable	97



Содержание

6.4.1	Annotation scale name	97
6.5	CANNOSCALEVALUE system variable	97
6.5.1	Annotation scale value	97
6.6	CDATE system variable	97
6.6.1	Calendar date	97
6.7	CECOLOR system variable	97
6.7.1	Entity color	97
6.8	CELSCALE system variable	98
6.8.1	Entity linetype scale	98
6.9	CELTTYPE system variable	98
6.9.1	Entity linetype	98
6.10	CELWEIGHT system variable	98
6.10.1	Entity linewidth	98
6.11	CENTERCROSSGAP system variable	99
6.11.1	Center mark cross gap	99
6.12	CENTERCROSSSIZE system variable	99
6.12.1	Center mark cross size	99
6.13	CENTEREXE system variable	100
6.13.1	Centerline extensions length	100
6.14	CENTERLAYER system variable	100
6.14.1	Default layer for center mark or centerline	100
6.15	CENTERLTSCALE system variable	101
6.15.1	Linetype scale for center mark or centerline	101
6.16	CENTERLTYPE system variable	101
6.16.1	Linetype for center mark or centerline	101
6.17	CENTERLTYPEFILE system variable	101
6.17.1	Linetype file for center mark or centerline	101
6.18	CENTERMARKEXE system variable	101
6.18.1	Automatic extension for center mark or centerline	101
6.19	CETRANSPARENCY system variable	102
6.19.1	Transparency for new entities	102
6.20	CHAMFERA system variable	103
6.20.1	Chamfer first distance	103
6.21	CHAMFERB system variable	103
6.21.1	Chamfer second distance	103
6.22	CHAMFERC system variable	103
6.22.1	Chamfer length	103
6.23	CHAMFERD system variable	103
6.23.1	Chamfer angle	103
6.24	CHAMMODE system variable	104
6.24.1	Chamfer mode	104
6.25	CHECKDWLPRESENCE system variable	104
6.25.1	Check Dwl file existence before open	104
6.26	CIRCLERAD system variable	105
6.26.1	Circle radius	105
6.27	CLAYER system variable	105
6.27.1	Current layer	105
6.28	CLEANSCREENOPTIONS system variable	105



Содержание

6.28.1	Clean screen options	105
6.29	CLEANSCREENSTATE system variable	106
6.29.1	Clean screen state	106
6.30	CLIPBOARDFORMAT system variable	106
6.30.1	Clipboard DWG format	106
6.31	CLIPBOARDFORMATS system variable	107
6.31.1	Clipboard Formats	107
6.32	CLIPROMPTLINES system variable	107
6.32.1	Prompt Lines	107
6.33	CLISTATE system variable	108
6.33.1	Command line state	108
6.34	CLOSECHECKSONLYFIRSTBITDBMOD system variable	108
6.34.1	Ignore all but first bit of DBMOD for close	108
6.35	CLOUDDOWNLOADPATH system variable	109
6.35.1	Cloud download path	109
6.36	CLOUDLOG system variable	109
6.36.1	Cloud log	109
6.37	CLOUDLOGVERBOSE system variable	109
6.37.1	Cloud log verbose	109
6.38	CLOUDONMODIFIED system variable	110
6.38.1	Cloud on modified	110
6.39	CLOUDSERVER system variable	110
6.39.1	Cloud server	110
6.40	CLOUDTEMPFOLDER system variable	110
6.40.1	Cloud temporary folder	110
6.41	CLOUDUPLOADDEPENDENCIES system variable	111
6.41.1	Cloud upload dependencies	111
6.42	CMATERIAL system variable	111
6.42.1	Current material	111
6.43	CMDACTIVE system variable	112
6.43.1	Active command	112
6.44	CMDDIA system variable	112
6.44.1	Command dialogs	112
6.45	CMDECHO system variable	112
6.45.1	Command echo	112
6.46	CMDLINEEDITBGCOLOR system variable	113
6.46.1	Command line edit background color	113
6.47	CMDLINEEDITFGCOLOR system variable	113
6.47.1	Command line edit foreground color	113
6.48	CMDLINEFADINGLOGBGCOLOR system variable	114
6.48.1	Command line fading log background color	114
6.49	CMDLINEFADINGLOGFADEDDELAY system variable	114
6.49.1	Command line fading log fade delay	114
6.50	CMDLINEFADINGLOGFGCOLOR system variable	114
6.50.1	Command line fading log foreground color	114
6.51	CMDLINEFADINGLOGTRANSPARENCY system variable	115
6.51.1	Command line fading log transparency	115
6.52	CMDLINEFONTNAME system variable	115



Содержание

6.52.1	Command line font name	115
6.53	CMDLINEFONTSIZE system variable	115
6.53.1	Command line font size	115
6.54	CMDLINEFRAMEACTIVETRANSPARENCY system variable	116
6.54.1	Command line frame transparency when active (Windows)	116
6.55	CMDLINEFRAMEINACTIVETRANSPARENCY system variable	116
6.55.1	Command line frame transparency when inactive (Windows)	116
6.56	CMDLINEFRAMEUSETEXTSCR system variable	116
6.56.1	Command line frame TEXTSCR	116
6.57	CMDLINELISTBGCOLOR system variable	117
6.57.1	Command line list background color	117
6.58	CMDLINELISTFGCOLOR system variable	117
6.58.1	Command line list foreground color	117
6.59	CMDLINEOPTIONBGCOLOR system variable	117
6.59.1	Command line option background color	117
6.60	CMDLINEOPTIONSHORTCUTCOLOR system variable	118
6.60.1	Command line option shortcut color	118
6.61	CMDLINEUSEMINIFRAME system variable	118
6.61.1	Command line mini floating frame	118
6.62	CMDLNTEXT system variable	118
6.62.1	Prompt prefix	118
6.63	CMDNAMES system variable	119
6.63.1	Active Command Name	119
6.64	CMLEADERSTYLE system variable	119
6.64.1	Multileader style	119
6.65	CMLJUST system variable	119
6.65.1	Multiline justification	119
6.66	CMLSCALE system variable	120
6.66.1	Multiline scale	120
6.67	CMLSTYLE system variable	120
6.67.1	Multiline style	120
6.68	CMPCLRMISST system variable	120
6.68.1	Color for displaying of missing entities in DWGCOMPARE mode	120
6.69	CMPCLRMOD1 system variable	121
6.69.1	Color for displaying of modified entities in this drawing in DWGCOMPARE mode	121
6.70	CMPCLRMOD2 system variable	121
6.70.1	Color for displaying of modified entities in the second drawing in DWGCOMPARE mode	121
6.71	CMPCLRNEW system variable	121
6.71.1	Color for displaying of new entities in DWGCOMPARE mode	121
6.72	CMPDIFFLIMIT system variable	122
6.72.1	Maximal number of entities in the output of DWGCOMPARE command	122
6.73	CMPFADECTL system variable	122
6.73.1	DWGCOMPARE fade control	122
6.74	CMPLOG system variable	122
6.74.1	DWGCOMPARE log control	122
6.75	COLORBOOKPATH system variable	123
6.75.1	Color book file search path	123
6.76	COLORTHEME system variable	123



Содержание

6.76.1	UI color theme	123
6.77	COLORX system variable	123
6.77.1	X axis color	123
6.78	COLORY system variable	124
6.78.1	Y axis color	124
6.79	COLORZ system variable	124
6.79.1	Z axis color	124
6.80	COMACADCOMPATIBILITY system variable	124
6.80.1	COM Acad compatibility	124
6.81	COMBINETEXTMODE system variable	125
6.81.1	Options for COMBINETEXTMODE	125
6.82	COMMUNICATORBACKGROUNDMODE system variable	125
6.82.1	Perform import and export in background	125
6.83	COMPASS system variable	126
6.83.1	Compass	126
6.84	COMPONENTSCONFIG system variable	126
6.84.1	Library panel configuration	126
6.85	COMPONENTSPATH system variable	126
6.85.1	Library directory path	126
6.86	CONSTRAINTBARDISPLAY system variable	126
6.86.1	Constraint Bar Display	126
6.87	CONTINUOUSMOTION system variable	127
6.87.1	Continuous motion	127
6.88	CONVERTODMAX system variable	127
6.88.1	Maximal multiplier for outer diameter	127
6.89	CONVERTODMIN system variable	127
6.89.1	Minimal multiplier for outer diameter	127
6.90	CONVERTTHMAX system variable	128
6.90.1	Maximal multiplier for thickness	128
6.91	CONVERTTHMIN system variable	128
6.91.1	Minimal multiplier for thickness	128
6.92	COORDS system variable	128
6.92.1	Coordinates	128
6.93	COPYMODE system variable	129
6.93.1	Copy mode	129
6.94	CPLOTPATTERN system variable	129
6.94.1	Current plot pattern	129
6.95	CPROFILE system variable	129
6.95.1	Current profile	129
6.96	CREATETHUMBNAILONTHEFLY system variable	130
6.96.1	Create preview thumbnail on the fly	130
6.97	CREATESKETCHFEATURE system variable	130
6.97.1	Sketch based feature (experimental)	130
6.98	CREATEVIEWPORTS system variable	131
6.98.1	Automatic viewport creation	131
6.99	CROSSHAIRDRAWMODE system variable	131
6.99.1	Crosshair rendering mode	131
6.100	CROSSINGAREACOLOR system variable	132



Содержание

6.100.1	Crossing area color	132
6.101	CTAB system variable	132
6.101.1	Current tab	132
6.102	CTABLESTYLE system variable	132
6.102.1	Current table style	132
6.103	CTRL3DMOUSE system variable	133
6.103.1	3D mouse mode	133
6.104	CTRLMOUSE system variable	133
6.104.1	Mouse shortcuts	133
6.105	CURSORSIZE system variable	134
6.105.1	Crosshairs size	134
6.106	CVPORT system variable	134
6.106.1	Current viewport	134
6.107	CVERSIONCONTROLPATH system variable	134
6.107.1	Current version control path	134
6.108	CLOUDSSOSCOPE system variable	135
6.108.1	Cloud SSO Scope	135
6.109	CLOUDSSOCLIENTID system variable	135
6.109.1	Cloud SSO Client ID	135
6.110	CTRLMBUTTON system variable	135
6.110.1	Middle Button Click	135
7.	D	136
7.1	DATACOLLECTION system variable	136
7.1.1	Diagnostics and usage data collection	136
7.2	DATACOLLECTIONENABLED system variable	136
7.2.1	Current state of data collection	136
7.3	DATACOLLECTIONLOGINTYPE system variable	137
7.3.1	Current type of login for data collection	137
7.4	DATALINKNOTIFY system variable	137
7.4.1	Notification of data links	137
7.5	DATE system variable	138
7.5.1	Current date	138
7.6	DBCSTATE system variable	138
7.6.1	DbConnect state	138
7.7	DBLCLKEDIT system variable	138
7.7.1	Double click editing	138
7.8	DBMOD system variable	139
7.8.1	Modification status	139
7.9	DCTCUST system variable	139
7.9.1	Custom spelling dictionary	139
7.10	DCTMAIN system variable	139
7.10.1	Main spelling dictionary	139
7.11	DEFAULTBSYSLIBIMPERIAL system variable	140
7.11.1	Default Bsylis imperial	140
7.12	DEFAULTBSYSLIBMETRIC system variable	140
7.12.1	Default Bsylis metric	140
7.13	DEFAULTCURVETYPEHA system variable	140
7.13.1	Default curve for horizontal alignments	140



Содержание

7.14	DEFAULTCURVETYPEVA system variable	141
7.14.1	Default curve for vertical alignments	141
7.15	DEFAULTLIGHTING system variable	141
7.15.1	Default lighting	141
7.16	DEFAULTLIGHTSHADOWBLUR system variable	141
7.16.1	Default light shadow blur	141
7.17	DEFAULTNEWSHEETTEMPLATE system variable	142
7.17.1	Default new sheet template	142
7.18	DEFAULTPLOTTSTYLETABLE system variable	142
7.18.1	Default plot style table	142
7.19	DEFAULTSPACEHEIGHT system variable	142
7.19.1	Default Space Height	142
7.20	DEFAULTSTYLEPIPECROSS system variable	143
7.20.1	Default style for pipe cross	143
7.21	DEFAULTSTYLEPIPEECCENTRICREDUCER system variable	143
7.21.1	Default style for pipe reducer	143
7.22	DEFAULTSTYLEPIPEELBOW45 system variable	143
7.22.1	Default style for pipe elbow (45 deg)	143
7.23	DEFAULTSTYLEPIPEELBOW90 system variable	144
7.23.1	Default style for pipe elbow (90 deg)	144
7.24	DEFAULTSTYLEPIPEREDUCER system variable	144
7.24.1	Default style for pipe reducer	144
7.25	DEFAULTSTYLEPIPESEGMENT system variable	144
7.25.1	Default style for pipe segment	144
7.26	DEFAULTSTYLEPIPETEE system variable	144
7.26.1	Default style for pipe tee	144
7.27	DEFPLSTYLE system variable	145
7.27.1	Default layer plot style	145
7.28	DEFPLSTYLE system variable	145
7.28.1	Default entity plot style	145
7.29	DELETEINTERFERENCE system variable	145
7.29.1	Delete interference	145
7.30	DELETETOOL system variable	146
7.30.1	Delete tool	146
7.31	DELOBJ system variable	146
7.31.1	Delete entity	146
7.32	DEMANDLOAD system variable	147
7.32.1	Demand load	147
7.33	DETAILSPATH system variable	147
7.33.1	Details directory path	147
7.34	DGNEXPXREFMODE system variable	148
7.34.1	Export Conversion of Xrefs	148
7.35	DGNFRAME system variable	148
7.35.1	DGN frame	148
7.36	DGNIMP2DCLOSEDBSPLINECURVEIMPORTMODE system variable	148
7.36.1	2D closed B-spline curve import mode	148
7.37	DGNIMP2DELLIPSEIMPORTMODE system variable	149
7.37.1	2D ellipse import mode	149



Содержание

7.38	DGNIMP2DSHAPEIMPORTMODE system variable	149
7.38.1	2D shape import mode	149
7.39	DGNIMP3DCLOSEDBSPLINECURVEIMPORTMODE system variable	150
7.39.1	3D closed B-spline curve import mode	150
7.40	DGNIMP3DELLIPSEIMPORTMODE system variable	150
7.40.1	3D ellipse import mode	150
7.41	DGNIMP3DOBJECTIMPORTMODE system variable	151
7.41.1	3D object import mode	151
7.42	DGNIMP3DSHAPEIMPORTMODE system variable	151
7.42.1	3D shape import mode	151
7.43	DGNIMPBREAKDIMENSIONASSOCIATION system variable	151
7.43.1	Break dimension association	151
7.44	DGNIMP CONVERTDGNCOLORINDICESTOTRUECOLORS system variable	152
7.44.1	Convert DGN color indices to true colors	152
7.45	DGNIMP CONVERTEMPTYDATAFIELDSTOSPACES system variable	152
7.45.1	Convert empty data fields to spaces	152
7.46	DGNIMPERASEUNUSEDRESOURCES system variable	153
7.46.1	Erase unused resources	153
7.47	DGNIMPEXPLODETEXTNODES system variable	153
7.47.1	Explode text nodes	153
7.48	DGNIMP IMPORTACTIVEMODELTOModelSpace system variable	154
7.48.1	Import active model to Model Space	154
7.49	DGNIMP IMPORTDGTEXTSASDBMTEXTS system variable	154
7.49.1	Import Texts as MTexts	154
7.50	DGNIMP IMPORTINVISIBLEELEMENTS system variable	154
7.50.1	Import invisible elements	154
7.51	DGNIMP IMPORTPAPERSPACEMODELS system variable	155
7.51.1	Import Paper Space models	155
7.52	DGNIMP IMPORTVIEWINDEX system variable	155
7.52.1	Import view index	155
7.53	DGNIMP RECOMPUTEDIMENSIONS AFTERIMPORT system variable	156
7.53.1	Recompute dimensions after import	156
7.54	DGNIMP SYMBOLRESOURCEFILES system variable	156
7.54.1	Symbol resource files	156
7.55	DGNIMP XREFIMPORTMODE system variable	156
7.55.1	External references import mode	156
7.56	DGNOSNAP system variable	157
7.56.1	Dgn entity snap	157
7.57	DIASTAT system variable	157
7.57.1	Dialog state	157
7.58	DIMADEC system variable	158
7.58.1	Dim angle precision	158
7.59	DIMALT system variable	158
7.59.1	Alt units	158
7.60	DIMALTD system variable	158
7.60.1	Alt precision	158
7.61	DIMALTF system variable	159
7.61.1	Alt multiplier	159



Содержание

7.62	DIMALTRND system variable	159
7.62.1	Alt roundoff	159
7.63	DIMALTTD system variable	159
7.63.1	Alt tolerance precision	159
7.64	DIMALTTZ system variable	160
7.64.1	Alt tolerance suppress zeros	160
7.65	DIMALTU system variable	160
7.65.1	Alt unit type	160
7.66	DIMALTZ system variable	161
7.66.1	Alt suppress zeros	161
7.67	DIMANNO system variable	161
7.67.1	Style is annotative	161
7.68	DIMAPOST system variable	161
7.68.1	Alt units prefix/suffix	161
7.69	DIMARCSYM system variable	162
7.69.1	Arc symbol	162
7.70	DIMASO system variable	162
7.70.1	Associativity (Obsolete)	162
7.71	DIMASSOC system variable	162
7.71.1	Associativity	162
7.72	DIMASZ system variable	163
7.72.1	Arrow size	163
7.73	DIMATFIT system variable	163
7.73.1	Arrow and text fit	163
7.74	DIMAUNIT system variable	163
7.74.1	Dim angle units	163
7.75	DIMAZIN system variable	164
7.75.1	Suppress angle zeros	164
7.76	DIMBLK system variable	164
7.76.1	Arrow	164
7.77	DIMBLK1 system variable	165
7.77.1	Arrow 1	165
7.78	DIMBLK2 system variable	165
7.78.1	Arrow 2	165
7.79	DIMCEN system variable	165
7.79.1	Center mark	165
7.80	DIMCLRD system variable	166
7.80.1	Dim line color	166
7.81	DIMCLRE system variable	166
7.81.1	Ext line color	166
7.82	DIMCLRT system variable	166
7.82.1	Text color	166
7.83	DIMDEC system variable	167
7.83.1	Dim precision	167
7.84	DIMDLE system variable	167
7.84.1	Dim line ext	167
7.85	DIMDLI system variable	167
7.85.1	Dim baseline spacing	167



Содержание

7.86	DIMDSEP system variable	168
7.86.1	Decimal separator	168
7.87	DIMEXE system variable	168
7.87.1	Ext line ext	168
7.88	DIMEXO system variable	168
7.88.1	Ext line offset	168
7.89	DIMFIT system variable	169
7.89.1	Dimension text fit (Obsolete)	169
7.90	DIMFRAC system variable	169
7.90.1	Fractional type	169
7.91	DIMFXL system variable	169
7.91.1	Ext line fixed length	169
7.92	DIMFXLON system variable	170
7.92.1	Ext line fixed	170
7.93	DIMGAP system variable	170
7.93.1	Text offset	170
7.94	DIMJOGANG system variable	170
7.94.1	Jogged angle	170
7.95	DIMJUST system variable	171
7.95.1	Horizontal text position	171
7.96	DIMLAYER system variable	171
7.96.1	Default layer for new dimensions	171
7.97	DIMLDRBLK system variable	172
7.97.1	Leader arrow	172
7.98	DIMLFAC system variable	172
7.98.1	Dim scale linear	172
7.99	DIMLLIM system variable	172
7.99.1	Tolerance method	172
7.100	DIMLTEX1 system variable	172
7.100.1	Ext line 1 linetype	172
7.101	DIMLTEX2 system variable	173
7.101.1	Ext line 2 linetype	173
7.102	DIMLTYPE system variable	173
7.102.1	Dim line linetype	173
7.103	DIMLUNIT system variable	173
7.103.1	Dim units	173
7.104	DIMLWD system variable	174
7.104.1	Dim line linewidth	174
7.105	DIMLWE system variable	174
7.105.1	Ext line LW	174
7.106	DIMMARKTYPE system variable	175
7.106.1	Dimension override marking	175
7.107	DIMPOST system variable	175
7.107.1	Dim prefix/suffix	175
7.108	DIMRND system variable	175
7.108.1	Dim round	175
7.109	DIMSAH system variable	176
7.109.1	Arrowheads	176



Содержание

7.110	DIMSCALE system variable	176
7.110.1	Dim scale overall	176
7.111	DIMSD1 system variable	177
7.111.1	Dim line 1	177
7.112	DIMSD2 system variable	177
7.112.1	Dim line 2	177
7.113	DIMSE1 system variable	177
7.113.1	Ext line 1	177
7.114	DIMSE2 system variable	178
7.114.1	Ext line 2	178
7.115	DIMSHO system variable	178
7.115.1	Dimension show (Obsolete)	178
7.116	DIMSOXD system variable	178
7.116.1	Dim line inside	178
7.117	DIMSTYLE system variable	179
7.117.1	Dimension style	179
7.118	DIMTAD system variable	179
7.118.1	Vertical text position	179
7.119	Системная переменная DIMTDEC	179
7.119.1	Точность допуска	179
7.120	DIMTFAC system variable	180
7.120.1	Tolerance text height	180
7.121	DIMTFILL system variable	180
7.121.1	Text fill	180
7.122	DIMTFILLCLR system variable	180
7.122.1	Text fill color	180
7.123	DIMTIH system variable	181
7.123.1	Text inside align	181
7.124	DIMTIX system variable	181
7.124.1	Text inside	181
7.125	DIMTM system variable	182
7.125.1	Tolerance limit lower	182
7.126	DIMTMOVE system variable	182
7.126.1	Text movement	182
7.127	DIMTOFL system variable	182
7.127.1	Dim line forced	182
7.128	DIMTOH system variable	183
7.128.1	Text outside align	183
7.129	DIMTOL system variable	183
7.129.1	Tolerance display	183
7.130	DIMTOLJ system variable	183
7.130.1	Tolerance pos vert	183
7.131	DIMTP system variable	184
7.131.1	Tolerance limit upper	184
7.132	DIMTSZ system variable	184
7.132.1	Dim tick size	184
7.133	DIMTVP system variable	185
7.133.1	Text offset vert	185



Содержание

7.134	DIMTXSTY system variable	185
7.134.1	Text style	185
7.135	DIMTXT system variable	185
7.135.1	Text height	185
7.136	DIMTXTDIRECTION system variable	185
7.136.1	Text direction	185
7.137	DIMTZIN system variable	186
7.137.1	Tolerance suppress zeros	186
7.138	DIMUNIT system variable	186
7.138.1	Dim unit type (Obsolete)	186
7.139	DIMUPT system variable	187
7.139.1	Place text manually	187
7.140	DIMZIN system variable	187
7.140.1	Suppress dim zeros	187
7.141	DISPLAYAXES system variable	188
7.141.1	Display Axes	188
7.142	DISPLAYAXESFORMEP system variable	188
7.142.1	Display axes	188
7.143	DISPLAYSCALING system variable	188
7.143.1	Automatic display scaling	188
7.144	DISPLAYSIDESANDENDS system variable	189
7.144.1	Display sides and ends	189
7.145	DISPLAYSNAPMARKERINALLVIEWS system variable	189
7.145.1	Snap marker in all views	189
7.146	DISPLAYTOOLTIPS system variable	190
7.146.1	Snap tooltips	190
7.147	DISPPAPERBKG system variable	190
7.147.1	Paper background	190
7.148	DISPPAPERMARGINS system variable	190
7.148.1	Printable area	190
7.149	DISPSILH system variable	191
7.149.1	Display silhouette curves	191
7.150	DISTANCE system variable	191
7.150.1	Distance	191
7.151	DMAUDITLEVEL system variable	191
7.151.1	DMAUDIT command, level of details	191
7.152	DMAUTOUPDATE system variable	192
7.152.1	3D constraints recalculation mode	192
7.153	DMCONNECTIONCUTTYPE system variable	192
7.153.1	Connection type	192
7.154	DMPUSHPULLSUBTRACT system variable	193
7.154.1	DMPUSHPULL subtract	193
7.155	DMRECOGNIZE system variable	193
7.155.1	Automatic 3D geometry constraints recognition	193
7.156	DOCKPRIORITY system variable	194
7.156.1	Docking Priority	194
7.157	DOCTABPOSITION system variable	195
7.157.1	Tabs position	195



Содержание

7.158	DONUTID system variable	195
7.158.1	Donut inside diameter	195
7.159	DONUTOD system variable	195
7.159.1	Donut outside diameter	195
7.160	DRAGMODE system variable	196
7.160.1	Entity dragging	196
7.161	DRAGMODEHIDE system variable	196
7.161.1	Hide original entity when dragging	196
7.162	DRAGMODEINTERRUPT system variable	196
7.162.1	Dragging interruption mode	196
7.163	DRAGOPEN system variable	197
7.163.1	Drag open	197
7.164	DRAGP1 system variable	197
7.164.1	Regen-drag rate	197
7.165	DRAGP2 system variable	198
7.165.1	Fast-drag rate	198
7.166	DRAGSNAP system variable	198
7.166.1	Snap dragged entities	198
7.167	DRAWINGPATH system variable	198
7.167.1	Drawings path	198
7.168	DRAWINGVIEWASM system variable	199
7.168.1	Assemblies optimization	199
7.169	DRAWINGVIEWFLAGS system variable	199
7.169.1	Drawing View Flags	199
7.170	DRAWINGVIEWPRESET system variable	199
7.170.1	Drawing view preset	199
7.171	DRAWINGVIEWPRESETHIDDEN system variable	200
7.171.1	Drawing view hidden lines preset	200
7.172	DRAWINGVIEWPRESETSCALE system variable	200
7.172.1	Scale for drawing view preset	200
7.173	DRAWINGVIEWPRESETTANGENT system variable	200
7.173.1	Drawing view tangent lines preset	200
7.174	DRAWINGVIEWPRESETTRAILING system variable	201
7.174.1	Drawing view trailing lines preset	201
7.175	DRAWINGVIEWQUALITY system variable	201
7.175.1	Quality of drawing views	201
7.176	DRAWORDERCTL system variable	202
7.176.1	Draworder control	202
7.177	DWFFORMAT system variable	202
7.177.1	Default DWF format	202
7.178	DWFFRAME system variable	203
7.178.1	DWF frame	203
7.179	DWFOSNAP system variable	203
7.179.1	Dwf entity snap	203
7.180	DWFVERSION system variable	203
7.180.1	DWF version	203
7.181	DWGCHECK system variable	204
7.181.1	Drawing check	204



Содержание

7.182	DWGCODEPAGE system variable	204
7.182.1	Drawing codepage	204
7.183	DWGGUIDCLOUDAI system variable	205
7.183.1	Drawing Guid	205
7.184	DWGNAME system variable	205
7.184.1	Drawing name	205
7.185	DWGPREFIX system variable	205
7.185.1	Drawing prefix	205
7.186	DWGTITLED system variable	205
7.186.1	Drawing titled	205
7.187	DXEVAL system variable	206
7.187.1	Data extraction update mode	206
7.188	DXFTEXTADJUSTALIGNMENT system variable	206
7.188.1	Dxf text adjust alignment	206
7.189	DYNCONSTRAINTMODE system variable	207
7.189.1	Dynamic Constraint Mode	207
7.190	DYNDIGRIP system variable	207
7.190.1	Show dynamic dimensions	207
7.191	DYNDIMAPERTURE system variable	208
7.191.1	Dynamic dimension aperture	208
7.192	DYNDIMCOLORHOT system variable	208
7.192.1	Dynamic dimension hot color	208
7.193	DYNDIMCOLORHOVER system variable	209
7.193.1	Dynamic dimension hover color	209
7.194	DYNDIMDISTANCE system variable	209
7.194.1	Dynamic dimension distance	209
7.195	DYNDIMLINETYPE system variable	209
7.195.1	Dynamic dimension linetype	209
7.196	DYNDIVIS system variable	210
7.196.1	Dynamic dimension visibility	210
7.197	DYNINPUTTRANSPARENCY system variable	210
7.197.1	Transparency of dynamic input fields	210
7.198	DYNMODE system variable	211
7.198.1	Dynamic input mode	211
7.199	DYNPICOORDS system variable	211
7.199.1	Default mode for dynamic coordinates input	211
8.	E	212
8.1	EDGEMODE system variable	212
8.1.1	Edge mode	212
8.2	ELEVATION system variable	212
8.2.1	Elevation	212
8.3	ELEVATIONATBREAKLINECROSSINGS system variable	213
8.3.1	Elevation at breakline crossings	213
8.4	ENABLEATTRACTION system variable	213
8.4.1	Grips attraction	213
8.5	ENABLEBIMBKUPDATE system variable	213
8.5.1	Enable sections update in background	213
8.6	ENABLEHYPERLINKMENU system variable	214



Содержание

8.6.1	Hyperlink menu	214
8.7	ENABLEHYPERLINKTOOLTIP system variable	214
8.7.1	Hyperlink tooltip	214
8.8	ERRNO system variable	214
8.8.1	Error number	214
8.9	EXPERT system variable	215
8.9.1	Expert	215
8.10	EXPINSALIGN system variable	215
8.10.1	Explorer Insert Aligned	215
8.11	EXPINSANGLE system variable	216
8.11.1	Explorer Insert Angle	216
8.12	EXPINSFIXANGLE system variable	216
8.12.1	Explorer Insert Fix Angle	216
8.13	EXPINSFIXSCALE system variable	216
8.13.1	Explorer Insert Fix Scale	216
8.14	EXPINSSCALE system variable	217
8.14.1	Explorer Insert Scale	217
8.15	EXPLMODE system variable	217
8.15.1	Explode mode	217
8.16	EXPORT3DPDFWRITER system variable	217
8.16.1	3D PDF writer	217
8.17	EXPORTACISASSEMBLYWRITER system variable	218
8.17.1	ASAT/ASAB writer	218
8.18	EXPORTACISFORMATVERSION system variable	218
8.18.1	ACIS export format version	218
8.19	EXPORTCATIAV4FORMATVERSION system variable	219
8.19.1	CATIA V4 export format version	219
8.20	EXPORTCATIAV5FORMATVERSION system variable	219
8.20.1	CATIA V5 export format version	219
8.21	EXPORTGEOMETRYFLAGS system variable	220
8.21.1	Export Geometry Flags	220
8.22	EXPORTHIDDENPARTS system variable	221
8.22.1	Hidden parts	221
8.23	EXPORTMODELSPACE system variable	221
8.23.1	Export model space	221
8.24	EXPORTPAGESETUP system variable	222
8.24.1	Export page setup	222
8.25	EXPORTPAPERSPACE system variable	222
8.25.1	Export paper space	222
8.26	EXPORTPARASOLIDFORMATVERSION system variable	222
8.26.1	Parasolid export format version	222
8.27	EXPORTPRODUCTSTRUCTURE system variable	223
8.27.1	Product structure	223
8.28	EXPORTSTEPFORMATVERSION system variable	224
8.28.1	STEP export format version	224
8.29	EXPORTXCGMFORMATVERSION system variable	224
8.29.1	XCGM export format version	224
8.30	EXTMAX system variable	225



Содержание

8.30.1	Extents maximum	225
8.31	EXTMIN system variable	225
8.31.1	Extents minimum	225
8.32	EXTNAMES system variable	226
8.32.1	Extend names	226
8.33	EXTRUDEINSIDE system variable	226
8.34	EXTRUDEOUTSIDE system variable	226
9.	F	228
9.1	FACETRATIO system variable	228
9.1.1	Faceting aspect ratio	228
9.2	FACETRES system variable	228
9.2.1	Facet resolution	228
9.3	FBXEXPORTCAMERAS system variable	228
9.3.1	Fbx Export Cameras	228
9.4	FBXEXPORTENTITIES system variable	229
9.4.1	Fbx Export Entities	229
9.5	FBXEXPORTENTITIESSELTYPE system variable	229
9.5.1	Fbx entities to export	229
9.6	FBXEXPORTLIGHTS system variable	230
9.6.1	Fbx Export Lights	230
9.7	FBXEXPORTMATERIALS system variable	230
9.7.1	Fbx Export Materials	230
9.8	FBXEXPORTTEXTURES system variable	230
9.8.1	Fbx Export Textures	230
9.9	FBXEXPORTTEXTURESPATH system variable	231
9.9.1	FBX Export Textures path	231
9.10	FEATURECOLORS system variable	231
9.10.1	Feature colors	231
9.11	FIELDDISPLAY system variable	231
9.11.1	Field display	231
9.12	FIELDEVAL system variable	232
9.12.1	Field update mode	232
9.13	FILEDIA system variable	232
9.13.1	File dialog	232
9.14	FILLETRAD system variable	233
9.14.1	Fillet radius	233
9.15	FILLETWELDINGCOMBINEADJACENT system variable	233
9.15.1	Combine adjacent fillet welds	233
9.16	FILLETWELDINGMAXGAPRATIO system variable	233
9.16.1	Maximal ratio of a gap to a weld size	233
9.17	FILLETWELDINGZSIZE system variable	234
9.17.1	Default fillet weld Z size	234
9.18	FILLMODE system variable	234
9.18.1	Fill mode	234
9.19	FITLINEFITARCMODE system variable	234
9.19.1	FitLine FitArc mode	234
9.20	FITTINGRADIUSTYPE system variable	235
9.20.1	Fitting Radius Type	235



Содержание

9.21	FITTINGRADIUSVALUE system variable	235
9.21.1	Fitting Radius Value	235
9.22	FONTALT system variable	236
9.22.1	Alternate font	236
9.23	FONTMAP system variable	236
9.23.1	Font mapping file	236
9.24	FRAME system variable	236
9.24.1	Frame	236
9.25	FRAMESELECTION system variable	237
9.25.1	Frame selection	237
9.26	FRONTZ system variable	237
9.26.1	Front clipping plane offset	237
9.27	FULLOPEN system variable	237
9.27.1	Full open	237
10.	G	238
10.1	GEARTEETHNUMBER system variable	238
10.1.1	Maximum number of sprocket teeth	238
10.2	GENERATEASSOCATTRS system variable	238
10.2.1	Generate associative attributes	238
10.3	GENERATEASSOCVIEWS system variable	238
10.3.1	Generate associative drawings	238
10.4	GEOLATLONGFORMAT system variable	239
10.4.1	Geographic latitude/longitude format	239
10.5	GEOMARKERVISIBILITY system variable	239
10.5.1	Geographic marker visibility	239
10.6	GEOMRELATIONS system variable	240
10.6.1	Geometric relationship indication	240
10.7	GETSTARTED system variable	240
10.7.1	Get Started	240
10.8	GFANG system variable	240
10.8.1	Gradient fill angle	240
10.9	GFCLR1 system variable	241
10.9.1	Gradient fill primary color	241
10.10	GFCLR2 system variable	241
10.10.1	Gradient fill secondary color	241
10.11	GFCLRLUM system variable	241
10.11.1	Gradient fill tint level	241
10.12	GFCLRSTATE system variable	242
10.12.1	Number of colors for a gradient fill	242
10.13	GFNAME system variable	242
10.13.1	Gradient fill name	242
10.14	GFSHIFT system variable	242
10.14.1	Gradient fill shift	242
10.15	GLSWAPMODE system variable	243
10.15.1	GL Swap Mode	243
10.16	GRADIENTCOLORBOTTOM system variable	243
10.16.1	Background gradient color bottom	243
10.17	GRADIENTCOLORMIDDLE system variable	244



Содержание

10.17.1	Background gradient color middle	244
10.18	GRADIENTCOLORTOP system variable	244
10.18.1	Background gradient color top	244
10.19	GRADIENTMODE system variable	244
10.19.1	Background gradient mode	244
10.20	GRIDAXISCOLOR system variable	245
10.20.1	Grid axis color	245
10.21	GRIDDISPLAY system variable	245
10.21.1	Grid display	245
10.22	GRIDMAJOR system variable	246
10.22.1	Grid major	246
10.23	GRIDMAJORCOLOR system variable	246
10.23.1	Grid major color	246
10.24	GRIDMINORCOLOR system variable	246
10.24.1	Grid minor color	246
10.25	GRIDMODE system variable	247
10.25.1	Grid mode	247
10.26	GRIDSTYLE system variable	247
10.26.1	Grid style	247
10.27	GRIDUNIT system variable	247
10.27.1	Grid unit	247
10.28	GRIDXYZTINT system variable	248
10.28.1	Grid XYZ tint	248
10.29	GRIPBLOCK system variable	248
10.29.1	Grips in blocks	248
10.30	GRIPCOLOR system variable	249
10.30.1	Grip color	249
10.31	GRIPDYNCOLOR system variable	249
10.31.1	Dynamic grip color	249
10.32	GRIPHOT system variable	249
10.32.1	Selected grip color	249
10.33	GRIPHOVER system variable	250
10.33.1	Hover grip color	250
10.34	GRIPOBJLIMIT system variable	250
10.34.1	Grip object limit	250
10.35	GRIPS system variable	250
10.35.1	Grips	250
10.36	GRIPSIZE system variable	251
10.36.1	Grip size	251
10.37	GRIPTIPS system variable	251
10.37.1	Grip tips	251
10.38	GSDEVICETYPE2D system variable	251
10.38.1	2D graphic system device	251
10.39	GSDEVICETYPE3D system variable	252
10.39.1	3D graphic system device	252
11.	H	253
11.1	HALOGAP system variable	253
11.1.1	Halo gap	253



Содержание

11.2	HANDLES system variable	253
11.2.1	Publish Handles	253
11.3	HANDSEED system variable	253
11.3.1	Handle seed	253
11.4	HIDEPRECISION system variable	254
11.4.1	Hide and shade precision	254
11.5	HIDESYSTEMPRINTERS system variable	254
11.5.1	Hide system printers	254
11.6	HIDETEXT system variable	254
11.6.1	Hide text on HIDE	254
11.7	HIDEXREFSCALES system variable	255
11.7.1	Hide xref scales	255
11.8	HIGHLIGHT system variable	255
11.8.1	Highlight	255
11.9	HIGHLIGHTCOLOR system variable	255
11.9.1	Selection Highlight Color	255
11.10	HIGHLIGHTEFFECT system variable	256
11.10.1	Selection Highlight Style	256
11.11	HORIZONBKG_ENABLE system variable	256
11.11.1	Horizon background	256
11.12	HORIZONBKG_GROUNDHORIZON system variable	257
11.12.1	Ground horizon	257
11.13	HORIZONBKG_GROUNDORIGIN system variable	257
11.13.1	Ground origin	257
11.14	HORIZONBKG_SKYHIGH system variable	257
11.14.1	Sky high	257
11.15	HORIZONBKG_SKYHORIZON system variable	257
11.15.1	Sky horizon	257
11.16	HORIZONBKG_SKYLOW system variable	258
11.16.1	Sky low	258
11.17	HOTKEYASSISTANT system variable	258
11.17.1	Hotkey Assistant	258
11.18	HPANG system variable	258
11.18.1	Hatch pattern angle	258
11.19	HPANNOTATIVE system variable	259
11.19.1	Hatch pattern annotative	259
11.20	HPASSOC system variable	259
11.20.1	Hatch pattern associativity	259
11.21	HPBACKGROUNDCOLOR system variable	259
11.21.1	Hatch background default color	259
11.22	HPBOUND system variable	260
11.22.1	Hatch pattern boundary	260
11.23	HPBOUNDRETAIN system variable	260
11.23.1	Hatch pattern boundary retain	260
11.24	HPCOLOR system variable	260
11.24.1	Hatch default color	260
11.25	HPDOUBLE system variable	261
11.25.1	Hatch pattern doubling	261



Содержание

11.26	HPDRAWORDER system variable	261
11.26.1	Hatch pattern draw order	261
11.27	HPGAPTOL system variable	261
11.27.1	Hatch pattern gap tolerance	261
11.28	HPISLANDDETECTION system variable	262
11.28.1	Hatch pattern island detection	262
11.29	HPLAYER system variable	262
11.29.1	Default layer for new hatches	262
11.30	HPLINETYPE system variable	263
11.30.1	Hatch pattern linetype	263
11.31	HPMAXAREAS system variable	263
11.31.1	Fill mode for sparse hatches	263
11.32	HPMAXCONTOURPOINTS system variable	263
11.32.1	Maximum number of points on a hatch contour	263
11.33	HPNAME system variable	264
11.33.1	Hatch pattern name	264
11.34	HPOBJWARNING system variable	264
11.34.1	Hatch pattern object warning	264
11.35	HPORIGIN system variable	264
11.35.1	Hatch pattern origin	264
11.36	HPSCALE system variable	265
11.36.1	Hatch pattern scale	265
11.37	HPSEPARATE system variable	265
11.37.1	Hatch pattern separate	265
11.38	HPSPACE system variable	265
11.38.1	Hatch pattern spacing	265
11.39	HPTRANSPARENCY system variable	266
11.39.1	Default transparency for new hatches	266
11.40	HYPERLINKBASE system variable	266
11.40.1	Hyperlink base	266
12.	I	267
12.1	IFCCREATEUNIQUEGUID system variable	267
12.1.1	Export with unique guids	267
12.2	IFCEXplodeExternalReferences system variable	267
12.2.1	Explode external references in IFC spatial structure	267
12.3	IFCEXPORTBASEQUANTITIES system variable	267
12.3.1	Export base quantities	267
12.4	IFCEXPORTELEMENTSONOFFANDFROZENLAYER system variable	268
12.4.1	Export elements on OFF and FROZEN layers	268
12.5	IFCEXPORTMAPPINGPATH system variable	268
12.5.1	Export mapping file path	268
12.6	IFCEXPORTMULTIPLYELEMENTSASAGGREGATED system variable	268
12.6.1	Export multi-ply elements as aggregated elements	268
12.7	IFCEXPORTPROFILECENTEROFGRAVITY system variable	269
12.7.1	Export profile center of gravity	269
12.8	IFCEXPORTSWEPTSOLIDSBREP system variable	269
12.8.1	Always export swept solids as BRep	269
12.9	IFCEXPORTTESSELATION system variable	269



Содержание

12.9.1	Level of tessellation	269
12.10	IFCEXPORTVERIFYMODEL system variable	270
12.10.1	Apply IFC model verification	270
12.11	IFCIMPORTBIMDATA system variable	270
12.11.1	Import BIM Data	270
12.12	IFCIMPORTBREPGEOMETRYASMESHES system variable	270
12.12.1	Import BREP geometry as meshes	270
12.13	IFCIMPORTMAPPINGPATH system variable	271
12.13.1	Import mapping file path	271
12.14	IFCIMPORTMODELORIGIN system variable	271
12.14.1	Import model position	271
12.15	IFCIMPORTPARAMETRICCOMPONENTS system variable	271
12.15.1	Import Parametric Components	271
12.16	IFCIMPORTPROJECTSTRUCTUREASXREFS system variable	272
12.16.1	Import IFC project structure as xrefs	272
12.17	IFCIMPORTSPACES system variable	272
12.17.1	Import Spaces	272
12.18	IFCIMPORTUSESUBDMESH system variable	273
12.18.1	Import IFC meshes as subdivision meshes	273
12.19	IFCMATCHIMPORTEDPROFILESGEOMETRICALLY system variable	273
12.19.1	Import: use profiles from databases with corresponding geometry	273
12.20	IFCTESSELEATEBSPLINECURVESANDSURFACES system variable	273
12.20.1	Tesselate complex curves and surfaces	273
12.21	IMAGECACHEFOLDER system variable	274
12.21.1	Image disk cache folder	274
12.22	IMAGECACHEMAXMEMORY system variable	274
12.22.1	Maximum used memory	274
12.23	IMAGEDISKCACHE system variable	274
12.23.1	Image disk cache	274
12.24	IMAGEFRAME system variable	275
12.24.1	Image frame	275
12.25	IMAGEHLT system variable	275
12.25.1	Image highlight	275
12.26	IMAGENOTIFY system variable	275
12.26.1	Image notify	275
12.27	IMPORTACISWITHBRICSCAD system variable	276
12.27.1	Import ACIS using built-in importer	276
12.28	IMPORTCATIAV5REPRESENTATION system variable	276
12.28.1	Import representation	276
12.29	IMPORTCATIAV5EDGEATTRIBUTES system variable	276
12.29.1	Import edge attributes mode	276
12.30	IMPORTCATIAV5SEARCHPATHSPREFERENCE system variable	277
12.30.1	Search paths preference	277
12.31	IMPORTCREOCONFIGURATION system variable	277
12.31.1	Import Creo configuration	277
12.32	IMPORTCREOALTERNATESEARCHPATHS system variable	278
12.32.1	Alternate search paths	278
12.33	IMPORTGESSTITCH system variable	278



Содержание

12.33.1	Perform stitching	278
12.34	IMPORTINVENTORSEARCHPATHSPREFERENCE system variable	278
12.34.1	Search paths preference	278
12.35	IMPORTNXCONFIGURATION system variable	279
12.35.1	Import NX configuration	279
12.36	IMPORTNXSEARCHPATHSPREFERENCE system variable	279
12.36.1	Search paths preference	279
12.37	IMPORTJTREPRESENTATION system variable	280
12.37.1	Import representation	280
12.38	IMPORTCOLORS system variable	280
12.38.1	Translate colors	280
12.39	IMPORTCUIFILEEXISTS system variable	280
12.39.1	Import cui file exists	280
12.40	IMPORTHIDDENPARTS system variable	281
12.40.1	Hidden parts	281
12.41	IMPORTIGESSIMPLIFY system variable	281
12.41.1	Perform simplification	281
12.42	IMPORTINVENTORALTERNATESEARCHPATHS system variable	282
12.42.1	Alternate search paths	282
12.43	IMPORTNXALTERNATESEARCHPATHS system variable	282
12.43.1	Alternate search paths	282
12.44	IMPORTPMI system variable	282
12.44.1	Product and manufacturing information	282
12.45	IMPORTPRODUCTSTRUCTURE system variable	283
12.45.1	Product structure	283
12.46	IMPORTREPAIR system variable	283
12.46.1	Repair model on import	283
12.47	IMPORTSIMPLIFY system variable	284
12.47.1	Perform simplification	284
12.48	IMPORTSOLIDEDGEALTERNATESEARCHPATHS system variable	284
12.48.1	Alternate search paths	284
12.49	IMPORTSOLIDGESEARCHPATHSPREFERENCE system variable	284
12.49.1	Search paths preference	284
12.50	IMPORTSOLIDWORKSALTERNATESEARCHPATHS system variable	285
12.50.1	Alternate search paths	285
12.51	IMPORTSOLIDWORKSCONFIGURATION system variable	285
12.51.1	Import SolidWorks configuration	285
12.52	IMPORTSOLIDWORKSREPRESENTATION system variable	285
12.52.1	Import representation	285
12.53	IMPORTSOLIDWORKSROTATEYZ system variable	286
12.53.1	Map SolidWorks Y to current Z axis	286
12.54	IMPORTSOLIDWORKSSEARCHPATHSPREFERENCE system variable	286
12.54.1	Search paths preference	286
12.55	IMPORTSTEPROTATEYZ system variable	287
12.55.1	Map Y to current Z axis	287
12.56	IMPORTSTITCH system variable	287
12.56.1	Perform stitching	287
12.57	INCLUDEPLOTPATTERN system variable	288



Содержание

12.57.1	Include Plot Stamp	288
12.58	INDEXCTL system variable	288
12.58.1	Index control	288
12.59	INETLOCATION system variable	288
12.59.1	Internet location	288
12.60	INSBASE system variable	289
12.60.1	Insertion base point	289
12.61	INSMODEAUTO system variable	289
12.61.1	Insertion mode Auto	289
12.62	INSNAME system variable	289
12.62.1	Insertion name	289
12.63	INSUNITS system variable	290
12.63.1	Insertion units	290
12.64	INSUNITSDEFSOURCE system variable	291
12.64.1	Insertion units default source	291
12.65	INSUNITSDEFTARGET system variable	291
12.65.1	Insertion units default target	291
12.66	INSUNITSSCALING system variable	292
12.66.1	Insertion units scaling	292
12.67	INTERFERECOLOR system variable	293
12.67.1	Interference color	293
12.68	INTERFERELAYER system variable	293
12.68.1	Interference layer	293
12.69	INTERFERENCELEVEL system variable	293
12.69.1	Interference Check Level	293
12.70	INTERFEREOBJVS system variable	294
12.70.1	Interference object visual style	294
12.71	INTERFEREVPVS system variable	294
12.71.1	Interference viewport visual style	294
12.72	INTERIORELEVATIONMINLENGTH system variable	295
12.72.1	Interior Elevation Minimum Length	295
12.73	INTERIORELEVATIONOFFSET system variable	295
12.73.1	Interior Elevation Offset Distance	295
12.74	INTERSECTEDENTITIES system variable	295
12.75	INTERSECTIONCOLOR system variable	296
12.75.1	Intersection color	296
12.76	INTERSECTIONDISPLAY system variable	296
12.76.1	Intersection display	296
12.77	ISAVEBAK system variable	297
12.77.1	Incremental save backup	297
12.78	ISAVEPERCENT system variable	297
12.78.1	Save percent	297
12.79	ISOLINES system variable	297
12.79.1	Isolines	297
13.	J	299
14.	K	300
15.	L	301
15.1	LASTANGLE system variable	301



Содержание

15.1.1	Last angle	301
15.2	LASTPOINT system variable	301
15.2.1	Last point	301
15.3	LASTPROMPT system variable	301
15.3.1	Last prompt	301
15.4	LATITUDE system variable	301
15.4.1	Latitude	301
15.5	LAYERFILTEREXCESS system variable	302
15.5.1	Layer Filter Excess	302
15.6	LAYERPMODE system variable	302
15.6.1	Layer previous mode	302
15.7	LAYLOCKFADECTL system variable	303
15.7.1	Locked layer fade control	303
15.8	LAYOUTREGENCTL system variable	303
15.8.1	Layout regeneration control	303
15.9	LAYOUTTAB system variable	303
15.9.1	Layout and model tabs	303
15.10	LEGACYCODESEARCH system variable	304
15.10.1	Legacy code search mode	304
15.11	LENGTHSAMPLINGINTERVAL system variable	304
15.11.1	Sampling interval for straight segments	304
15.12	LENGTHUNITS system variable	304
15.12.1	Length units	304
15.13	LENSLENGTH system variable	305
15.13.1	Lens length	305
15.14	LEVELOFLDETAIL system variable	305
15.14.1	Length units	305
15.15	LICFLAGS system variable	306
15.15.1	Licensed components	306
15.16	LIGHTGLYPHCOLOR system variable	306
15.16.1	Color for light glyph	306
15.17	LIGHTGLYPHDISPLAY system variable	306
15.17.1	Light glyph display	306
15.18	LIGHTINGUNITS system variable	307
15.18.1	Lighting units	307
15.19	LIGHTWEBGLYPHCOLOR system variable	307
15.19.1	Color for web light glyph	307
15.20	LIMCHECK system variable	308
15.20.1	Limits check	308
15.21	LIMMAX system variable	308
15.21.1	Limits maximum	308
15.22	LIMMIN system variable	308
15.22.1	Limits minimum	308
15.23	LINEARBRIGHTNESS system variable	309
15.23.1	Linear brightness	309
15.24	LINEARCONTRAST system variable	309
15.24.1	Linear contrast	309
15.25	LISPINIT system variable	309



Содержание

15.25.1	LISP init	309
15.26	LOADMECHANICAL2D system variable	310
15.26.1	Mechanical 2D enablers	310
15.27	LOCALE system variable	310
15.27.1	Locale	310
15.28	LOCALROOTPREFIX system variable	310
15.28.1	Local root prefix	310
15.29	LOCKUI system variable	311
15.29.1	Lock user interface elements	311
15.30	LOFTANG1 system variable	311
15.30.1	Loft angle 1	311
15.31	LOFTANG2 system variable	312
15.31.1	Loft angle 2	312
15.32	LOFTMAG1 system variable	313
15.32.1	Loft magnitude 1	313
15.33	LOFTMAG2 system variable	314
15.33.1	Loft magnitude 2	314
15.34	LOFTNORMALS system variable	314
15.34.1	Loft normals	314
15.35	LOFTPARAM system variable	315
15.35.1	Loft param	315
15.36	LOGFILEMODE system variable	315
15.36.1	Log file mode	315
15.37	LOGFILENAME system variable	315
15.37.1	Log file name	315
15.38	LOGFILEPATH system variable	316
15.38.1	Log file path	316
15.39	LOGGEDIN system variable	316
15.39.1	Logged in	316
15.40	LOGINNAME system variable	316
15.40.1	Login name	316
15.41	LONGITUDE system variable	316
15.41.1	Longitude	316
15.42	LOOKFROMDIRECTIONMODE system variable	317
15.42.1	LookFrom direction mode	317
15.43	LOOKFROMFEEDBACK system variable	317
15.43.1	LookFrom feedback	317
15.44	LOOKFROMZOOMEXTENTS system variable	318
15.44.1	LookFrom zoom extents	318
15.45	LTGAPSELECTION system variable	318
15.45.1	Linetype gap selection	318
15.46	LTSCALE system variable	319
15.46.1	Linetype scale	319
15.47	LUNITS system variable	319
15.47.1	Linear unit type	319
15.48	LUPREC system variable	319
15.48.1	Linear unit precision	319
15.49	LWDEFAULT system variable	320



Содержание

15.49.1	Default linewidth	320
15.50	LWDISPLAY system variable	320
15.50.1	Lineweight display	320
15.51	LWDISPSCALE system variable	321
15.51.1	Lineweight display scale	321
15.52	LWUNITS system variable	321
15.52.1	Lineweight units	321
16.	M	322
16.1	MACROREC system variable	322
16.1.1	Macro recording	322
16.2	MAKEBAK system variable	322
16.2.1	Make backup (Obsolete)	322
16.3	MANIPULATOR system variable	322
16.3.1	Manipulator	322
16.4	MANIPULATORCOLORTHEME system variable	323
16.4.1	Color theme of Manipulator	323
16.5	MANIPULATORDURATION system variable	324
16.5.1	Manipulator duration	324
16.6	MANIPULATORHANDLE system variable	324
16.6.1	Manipulator handle	324
16.7	MANIPULATORSIZE system variable	324
16.7.1	Size of Manipulator	324
16.8	MASSPREC system variable	325
16.8.1	Mass precision	325
16.9	MASSPROPACCURACY system variable	325
16.9.1	Mass properties calculation relative accuracy	325
16.10	MASSUNITS system variable	326
16.10.1	Mass units	326
16.11	MAXACTVP system variable	326
16.11.1	Maximum active viewports	326
16.12	MAXHATCH system variable	327
16.12.1	Maximum hatch dashes	327
16.13	MAXSORT system variable	327
16.13.1	Maximum sort	327
16.14	MAXTHREADS system variable	327
16.14.1	Maximum number of threads	327
16.15	MBSTATE system variable	328
16.15.1	Mechanical browser state	328
16.16	MBUTTONPAN system variable	328
16.16.1	Middle button pan	328
16.17	MEASUREINIT system variable	329
16.17.1	Measurement initial	329
16.18	MEASUREMENT system variable	329
16.18.1	Measurement	329
16.19	MECH2DSAVEFORMAT system variable	329
16.19.1	Mechanical 2D save format	329
16.20	Системная переменная MECHANICALBLOCKS	330
16.20.1	Механические блоки (экспериментально)	330



Содержание

16.21	MECHANICALBROWSERSETTINGS system variable	330
16.21.1	Mechanical browser options	330
16.22	MENUBAR (EXCEPT OS X) system variable	331
16.22.1	Menu bar	331
16.23	MENUCTL system variable	331
16.23.1	Menu control	331
16.24	MENUECHO system variable	332
16.24.1	Menu echo	332
16.25	MENUNAME system variable	332
16.25.1	Menu name	332
16.26	MESHTYPE system variable	332
16.26.1	Mesh type	332
16.27	MIDDLECLICKCLOSE system variable	333
16.27.1	Middle click close (Mac & Linux)	333
16.28	MILLISECS system variable	333
16.28.1	Milliseconds	333
16.29	MIRRHATCH system variable	333
16.29.1	Hatch pattern mirroring	333
16.30	MIRRTEXT system variable	334
16.30.1	Mirror text	334
16.31	MLEADERSCALE system variable	334
16.31.1	Multileader scale	334
16.32	MODEMACRO system variable	334
16.32.1	Mode macro	334
16.33	MSLTSCALE system variable	335
16.33.1	Model space linetype scale	335
16.34	MSOLESCALE system variable	335
16.34.1	Model space OLE scale	335
16.35	MTEXTCOLUMN system variable	335
16.35.1	Multiline text column setting	335
16.36	MTEXTDETECTSPACE system variable	336
16.36.1	Space detection for creating lists in mtext editor	336
16.37	MTEXTED system variable	336
16.37.1	Multiline text editor	336
16.38	MTEXTFIXED system variable	336
16.38.1	Multiline text fixed	336
16.39	MTEXTTOOLBAR system variable	337
16.39.1	MText Formatting toolbar	337
16.40	MTFLAGS system variable	337
16.40.1	Multi-Threading Flags	337
16.41	MULTISELECTANGULARTOLERANCE system variable	338
16.41.1	BimMultiSelect angular tolerance	338
16.42	MYDOCUMENTSPREFIX system variable	338
16.42.1	MyDocuments root prefix	338
17.	N	339
17.1	NAVVCUBEDIPLAY system variable	339
17.1.1	LookFrom display	339
17.2	NAVVCUBELOCATION system variable	339



Содержание

17.2.1	LookFrom location	339
17.3	NAVVCUBEOPACITY system variable	340
17.3.1	LookFrom opacity	340
17.4	NAVVCUBEORIENT system variable	340
17.4.1	LookFrom orientation	340
17.5	NEARESTDISTANCE system variable	340
17.5.1	Nearest Distance	340
17.6	NOMUTT system variable	341
17.6.1	No muttering	341
17.7	NORTHDIRECTION system variable	342
17.7.1	North direction	342
18.	O	343
18.1	OBJECTISOLATIONMODE system variable	343
18.1.1	Object Isolation Mode	343
18.2	OBSCUREDCOLOR system variable	343
18.2.1	Obscured color	343
18.3	OBSCUREDTYPE system variable	344
18.3.1	Obscured linetype	344
18.4	OFFSETDIST system variable	344
18.4.1	Offset distance	344
18.5	OFFSETERASE system variable	345
18.5.1	Offset erase	345
18.6	OFFSETGAPTYPE system variable	345
18.6.1	Offset gap type	345
18.7	OLEFRAME system variable	345
18.7.1	OLE frame	345
18.8	OLEHIDE system variable	346
18.8.1	OLE hide	346
18.9	OLEQUALITY system variable	346
18.9.1	OLE quality	346
18.10	OLESTARTUP system variable	347
18.10.1	OLE startup	347
18.11	OPMSTATE system variable	347
18.11.1	Properties bar state	347
18.12	ORBITAUTOTARGET system variable	348
18.12.1	Orbit Auto Target	348
18.13	ORTHOMODE system variable	348
18.13.1	Orthogonal mode	348
18.14	OSMODE system variable	348
18.14.1	Entity snap mode	348
18.15	OSNAPCOORD system variable	349
18.15.1	Entity snap coordinates	349
18.16	OSNAPZ system variable	350
18.16.1	Ignore entity snap elevation	350
18.17	OSOPTIONS system variable	350
18.17.1	Entity snap options	350
18.18	OVERKILLAYER system variable	350
18.18.1	Duplicate Entities Layer	350



Содержание

19.	P	352
19.1	PANBUFFER system variable	352
19.1.1	Pan buffer	352
19.2	PANELBUTTONSIZE system variable	352
19.2.1	Panelset icon button size	352
19.3	PAPERUPDATE system variable	352
19.3.1	Paper update	352
19.4	PARAMETERCOPYMODE system variable	353
19.4.1	Parameter copy mode	353
19.5	PARAMETRICBLOCKS2DPATH system variable	353
19.5.1	Parametric blocks 2D directory path	353
19.6	PDFCACHE system variable	354
19.6.1	PDF cache	354
19.7	PDFEMBEDDEDTTF system variable	354
19.7.1	Pdf embedded fonts	354
19.8	PDFEXPORTHYPERLINKS system variable	355
19.8.1	Export hyperlinks	355
19.9	PDFFRAME system variable	355
19.9.1	PDF frame	355
19.10	PDFIMAGEANTIALIAS system variable	355
19.10.1	Image anti-aliasing	355
19.11	PDFIMAGECOMPRESSION system variable	356
19.11.1	Image compression	356
19.12	PDFIMAGEDPI system variable	356
19.12.1	Image DPI	356
19.13	PDFIMPORTAPPLYLINEWEIGHT system variable	356
19.13.1	Apply linewidth properties	356
19.14	PDFIMPORTASBLOCK system variable	357
19.14.1	Import as block	357
19.15	PDFIMPORTCHARSPACEFACTOR system variable	357
19.15.1	Inter-character space factor	357
19.16	PDFIMPORTCOMBINETEXTOBJECTS system variable	358
19.16.1	Combine text objects	358
19.17	PDFIMPORTCONVERTSOLIDSTOHATCHES system variable	358
19.17.1	Convert solid fills to hatches	358
19.18	PDFIMPORTIMAGEPATH system variable	358
19.18.1	Raster Images Folder	358
19.19	PDFIMPORTJOINLINEANDARCSEGMENTS system variable	359
19.19.1	Join line and arc segments	359
19.20	PDFIMPORTLAYERSUSETYPE system variable	359
19.20.1	Layers	359
19.21	PDFIMPORTRASTERIMAGES system variable	360
19.21.1	Raster Images	360
19.22	PDFIMPORTSOLIDFILLS system variable	360
19.22.1	Solid fills	360
19.23	PDFIMPORTSPACEFACTOR system variable	360
19.23.1	Inter-word space factor	360
19.24	PDFIMPORTTRUETYPETEXT system variable	361



Содержание

19.24.1	TrueType text	361
19.25	PDFIMPORTTRUETYPE TEXT AS GEOMETRY system variable	361
19.25.1	Import True Type text as geometry	361
19.26	PDFIMPORTUSECLIPPING system variable	362
19.26.1	Apply clipping	362
19.27	PDFIMPORTUSEGEOMETRYOPTIMIZATION system variable	362
19.27.1	Import geometry with optimization	362
19.28	PDFIMPORTUSEIMAGECLIPPING system variable	362
19.28.1	Clip images	362
19.29	PDFIMPORTUSEPAGEBORDERCLIPPING system variable	363
19.29.1	Apply clipping at page border	363
19.30	PDFIMPORTVECTORGEOMETRY system variable	363
19.30.1	Vector geometry	363
19.31	PDFLAYERSSETTING system variable	364
19.31.1	Pdf layer support	364
19.32	PDFLAYOUTSTOEXPORT system variable	364
19.32.1	Pdf layouts to export	364
19.33	PDFMERGECONTROL system variable	364
19.33.1	Pdf Merge Control	364
19.34	PDFNOTIFY system variable	365
19.34.1	PDF notify	365
19.35	PDFOSNAP system variable	365
19.35.1	PDF entity snap	365
19.36	PDFPAPERHEIGHT system variable	366
19.36.1	Pdf overridden paper height	366
19.37	PDFPAPERSIZE OVERRIDE system variable	366
19.37.1	Pdf papersize override	366
19.38	PDFPAPERWIDTH system variable	366
19.38.1	Pdf overridden paper width	366
19.39	PDFPRCCOMPRESSION system variable	367
19.39.1	PRC Compression	367
19.40	PDFPRCEXPORT system variable	367
19.40.1	PRC Export Mode	367
19.41	PDFPRCPROJECTION system variable	367
19.41.1	PRC Projection	367
19.42	PDFPRCVIEWMODE system variable	368
19.42.1	PRC View mode	368
19.43	PDFSHXTEXTASGEOMETRY system variable	368
19.43.1	Pdf SHX text as geometry	368
19.44	PDFSIMPLEGEOMOPTIMIZATION system variable	369
19.44.1	Pdf simple geometry optimization	369
19.45	PDFTTFFTEXTASGEOMETRY system variable	369
19.45.1	Pdf TTF text as geometry	369
19.46	PDFUSEPLOTSTYLES system variable	370
19.46.1	Pdf use plotstyles	370
19.47	PDFVECTORRESOLUTIONDPI system variable	370
19.47.1	Vector Resolution DPI	370
19.48	PDFZOOMTOEXTENTSMODE system variable	370



Содержание

19.48.1	Pdf zoom to extents mode	370
19.49	PDMODE system variable	371
19.49.1	Point display mode	371
19.50	PDSIZE system variable	372
19.50.1	Point display size	372
19.51	PEDITACCEPT system variable	372
19.51.1	Polyline edit accept	372
19.52	PELLIPSE system variable	373
19.52.1	Polyline ellipse	373
19.53	PERIMETER system variable	373
19.53.1	Last perimeter	373
19.54	PERSPECTIVE system variable	373
19.54.1	Perspective	373
19.55	PFACEVMAX system variable	374
19.55.1	Polyface mesh maximum vertices	374
19.56	PICKADD system variable	374
19.56.1	Pick add	374
19.57	PICKAUTO system variable	375
19.57.1	Pick automatic	375
19.58	PICKBOX system variable	375
19.58.1	Pick box	375
19.59	PICKDRAG system variable	376
19.59.1	Pick drag	376
19.60	PICKFIRST system variable	376
19.60.1	Pick first	376
19.61	PICKSTYLE (EXCEPT OS X) system variable	376
19.61.1	Pick style	376
19.62	PICTUREEXPORTSCALE system variable	377
19.62.1	Picture format export scale factor	377
19.63	PLACESBARFOLDER1 system variable	377
19.63.1	First folder (Windows)	377
19.64	PLACESBARFOLDER2 system variable	378
19.64.1	Second folder (Windows)	378
19.65	PLACESBARFOLDER3 system variable	378
19.65.1	Third folder (Windows)	378
19.66	PLACESBARFOLDER4 system variable	379
19.66.1	Fourth folder (Windows)	379
19.67	PLATFORM system variable	379
19.67.1	Platform	379
19.68	PLINECACHE system variable	380
19.68.1	Polyline cache	380
19.69	PLINECONVERTMODE system variable	380
19.69.1	Polyline convert mode	380
19.70	PLINEGEN system variable	380
19.70.1	Polyline generation	380
19.71	PLINETYPE system variable	381
19.71.1	Polyline type	381
19.72	PLINEWID system variable	382



Содержание

19.72.1	Polyline width	382
19.73	PLOTCFGPATH system variable	382
19.73.1	Plotter configuration path	382
19.74	PLOTID system variable	382
19.74.1	Plot id (Obsolete)	382
19.75	PLOTOUTPUTPATH system variable	382
19.75.1	Plot output path	382
19.76	PLOTSTYLEPATH system variable	383
19.76.1	Plot styles path	383
19.77	PLOTTER system variable	383
19.77.1	Plotter (Obsolete)	383
19.78	PLOTRANSPARENCY OVERRIDE system variable	383
19.78.1	Plot transparency override	383
19.79	PLQUIET system variable	384
19.79.1	Plot quiet	384
19.80	POINTCLOUD2DVSDISPLAY system variable	384
19.80.1	Point cloud toggle show/hide bounding box in 2D wireframe mode	384
19.81	POINTCLOUDADAPTIVEDISPLAY system variable	384
19.81.1	Point cloud toggle adaptive vs. fixed point sizes	384
19.82	POINTCLOUDBOUNDARY system variable	385
19.82.1	Point cloud point boundary	385
19.83	POINTCLOUDCACHEFOLDER system variable	385
19.83.1	Point Cloud disk cache folder	385
19.84	POINTCLOUDHSPC system variable	386
19.84.1	Point Cloud format (hspc/bcad)	386
19.85	POINTCLOUDIGNOREGEOTAGS system variable	386
19.85.1	Point Cloud ignore geo tags in source data	386
19.86	POINTCLOUDPOINTMAX system variable	386
19.86.1	Point cloud max points	386
19.87	POINTCLOUDPOINTSIZEx system variable	387
19.87.1	Point cloud point size	387
19.88	POLARADDANG system variable	387
19.88.1	Polar add angles	387
19.89	POLARANG system variable	388
19.89.1	Polar angle	388
19.90	POLARDIST system variable	388
19.90.1	Polar distance	388
19.91	POLARMODE system variable	388
19.91.1	Polar mode	388
19.92	POLYSIDES system variable	389
19.92.1	Polygon sides	389
19.93	POPUPS system variable	389
19.93.1	Popups	389
19.94	PREVIEWDELAY system variable	390
19.94.1	Delay to preview selection	390
19.95	PREVIEWEFFECT system variable	390
19.95.1	Selection preview effect	390
19.96	PREVIEWFILTER system variable	390



Содержание

19.96.1	Selection preview filter	390
19.97	PREVIEWTYPE system variable	391
19.97.1	Preview type	391
19.98	PREVIEWWNDINOPENDLG system variable	391
19.98.1	Preview window in open dialog	391
19.99	PRINTFILE system variable	392
19.99.1	Print file	392
19.100	PRINTPDFPREVIEW system variable	392
19.100.1	Print As PDF Preview	392
19.101	PRODUCT system variable	392
19.101.1	Product	392
19.102	PROFILEOFFSETBEHAVIOR system variable	393
19.102.1	Profile offset behavior	393
19.103	PROGBAR system variable	393
19.103.1	Progress bar	393
19.104	PROGRAM system variable	393
19.104.1	Program	393
19.105	PROJECTIONTYPE system variable	394
19.105.1	Drawing views position scheme	394
19.106	PROJECTNAME system variable	396
19.106.1	Project name	396
19.107	PROJECTSEARCHPATHS system variable	396
19.107.1	Project search paths	396
19.108	PROJMODE system variable	396
19.108.1	Projection mode	396
19.109	PROMPTMENU system variable	397
19.109.1	Prompt menu	397
19.110	PROMPTMENUFLAGS system variable	397
19.110.1	Prompt menu flags	397
19.111	PROMPTOPTIONFORMAT system variable	398
19.111.1	Prompt option format	398
19.112	PROMPTOPTIONTRANSLATEKEYWORDS system variable	399
19.112.1	Prompt option translate keywords	399
19.113	PROPAGATESEARCHSPACE system variable	399
19.113.1	Search space	399
19.114	PROPAGATETOLERANCE system variable	400
19.114.1	Position tolerance	400
19.115	PROPERTYPREVIEW system variable	400
19.115.1	Property preview	400
19.116	PROPERTYPREVIEWDELAY system variable	400
19.116.1	Property Preview Delay	400
19.117	PROPERTYPREVIEWOBJLIMIT system variable	401
19.117.1	Property Preview Object Limit	401
19.118	PROPPREVTIMEOUT system variable	401
19.118.1	Property Preview Timeout	401
19.119	PROPUNITS system variable	402
19.119.1	Property units	402
19.120	PROXYGRAPHICS system variable	402



Содержание

19.120.1	Proxy graphics	402
19.121	PROXYNOTICE system variable	402
19.121.1	Proxy notice	402
19.122	PROXYSHOW system variable	403
19.122.1	Proxy show	403
19.123	PROXYWEBSEARCH system variable	403
19.123.1	Proxy web search	403
19.124	PSLTSCALE system variable	404
19.124.1	Paper space linetype scale	404
19.125	PSOLHEIGHT system variable	404
19.125.1	Polysolid height	404
19.126	PSOLWIDTH system variable	404
19.126.1	Polysolid width	404
19.127	PSTYLEMODE system variable	405
19.127.1	Plot style mode	405
19.128	PSTYLEPOLICY system variable	405
19.128.1	Plot style policy	405
19.129	PSVPSCALE system variable	405
19.129.1	Paper space viewport scale	405
19.130	PUBLISHALLSHEETS system variable	406
19.130.1	Publish all sheets	406
19.131	PUBLISHCOLLATE system variable	406
19.131.1	Collate published sheets	406
19.132	PUCSBASE system variable	406
19.132.1	Paper space UCS base	406
19.133	PDFANIMATIONFPS system variable	407
19.133.1	Frames per second	407
20.	Q	408
20.1	QAFLAGS system variable	408
20.1.1	Quality Assurance flags	408
20.2	QTEXTMODE system variable	408
20.2.1	Quick text mode	408
20.3	QUADCOMMANDLAUNCH system variable	411
20.3.1	Quad default command launch	411
20.4	QUADDISPLAY system variable	411
20.4.1	Quad display	411
20.5	QUADEXPANDDELAY system variable	412
20.5.1	Quad expand delay	412
20.6	QUADEXPANDTABDELAY system variable	412
20.6.1	Quad expand tab delay	412
20.7	QUADGOTRSPARENT system variable	412
20.7.1	Quad go transparent	412
20.8	QUADHIDEDELAY system variable	413
20.8.1	Quad hide delay	413
20.9	QUADHIDEMARGIN system variable	413
20.9.1	Quad hide margin	413
20.10	QUADICONSIZE system variable	413
20.10.1	Quad icon size	413



Содержание

20.11	QUADICONSPACE system variable	414
20.11.1	Quad icon space	414
20.12	QUADMOSTRECENTITEMS system variable	415
20.12.1	Quad most recent items	415
20.13	QUADPOPUPCORNER system variable	415
20.13.1	Quad popup corner	415
20.14	QUADROLLOVERDELAY system variable	416
20.14.1	Quad rollover delay	416
20.15	QUADSHOWDELAY system variable	416
20.15.1	Quad show delay	416
20.16	QUADWIDTH system variable	417
20.16.1	Quad width	417
21.	R	418
21.1	R12SAVEACCURACY system variable	418
21.1.1	R12 Save accuracy	418
21.2	R12SAVEDEVIATION system variable	418
21.2.1	R12 Save deviation	418
21.3	RASTERPREVIEW system variable	418
21.3.1	Raster preview	418
21.4	RE_INIT system variable	419
21.4.1	Reinitialize Aliases	419
21.5	REALTIMESPEEDUP system variable	419
21.5.1	Realtime speedup	419
21.6	REALWORLDSCALE system variable	419
21.6.1	Real world scale	419
21.7	RECENTFILES system variable	420
21.7.1	Recent file list max count	420
21.8	RECENTPATH system variable	420
21.8.1	Recent path	420
21.9	REDHILITE_DUCSLOCKED_FACE_ALPHA system variable	420
21.9.1	Face opacity	420
21.10	REDHILITE_DUCSLOCKED_FACE_COLOR system variable	421
21.10.1	Face color	421
21.11	REDHILITE_HIDDENEDGE_ALPHA system variable	421
21.11.1	Edge opacity	421
21.12	REDHILITE_HIDDENEDGE_COLOR system variable	421
21.12.1	Edge color	421
21.13	REDHILITEFULL_EDGE_ALPHA system variable	422
21.13.1	Edge opacity	422
21.14	REDHILITEFULL_EDGE_COLOR system variable	422
21.14.1	Edge color	422
21.15	REDHILITEFULL_EDGE_SHOWHIDDEN system variable	422
21.15.1	Hidden edges	422
21.16	REDHILITEFULL_EDGE_SMOOTHING system variable	423
21.16.1	Edge smoothing	423
21.17	REDHILITEFULL_EDGE_THICKNESS system variable	423
21.17.1	Edge thickness	423
21.18	REDHILITEFULL_FACE_ALPHA system variable	424



Содержание

21.18.1	Face opacity	424
21.19	REDHILITEFULL_FACE_COLOR system variable	424
21.19.1	Face color	424
21.20	REDHILITEPARTIAL_SELECTEDEDGE_ALPHA system variable	424
21.20.1	Edge opacity	424
21.21	REDHILITEPARTIAL_SELECTEDEDGE_COLOR system variable	425
21.21.1	Edge color	425
21.22	REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable	425
21.22.1	Glow	425
21.23	REDHILITEPARTIAL_SELECTEDEDGE_SMOOTHING system variable	425
21.23.1	Edge smoothing	425
21.24	REDHILITEPARTIAL_SELECTEDEDGE_THICKNESS system variable	426
21.24.1	Edge thickness	426
21.25	REDHILITEPARTIAL_SELECTEDEDGEGLOW_ALPHA system variable	426
21.25.1	Glow opacity	426
21.26	REDHILITEPARTIAL_SELECTEDEDGEGLOW_COLOR system variable	426
21.26.1	Glow color	426
21.27	REDHILITEPARTIAL_SELECTEDEDGEGLOW_SMOOTHING system variable	427
21.27.1	Glow smoothing	427
21.28	REDHILITEPARTIAL_SELECTEDEDGEGLOW_THICKNESS system variable	427
21.28.1	Glow thickness	427
21.29	REDHILITEPARTIAL_SELECTEDFACE_ALPHA system variable	428
21.29.1	Face opacity	428
21.30	REDHILITEPARTIAL_SELECTEDFACE_COLOR system variable	428
21.30.1	Face color	428
21.31	REDHILITEPARTIAL_UNSELECTEDEDGE_SHOWHIDDEN system variable	429
21.31.1	Hidden edges	429
21.32	REDSDKLINESMOOTHING system variable	429
21.32.1	Line smoothing	429
21.33	REDUCELENGTHTYPE system variable	429
21.33.1	Reduce Length Type	429
21.34	REDUCELENGTHVALUE system variable	430
21.34.1	Reduce Length Value	430
21.35	REFEDITLOCKNOTINWORKSET system variable	430
21.35.1	Refedit lock	430
21.36	REFEDITNAME system variable	431
21.36.1	Refedit name	431
21.37	REFPATHTYPE system variable	431
21.37.1	Default path type of reference files	431
21.38	REGENMODE system variable	431
21.38.1	Regeneration mode	431
21.39	REGEXPAND system variable	432
21.39.1	Registry paths expanding type	432
21.40	REMEMBERFOLDERS system variable	432
21.40.1	Remember folders	432
21.41	RENDERCOMPOSITIONMATERIAL system variable	433
21.41.1	Render composition material	433
21.42	RENDERMATERIALDOWNLOAD system variable	433



Содержание

21.42.1	Download missing resources for render materials	433
21.43	RENDERMATERIALSPATH system variable	433
21.43.1	Render materials directory path	433
21.44	RENDERUSINGHARDWARE system variable	434
21.44.1	Render using hardware	434
21.45	REPORTPANELMODE system variable	434
21.45.1	Report panel mode	434
21.46	REPOSITORYFOLDER system variable	435
21.46.1	Repository folder	435
21.47	RESTORECONNECTIONS system variable	435
21.47.1	Restore Connections	435
21.48	RESTORELOSTFOCUS system variable	435
21.48.1	Restore lost focus (Linux)	435
21.49	RETAINEDGRAPHICS system variable	436
21.49.1	Retained Graphics	436
21.50	REVCLOUDARCSTYLE system variable	436
21.50.1	Revision cloud default arc style	436
21.51	REVCLOUDCREATEMODE system variable	437
21.51.1	Revision cloud creation mode	437
21.52	REVCLOUDGRIPS system variable	437
21.52.1	Revision cloud grips	437
21.53	REVCLOUDMAXARCLENGTH system variable	438
21.53.1	Revision cloud default maximum arc length	438
21.54	REVCLOUDMINARCLENGTH system variable	438
21.54.1	Revision cloud default minimum arc length	438
21.55	RHINOVERSION system variable	438
21.55.1	Rhino version	438
21.56	RIBBONDOCKEDHEIGHT system variable	439
21.56.1	Ribbon docked height	439
21.57	RIBBONPANELMARGIN system variable	439
21.57.1	Panel margin	439
21.58	RIBBONSTATE system variable	439
21.58.1	Ribbon state	439
21.59	RIBBONTOOLSIZEx system variable	440
21.59.1	Ribbon tool size	440
21.60	ROAMABLEROOTPREFIX system variable	440
21.60.1	Roamable root prefix	440
21.61	ROLLOVEROPACITY system variable	441
21.61.1	Rollover opacity	441
21.62	ROLLOVERSELECTIONSET system variable	441
21.62.1	Rollover selection set	441
21.63	ROLLOVERTIPS system variable	441
21.63.1	Rollover tips	441
21.64	RTDISPLAY system variable	442
21.64.1	Realtime display	442
21.65	RTROTATIONSPSEDFACTOR system variable	442
21.65.1	Realtime Rotation Speed Factor	442
21.66	RUBBERBANDCOLOR system variable	442



Содержание

21.66.1	Rubberband color	442
21.67	RUBBERBANDSTYLE system variable	443
21.67.1	Rubberband dashed style	443
21.68	RUBBERSHEET (for OS X) system variable	443
21.68.1	Rubbersheet Touchpad	443
21.69	RUBBERSHEETSENSIBILITY (FOR OS X) system variable	444
21.69.1	Rubbersheet gesture activation sensibility	444
21.70	RULERDISPLAY system variable	444
21.70.1	Ruler Display	444
21.71	RULERTEXTCOLOR system variable	444
21.71.1	Ruler Text Color	444
21.72	RUNASLEVEL system variable	445
21.72.1	Run as license level	445
21.73	RVTRFALEVELOFDETAIL system variable	445
21.73.1	Level of detail	445
21.74	RVVALIDATEBREP system variable	446
21.74.1	Validate BREP geometry	446
22.	S	447
22.1	SAFEMODE system variable	447
22.1.1	Safe mode	447
22.2	SAVECHANGETOLAYOUT system variable	447
22.2.1	Save changes to layout	447
22.3	SAVEFIDELITY system variable	447
22.3.1	Save fidelity	447
22.4	SAVEFILE system variable	448
22.4.1	Save file name	448
22.5	SAVEFILEPATH system variable	448
22.5.1	Save file path	448
22.6	SAVEFORMAT system variable	448
22.6.1	Save format	448
22.7	SAVELAYERSNAPSHOT system variable	449
22.7.1	Save Layer Snapshot with view	449
22.8	SAVENAME system variable	450
22.8.1	Saved drawing name	450
22.9	SAVEONDOCSWITCH system variable	450
22.9.1	Save on document switch	450
22.10	SAVEROUNDTRIP system variable	450
22.10.1	Save roundtrip	450
22.11	SAVETIME system variable	451
22.11.1	Save time interval	451
22.12	SCREENBOXES system variable	451
22.12.1	Screen menu boxes	451
22.13	SCREENMODE system variable	451
22.13.1	Screen mode	451
22.14	SCREENSIZE system variable	452
22.14.1	Screen size	452
22.15	SCRLHIST system variable	452
22.15.1	Scroll history	452



Содержание

22.16	SDI system variable	452
22.16.1	Single-document interface (Windows)	452
22.17	SECTIONRESULTINTERVAL system variable	453
22.17.1	Section result interval	453
22.18	SECTIONSCALE system variable	453
22.18.1	Section scale	453
22.19	SECTIONSETTINGSSEARCHPATH system variable	454
22.19.1	Section settings search path	454
22.20	SECTIONSHEETSETTEMPLATEIMPERIAL system variable	454
22.20.1	Section sheet set template imperial	454
22.21	SECTIONSHEETSETTEMPLATEMETRIC system variable	454
22.21.1	Section sheet set template metric	454
22.22	SECURELOAD system variable	455
22.22.1	Executable file security policy	455
22.23	SELECTIONANNODISPLAY system variable	455
22.23.1	Show all annotation scales on selection	455
22.24	SELECTIONAREA system variable	456
22.24.1	Selection area	456
22.25	SELECTIONAREAOPACITY system variable	456
22.25.1	Selection area opacity	456
22.26	SELECTIONMODES system variable	456
22.26.1	Selection modes	456
22.27	SELECTIONPREVIEW system variable	457
22.27.1	Selection preview display	457
22.28	SELECTSIMILARMODE system variable	457
22.28.1	Match options for SELECTSIMILAR	457
22.29	SETBYLAYERMODE system variable	458
22.29.1	Options for SETBYLAYERMODE	458
22.30	SHADEEDGE system variable	458
22.30.1	Shading edges	458
22.31	SHADEDIF system variable	459
22.31.1	Shading diffusion	459
22.32	SHEETNUMBERLEADINGZEROES system variable	459
22.32.1	Sheet number leading zeroes	459
22.33	SHEETSETAUTOBACKUP system variable	460
22.33.1	Sheet set automatic backup	460
22.34	SHEETSETTEMPLATEPATH system variable	460
22.34.1	Sheet Set template path	460
22.35	SHORTCUTMENU system variable	460
22.35.1	Shortcut menus	460
22.36	SHORTCUTMENUDURATION system variable	461
22.36.1	Shortcut menu duration	461
22.37	SHOWDOCTABS system variable	461
22.37.1	Tabs visibility	461
22.38	SHOWFULLPATHINTITLE system variable	462
22.38.1	Display full path in title	462
22.39	SHOWLAYERUSAGE system variable	462
22.39.1	Layer Usage	462



Содержание

22.40	SHOWSCROLLBUTTONS system variable	462
22.40.1	Scroll buttons (Mac & Linux)	462
22.41	SHOWTABCLOSEBUTTON system variable	463
22.41.1	Close button on tabs (Mac & Linux)	463
22.42	SHOWTABCLOSEBUTTONACTIVE system variable	463
22.42.1	Close button on active tab (Mac & Linux)	463
22.43	SHOWTABCLOSEBUTTONALL system variable	464
22.43.1	Close button on all tabs (Mac & Linux)	464
22.44	SHOWWINDOWLISTBUTTON system variable	464
22.44.1	Window list button (Mac & Linux)	464
22.45	SHPNAME system variable	464
22.45.1	Shape name	464
22.46	SIGWARN system variable	465
22.46.1	Signature warning	465
22.47	SINGLETONMODE system variable	465
22.47.1	Singleton mode	465
22.48	SKETCHINC system variable	465
22.48.1	Sketch increment	465
22.49	SKPOLY system variable	466
22.49.1	Sketch poly	466
22.50	SKYSTATUS system variable	466
22.50.1	Sky status	466
22.51	SMASSEMBLYEXPORTMODE system variable	467
22.51.1	Modification of exported assemblies	467
22.52	SMASSEMBLYEXPORTREPORTPATHTYPE system variable	467
22.52.1	Report file path type	467
22.53	SMASSEMBLYEXPORTSOLIDTYPESINREPORTS system variable	467
22.53.1	Solid types in reports	467
22.54	SMATTRIBUTESLAYERCOLOR system variable	468
22.54.1	Color of the attributes layer	468
22.55	SMATTRIBUTESLAYERTEXTHEIGHT system variable	468
22.55.1	Height of the text	468
22.56	SMATTRIBUTESLAYERTEXTHEIGHTTYPE system variable	468
22.56.1	Type of the text height	468
22.57	SMBENDANNOTATIONSLAYERCOLOR system variable	469
22.57.1	Color of the bend annotations text layer	469
22.58	SMBENDANNOTATIONSLAYERTEXTHEIGHT system variable	469
22.58.1	Height of the text	469
22.59	SMBENDANNOTATIONSLAYERTEXTHEIGHTTYPE system variable	470
22.59.1	Type of the text height	470
22.60	SMBENDLINESDOWNLAYERCOLOR system variable	470
22.60.1	Color of the bend down lines layer	470
22.61	SMBENDLINESDOWNLAYERLINETYPE system variable	470
22.61.1	Linetype of the bend down lines layer	470
22.62	SMBENDLINESDOWNLAYERLINEWEIGHT system variable	471
22.62.1	Lineweight of the bend down layer	471
22.63	SMBENDLINESUPLAYERCOLOR system variable	471
22.63.1	Color of the bend up lines layer	471



Содержание

22.64	SMBENDLINESUPPLAYERLINETYPE system variable	471
22.64.1	Linetype of the bend up lines layer	471
22.65	SMBENDLINESUPPLAYERLINEWEIGHT system variable	472
22.65.1	Lineweight of the bend up layer	472
22.66	SMBEVELFEATURECOLOR system variable	472
22.66.1	Color of the bevel features layer	472
22.67	SMCOLORBEND system variable	472
22.67.1	Bend relief feature color	472
22.68	SMCOLORBENDRELIEF system variable	473
22.68.1	Bend relief feature color	473
22.69	SMCOLORBEVEL system variable	473
22.69.1	Bevel feature color	473
22.70	SMCOLORCORNERRELIEF system variable	473
22.70.1	Corner relief feature color	473
22.71	SMCOLORFLANGE system variable	474
22.71.1	Flange feature color	474
22.72	SMCOLORFLANGEREFERENCESIDE system variable	474
22.72.1	Flange feature reference side color	474
22.73	SMCOLORFORM system variable	474
22.73.1	Form feature color	474
22.74	SMCOLORHEM system variable	475
22.74.1	Hem feature color	475
22.75	SMCOLORJOG system variable	475
22.75.1	Jog feature color	475
22.76	SMCOLORJUNCTION system variable	475
22.76.1	Junction feature color	475
22.77	SMCOLORLOFTEDBEND system variable	475
22.77.1	Lofted bend feature color	475
22.78	SMCOLORMITER system variable	476
22.78.1	Miter feature color	476
22.79	SMCOLORROLLEDEDGE system variable	476
22.79.1	Rolled edge feature color	476
22.80	SMCOLORTAB system variable	476
22.80.1	Tab feature color	476
22.81	SMCOLORWRONGBEND system variable	477
22.81.1	Wrong bend feature color	477
22.82	SMCOLORWRONGFLANGE system variable	477
22.82.1	Wrong flange feature color	477
22.83	SMCONTOURSLAYERCOLOR system variable	477
22.83.1	Color of the contour layer	477
22.84	SMCONTOURSLAYERLINETYPE system variable	478
22.84.1	Linetype of the contour layer	478
22.85	SMCONTOURSLAYERLINEWEIGHT system variable	478
22.85.1	Lineweight of the contour layer	478
22.86	SMCONVERTMAXIMALBEVELANGLE system variable	478
22.86.1	Maximal angle of bevel	478
22.87	SMCONVERTMINIMALBEVELANGLE system variable	479
22.87.1	Minimal angle of bevel	479



Содержание

22.88	SMCONVERTPREFERFORMFEATURES system variable	479
22.88.1	Prefer form features to flanges and bends	479
22.89	SMCONVERTPREFERHEMFEATURES system variable	480
22.89.1	Prefer hem features to flanges and bends	480
22.90	SMCONVERTPREFERZEROBENDFEATURES system variable	480
22.90.1	Prefer zero bend features to wrong bends	480
22.91	SMCONVERTRECOGNIZEHOLES system variable	480
22.91.1	Recognize holes	480
22.92	SMCONVERTRECOGNIZERIBCONTROLCURVES system variable	481
22.92.1	Recognize rib control curves	481
22.93	SMCONVERTWRONGFEATURETHICKNESSDEVIATIONTYPE system variable	481
22.93.1	Type of deviation of wrong feature thickness	481
22.94	SMCONVERTWRONGFEATURETHICKNESSDEVIATIONVALUE system variable	482
22.94.1	Deviation value of wrong feature thickness	482
22.95	SMDEFAULTBENDLINEEXTENTTYPE system variable	482
22.95.1	Bend line extent type	482
22.96	SMDEFAULTBENDLINEEXTENTVALUE system variable	482
22.96.1	Bend line extent value	482
22.97	SMDEFAULTBENDRADIUSTYPE system variable	483
22.97.1	Bend radius type	483
22.98	SMDEFAULTBENDRADIUSVALUE system variable	483
22.98.1	Bend radius value	483
22.99	SMDEFAULTBENDRELIEFWIDHTTYPE system variable	484
22.99.1	Bend relief type	484
22.100	SMDEFAULTBENDRELIEFWIDTHVALUE system variable	484
22.100.1	Bend relief width value	484
22.101	SMDEFAULTBEVELFEATUREUNFOLDMODE system variable	484
22.101.1	Bevel unfolding mode	484
22.102	SMDEFAULTCORNERRELIEFDIAMETERVALUE system variable	485
22.102.1	Corner relief diameter value	485
22.103	SMDEFAULTFLANGESPLITEXTENSIONTYPE system variable	485
22.103.1	Miter extension type	485
22.104	SMDEFAULTFLANGESPLITEXTENSIONVALUE system variable	485
22.104.1	Miter extension value	485
22.105	SMDEFAULTFLANGESPLITGAPTYPE system variable	486
22.105.1	Miter gap type	486
22.106	SMDEFAULTFLANGESPLITGAPVALUE system variable	486
22.106.1	Miter gap value	486
22.107	SMDEFAULTFORMFEATUREUNFOLDMODE system variable	487
22.107.1	Form feature unfolding mode	487
22.108	SMDEFAULTGUSSETDEPTHVALUE system variable	487
22.108.1	Gusset depth value	487
22.109	SMDEFAULTGUSSETDEPTHTYPE system variable	487
22.109.1	Gusset depth type	487
22.110	SMDEFAULTGUSSETFILLETRADIUSVALUE system variable	488
22.110.1	Gusset fillet radius value	488
22.111	SMDEFAULTGUSSETFILLETRADIUSTYPE system variable	488
22.111.1	Gusset fillet radius type	488



Содержание

22.112	SMDEFAULTGUSSETTYPE system variable	489
22.112.1	Gusset type	489
22.113	SMDEFAULTGUSSETWIDTHVALUE system variable	489
22.113.1	Gusset width value	489
22.114	SMDEFAULTGUSSETWIDHTHTYPE system variable	489
22.114.1	Gusset width type	489
22.115	SMDEFAULTHEMGAPTYPE system variable	490
22.115.1	Open Hem gap type	490
22.116	SMDEFAULTHEMGAPVALUE system variable	490
22.116.1	Open Hem gap value (in addition to the thickness)	490
22.117	SMDEFAULTHEMRELATIVEBENDDEDUCTION system variable	491
22.117.1	Hem relative bend deduction value	491
22.118	SMDEFAULTJUNCTIONALIGNMENTTORELIEF system variable	491
22.118.1	Junction alignment to relief	491
22.119	SMDEFAULTJUNCTIONGAPTYPE system variable	491
22.119.1	Junction gap type	491
22.120	SMDEFAULTJUNCTIONGAPVALUE system variable	492
22.120.1	Junction gap value	492
22.121	SMDEFAULTKFACTOR system variable	492
22.121.1	K-Factor value	492
22.122	SMDEFAULTLOFTEDBENDNUMBERSAMPLES system variable	493
22.122.1	Lofted bend subdivisions	493
22.123	SMDEFAULTRELIEFEXTENSIONTYPE system variable	493
22.123.1	Relief extension type	493
22.124	SMDEFAULTRELIEFEXTENSIONVALUE system variable	493
22.124.1	Relief extension value	493
22.125	SMDEFAULTTRIBFILLETRADIUSTYPE system variable	494
22.125.1	Bead fillet radius type	494
22.126	SMDEFAULTTRIBFILLETRADIUSVALUE system variable	494
22.126.1	Bead fillet radius value	494
22.127	SMDEFAULTTRIBPROFILERADIUSTYPE system variable	494
22.127.1	Bead profile radius type	494
22.128	SMDEFAULTTRIBPROFILERADIUSVALUE system variable	495
22.128.1	Bead profile radius value	495
22.129	SMDEFAULTTRIBROUNDRADIUSTYPE system variable	495
22.129.1	Bead round radius type	495
22.130	SMDEFAULTTRIBROUNDRADIUSVALUE system variable	495
22.130.1	Bead round radius value	495
22.131	SMDEFAULTSHARBENDRADIUSLIMITRATIO system variable	496
22.131.1	Sharp bend radius limit ratio	496
22.132	SMDEFAULTTABCHAMFERDISTANCETYPE system variable	496
22.132.1	Tab chamfer distance type	496
22.133	SMDEFAULTTABCHAMFERDISTANCEVALUE system variable	496
22.133.1	Tab chamfer distance value	496
22.134	SMDEFAULTTABCLEARANCETYPE system variable	497
22.134.1	Tab clearance type	497
22.135	SMDEFAULTTABCLEARANCEVALUE system variable	497
22.135.1	Tab clearance value	497



Содержание

22.136	SMDEFAULTTABDISTANCETYPE system variable	497
22.136.1	Tab distance type	497
22.137	SMDEFAULTTABDISTANCEVALUE system variable	498
22.137.1	Tab distance value	498
22.138	SMDEFAULTTABEDGE TYPE system variable	498
22.138.1	Tab edge type	498
22.139	SMDEFAULTTABFILLETRADIUSTYPE system variable	499
22.139.1	Tab fillet radius type	499
22.140	SMDEFAULTTABFILLETRADIUSVALUE system variable	499
22.140.1	Tab fillet radius value	499
22.141	SMDEFAULTTABHEIGHTTYPE system variable	499
22.141.1	Tab height type	499
22.142	SMDEFAULTTABHEIGHTVALUE system variable	500
22.142.1	Tab height value	500
22.143	SMDEFAULTTABLENGTHTYPE system variable	500
22.143.1	Tab length type	500
22.144	SMDEFAULTTABLENGTHVALUE system variable	500
22.144.1	Tab length value	500
22.145	SMDEFAULTTABSLOTCOLOR system variable	501
22.145.1	Tab slot color	501
22.146	SMDEFAULTTHICKNESS system variable	501
22.146.1	Thickness value	501
22.147	SMEXPORTOSMAPPROXIMATIONACCURACY system variable	501
22.148	SMEXPORTOSMMINIMALEGELENGTH system variable	501
22.149	SMFORMFEATURESDOWNCOLOR system variable	501
22.149.1	Color of the form features down layer	501
22.150	SMFORMFEATURESDOWNLAYERLINETYPE system variable	502
22.150.1	Linetype of the form features down layer	502
22.151	SMFORMFEATURESDOWNLAYERLINEWEIGHT system variable	502
22.151.1	Lineweight of the form features down layer	502
22.152	SMFORMFEATURESUPCOLOR system variable	502
22.152.1	Color of the form features up layer	502
22.153	SMFORMFEATURESUPLAYERLINETYPE system variable	503
22.153.1	Linetype of the form features up layer	503
22.154	SMFORMFEATURESUPLAYERLINEWEIGHT system variable	503
22.154.1	Lineweight of the form features up layer	503
22.155	SMJUNCTIONCREATEHEALCOINCIDENT system variable	503
22.155.1	Heal coincident junction faces	503
22.156	SMOOTHMESHCONVERT system variable	504
22.156.1	Mesh conversion mode	504
22.157	SMOVERALLANNOTATIONSLAYERCOLOR system variable	504
22.157.1	Color of the overall dimensions annotations layer	504
22.158	SMOVERALLANNOTATIONSLAYERLINETYPE system variable	505
22.158.1	Linetype of the overall annotation layer	505
22.159	SMOVERALLANNOTATIONSLAYERLINEWEIGHT system variable	505
22.159.1	Lineweight of the overall annotation layer	505
22.160	SMPARAMETRIZEHOLES PARAMETRIZATION system variable	505
22.160.1	Hole parametrization	505



Содержание

22.161	SMREPAIRLOFTEDBENDMERGE system variable	506
22.161.1	Merge lofted bends	506
22.162	SMSMARTFEATURES system variable	506
22.162.1	Automatically update sheet metal features	506
22.163	SMSPLITAMBIGUOUSINPUT system variable	507
22.163.1	Ambiguous input behavior	507
22.164	SMSPLITCONVERTBENDTOJUNCTION system variable	507
22.164.1	Convert bend to junction	507
22.165	SMSPLITHEALCOINCIDENT system variable	507
22.165.1	Heal coincident miter faces	507
22.166	SMSPLITORTHOGONALBENDSPLIT system variable	508
22.166.1	Orthogonal bend split	508
22.167	SMTARGETCAM system variable	508
22.167.1	Target CAM	508
22.168	SNAPANG system variable	508
22.168.1	Snap angle	508
22.169	SNAPBASE system variable	509
22.169.1	Snap base	509
22.170	SNAPCOLOR system variable	509
22.170.1	Snap color (Obsolete)	509
22.171	SNAPISOPAIR system variable	509
22.171.1	Snap isometric pair	509
22.172	SNAPMARKERCOLOR system variable	510
22.172.1	Snap marker color	510
22.173	SNAPMARKERSIZE system variable	510
22.173.1	Snap marker size	510
22.174	SNAPMARKERTHICKNESS system variable	511
22.174.1	Snap marker thickness	511
22.175	SNAPMODE system variable	511
22.175.1	Snap mode	511
22.176	SNAPSIZEx system variable	511
22.176.1	Snap size (Obsolete)	511
22.177	SNAPSTYL system variable	512
22.177.1	Snap style	512
22.178	SNAPTHICKNESS system variable	512
22.178.1	Snap thickness (Obsolete)	512
22.179	SNAPTYPE system variable	512
22.179.1	Snap type	512
22.180	SNAPUNIT system variable	513
22.180.1	Snap unit	513
22.181	SOLIDCHECK system variable	513
22.181.1	Solid check	513
22.182	SORTENTS system variable	513
22.182.1	Sort entities	513
22.183	SPAADJUSTMODE system variable	514
22.183.1	Adjust mode	514
22.184	SPACHECKLEVEL system variable	514
22.184.1	Check level	514



Содержание

22.185	SPAGRIDASPECTRATIO system variable	515
22.185.1	Grid aspect ratio	515
22.186	SPAGRIDMODE system variable	516
22.186.1	Grid mode	516
22.187	SPAMAXFACETEDGELENGTH system variable	516
22.187.1	Maximum facet edge length	516
22.188	SPAMAXNUMGRIDLINES system variable	516
22.188.1	Maximum number of grid lines	516
22.189	SPAMINUGRIDLINES system variable	517
22.189.1	Minimum number of U grid lines	517
22.190	SPAMINVGRIDLINES system variable	517
22.190.1	Minimum number of V grid lines	517
22.191	SPANORMALTOL system variable	517
22.191.1	Normal tolerance	517
22.192	SPASURFACETOL system variable	518
22.192.1	Surface tolerance	518
22.193	SPATRIANGMODE system variable	518
22.193.1	Triangulation mode	518
22.194	SPAUSEFACETRES system variable	519
22.194.1	Use FACETRES system variable	519
22.195	SPLFRAME system variable	519
22.195.1	Spline frame	519
22.196	SPLINESEGS system variable	519
22.196.1	Spline segments	519
22.197	SPLINETYPE system variable	520
22.197.1	Spline type	520
22.198	SRCHPATH system variable	520
22.198.1	Support file search path	520
22.199	SSAUTOSAVE system variable	521
22.199.1	Sheet set autosave	521
22.200	SSFOUND system variable	521
22.200.1	Sheet set found	521
22.201	SSLOCATE system variable	521
22.201.1	Sheet set locate	521
22.202	SSMAUTOOPEN system variable	522
22.202.1	Sheet set manager auto open	522
22.203	SSMPOLLTIME system variable	522
22.203.1	Sheet set manager poll time	522
22.204	SSMSHEETSTATUS system variable	522
22.204.1	Sheet set manager status	522
22.205	SSMSTATE system variable	523
22.205.1	Sheet set manager state	523
22.206	STACKPANELTYPE system variable	523
22.206.1	Stack panel type	523
22.207	STAMPFONTSIZE system variable	524
22.207.1	Font Size	524
22.208	STAMPFONTSTYLE system variable	524
22.208.1	Font Style	524



Содержание

22.209	STAMPFOOTER system variable	524
22.209.1	Footer	524
22.210	STAMPFOOTEROFFSETX system variable	525
22.210.1	Stamp footer X offset	525
22.211	STAMPFOOTEROFFSETY system variable	525
22.211.1	Stamp footer Y offset	525
22.212	STAMPHEADER system variable	525
22.212.1	Header	525
22.213	STAMPHEADEROFFSETX system variable	525
22.213.1	Stamp header X offset	525
22.214	STAMPHEADEROFFSETY system variable	526
22.214.1	Stamp header Y offset	526
22.215	STAMPUNITS system variable	526
22.215.1	Units	526
22.216	STANDARDSOPTIONS system variable	526
22.216.1	Standards validation options	526
22.217	STANDARDSVIOLATION system variable	527
22.217.1	Standards Violation Notification	527
22.218	STARTUP system variable	527
22.218.1	Startup	527
22.219	STARTUPTODAY system variable	528
22.219.1	Startup today (Obsolete)	528
22.220	STATUSBAR system variable	528
22.220.1	Window status bar	528
22.221	STEPSENTRY system variable	528
22.221.1	Step size	528
22.222	STEPSPERSEC system variable	529
22.222.1	Steps per second	529
22.223	STLPOSITIVEQUADRANT system variable	529
22.223.1	STL export coordinates adjustment	529
22.224	STORYBAR system variable	529
22.224.1	Display Story Bar	529
22.225	STRUCTURETREECONFIG system variable	530
22.225.1	Structure Tree Configuration	530
22.226	SURFTAB1 system variable	530
22.226.1	Surface tabulation 1	530
22.227	SURFTAB2 system variable	531
22.227.1	Surface tabulation 2	531
22.228	SURFTYPE system variable	531
22.228.1	Surface-fitting type	531
22.229	SURFU system variable	531
22.229.1	Surface U	531
22.230	SURFV system variable	532
22.230.1	Surface V	532
22.231	SVGBLENDEDGRADIENTS system variable	532
22.231.1	Svg Blended Gradients	532
22.232	SVGDEFAULTIMAGEEXTENSION system variable	532
22.232.1	Svg Default Image Extension	532



Содержание

22.233	SVGGENERICFONTFAMILY system variable	533
22.233.1	Svg Generic Font Family	533
22.234	SVGIMAGEBASE system variable	533
22.234.1	Svg Image base path	533
22.235	SVGIMAGEURL system variable	533
22.235.1	Svg Image Url	533
22.236	SVGLINEWEIGHTSCALE system variable	534
22.236.1	Svg Line Weight Scale	534
22.237	SVGOUTPUTHEIGHT system variable	534
22.237.1	Svg Output Height (in pixels)	534
22.238	SVGOUTPUTWIDTH system variable	534
22.238.1	Svg Output Width (in pixels)	534
22.239	SVGPRECISION system variable	535
22.239.1	Svg Floating Point Precision	535
22.240	SVGSCALEFACTOR system variable	535
22.240.1	Svg Scale Factor	535
22.241	SYSCODEPAGE system variable	535
22.241.1	System code page	535
23.	T	536
23.1	TABCONTROLHEIGHT system variable	536
23.1.1	Tab control height in pixels (Mac & Linux)	536
23.2	TABMODE system variable	536
23.2.1	Tablet mode	536
23.3	TABSFIXEDWIDTH system variable	536
23.3.1	Tabs fixed width (Mac & Linux)	536
23.4	TANGENTLENGTHTYPE system variable	537
23.4.1	Tangent Length Type	537
23.5	TANGENTLENGTHVALUE system variable	537
23.5.1	Tangent Length Value	537
23.6	TARGET system variable	537
23.6.1	Target	537
23.7	TDCREATE system variable	538
23.7.1	Time/Date create	538
23.8	TDINDWG system variable	538
23.8.1	Time/Date in drawing	538
23.9	TDUCREATE system variable	538
23.9.1	Time/Date universal create	538
23.10	TDUPDATE system variable	538
23.10.1	Time/Date update	538
23.11	TDUSR TIMER system variable	539
23.11.1	Time/Date user timer	539
23.12	TDUUPDATE system variable	539
23.12.1	Time/Date universal update	539
23.13	TEETANGENTLENGTHTYPE system variable	539
23.13.1	Tee Length Type	539
23.14	TEETANGENTLENGTHVALUE system variable	539
23.14.1	Tee Length Value	539
23.15	TEMPLATEPATH system variable	540



Содержание

23.15.1	Template path	540
23.16	TEMPPREFIX system variable	540
23.16.1	Temporary prefix	540
23.17	TEXTANGLE system variable	540
23.17.1	Text angle	540
23.18	TEXTED system variable	540
23.18.1	Text editor for single line text entities	540
23.19	TEXTEDITMODE system variable	541
23.19.1	Text edit mode	541
23.20	TEXTEVAL system variable	541
23.20.1	Text evaluation	541
23.21	TEXTFILL system variable	542
23.21.1	Text fill	542
23.22	TEXTQLTY system variable	542
23.22.1	Text quality (Mac & Linux)	542
23.23	TEXTSIZE system variable	543
23.23.1	Text size	543
23.24	TEXTSTYLE system variable	543
23.24.1	Text style	543
23.25	TEXTUREMAPPATH system variable	543
23.25.1	Texture map path	543
23.26	THICKNESS system variable	544
23.26.1	Thickness	544
23.27	THREADDISPLAY system variable	544
23.27.1	Thread representation	544
23.28	THUMBSIZE system variable	544
23.28.1	Thumbnail preview image size	544
23.29	TILEMODE system variable	545
23.29.1	Tile mode	545
23.30	TILEMODELIGHTSYNCH system variable	545
23.30.1	Tile mode light synch	545
23.31	TIMEZONE system variable	546
23.31.1	Timezone	546
23.32	TOOLBARMARGIN system variable	548
23.32.1	Toolbar margin	548
23.33	TOOLBUTTONSIZE system variable	548
23.33.1	Tool button size	548
23.34	TOOLICONPADDING system variable	549
23.34.1	Tool icon padding	549
23.35	TOOLPALETTEPATH system variable	549
23.35.1	Tool palettes path	549
23.36	TOOLTIPDELAY system variable	549
23.36.1	Tooltip delay	549
23.37	TOOLTIPS system variable	550
23.37.1	Tooltips	550
23.38	TPSTATE system variable	550
23.38.1	Tool Palettes bar state	550
23.39	TRACEWID system variable	550



Содержание

23.39.1	Trace width	550
23.40	TRACKPATH system variable	551
23.40.1	Track path	551
23.41	TRANSPARENCYDISPLAY system variable	551
23.41.1	Transparency display	551
23.42	TRAYICONS system variable	551
23.42.1	Tray icons	551
23.43	TRAYNOTIFY system variable	552
23.43.1	Tray notify	552
23.44	TRAYTIMEOUT system variable	552
23.44.1	Tray timeout	552
23.45	TREEDEPTH system variable	552
23.45.1	Tree depth	552
23.46	TREEMAX system variable	553
23.46.1	Tree maximum	553
23.47	TRIMMODE system variable	553
23.47.1	Trim mode	553
23.48	TRUSTEDPATHS system variable	554
23.48.1	Trusted executable file locations	554
23.49	TSPACEFAC system variable	554
23.49.1	Text space factor	554
23.50	TSPACETYPE system variable	555
23.50.1	Text space type	555
23.51	TSTACKALIGN system variable	555
23.51.1	Text stack align	555
23.52	TSTACKSIZE system variable	556
23.52.1	Text stack size	556
23.53	TTFASTTEXT system variable	556
23.53.1	TrueType Text displaying mode	556
24.	<u>U</u>	557
24.1	UCSAXISANG system variable	557
24.1.1	UCS axis angle	557
24.2	UCSBASE system variable	557
24.2.1	UCS base	557
24.3	UCSDETECT system variable	557
24.3.1	UCS detect	557
24.4	UCSFOLLOW system variable	558
24.4.1	UCS follow	558
24.5	UCSICON system variable	558
24.5.1	UCS icon	558
24.6	UCSICONPOS system variable	558
24.6.1	UCS icon position	558
24.7	UCSNAME system variable	559
24.7.1	UCS name	559
24.8	UCSORG system variable	559
24.8.1	UCS origin	559
24.9	UCSORTHO system variable	560
24.9.1	UCS orthographic	560



Содержание

24.10	UCSVIEW system variable	560
24.10.1	UCS view	560
24.11	UCSVP system variable	560
24.11.1	UCS viewports	560
24.12	UCSXDIR system variable	561
24.12.1	UCS X direction	561
24.13	UCSYDIR system variable	561
24.13.1	UCS Y direction	561
24.14	UNDOCTL system variable	561
24.14.1	Undo control	561
24.15	UNDOMARKS system variable	562
24.15.1	Undo marks	562
24.16	UNITESURFACES system variable	562
24.17	UNITMODE system variable	562
24.17.1	Unit mode	562
24.18	USECOMMUNICATOR system variable	563
24.18.1	Use Communicator	563
24.19	USENEWRIBBON system variable	563
24.19.1	Use the new Ribbon	563
24.20	USERI1 system variable	564
24.20.1	User integer 1	564
24.21	USERI2 system variable	564
24.21.1	User integer 2	564
24.22	USERI3 system variable	564
24.22.1	User integer 3	564
24.23	USERI4 system variable	565
24.23.1	User integer 4	565
24.24	USERI5 system variable	565
24.24.1	User integer 5	565
24.25	USERR1 system variable	565
24.25.1	User real 1	565
24.26	USERR2 system variable	565
24.26.1	User real 2	565
24.27	USERR3 system variable	566
24.27.1	User real 3	566
24.28	USERR4 system variable	566
24.28.1	User real 4	566
24.29	USERR5 system variable	566
24.29.1	User real 5	566
24.30	USERS1 system variable	567
24.30.1	User string 1	567
24.31	USERS2 system variable	567
24.31.1	User string 2	567
24.32	USERS3 system variable	567
24.32.1	User string 3	567
24.33	USERS4 system variable	567
24.33.1	User string 4	567
24.34	USERS5 system variable	567



Содержание

24.34.1	User string 5	567
24.35	USESTANDARDOPENFILEDIALOG system variable	568
24.35.1	Use standard open file dialog (Windows)	568
25.	V	569
25.1	VBAMACROS system variable	569
25.1.1	Enable macros	569
25.2	VENDORNAME system variable	569
25.2.1	Vendor name	569
25.3	VERBOSEBIMSECTIONUPDATE system variable	569
25.3.1	Additional diagnostics while section update	569
25.4	VERSIONCONTROLCONFIGPATH system variable	570
25.4.1	Version Control config path	570
25.5	VERSIONCONTROLDOWNLOADPATH system variable	570
25.5.1	Version Control download path	570
25.6	VERSIONCUSTOMIZABLEFILES system variable	570
25.6.1	Version customizable files	570
25.7	VIEWCTR system variable	570
25.7.1	View center	570
25.8	VIEWDIR system variable	571
25.8.1	View direction	571
25.9	VIEWMODE system variable	571
25.9.1	View mode	571
25.10	VIEWSIZE system variable	571
25.10.1	View size	571
25.11	VIEWTWIST system variable	572
25.11.1	View twist	572
25.12	VIEWUPDATEAUTO system variable	572
25.12.1	Automatically update drawing views	572
25.13	VISRETAIN system variable	572
25.13.1	Visibility retain	572
25.14	VOLUMEPREC system variable	573
25.14.1	Volume precision	573
25.15	VOLUMEUNITS system variable	574
25.15.1	Volume units	574
25.16	VPMAXIMIZEDSTATE system variable	574
25.16.1	Viewport maximized	574
25.17	VPROTATEASSOC system variable	575
25.17.1	Rotate view	575
25.18	VSMAX system variable	575
25.18.1	Virtual screen maximum	575
25.19	VSMIN system variable	575
25.19.1	Virtual screen minimum	575
25.20	VTDURATION system variable	576
25.20.1	View transition duration	576
25.21	VTENABLE system variable	576
25.21.1	Enable view transitions	576
25.22	VTFPS system variable	576
25.22.1	View transition minimum FPS	576



Содержание

26.	W	578
26.1	WARNINGMESSAGES system variable	578
26.1.1	Warning messages	578
26.2	WHIPARC system variable	578
26.2.1	Whip arcs	578
26.3	WHIPTHREAD system variable	579
26.3.1	Whip thread	579
26.4	WINDOWAREACOLOR system variable	579
26.4.1	Window area color	579
26.5	WIPEOUTFRAME system variable	580
26.5.1	Wipeout frame	580
26.6	WMFBKGND system variable	580
26.6.1	Windows Meta File background	580
26.7	WMFFOREGND system variable	580
26.7.1	Windows Meta File foreground	580
26.8	WNDLMAIN system variable	581
26.8.1	Main window state	581
26.9	WNDLSCRL system variable	581
26.9.1	Window scrollbars (Windows)	581
26.10	WNDLTEXT system variable	582
26.10.1	Text window state	582
26.11	WNDPMAIN system variable	582
26.11.1	Main window top left	582
26.12	WNDPTEXT system variable	582
26.12.1	Text window top left	582
26.13	WNDSMAIN system variable	582
26.13.1	Main window size	582
26.14	WNDSTEXT system variable	583
26.14.1	Text window size	583
26.15	WORLDUCS system variable	583
26.15.1	World UCS	583
26.16	WORLDVIEW system variable	583
26.16.1	World view	583
26.17	WRITESTAT system variable	584
26.17.1	Write status	584
26.18	WSAUTOSAVE system variable	584
26.18.1	Workspace autosave	584
26.19	WSCURRENT system variable	584
26.19.1	Current workspace	584
27.	X	586
27.1	XCLIPFRAME system variable	586
27.1.1	Xref clipping frame	586
27.2	XDWGFADECTL system variable	586
27.2.1	Xref database fade control	586
27.3	XEDIT system variable	586
27.3.1	Xref editable	586
27.4	XFADECTL system variable	587
27.4.1	Reference editing fade control	587



Содержание

27.5	XLOADCTL system variable	587
27.5.1	Xref load control	587
27.6	XLOADPATH system variable	588
27.6.1	Xref load path	588
27.7	XNOTIFYTIME system variable	588
27.7.1	Xnotify time	588
27.8	XREFCTL system variable	588
27.8.1	Xref control	588
27.9	XREFNOTIFY system variable	588
27.9.1	Xref notify	588
27.10	XREFOVERRIDE system variable	589
27.10.1	Xref override	589
28.	Y	590
29.	Z	591
29.1	ZOOMFACTOR system variable	591
29.1.1	Zoom factor	591
29.2	ZOOMWHEEL system variable	591
29.2.1	Mouse wheel zoom direction	591



1. System variable reference

The System variable reference gives an overview of all the system variables in BricsCAD®.

System variables and preferences variables are used to save BricsCAD® settings and user preferences. They can be accessed through the Settings dialog box. Many system variables correspond to other CAD software. When a variable is BricsCAD® specific, this is indicated as well.

Note: The AUTOCOMPLETEMODE system variable value defines whether system and/or preference variables are recognized when typing in the Command line.

1.1 System variable data types

- **Boolean:** the value is either 1 or 0 (True or False, Yes or No).
- **Short:** integer value in the range of -32,768 to +32,767.
- **Long:** integer value in the range of -2,147,483,648 to +2,147,483,647.
- **Real:** floating point numbers with a period for a decimal point and no thousands separator.
- **String:** text.
- **String Standard:** text according to a specific format, for example a folder path.
- **3D point:** specifies a point in a 3D space.
- **2D point:** specifies a point in the XY-plane.
- **Bit flag variables:** integer variable controlled by bit codes. The value of this variable changes by adding or removing options.

Entity snap mode		0x0007 (7)
1		<input checked="" type="checkbox"/> Endpoint
2		<input checked="" type="checkbox"/> Midpoint
4		<input checked="" type="checkbox"/> Center
8		<input type="checkbox"/> Node
16		<input type="checkbox"/> Quadrant
32		<input type="checkbox"/> Intersection
64		<input type="checkbox"/> Insertion
128		<input type="checkbox"/> Perpendicular
256		<input type="checkbox"/> Tangent
512		<input type="checkbox"/> Nearest
1024		<input type="checkbox"/> Geometric center
2048		<input type="checkbox"/> Apparent intersection
4096		<input type="checkbox"/> Extension
8192		<input type="checkbox"/> Parallel
16384		<input type="checkbox"/> Turn off all snaps

1.2 System variables save location

- Windows **registry** (or **config** file for macOS and LINUX): the value is saved in a user profile. When you start BricsCAD®, the values of the current user profile are loaded. The values apply to all drawings in the current BricsCAD® session. The current user profile is set in the User Profile Manager dialog box. Launch the PROFILEMANAGER command to open this dialog box.
- **Drawing:** the value is saved in the drawing and applies to that drawing only.
- **Preference:** the value is saved in a user profile. When you start BricsCAD the values of the current user profile are loaded. The values apply to all drawings in the current BricsCAD session.



- **NOT saved:** the default value is hard-coded, and the new value is not saved when BricsCAD® is restarted.
- **Workspace:** the value is saved in the current workspace.

Note: The distinction between system and preference variable is strictly about whether the setting is marked as a system variable (save="reg") or user preference (save="prf") in settings.xml.

1.3 Editing system variables

The system variables have a default value which can be edited:

- Through the Settings dialog box.
- By typing it in the Command line.

In the Settings dialog box, you can also filter variables that are no longer set to their default value.

1.4 Searching for variables

You can use the SETVAR command to search for a variable.



2. —

2.1 _QUADTABFLAGS system variable

2.1.1 Quad tab flags

Temporary setting used while new quad tab layout is being implemented. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 31
Default value:	12
Possible options:	<ul style="list-style-type: none">1: Fixed width tabs2: Center tab labels4: Tab borders8: Double tab height16: Show 3D Solid mass properties

2.2 _VERNUM system variable

2.2.1 Version number

Shows the program version number.

Read-only

Type:	String
Saved in:	Not saved



3. 3

3.1 3DCOMPAREMODE system variable

3.1.1 Compare visualization mode

The value of the 3DCOMPAREMODE system variable controls the display in the viewports of the Comparison layout.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	3
Possible values:	0: First model on the left, second model on the right. 1: First model with differences on the left, second model on the right. 2: First model on the left, second model with differences on the right. 3: First model with differences on the left, second model with differences on the right. 4: Both models with all differences in one viewport. 5: Both models with all differences in one viewport. 6: Both models with all differences in one viewport. 7: Both models with all differences in one viewport.

3.2 3DOSMODE system variable

3.2.1 3D entity snap mode

The current 3D entity snap modes are saved through the 3DOSMODE system variable as the sum of the bitcodes of the selected snap modes.

Type:	Long
Saved in:	Registry
Range:	0 to 33023
Default value:	11



Possible values:	1: Turn off all 3D snaps 2: 3D Entity Vertices and Control Vertices of Splines 4: Midpoint of edge 8: Center of face 16: Spline Knot 32: Perpendicular to face 64: Nearest to face 128: Pointcloud nearest Point 32768: Intersection with face
------------------	--

3.3 3DSNAPMARKERCOLOR system variable

3.3.1 3d snap marker color

Specifies the color of the 3d snap marker. Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	5



4. A

4.1 ACADLSPASDOC system variable

4.1.1 on_start.lsp for each doc

Specifies whether on_start_default.lsp and on_start.lsp are loaded into every drawing as are on_doc_load.lsp and on_doc_load_default.lsp, or just when the first drawing opens in a session.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Do not load on_start.lsp with every drawing On (1): Load on_start.lsp with every drawing

4.2 ACADPREFIX system variable

4.2.1 Program folder path

List of support paths, with path separators appended if necessary.

Read-only

Type:	String
Saved in:	Not saved

4.3 ACADVER system variable

4.3.1 AutoCAD version

Shows the AutoCAD compatible program version number.

Read-only

Type:	String
Saved in:	Not saved



4.4 ACISHLRRESOLUTION system variable

4.4.1 Hidden line removal resolution

Specifies the smallest distance taken into consideration during Hidden Line Removal calculation. A negative value means that auto-calibration based on the size of the model will be used. This is highly recommended. When dealing with entities that have very small sizes the value can be set to 0.001 or smaller.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	-1.0

4.5 ACISOUTVER system variable

4.5.1 Acisout version

Specifies the ACIS version of the SAT files created by ACISOUT.

Type:	Short
Saved in:	Not saved
Default value:	70

4.6 ADAPTIVEGRIDSTEPSENSE system variable

4.6.1 Adaptive grid step size

Specifies the snap spacing (in pixels) for 'Adaptive Grid Snap' mode of SNAPTYPE system variable. Values between 2 and 100 are accepted. The step size of the Ruler in Manipulator depends on this variable.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	4.0



4.7 AFLAGS system variable

4.7.1 Attribute options

Specifies the default options for attribute creation. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Not saved
Default value:	0
Possible options:	0: No mode selected 1: Invisible 2: Constant 4: Verify 8: Preset 16: Lock position 32: Multiline

4.8 ALLOWBREAKLINECROSSINGS system variable

4.8.1 Allow breakline crossings

If breakline crossings are allowed, intersections between breakline segments are calculated and added as points to the TIN surface.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1

4.9 ALLOWEDBENDANGLES system variable

4.9.1 Allowed bend angles

Defines allowed bend angles for connections that are created by the BIMFLOWCONNECT command.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Registry
Default value:	1
Possible values:	1: Any 2: 90 4: 60 8: 45 16: 30

4.10 ALLOWTABEXTERNALMOVE system variable

4.10.1 Move tabs externally (Mac & Linux)

Allows a tab to be moved to another tab control On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't allow a tab to be moved externally On (1): Allow a tab to be moved externally

4.11 ALLOWTABMOVE system variable

4.11.1 Move tabs (Mac & Linux)

Allows a tab to be moved horizontally by dragging On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't allow tabs to be moved On (1): Allow tabs to be moved



4.12 ALLOWTABSPLIT system variable

4.12.1 Split tabs (Mac & Linux)

Allows the tab control to be split by dragging a tab On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't allow tabs to be split On (1): Allow tabs to be split

4.13 ANGBASE system variable

4.13.1 Angle base

Specifies the direction of angle 0, relative to the current UCS.

Type:	Real
Saved in:	Drawing
Default value:	0.0

4.14 ANGDIR system variable

4.14.1 Angle direction

Specifies the positive angle direction from angle 0, relative to the current UCS.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Counter-clockwise On (1): Clockwise



4.15 ANGLESAMPLINGINTERVAL system variable

4.15.1 Angle sampling interval

Defines angle sampling interval in decimal degrees, which is used for grading rounding at convex vertices.
BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 90
Default value:	5

4.16 ANNOALLVISIBLE system variable

4.16.1 Annotation visibility

Hides or displays annotative entities that do not support the current annotation scale. The setting is saved individually for model space and each layout.

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	0: Only annotative entities that support the current scale representation are displayed 1: All annotative entities are displayed

4.17 Системная переменная ANNOAUTOSCALE

4.17.1 Масштабирование аннотаций

Обеспечивает синхронизацию аннотативных объектов с текущим масштабом аннотаций.

Type:	Short
Saved in:	Registry
Default value:	-4



Possible values:	0: Вновь установленный масштаб аннотаций не назначается аннотативным объектам. 1: Вновь установленный масштаб аннотаций назначается аннотативным объектам, поддерживающим его, за исключением объектов на заблокированных, выключенных, замороженных слоях и слоях замороженных для данного ВО. 2: Вновь установленный масштаб аннотаций назначается аннотативным объектам, поддерживающим его, за исключением объектов на выключенных, замороженных слоях и слоях замороженных для данного ВО. 3: Вновь установленный масштаб аннотаций назначается аннотативным объектам, поддерживающим его, за исключением объектов на заблокированных слоях. 4: Вновь установленный масштаб аннотаций назначается всем аннотативным объектам, поддерживающим его. -1: Вновь установленный масштаб аннотаций не назначается аннотативным объектам (переключено значение 1). -2: Вновь установленный масштаб аннотаций не назначается аннотативным объектам (переключено значение 2). -3: Вновь установленный масштаб аннотаций не назначается аннотативным объектам (переключено значение 3). -4: Вновь установленный масштаб аннотаций не назначается аннотативным объектам (переключено значение 4).
------------------	--

4.18 ANNOTATEDWG system variable

4.18.1 Annotative drawing

Specifies whether or not the drawing will behave as an annotative block when inserted into another drawing. The ANNOTATEDWG system variable becomes Read-only if the drawing contains annotative entities.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Not annotative On (1): Annotative



4.19 ANTIALIASRENDER system variable

4.19.1 Anti-alias amount for render

Specifies the smoothness of the output from RENDER command. For values higher than 1, an anti-aliased output is calculated. High anti-alias values incur a high calculation cost.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 5
Default value:	2
Possible values:	1: 1x1 (no anti-aliasing) 2: 2x2 3: 3x3 4: 4x4 5: 5x5 (maximum anti-aliasing)

4.20 ANTIALIASSCREEN system variable

4.20.1 Anti-alias amount for screen

Specifies the smoothness of on-screen curve display. For values higher than 1 and visual style 2DWireframe (which uses GDI), calculation of an anti-aliased display comes at a high performance cost (roughly a factor 7). For the other display modes the calculation time increases with less than 50%.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 5
Default value:	1
Possible values:	1: 1x1 (no anti-aliasing) 2: 2x2 3: 3x3 4: 4x4 5: 5x5 (maximum anti-aliasing)



4.21 APBOX system variable

4.21.1 Entity snap aperture box

Toggles the display of the Entity Snap aperture box. If the APBOX system variable is on, the entity Snap Aperture Box is added to the crosshairs when one or more entity snaps are active.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Does not display the aperture box. On (1): Displays the aperture box.


4.22 APERTURE system variable

4.22.1 Entity snap aperture

Specifies the size (in pixels) of the entity snap aperture box. Values between 1 and 50 are accepted.

The program searches the area inside the rectangular aperture cursor for geometric features, such as endpoints and mid points. A large aperture cursor makes it easier for you to hover over geometric features, but then the program may find too many matching entity snap points; a smaller one may be more difficult for you to position over geometry, but is more precise at snapping to geometric features.

Type:	Short
Saved in:	Registry
Default value:	10





4.23 ARCTESSELLATION system variable

4.23.1 Arc approximation mid-ordinate distance

Mid-ordinate distance is the maximal distance between arc and chord (straight) segment which is used for arc approximation.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.01

4.24 ARCTESSELLATIONGRADING system variable

4.24.1 Arc approximation mid-ordinate distance

Mid-ordinate distance is the maximal distance between arc and chord (straight) segment which is used for arc approximation.


BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.01

4.25 ARCTESSELLATIONTEMPLATEELEMENT system variable

4.25.1 Template Element arc approximation mid-ordinate distance

Mid-ordinate distance (1) is the maximal distance between arc and chord (straight) segment which is used for arc approximation.



BricsCAD only

Type:	Real
Saved in:	Drawing



Default value:	0.01
----------------	------

4.26 AREA system variable

4.26.1 Calculated area

Specifies the last calculated area by AREA, LIST or DBLIST.

Read-only

Type:	Real
Saved in:	Not saved

4.27 AREAPREC system variable

4.27.1 Area precision

Specifies the number of decimal places displayed for areas when the area bit of PROPUNITS is on. If negative, LUPREC is used.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	-1
Possible values:	<ul style="list-style-type: none">-1: Use LUPREC01: 0.02: 0.003: 0.0004: 0.00005: 0.000006: 0.0000007: 0.00000008: 0.00000000



4.28 AREAUNITS system variable

4.28.1 Area units

Specifies a list of units used for displaying areas when the area bit of PROPUNITS is on. If empty, all areas are displayed in the current drawing unit, as defined by INSUNITS. If multiple units are selected, the unit that fits best is used.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	in ft mi µm mm cm m km

4.29 ARRAYASSOCIATIVITY system variable

4.29.1 Associative arrays

Specifies whether newly created arrays are associative or non-associative.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Not associative On (1): Associative

4.30 ARRAYEDITSTATE system variable

4.30.1 Array editing state

Array editing state is activated while editing an associative array's source entities.

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	Off



4.31 ARRAYTYPE system variable

4.31.1 Array type

Specifies the default associative array type.

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Rectangular array 1: Path array 2: Polar array

4.32 CIVILASSOCIATIVITY system variable

4.32.1 Associativity

Defines if TIN Surface or Grading are associative.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	15
Possible options:	1: TIN Surface associativity 2: Grading associativity 4: TIN Volume Surface associativity 8: Corridor associativity

4.33 ATTDIA system variable

4.33.1 Attribute dialog

Specifies whether or not the INSERT command uses a dialog box for entering attribute values.

Type:	Boolean
Saved in:	Registry



Default value:	Off
Possible values:	Off (0): Don't use dialog box On (1): Use dialog box

4.34 ATTMODE system variable

4.34.1 Attribute display mode

Specifies whether attributes are visible or not. If the ATTMODE variable is set to 2, all attributes display, including Hidden attributes.

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	0: Don't show 1: As defined in block 2: Show all

4.35 ATTRACTONDISTANCE system variable

4.35.1 Grips attraction distance

Specifies the grips attraction distance. If the cursor is within this distance the cursor is attracted by the grip and jumps to it.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	4

4.36 ATTREQ system variable

4.36.1 Insertion default settings

Specifies whether default attribute settings are used by the INSERT command during block insertion.

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	1
Possible values:	Off (0): Use default values On (1): Prompt user

4.37 AUDITCTL system variable

4.37.1 Audit control

Toggles the creation of audit report (ADT) files by the AUDIT command. When you turn on the AUDITCTL settings variable, Audit creates an ASCII file describing problems and the action taken. This report, with the file extension .adt, is placed in the same directory as the current drawing.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't write ADT files On (1): Write ADT files

4.38 AUDITERRORCOUNT system variable

4.38.1 Audit Error Count

The number of errors found in the last audit.

Read-only

Type:	Short
Saved in:	Not saved

4.39 AUNITS system variable

4.39.1 Angular unit type

Specifies the angular unit type.

Type:	Short
-------	-------



Saved in:	Drawing
Default value:	0
Possible values:	0: Decimal degrees 1: Degrees/minutes/seconds 2: Gradians 3: Radians 4: Surveyor's units

4.40 AUPREC system variable

4.40.1 Angular unit precision

Specifies the number of decimal places for angular units.

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: 0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000 8: 0.00000000

4.41 AUTOCOMPLETEDELAY system variable

4.41.1 Auto complete delay

Specifies the amount of time that elapses before automated keyboard features display at the Command prompt.

Type:	Real
Saved in:	Registry



Default value:	0.3
----------------	-----

4.42 AUTOCOMPLETEMODE system variable

4.42.1 Auto complete mode

Specifies what types of automated keyboard features are available at the Command prompt. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 63
Default value:	47
Possible options:	1: Enable 2: Auto-Append 4: Suggestion List 8: Display Icons (unsupported) 16: Exclude the display of system variables 32: Display preference variables

4.43 AUTOMATICCONNECTION system variable

4.43.1 Automatic connection

Controls automatic creation of the connections in the BIMLINEARSOLID and BIMAPPLYPROFILE commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): Disable On (1): Enable

4.44 AUTOMATICSTAIRSECTIONBEHAVIOR system variable



4.44.1 Automatic stair section behavior

If set to Symbolic, a symbolic representation of entities classified as Stairs will be generated during section generation. This will affect only the automatic stair sectioning behavior. To customize, launch the BIMGENERATE2DSTAIR command before sectioning.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Symbolic 1: Geometric

4.45 AUTOMATICTEES system variable

4.45.1 Automatic tees

Controls automatic creation of the tee flow fitting in case of T type connection in the BIMFLOWCONNECT command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Disable On (1): Enable

4.46 AUTOMENULOAD system variable

4.46.1 Auto menu load

When you open a drawing, determines whether the default menu or a menu file associated with a drawing is loaded.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	On
Possible values:	Off (0): Not automatic menu loading On (1): Automatic menu loading

4.47 AUTORESETSCALES system variable

4.47.1 Purge unused scales

Unneeded annotation scales are deleted automatically when drawing contains a large number of annotation scales. Storing a large number of annotation scales decreases performance. Scales are purged when drawing is being loaded.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Ask in dialog box 1: Always purge unneeded scales 2: Don't purge scales and don't show dialog box when drawing contains a large number of scales

4.48 AUTOSAVECHECKSONLYFIRSTBITDBMOD system variable

4.48.1 Ignore all but first bit of DBMOD for autosave

The first bit(1) of DBMOD means that the object database is modified. If this user preference is switched on, no autosave file will be created for files that are viewed only (DBMOD changes as soon as you pan and zoom).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



Possible values:	Off (0): Autosave file for files that are viewed only On (1): No autosave file for files that are viewed only
------------------	--

4.49 AUTOSNAP system variable

4.49.1 AutoSnap

Toggles polar and entity snap tracking and controls the display of snap marker, tooltips and magnet. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 127
Default value:	127
Possible options:	0: All off 1: AutoSnap marker 2: AutoSnap tooltips 4: AutoSnap magnet 8: Polar tracking 16: Entity snap tracking 32: Tooltips for polar tracking and entity snap tracking 64: Tracking line from LASTPOINT

4.50 AUTOTRACKINGVECCOLOR system variable

4.50.1 Auto tracking vector color

Specifies the color of the polar/snap tracking vector.

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	171



4.51 AUTOVPFITTING system variable

4.51.1 Automatically fit viewport borders

Specifies if viewport borders automatically fit when updating the viewport.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't fit viewports' borders automatically On (1): Fit viewports' borders automatically



5. B

5.1 BACKGROUNDPLOT system variable

5.1.1 Background plotting

Specifies whether background plotting is enabled for plotting and/or publishing. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	2
Possible options:	0: None 1: When plotting (Not supported) 2: When publishing

5.2 BACKZ system variable

5.2.1 Back clipping plane offset

Specifies the current viewport's back clipping plane offset from the target plane, expressed in drawing units. Clipping planes are used in the CLIPPING option of the DVIEW command.

Type:	Real
Saved in:	Drawing
Default value:	0.0

5.3 BASEFILE system variable

5.3.1 Template

Specifies the path and name of the default template file to use when creating a new drawing. If empty, built-in defaults will be used.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
-----------	----------

5.4 BCFSOURCEURL system variable

5.4.1 BCF source url

Specifies the web address of the last used external BIM collaboration service, launched from the BIM BCF panel.

BricsCAD only

Type:	String
Saved in:	Registry

5.5 BILLOFMATERIALSSETTINGS system variable

5.5.1 Bill of materials defaults

Sets default options for bill of materials.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	10
Possible values:	1: Add thumbnails to new bill of materials 2: Automatically update thumbnails 4: Display warning messages 8: Allow multiple inserts of the same table

5.6 BIMACTIVATEPYTHON system variable

5.6.1 Activate Python

Enables embedded Python for BriqPy.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Don't enable embedded Python On (1): Enable embedded Python

5.7 BIMDEFAULTPROPERTIESPATH system variable

5.7.1 Default properties path

Paths to properties which are loaded in new document.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	bimproj_user.xml;bimproj_IFC2x3.xml;bimproj_IFC4.xml;bimproj_quantity.xml

5.8 BIMMATCHPROP system variable

5.8.1 Match BIM Properties

Enables matching BIM properties during the MATCHPROP command.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Match standard properties 1: Match standard and BIM properties

5.9 BIMOSMODE system variable

5.9.1 BIM snap mode

Overrules entity snap modes for BIM entities using bitcodes.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	0: Entity snap modes are not overruled for BIM entities 1: Axis of linear solid 2: Axis of BIM grid

5.10 BIMPROFILESTANDARDS system variable

5.10.1 Profile's standards

Specifies which profile standards will be used in the Profiles dialog box and panel. You can add multiple standards using the semicolon ; as a separator.

BricsCAD only

Type:	String
Saved in:	Registry

5.11 BINDTYPE system variable

5.11.1 Xref bind type

Specifies the handling of xref names when binding xrefs or when xrefs are edited in-place. If the BINDTYPE variable = 1 (Insert-like behavior), Xrefs will be converted into blocks. If BINDTYPE = 0 (traditional binding behavior), it binds the xref and makes the xref part of the drawing (the objects/layers from the external drawing will be added to the current drawing with the prefix equal to the file name).

Type:	Boolean
Saved in:	Not saved
Default value:	0
Possible values:	Off (0): Traditional binding behavior On (1): Insert-like behavior



5.12 BKGCOLOR system variable

5.12.1 Background color

Specifies the background color of the drawing window when working in model space.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	RGB:24,25,28

5.13 BKGCOLORPS system variable

5.13.1 Paper space background color

Set the background color of the drawing window when working in paper space.

BricsCAD only


Type:	String
Saved in:	Registry
Default value:	RGB:250,250,250

5.14 BLIPMODE system variable

5.14.1 Blip mode

Toggles the display of blips that are made as you pick points in the drawing.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't display marker blips On (1): Display marker blips



5.15 BLOCKEDITLOCK system variable

5.15.1 Block editor lock

Disables opening of the Block Editor and editing of dynamic block definitions.

Type:	Boolean
Saved in:	Registry
Default value:	Off

5.16 BLOCKEDITOR system variable

5.16.1 Block editor

Shows whether the Block Editor is open or not.

Read-only

Type:	Boolean
Saved in:	Not saved

5.17 BLOCKIFYMODE system variable

5.17.1 Blockify settings

Defines the behavior of the BLOCKIFY and PARAMETRICBLOCKIFY commands. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Registry
Range:	16 to 247
Default value:	48
Possible options:	<ul style="list-style-type: none">1: Use entire drawing as search space2: Use default block insertion point4: Use default block name32: Compare geometry only64: Convert unique solids to blocks128: Show preview

5.18 BLOCKIFYTOLERANCE system variable

5.18.1 Blockify tolerance

Specifies a relative tolerance used in the BLOCKIFY and PARAMETRICBLOCKIFY commands for determining whether two entities are equal. An example of a relative tolerance is the maximum ratio of the difference between two line lengths to the length of one line. A negative value means the algorithm will determine the optimal tolerance itself (0.000001 for 2D and 0.0003 for 3D entities). This option is highly recommended.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	-1.0

5.19 BLOCKLEVELOFDETAIL system variable

5.19.1 Block Level of detail

Controls the level of detail of blocks.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	1



Possible values:	0: Low 1: High
------------------	-------------------

Прим.: The low level of detail representation is a bounding box.

5.20 BLOCKSPATH system variable

5.20.1 Blocks path

Specifies an additional folder in the file dialog for the INSERT command.

BricsCAD only

Type:	String Standard
Saved in:	Preference

5.21 BMAUTOUPDATE system variable

5.21.1 Update external components

Specifies when external assembly components are reloaded to reflect the changes in their definition files.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	1
Possible values:	0: Only when BMUPDATE command is issued 1: Automatically on opening the file

5.22 BMFORMTEMPLATEPATH system variable

5.22.1 BMFORM template path

Specifies the path and name of the default BMFORM Template file.

BricsCAD only

Type:	String
Saved in:	Preference



5.23 BMUPDATEMODE system variable

5.23.1 Assembly components updating mode

Specifies if external assembly components are reloaded only in case they are modified (faster) or unconditionally (slower, but repairs assembly structure).

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Update only modified components 1: Update all components

5.24 BOMFILTERSETTINGS system variable

5.24.1 Default BOM filter settings

Sets default filter settings to define which objects to include.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 127
Default value:	1
Possible values:	1: Include mechanical components, blocks and solids 2: Include non-mechanical local blocks and solids 4: Include non-mechanical external references 8: Include solid plies 16: Ignore BOM status 32: Treat external references as transparent 64: Treat leaf parts as transparent

Прим.: If the file does not contain any mechanical components and the mode does not require to include any non-mechanical entities, then it will be extended to include all non-mechanical entities.



5.25 BOMPROPERTYSET system variable

5.25.1 Default BOM property set

Sets default set of properties for BOM tables.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	1: Mechanical-only properties 2: All properties except coordinates 3: All properties

Прим.: If the BOM filter mode requires to include non-mechanical objects (BOMFILTERSETTINGS = 2 / 4 / 6), then the property set will be automatically extended to include all properties except coordinates (BOMPROPERTYSET=2).

5.26 BOMTEMPLATE system variable

5.26.1 Default template

Defines a path to the file with the default BOM template.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	" "

5.27 BOMTHUMBNAILHEIGHT system variable

5.27.1 Default thumbnail height, px

Sets default thumbnail height for BOM tables, in pixels

BricsCAD only

Type:	Short
-------	-------



Saved in:	Registry
Default value:	200

5.28 BOMTHUMBNAILWIDTH system variable

5.28.1 Default thumbnail width, px

Sets default thumbnail width for BOM tables, in pixels

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	200

5.29 BOUNDARYCOLOR system variable

5.29.1 Detected Boundary Color

Specifies which color to be used for highlighting detected boundaries.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	95

5.30 BSYSLIBCOPYOVERWRITE system variable

5.30.1 Bsystlib copy overwrite

What to do when copying a material or composition with a name that already exists in the target database.

BricsCAD only

Type:	Short
Saved in:	Preference



Range:	0 to 3
Default value:	0
Possible values:	0: Prompt 1: Skip 2: Overwrite 3: Rename

5.31 BVMODE system variable

5.31.1 Block Visibility Mode

Specifies how hidden entities of the current visibility state are displayed in the Block Editor.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Hidden entities are invisible 1: Hidden entities are visible but dimmed



6. C

6.1 CACHELAYOUT system variable

6.1.1 Cache layout

Specifies whether layouts are cached, resulting in faster switching from one layout to another.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't cache layout On (1): Cache layout

6.2 CAMERADISPLAY system variable

6.2.1 Camera display

Specifies the display of camera glyphs.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display camera glyphs On (1): Display camera glyphs

6.3 CAMERAHEIGHT system variable

6.3.1 Camera height

Specifies the default height, in drawing units, for new camera entities.

Type:	Real
Saved in:	Drawing
Default value:	0.0



6.4 CANNOSCALE system variable

6.4.1 Annotation scale name

Specifies the name of the current annotation scale for the current space.

Type:	String
Saved in:	Drawing
Default value:	1:1

6.5 CANNOSCALEVALUE system variable

6.5.1 Annotation scale value

Displays the value of the current annotation scale.

Read-only

Type:	Real
Saved in:	Drawing
Default value:	1.0

6.6 CDATE system variable

6.6.1 Calendar date

Shows the current date and time in decimal format.

Read-only

Type:	Real
Saved in:	Not saved

6.7 CECOLOR system variable

6.7.1 Entity color

Specifies the color for new entities.

Type:	String
-------	--------



Saved in:	Drawing
Default value:	ByLayer

6.8 CELTSCALE system variable

6.8.1 Entity linetype scale

Specifies the current entity linetype scaling factor.

Type:	Real
Saved in:	Drawing
Range:	Greater than 0
Default value:	1.0

6.9 CELTYPE system variable

6.9.1 Entity linetype

Specifies the linetype for new entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer

6.10 CELWEIGHT system variable

6.10.1 Entity linewidth

Specifies the linewidth of new entities (in hundredths of millimeters).

Type:	Short
Saved in:	Drawing
Range:	-3 to 211
Default value:	-1




Possible values:	-3: Default (defined by LWDEFAULT) -2: ByBlock -1: ByLayer 0 - 211: Lineweight value in hundredths of millimeters
------------------	--

6.11 CENTERCROSSGAP system variable

6.11.1 Center mark cross gap

Specifies the gap between the center mark and its centerlines.

Type:	String
Saved in:	Drawing
Default value:	0.05x




6.12 CENTERCROSSSIZE system variable

6.12.1 Center mark cross size

Specifies the size of the associative center mark.

Type:	String
Saved in:	Drawing
Default value:	0.1x




6.13 CENTEREXE system variable

6.13.1 Centerline extensions length

Specifies the length of the centerline extensions. The value is expressed in drawing units.

Type:	Real
Saved in:	Drawing
Default value:	0.12



6.14 CENTERLAYER system variable

6.14.1 Default layer for center mark or centerline

Specifies a default layer for new center mark or centerline.

Type:	String
-------	--------



Saved in:	Drawing
Default value:	.

6.15 CENTERLTSIZE system variable

6.15.1 Linetype scale for center mark or centerline

Specifies the linetype scale used by center marks and centerlines.

Type:	Real
Saved in:	Drawing
Default value:	1.0

6.16 CENTERLTYPE system variable

6.16.1 Linetype for center mark or centerline

Specifies the linetype used by center marks and centerlines.

Type:	String
Saved in:	Drawing
Default value:	CENTER2

6.17 CENTERLTYPEFILE system variable

6.17.1 Linetype file for center mark or centerline


Specifies the linetype file used to create center marks and centerlines. Default in imperial unit drawings: default.lin. Default in metric unit drawings: iso.lin.

Type:	String
Saved in:	Drawing

6.18 CENTERMARKEXE system variable

6.18.1 Automatic extension for center mark or centerline

Specifies whether centerlines extend automatically from new center marks.



Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): No automatic extension On (1): Automatic extension

6.19 CETRANSPARENCY system variable

6.19.1 Transparency for new entities

Specifies the transparency level for new entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer
Possible values:	ByLayer: Apply the layer's transparency ByBlock: Apply the block's transparency 0: Apply no transparency (fully opaque) 1-90: Apply transparency percentage from least (1) to most (90) transparent



6.20 CHAMFERA system variable

6.20.1 Chamfer first distance

Specifies the first chamfer distance when the chamfer input mode requires two distances (CHAMMODE is Distance-Distance).

Type:	Real
Saved in:	Drawing
Default value:	0.0

6.21 CHAMFERB system variable

6.21.1 Chamfer second distance

Specifies the second chamfer distance when the chamfer input mode requires two distances (CHAMMODE is Distance-Distance).

Type:	Real
Saved in:	Drawing
Default value:	0.0

6.22 CHAMFERC system variable

6.22.1 Chamfer length

Specifies the chamfer length when the chamfer input mode requires a length and an angle (CHAMMODE is Length-Angle).

Type:	Real
Saved in:	Drawing
Default value:	0.0

6.23 CHAMFERD system variable

6.23.1 Chamfer angle

Specifies the chamfer angle when the chamfer input mode requires a length and an angle (CHAMMODE is Length-Angle).




Type:	Real
Saved in:	Drawing
Default value:	0.0

6.24 CHAMMODE system variable

6.24.1 Chamfer mode

Specifies the input method by which chamfers are created: Distance-Distance or Length-Angle.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Distance-Distance 1: Length-Angle



6.25 CHECKDWLPRESENT system variable

6.25.1 Check Dwl file existence before open

When trying to open a drawing, warn the user about the presence of a dwl lock file. The content of the lock files allows to inform other users trying to open that drawing, that it is in use, since when, and by whom. This is typically useful for drawings on a shared folder that can be accessed by multiple users from different operating systems.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	Off (Windows) On (Mac & Linux)
Possible values:	Off (0): Don't check dwl file existence before opening a drawing On (1): Check dwl file existence before opening a drawing

6.26 CIRCLERAD system variable

6.26.1 Circle radius

Specifies the default circle radius. If set to zero, there is no default.

Type:	Real
Saved in:	Not saved
Default value:	0.0

6.27 CLAYER system variable

6.27.1 Current layer

Specifies the layer for new entities.

Type:	String
Saved in:	Drawing
Default value:	0

6.28 CLEANSCREENOPTIONS system variable

6.28.1 Clean screen options

Specifies which UI elements are hidden by the CLEANSCREENON command. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Registry



Range:	0 to 127
Default value:	15
Possible options:	1: Hide document tabs 2: Hide dockable panels 4: Hide toolbars 8: Hide ribbon 16: Hide Command line panel 32: Hide status bar 64: Hide menu bar

6.29 CLEANSCREENSTATE system variable

6.29.1 Clean screen state

Specifies whether clean screen state is active or not. Clean screen state is controlled by the CLEANSCREENON and CLEANSCREENOFF commands. Activating the clean screen state makes the drawing area larger by hiding elements of the user interface.

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	Off

6.30 CLIPBOARDFORMAT system variable

6.30.1 Clipboard DWG format

Specifies the drawing format version used for copying to the clipboard.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	4



Possible values:	1: DWG 2018 4: DWG 2013 7: DWG 2010 10: DWG 2007 13: DWG 2004 16: DWG 2000 19: DWG R14 22: DWG R13 25: DWG R11/R12
------------------	--

6.31 CLIPBOARDFORMATS system variable

6.31.1 Clipboard Formats

Types of data that are supported when copying to the clipboard. Flags can be unchecked to improve performance. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 127
Default value:	127
Possible options:	1: Bitmap 2: Metafile Picture Format 4: Enhanced Metafile 8: AutoCAD.r14 16: BricsCAD 32: OLE Embed Source and Object Descriptor 64: CVS and XMLSS table data

6.32 CLIPROMPTLINES system variable

6.32.1 Prompt Lines

If the Command panel is not visible, the last few Command line entries are shortly displayed at the bottom of the main graphics window each time a command is entered. CLIPROMPTLINES specifies the number of lines to display. (set to zero to disable the feature).

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 64
Default value:	4

6.33 CLISTATE system variable

6.33.1 Command line state

Specifies whether the Command line is visible or not.

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	1
Possible values:	Off (0): Command line is invisible On (1): Command line is visible

6.34 CLOSECHECKSONLYFIRSTBITDBMOD system variable

6.34.1 Ignore all but first bit of DBMOD for close

The first bit(1) of DBMOD means that the object database is modified. If this user preference is switched on, you can view a file, then close it without getting a request to save the file.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't close drawing without getting a request to save the file. On (1): Close drawing without getting a request to save the file.



6.35 CLOUDDOWNLOADPATH system variable

6.35.1 Cloud download path

Specifies the folder where files downloaded through the Bricsys 24/7 Panel are saved.

BricsCAD only

Type:	String Standard
Saved in:	Registry
Default value:	{User}Documents/Bricsys247

6.36 CLOUDLOG system variable

6.36.1 Cloud log

Specifies whether Bricsys 24/7 transactions are being logged or not. If set to 2 ("Log file") the log file will be written in the folder specified by the LOGFILEPATH variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: No log 1: Log messages 2: Log file

6.37 CLOUDLOGVERBOSE system variable

6.37.1 Cloud log verbose

If switched on, more information is being logged but therefore Bricsys 24/7 actions will be slower.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	Off
Possible values:	Off (0): Verbose log off On (1): Verbose log on

6.38 CLOUDONMODIFIED system variable

6.38.1 Cloud on modified

Specifies what to do when a file opened from Bricsys 24/7, is modified and saved locally.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	1
Possible values:	0: Do nothing 1: Prompt 2: Always upload to new revision 3: Always save locally under new name

6.39 CLOUDSERVER system variable

6.39.1 Cloud server

Specifies the address of the Bricsys 24/7 server. Examples: <https://my.bricsys247.com/>, <https://apac.bricsys247.com/>

BricsCAD only

Type:	String
Saved in:	Registry

6.40 CLOUDTEMPFOLDER system variable

6.40.1 Cloud temporary folder

Specifies the folder where temporary files from Bricsys 24/7 are downloaded.

BricsCAD only



Type:	String
Saved in:	Preference
Default value:	{User}AppData/Local/Temp/Bricsys_24_7

6.41 CLOUDUPLOADDEPENDENCIES system variable

6.41.1 Cloud upload dependencies

Specifies what to do with dependencies (such as external references or images) when a drawing is uploaded to Bricsys 24/7.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Upload drawing only (ignore dependencies) 1: Use eTransmit dialog if the drawing contains external references 2: Always use eTransmit dialog

6.42 CMATERIAL system variable

6.42.1 Current material

Specifies the render material for new entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer



6.43 CMDACTIVE system variable

6.43.1 Active command

Stores the type of the current command: ordinary command, transparent command, script, dialog box, DDE, lisp or ObjectARX command. The value is stored as a bitcode using the sum of the values of all selected options.

Read-only

Type:	Short
Saved in:	Not saved
Default value:	1
Possible options:	1: Ordinary command is active 2: Ordinary command and a transparent command are active 4: Script is active 8: Dialog box is active 16: DDE is active 32: lisp is active (only visible to an ObjectARX-defined command) 64: ObjectARX command is active

6.44 CMDDIA system variable

6.44.1 Command dialogs

Specifies whether dialog boxes are turned on for commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't use dialog box for commands On (1): Use dialog box for commands

6.45 CMDECHO system variable

6.45.1 Command echo

Toggles the display of prompts and input during the lisp 'command' function.



Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Echoing off On (1): Echoing on

6.46 CMDLINEEDITBGCOLOR system variable

6.46.1 Command line edit background color

Specifies the background color of the Command line's edit field. Color may be represented as a name (for standard colors) or as RGB values. At the Command line, color may be entered as a name (for standard colors), RGB values, or HTML color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	50 54 56 (Settings dialog) #323638 (Command line)

6.47 CMDLINEEDITFGCOLOR system variable

6.47.1 Command line edit foreground color

Specifies the foreground color (RGB) of the Command line's edit field. Color may be represented as a name (for standard colors) or as RGB values. At the Command line, color may be entered as a name (for standard colors), RGB values, or HTML color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White (Settings dialog) #FFFFFF (Command line)



6.48 CMDLINEFADINGLOGBCOLOR system variable

6.48.1 Command line fading log background color

Specifies the background color (RGB) of the Command line's fading log. Color may be represented as a name (for standard colors) or as RGB values. At the Command line, color may be entered as a name (for standard colors), RGB values, or HTML color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	50 54 56 (Settings dialog) #323638 (Command line)

6.49 CMDLINEFADINGLOGFADEDELAY system variable

6.49.1 Command line fading log fade delay

Specifies the amount of time (in seconds) that elapses before Command line's fading log starts to fade.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 10.0
Default value:	2.0

6.50 CMDLINEFADINGLOGFGCOLOR system variable

6.50.1 Command line fading log foreground color

Specifies the foreground color of the Command line's fading log.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White



6.51 CMDLINEFADINGLOGTRANSPARENCY system variable

6.51.1 Command line fading log transparency

Specifies the transparency of the Command line's fading log. A value of 0 sets the log to be fully opaque, and a value of 100 sets the log to be fully transparent.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	30

6.52 CMDLINEFONTNAME system variable

6.52.1 Command line font name

Specifies the font to use in the Command line.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	Consolas
Possible values:	

6.53 CMDLINEFONTSIZE system variable

6.53.1 Command line font size

Specifies a font size for the Command line.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	10



6.54 CMDLINEFRAMEACTIVETRANSPARENCY system variable

6.54.1 Command line frame transparency when active (Windows)

Specifies the transparency of the Command line frame when active. A value of 0 sets the frame to be fully opaque, and a value of 100 sets the frame to be fully transparent.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	10

6.55 CMDLINEFRAMEINACTIVETRANSPARENCY system variable

6.55.1 Command line frame transparency when inactive (Windows)

Specifies the transparency of the Command line frame when inactive. A value of 0 sets the frame to be fully opaque, and a value of 100 sets the frame to be fully transparent.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	30

6.56 CMDLINEFRAMEUSETEXTSCR system variable

6.56.1 Command line frame TEXTSCR

When the Command line is displayed as a mini-frame, it controls the effect of TEXTSCR command. If enabled, a separate window is displayed (same as in the docked state). If not enabled, a slide-out window is integrated with the mini-frame. Additionally, the setting has impact on how long prompts are displayed (e.g. for the LIST command).

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't display (TEXTSCR) history window in a separate floating frame On (1): Display (TEXTSCR) history window in a separate floating frame

6.57 CMDLINELISTBGCOLOR system variable

6.57.1 Command line list background color

Specifies the background color of the Command line's history list.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:130,130,130

6.58 CMDLINELISTFGCOLOR system variable

6.58.1 Command line list foreground color

Specifies the foreground color of the Command line's history list.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White

6.59 CMDLINEOPTIONBGCOLOR system variable

6.59.1 Command line option background color

Specifies the background color of the Command line's options.

BricsCAD only

Type:	String
-------	--------



Saved in:	Preference
Default value:	RGB:121,132,142

6.60 CMDLINEOPTIONSHORTCUTCOLOR system variable

6.60.1 Command line option shortcut color

Specifies the color of the Command line's option shortcut.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:255,187,0

6.61 CMDLINEUSEMINIFRAME system variable

6.61.1 Command line mini floating frame

Controls whether the new mini-frame is used when the Command line is floating.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't use new mini-frame On (1): Use new mini-frame

Note: The CMDLINEUSEMINIFRAME system variable replaces the CMDLINEUSENEWFRAME system variable.

6.62 CMDLNTEXT system variable

6.62.1 Prompt prefix

Specifies the prompt prefix shown in the Command line.

BricsCAD only



Type:	String
Saved in:	Registry
Default value:	:

6.63 CMDNAMES system variable

6.63.1 Active Command Name

Shows the names of the active and transparent commands.

Read-only

Type:	String
Saved in:	Not saved

6.64 CMLEADERSTYLE system variable

6.64.1 Multileader style

Specifies the multileader style for new multileader entities.

Type:	String
Saved in:	Drawing
Default value:	Standard

6.65 CMLJUST system variable

6.65.1 Multiline justification

Specifies the justification when creating multilines relative to the point you pick.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0



Possible values:	0: Top 1: Zero 2: Bottom
------------------	--------------------------------

6.66 CMLSCALE system variable

6.66.1 Multiline scale

Specifies the overall width scale factor for multilines. A negative scale factor mirrors the offset lines.

Type:	Real
Saved in:	Drawing
Default value:	1.0

6.67 CMLSTYLE system variable

6.67.1 Multiline style

Specifies the multiline style for new multiline entities.

Type:	String
Saved in:	Drawing
Default value:	Standard

6.68 CMPCLRMISS system variable

6.68.1 Color for displaying of missing entities in DWGCOMPARE mode

Specifies the color for displaying of missing entities in DWGCOMPARE mode.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	1



6.69 CMPCLRMOD1 system variable

6.69.1 Color for displaying of modified entities in this drawing in DWGCOMPARE mode

Specifies the color for displaying of modified entities in this drawing in DWGCOMPARE mode.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	253

6.70 CMPCLRMOD2 system variable

6.70.1 Color for displaying of modified entities in the second drawing in DWGCOMPARE mode

Specifies the color for displaying of modified entities in the second drawing in DWGCOMPARE mode.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	2

6.71 CMPCLRNEW system variable

6.71.1 Color for displaying of new entities in DWGCOMPARE mode

Specifies the color for displaying of new entities in DWGCOMPARE mode.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255



Default value:	3
----------------	---

6.72 CMPDIFFLIMIT system variable

6.72.1 Maximal number of entities in the output of DWGCOMPARE command

Specifies the limit for entities comparison in DWGCOMPARE command.

BricsCAD only

Type:	Long
Saved in:	Registry
Range:	1 to 10000000
Default value:	10000000

6.73 CMPFADECTL system variable

6.73.1 DWGCOMPARE fade control

Specifies the fading level for unmodified entities.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 90
Default value:	80

6.74 CMPLOG system variable

6.74.1 DWGCOMPARE log control

Toggles the creation of DWGCOMPARE log report (cmplog) files by the DWGCOMPARE command.

Type:	Boolean
Saved in:	Registry
Default value:	Off



Possible values:	Off (0): Don't write cmplog files On (1): write cmplog files
------------------	---

6.75 COLORBOOKPATH system variable

6.75.1 Color book file search path

Specifies the folder(s) in which BricsCAD should look for color book files.

BricsCAD only

Type:	String
Saved in:	Registry

6.76 COLORTHEME system variable

6.76.1 UI color theme

Choose a dark or light color scheme for UI elements.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Dark color theme 1: Light color theme

6.77 COLORX system variable

6.77.1 X axis color

Specifies the color for the X-axis of the crosshairs. Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255



Default value:	11
----------------	----

6.78 COLORY system variable

6.78.1 Y axis color

Specifies the color for the Y-axis of the crosshairs. Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	112

6.79 COLORZ system variable

6.79.1 Z axis color

Specifies the color for the Z-axis of the crosshairs.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	150

6.80 COMACADCOMPATIBILITY system variable

6.80.1 COM Acad compatibility

Use registry settings to make existing VB applications run with BricsCAD®.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	Off
Possible values:	Off (0): Don't use registry settings On (1): Use registry settings

Note: When the COMACADCOMPATIBILITY system variable is set to **On**, AutoCAD® drawing files that are embedded as OLE objects in other applications will open in BricsCAD®.

6.81 COMBINETEXTMODE system variable

6.81.1 Options for COMBINETEXTMODE

Controls an order of text selection, word-wrap method and linespacing style for TXT2MTXT command.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	11
Possible options:	1: Combine into a single mtext 2: Sort top-down 4: Word-wrap text 8: Uniform linespacing

6.82 COMMUNICATORBACKGROUNDMODE system variable

6.82.1 Perform import and export in background

Enables user interaction while import/export is performed.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable the import and export in background On (1): Enable the import and export in background



6.83 COMPASS system variable

6.83.1 Compass

Toggles the display of the 3D compass On/Off in the current viewport.

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): 3D Compass off On (1): 3D Compass on

6.84 COMPONENTS CONFIG system variable

6.84.1 Library panel configuration

Name of the active Library panel configuration file. This file contains which libraries are shown in the components panel. SRCHPATH is used for finding the file.

BricsCAD only

Type:	String
Saved in:	Workspace
Default value:	default.cct

6.85 COMPONENTSPATH system variable

6.85.1 Library directory path

Specifies the folder(s) in which BricsCAD should look for user created library files.

BricsCAD only

Type:	String
Saved in:	Registry

6.86 CONSTRAINTBARDISPLAY system variable

6.86.1 Constraint Bar Display

Specifies when the constraint bar will be displayed.



Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	1: Displays constraint bars when geometrical constraints are added. 2: Displays hidden constraint bars when constrained entities are selected.

6.87 CONTINUOUSMOTION system variable

6.87.1 Continuous motion

Specifies whether rotation continues after releasing the mouse when using the Realtime View Rotate command.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Disable continuous inertial motion in realtime On (1): Enable continuous inertial motion in realtime

6.88 CONVERTODMAX system variable

6.88.1 Maximal multiplier for outer diameter

Type:	Real
Saved in:	Registry
Default value:	1.1

6.89 CONVERTODMIN system variable

6.89.1 Minimal multiplier for outer diameter



Type:	Real
Saved in:	Registry
Default value:	0.95

6.90 CONVERTTHMAX system variable

6.90.1 Maximal multiplier for thickness

Type:	Real
Saved in:	Registry
Default value:	2

6.91 CONVERTTHMIN system variable

6.91.1 Minimal multiplier for thickness

Type:	Real
Saved in:	Registry
Default value:	0.5

6.92 COORDS system variable

6.92.1 Coordinates

Specifies the format and update frequency of the coordinate field in the status bar.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1



Possible values:	0: Update coordinates only when selecting points 1: Coordinates always show pointer location 2: Coordinates in polar form for point, distance and angle selection 3: Coordinates in geographic form as latitude and longitude
------------------	--

6.93 COPYMODE system variable

6.93.1 Copy mode

Specifies whether the COPY command creates a single copy or multiple copies.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Repeat automatically 1: Create single copy

6.94 CPLOTSTYLE system variable

6.94.1 Current plot style

Specifies the plot style for new entities. In color-dependent mode drawings (PSTYLEMODE = 1), CPLOTSTYLE is set to "BYCOLOR" (Read-only). In named-plot-style mode drawings (PSTYLEMODE = 0), the options for CPLOTSTYLE are: "BYLAYER" (default), "BYBLOCK", "NORMAL" and "USER DEFINED". Use the CONVERTPSTYLES command to convert the current drawing to use named or color-dependent plot styles.

Type:	String
Saved in:	Drawing

6.95 CPROFILE system variable

6.95.1 Current profile

The name of the current user profile.

Read-only

Type:	String
-------	--------



Saved in:	Registry
Default value:	Default

6.96 CREATETHUMBNAILONTHEFLY system variable

6.96.1 Create preview thumbnail on the fly

Generates the preview thumbnail in the Open Dialog, if the drawing doesn't have prepared thumbnail (drawing was saved with RASTERPREVIEW set to 0).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't create preview thumbnail on the fly On (1): Create preview thumbnail on the fly

6.97 CREATESKETCHFEATURE system variable

6.97.1 Sketch based feature (experimental)

Controls whether sketch based feature should be created in Extrude and Revolve commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Do not create sketch based feature 1: Create sketch based feature

Прим.: This system variable can also be set by pressing the **CreateSketchFeature** toggle button  in the ribbon.

The location of the toggle button depends on the loaded CUI file and the workspace:

**Classic interface**

Modeling workspace: **Solid & Surface** tabs > **Direct Modeling** ribbon panel.

Mechanical workspace: **Solid & Surface** tabs > **Create** ribbon panel.

Modern interface

Modeling & Mechanical workspaces: **Home** tab > **Controls** ribbon panel.

6.98 CREATEVIEWPORTS system variable

6.98.1 Automatic viewport creation

Specifies whether a viewport will be created automatically for newly created layouts.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't create viewport for new layouts On (1): Create viewport for new layouts

6.99 CROSSHAIRDRAWMODE system variable

6.99.1 Crosshair rendering mode

Specifies the way the mouse cursor is rendered while inside the drawing window (crosshair, pickbox, etc.). If the value of CROSSHAIRDRAWMODE is 0, the crosshair is always rendered at window toolkit level. The sub-items enable a rendered cursor depending on visual style.

- In 2dwireframe, render the crosshair in OpenGL. Attempts to eliminate cursor duplicates or flickering, which may happen using the window toolkit.
- In RedSDK visual styles, render the crosshair by RedSDK. Rendering the cursor by RedSDK tends to be faster, but some old systems might not support it.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0 (Mac & Linux) 2 (Windows)



Possible values:	0: Always render crosshair at window toolkit level 1: Render crosshair in OpenGL, for 2d drawings 2: Render crosshair by RedSDK, for 3d drawings
------------------	--

6.100 CROSSINGAREACOLOR system variable

6.100.1 Crossing area color

Specifies the color for crossing selection areas. In effect only when SELECTIONAREA setting is on.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	91

6.101 CTAB system variable

6.101.1 Current tab

Stores the name of the current (model or layout) tab in the drawing. Allows to control which tab is active.

Type:	String
Saved in:	Drawing
Default value:	Model

6.102 CTABLESTYLE system variable

6.102.1 Current table style

Specifies the table style for new table entities.

Type:	String
Saved in:	Drawing
Default value:	Standard



6.103 CTRL3DMOUSE system variable

6.103.1 3D mouse mode

Specifies view navigation with 3Dconnexion 3D mouse.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Disable 3D mouse 1: Enable 3D mouse

6.104 CTRLMOUSE system variable

6.104.1 Mouse shortcuts

Toggles mouse shortcuts for several operations:

- Ctrl + Shift + Left button for realtime zoom.
- Ctrl + Shift + Right button for realtime pan.
- Ctrl + middle button for view rotation.
- Ctrl + right button for view rotation with fixed Z-axis.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Disable mouse shortcuts 1: Enable mouse shortcuts



6.105 CURORSIZE system variable

6.105.1 Crosshairs size

Specifies the crosshairs size as a percentage of the size of the screen.

Type:	Short
Saved in:	Registry
Range:	1 to 100
Default value:	3

6.106 CVPORT system variable

6.106.1 Current viewport

Stores the identification number of the current viewport. Change this value to change the current viewport on three conditions: (1) the identification number is that of an active viewport, (2) cursor movement in that viewport is not locked by a command in progress and (3) tablet mode is off.

Type:	Short
Saved in:	Drawing
Range:	1 or greater
Default value:	2

6.107 CVERSIONCONTROLPATH system variable

6.107.1 Current version control path

Specifies the folder to the current version control project.

BricsCAD only

Type:	String
Saved in:	Registry



6.108 CLOUDSSOSCOPE system variable

6.108.1 Cloud SSO Scope

Specifies scopes or permissions to be used when connecting to SSO service.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	openid profile email

6.109 CLOUDSSOCLIENTID system variable

6.109.1 Cloud SSO Client ID

Specifies the client_id to be used when connecting to SSO service.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	bricscad

6.110 CTRLMBUTTON system variable

6.110.1 Middle Button Click

Enables/disables temporary tracking points on middle click (mouse wheel click).

Прим.: This variable is only available on the command line.

If CTRLMBUTTON is ON, then during a command a mouse middle click can be used to start entering temporary tracking points.

Default value:	1
Possible values:	0: Disables temporary tracking points on middle button click. 1: Enables temporary tracking points on middle button click.



7. D

7.1 DATACOLLECTION system variable

7.1.1 Diagnostics and usage data collection

Specifies whether you wish to share anonymous usage data to help to improve BricsCAD.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	-2 to 1
Default value:	-2
Possible values:	-2: Not asked -1: Not set 0: Off 1: On

7.2 DATACOLLECTIONENABLED system variable

7.2.1 Current state of data collection

Controls diagnostic and usage data collection.

BricsCAD only

Type:	Boolean
Saved in:	Not saved
Range:	Off
Possible values:	Off (0): Data collection is disabled. On (1): Data collection is enabled.

Прим.: This is a read-only system variable.

Прим.: The value of this system variable is by default based on the value of the DATACOLLECTION preference variable, however it is possible to override the default by applying an administrative override. The administrative override is applied by manually adding the registry value in *HKLM\Software\Bricsys\BricsCAD\V23x64\AdminPolicy*.



To add this override follow the next steps:

- Go to: Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Bricsys\BricsCAD\V23x64.
- Right-click the V23x64 key and choose **New > Key** and rename it to **AdminPolicy**.
- Right-click on the new created key and choose **New > DWORD (32-bit)** and name the value **DATACOLLECTIONENABLED**.
- Change its value to 0 or 1 to override the value of DATACOLLECTION user preference.

Прим.: The AdminPolicy values are only read when BricsCAD starts, so any change requires a restart.

7.3 DATAcollectionlogintype system variable

7.3.1 Current type of login for data collection

Determines the login type for data collection. (Off/Anonymous/User Password)

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	Off
Possible values:	-1: Off 0: Anonymous 1: User/Password

Прим.: This is a read-only system variable.

7.4 Datalinknotify system variable

7.4.1 Notification of data links

Specifies the notification for updated or missing data links. Enables or disables data link notifications and balloon message notifications.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2



Possible values:	0: Disables data link update notification. 1: Enables data link notification. 2: Enables data link notification and balloon message notifications.
------------------	--

7.5 DATE system variable

7.5.1 Current date

Shows the current date and time in Julian Day format.

Read-only

Type:	Real
Saved in:	Not saved

7.6 DBCSTATE system variable

7.6.1 DbConnect state

Shows whether the dbConnect Manager is active or not.

Read-only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display dbConnect Manager On (1): Display dbConnect Manager

7.7 DBLCLKEDIT system variable

7.7.1 Double click editing

Specifies the double click editing behavior in the drawing area.

Type:	Boolean
Saved in:	Registry
Range:	On



Possible values:	Off (0): Disable double click editing On (1): Enable double click editing
------------------	--

7.8 DBMOD system variable

7.8.1 Modification status

Shows the status of the drawing modification as a bit-code.

Read-only

Type:	Short
Saved in:	Not saved
Possible values:	1: Object database modified 4: Database variable modified 8: Window modified 16: View modified 32: Field modified

7.9 DCTCUST system variable

7.9.1 Custom spelling dictionary

Stores the path and file name of the current custom spelling dictionary. During a spelling check, the SPELL command matches the words in the drawing or the current selection set to the words in the current main dictionary and the current custom dictionary. Custom dictionaries are used for discipline-specific words, such as medical or mechanical.

Type:	String
Saved in:	Registry

7.10 DCTMAIN system variable

7.10.1 Main spelling dictionary

Stores the file name of the current main spelling dictionary, which is supposed to sit in the support folder, therefore the full path is not shown. During a spelling check, the SPELL command matches the words in the drawing or the current selection set to the words in the current main dictionary and the current custom dictionary.

Type:	String
-------	--------



Saved in:	Registry
-----------	----------

7.11 DEFAULTBSYSLIBIMPERIAL system variable

7.11.1 Default Bsystlib imperial

Default location of the Bsystlib library database when MEASUREMENT is 0 (imperial).

BricsCAD only

Type:	String
Saved in:	Preference

7.12 DEFAULTBSYSLIBMETRIC system variable

7.12.1 Default Bsystlib metric

Default location of the Bsystlib library database when MEASUREMENT is 1 (metric).

BricsCAD only

Type:	String
Saved in:	Preference

7.13 DEFAULTCURVETYPEHA system variable

7.13.1 Default curve for horizontal alignments

Specifies the curve type to be used when create a new horizontal alignment or adding new PI.

BricsCAD only

Type:	Short
Saved in:	Drawing
Possible values:	-1: None 0: Auto Arc 1: Free Arc 2: Auto Spiral-Curve-Spiral 3: Free Spiral-Curve-Spiral



7.14 DEFAULTCURVETYPEVA system variable

7.14.1 Default curve for vertical alignments

Specifies the curve type to be used when create a new vertical alignment or adding new PVI.

BricsCAD only

Type:	Short
Saved in:	Drawing
Possible values:	-1: None 0: Auto Arc 1: Free Arc 2: Auto Parabola 3: Free Parabola

7.15 DEFAULTLIGHTING system variable

7.15.1 Default lighting

Specifies whether default lighting should be used always or only in case no other lights have been switched on. Default lighting consists of distant light that follows the view direction. This setting can be specified per viewport. When default lighting is used, it replaces all other light sources defined in the drawing.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Default lighting is used only in case no other lights are switched on On (1): Default lighting is used instead of the light sources defined in the drawing

7.16 DEFAULTLIGHTSHADOWBLUR system variable

7.16.1 Default light shadow blur

Shadow blur amount for default light.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Preference
Range:	1 to 40
Default value:	8

7.17 DEFAULTNEWSHEETTEMPLATE system variable

7.17.1 Default new sheet template

Specifies the default drawing template file (.dwg or .dwt) for new sheets.

BricsCAD only

Type:	String
Saved in:	Preference

7.18 DEFAULTPLOTSTYLETABLE system variable

7.18.1 Default plot style table

Specifies the default plot style table for new page setups and new layouts. Changing this preference will not apply to the layouts that already exist.

BricsCAD only

Type:	String
Saved in:	Preference

7.19 DEFAULTSPACEHEIGHT system variable

7.19.1 Default Space Height

Default height of a space's solid representation. This will be used if there are no ceilings to connect to or walls to get the height from.

BricsCAD only

Type:	Real
Saved in:	Drawing



Default value:	120 for MEASUREMENT=0 (inches) 3000 for MEASUREMENT=1 (millimeters)
----------------	--

7.20 DEFAULTSTYLEPIPECROSS system variable

7.20.1 Default style for pipe cross

Style display as default while BIM FlowFitting cross is converting to Stdpart.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Cross

7.21 DEFAULTSTYLEPIPEECCENTRICREDUCER system variable

7.21.1 Default style for pipe reducer

Style display as default while BIM FlowFitting reducer is converting to Stdpart.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Eccentric Reducer

7.22 DEFAULTSTYLEPIPEELBOW45 system variable

7.22.1 Default style for pipe elbow (45 deg)

Style display as default while BIM FlowBend with 45 degrees angle is converting to Stdpart.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Elbow LR 45 Deg



7.23 DEFAULTSTYLEPIPEELBOW90 system variable

7.23.1 Default style for pipe elbow (90 deg)

Style display as default while BIM FlowBend with 90 degrees angle is converting to Stdpart.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Elbow LR 90 Deg

7.24 DEFAULTSTYLEPIPERREDUCER system variable

7.24.1 Default style for pipe reducer

Style display as default while BIM FlowFitting reducer is converting to Stdpart.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Reducer

7.25 DEFAULTSTYLEPIPESEGMENT system variable

7.25.1 Default style for pipe segment

Style display as default while BIM FlowSegment is converting to Stdpart.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B36.10M Pipe

7.26 DEFAULTSTYLEPIPETEE system variable

7.26.1 Default style for pipe tee

Style display as default while BIM FlowFitting tee is converting to Stdpart.



BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Tee

7.27 DEFLPLSTYLE system variable

7.27.1 Default layer plot style

Specifies the default plot style for layer 0. In color-dependent mode drawings (PSTYLEMODE = 1), DEFLPLSTYLE is set to "BYCOLOR" (Read-only). In named-plot-style mode drawings (PSTYLEMODE = 0), DEFLPLSTYLE is set to "NORMAL" and can be changed. Use the CONVERTPSTYLES command to convert the current drawing to use named or color-dependent plot styles.

Type:	String
Saved in:	Registry

7.28 DEFPLSTYLE system variable

7.28.1 Default entity plot style

Specifies the default plot style for new entities. In color-dependent mode drawings (PSTYLEMODE = 1), DEFPLSTYLE is set to "BYCOLOR" (Read-only). In named-plot-style mode drawings (PSTYLEMODE = 0), DEFPLSTYLE is set to "NORMAL" and can be changed. Use the CONVERTPSTYLES command to convert the current drawing to use named or color-dependent plot styles.

Type:	String
Saved in:	Registry

7.29 DELETEINTERFERENCE system variable

7.29.1 Delete interference

Specifies whether interferences between source and other 3d solids are retained or resolved (i.e. source solids will be subtracted from any interfering solids).

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't solve interferences after commands On (1): Solve interferences after commands


7.30 DELETETOOL system variable

7.30.1 Delete tool

Specifies whether tool entities in command SUBTRACT are retained or deleted.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Default value:	On
Possible values:	Off (0): Don't delete tool entities in command SUBTRACT On (1): Delete tool entities in command SUBTRACT



7.31 DELOBJ system variable

7.31.1 Delete entity

Specifies whether source entities used to create 3D entities are retained or deleted.



Type:	Short
Saved in:	Registry
Default value:	1
Possible values:	0: Retain defining entities 1: Delete profile entities 2: Delete all defining entities -1: Prompt to delete profile entities -2: Prompt to delete all defining entities (including paths and reference curves)

7.32 DEMANDLOAD system variable

7.32.1 Demand load

Specifies how BricsCAD interacts with custom entities created by a third-party application. If you set this system variable to 0, third-party applications and some BricsCAD commands cannot function.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	1: Demand-load source application when opening a drawing that contains custom entities 2: Demand-load source application when invoking one of the application's commands

7.33 DETAILSPATH system variable

7.33.1 Details directory path

Specifies the folder(s) in which BricsCAD should look for user created detail files.

BricsCAD only

Type:	String
Saved in:	Registry



7.34 DGNEXPXREFMODE system variable

7.34.1 Export Conversion of Xrefs

Specifies conversion of references to xrefs. The dependent files themselves are not converted when exporting the parent. They must be converted separately.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: Convert reference to DGN 1: Keep reference to DWG 2: Bind reference file to the parent DGN 3: Detach xref

7.35 DGNFRAME system variable

7.35.1 DGN frame

Specifies if DGN frames in the current drawing are visible or plotted.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Hide DGN frames 1: Display and plot DGN frames 2: Display but do not plot DGN frames

7.36 DGNIMP2DCLOSEDBSPLINECURVEIMPORTMODE system variable

7.36.1 2D closed B-spline curve import mode

Specifies how to convert closed 2D B-Spline curve elements.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Convert to spline 1: Convert to region

7.37 DGNIMP2DELLIPSEIMPORTMODE system variable

7.37.1 2D ellipse import mode

Specifies how to convert 2D Ellipse elements.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Convert to ellipse 1: Convert to region

7.38 DGNIMP2DSHAPEIMPORTMODE system variable

7.38.1 2D shape import mode

Specifies how to convert 2D Shape and 2D Complex Shape elements. If an element is filled, then a hatch is created as well as the result of importing.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2



Default value:	0
Possible values:	0: Convert to polyline 1: Convert to region 2: Convert to polyface mesh

7.39 DGNIMP3DCLOSEDBSPLINECURVEIMPORTMODE system variable

7.39.1 3D closed B-spline curve import mode

Specifies how to convert closed 3D B-Spline curve elements.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: Convert to spline 1: Convert to region

7.40 DGNIMP3DELLIPSEIMPORTMODE system variable

7.40.1 3D ellipse import mode

Specifies how to convert 3D Ellipse elements.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Convert to ellipse 1: Convert to region



7.41 DGNIMP3DOBJECTIMPORTMODE system variable

7.41.1 3D object import mode

Specifies how to convert 3D entities.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: Convert to polyface mesh 1: Convert to 3D Solid, Body or Surface

7.42 DGNIMP3DSHAPEIMPORTMODE system variable

7.42.1 3D shape import mode

Specifies how to convert 3D Shape and 3D Complex Shape elements. If an element is filled, then a hatch is created as well as the result of importing.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Convert to polyline 1: Convert to region 2: Convert to polyface mesh

7.43 DGNIMPBREAKDIMENSIONASSOCIATION system variable

7.43.1 Break dimension association

Specifies if dimensions lose their associativity upon import. If on, then dgn dimension associations are broken in the dwg.



BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't break dimension associations On (1): Break dimension associations

7.44 DGNIMP CONVERTDGN COLOR INDICES TO TRUE COLORS system variable

7.44.1 Convert DGN color indices to true colors

Specifies how Microstation colors are mapped to BricsCAD colors. Microstation assigns color numbers to colors that are different from BricsCAD. If on, then BricsCAD converts dgn color indexes to RGB true colors. Otherwise it tries to convert dgn color indices to dwg color indices. BricsCAD gets the color from the dgn color table and tries to find the same color in dwg color table. If it is not possible, then the color will be saved as an RGB true color to the dwg file.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Convert DGN color indices to DWG color indices On (1): Convert DGN color indices to RGB true colors

7.45 DGNIMP CONVERTEMPTYDATAFIELDS TOSPACES system variable

7.45.1 Convert empty data fields to spaces

Specifies how empty field values are handled. If on, then empty field values from a dgn file are replaced by space symbols in the dwg file. Otherwise empty field values from a dgn file are replaced by underscore symbols ("_") in the dwg file.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	On
Possible values:	Off (0): Replace by underscore symbols ("_") On (1): Replace by space symbols

7.46 DGNIMPERASEUNUSEDRESOURCES system variable

7.46.1 Erase unused resources

Specifies if unreferenced elements, such as text styles and linetypes, are imported or deleted.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Import unreferenced elements. On (1): Erase unreferenced imported items

7.47 DGNIMPEXPLODETEXTNODES system variable

7.47.1 Explode text nodes

Specifies how to handle text nodes (empty text fields). If on, imported dgn text nodes are converted to simple entities (text, line, etc.). Otherwise they are converted to multiline text. Microstation uses text nodes as empty fields that are used to reserve space for text that will be added later so the length of the text is not yet known.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Convert text nodes to multiline text On (1): Convert text nodes to simple entities, such as text and lines



7.48 DGNIMPIMPORTACTIVEMODELTOmodeleSpace system variable

7.48.1 Import active model to Model Space

Specifies how active spaces are handled. If on, BricsCAD imports the active dgn model to dwg Model Space. Otherwise BricsCAD imports the first dgn design model from the model table to the dwg Model Space. Microstation uses the phrase "design model" for model space, and "active model" for the current view of a model.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Import the first design model from the model table to the model space On (1): Import the active model to model space

7.49 DGNIMPIMPORTDGTEXTSASDBMTEXTS system variable

7.49.1 Import Texts as MTexts

If true, import simple text objects as multiline texts.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Does not import simple text objects as multiline texts. On (1): Imports simple text objects as multiline texts.

7.50 DGNIMPIMPORTINVISIBLEELEMENTS system variable

7.50.1 Import invisible elements

Specifies how invisible elements (entities) are handled. If on, BricsCAD imports invisible dgn elements as invisible entities. Otherwise they are skipped.

BricsCAD only



Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Skip invisible elements On (1): Import invisible elements

7.51 DGNIMPIMPORTPAPERSPACEMODELS system variable

7.51.1 Import Paper Space models

Specifies whether to import sheet models (paper space). If on, all dgn sheet models are imported to the Paper Space layouts. Otherwise sheet models are not imported. Microstation uses the phrase "sheet model" for paper space.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import sheet models On (1): Import sheet models to paper space layouts

7.52 DGNIMPIMPORTVIEWINDEX system variable

7.52.1 Import view index

Specifies the number of dgn views to use level masks and dgn view settings. If the view number is "-1", then the view is not defined, and view settings and level masks are not used. Microstation uses the word "level" for layers; a "mask" hides content in areas or levels/layers.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	-1 to 7



Default value:	-1
Possible values:	-1: View is not defined 1 to 7: Specifies level mask

7.53 DGNIMPRECOMPUTEDIMENSIONS AFTERIMPORT system variable

7.53.1 Recompute dimensions after import

Specifies how to handle imported dimensions. If on, BricsCAD will re-compute all dimensions to create dwg-based dimension geometry blocks; otherwise it will create dgn-based dimension geometry blocks.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): create DGN-style dimension geometry blocks On (1): re-compute all dimensions to create DWG dimension geometry blocks

7.54 DGNIMPSYMBOLRESOURCEFILES system variable

7.54.1 Symbol resource files

Specifies the paths to folders holding DGN and RSC files. Microstation uses RSC resource files to store fonts, line styles, and so on. (analog to MS_SYMBRSRC MicroStation setting).

BricsCAD only

Type:	String
Saved in:	Preference

7.55 DGNIMPXREFIMPORTMODE system variable

7.55.1 External references import mode

Specifies how to import dgn reference attachments. The options are "Omit" - don't import dgn reference attachments; "Retain" - convert attached dgn files to dwg and create dwg Xref; "Merge to cell" - create block definition and import attached dgn file to it, then create block reference to dgn attachment block; "Create DGN Underlay" - create DGN Underlay object.



BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	2
Possible values:	0: Omit 1: Retain 2: Merge to cell 3: Create DGN Underlay

7.56 DGNOSNAP system variable

7.56.1 Dgn entity snap

Enable snapping to entities in DGN underlay files.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable DGN entity snap On (1): Enable DGN entity snap

7.57 DIASTAT system variable

7.57.1 Dialog state

Shows how the user exited the most recently used dialog box.

Read-only

Type:	Boolean
Saved in:	Not saved
Possible values:	Off (0): Cancel On (1): OK



7.58 DIMADEC system variable

7.58.1 Dim angle precision

Specifies the display precision for angular dimensions. Values between -1 and 8 are accepted. If -1 is entered, DIMADEC is initialized with the value of the DIMDEC setting. Values 0 to 8 specify the number of decimal places for angular dimensions, independent of DIMDEC.

Type:	Short
Saved in:	Drawing
Range:	-1 to 8
Default value:	0
Possible values:	-1: Use DIMDEC setting 0 - 8: Decimal places

7.59 DIMALT system variable

7.59.1 Alt units

Enables alternate units in dimensions.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Disable alternate units On (1): Enable alternate units

7.60 DIMALTD system variable

7.60.1 Alt precision

Specifies the display precision for the alternate dimension units.

Type:	Short
Saved in:	Drawing



Range:	0 to 8
Default value:	3

7.61 DIMALTF system variable

7.61.1 Alt multiplier

Specifies the multiplier for alternate units. If DIMALT is on, linear dimensions are multiplied by DIMALTF to provide an alternate linear dimension. E.g. if one drawing unit equals 1 inch, and DIMALTF=25.4, alternate linear dimensions are expressed in mm.

Type:	Real
Saved in:	Drawing
Default value:	0.0394

7.62 DIMALTRND system variable

7.62.1 Alt roundoff

Specifies the roundoff rules for alternate units.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.63 DIMALTTD system variable

7.63.1 Alt tolerance precision

Specifies the tolerance precision in the alternate dimension units.

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	3



7.64 DIMALTTZ system variable

7.64.1 Alt tolerance suppress zeros

Specifies the suppression of zeros in tolerance values.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions

7.65 DIMALTU system variable

7.65.1 Alt unit type

Specifies the alternate unit type for linear dimensions.

Type:	Short
Saved in:	Drawing
Range:	1 to 8
Default value:	2
Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural (stacked) 5: Fractional (stacked) 6: Architectural 7: Fractional 8: Windows control panel



7.66 DIMALTZ system variable

7.66.1 Alt suppress zeros

Suppresses leading and/or trailing zeros in alternate unit dimension values.

Type:	Short
Saved in:	Drawing
Range:	0 to 12
Default value:	0
Possible values:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions

7.67 DIMANNO system variable

7.67.1 Style is annotative

Indicates if the current dimension style is annotative.

Read-only

Type:	Boolean
Saved in:	Drawing

7.68 DIMAPOST system variable

7.68.1 Alt units prefix/suffix

Specifies a prefix and/or suffix that to appear in the alternate dimension text. The general format is just the suffix string or 'prefix[]suffix'. DIMAPOST does not apply to angular dimensions. In the DimStyle explorer the variable is split up into Alt Prefix and Alt Suffix for editing.

Type:	String
Saved in:	Drawing



7.69 DIMARCSYM system variable

7.69.1 Arc symbol

Specifies how the arc length symbol displays in an arc dimension.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Arc length symbol is placed before the dimension text 1: Arc length symbol is placed above the dimension text 2: The display of the arc length symbol is suppressed

7.70 DIMASO system variable

7.70.1 Associativity (Obsolete)

Replaced by DIMASSOC. Has no effect except to preserve the integrity of scripts.

Type:	Boolean
Saved in:	Drawing
Default value:	On

7.71 DIMASSOC system variable

7.71.1 Associativity

Specifies the associativity of dimension entities or whether they are exploded.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2



Possible values:	0: Exploded dimensions 1: Non-associative dimension entities 2: Associative dimension entities
------------------	--

7.72 DIMASZ system variable

7.72.1 Arrow size

Specifies the size of arrowheads of dimension lines and leader lines.

Type:	Real
Saved in:	Drawing
Default value:	0.18

7.73 DIMATFIT system variable

7.73.1 Arrow and text fit

Specifies how dimension text and arrows are arranged when there is insufficient place within the extension lines. When DIMMOVE=1, a leader is added if the dimension text is placed outside.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible values:	0: Place both text and arrows outside extension lines 1: Move arrows first, then text 2: Move text first, then arrows 3: Move either text or arrows, whichever fits best

7.74 DIMAUNIT system variable

7.74.1 Dim angle units

Specifies angular dimensions unit type.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 3
Default value:	0
Possible values:	0: Decimal degrees 1: Degrees/minutes/seconds 2: Gradians 3: Radians

7.75 DIMAZIN system variable

7.75.1 Suppress angle zeros

Suppresses leading and/or trailing zeros for angular dimensions. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	0
Possible options:	1: Suppress leading zeros 2: Suppress trailing zeros

7.76 DIMBLK system variable

7.76.1 Arrow

Specifies the name of the block displayed at the ends of dimension lines and leader lines. The block name can be either a standard name or refer to a user-defined arrowhead block.

Type:	String
Saved in:	Drawing



7.77 DIMBLK1 system variable

7.77.1 Arrow 1

Specifies the name of the block displayed at the first end of dimension line when DIMSAH is on (= use different blocks for the first and the second arrowhead).

Type:	String
Saved in:	Drawing

7.78 DIMBLK2 system variable

7.78.1 Arrow 2

Specifies the name of the block displayed at the second end of dimension line when DIMSAH is on (= use different blocks for the first and the second arrowhead).

Type:	String
Saved in:	Drawing

7.79 DIMCEN system variable

7.79.1 Center mark

Specifies if and how center marks and centerlines of circles and arcs are drawn by DIMCENTER, DIMDIAMETER and DIMRADIUS commands. Set to zero for no center mark, negative for Line or positive for Mark. The DIMCEN system variable also controls the length of center mark lines and size of the center marks.

Type:	Real
Saved in:	Drawing
Default value:	0.09
Possible values:	0: None <0: Line >0: Mark



7.80 DIMCLRD system variable

7.80.1 Dim line color

Specifies the color for dimension lines, arrowheads and dimension leader lines.

Type:	Short
Saved in:	Drawing
Range:	0 to 256
Default value:	0
Possible values:	0: ByBlock 1 - 255: index 256: ByLayer

7.81 DIMCLRE system variable

7.81.1 Ext line color

Specifies the color for dimension extension lines.

Type:	Short
Saved in:	Drawing
Range:	0 to 256
Default value:	0
Possible values:	0: ByBlock 1 - 255: index 256: ByLayer

7.82 DIMCLRT system variable

7.82.1 Text color

Specifies the color for dimension text.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 256
Default value:	0
Possible values:	0: ByBlock 1 - 255: index 256: ByLayer

7.83 DIMDEC system variable

7.83.1 Dim precision

Specifies the display precision for the primary dimension units.

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	4

7.84 DIMDLE system variable

7.84.1 Dim line ext

Specifies the extension of the dimension line beyond the extension lines in case obliques or architectural ticks are drawn instead of arrowheads.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.85 DIMDLI system variable

7.85.1 Dim baseline spacing

Specifies the spacing between dimension lines in baseline dimensions.



Type:	Real
Saved in:	Drawing
Default value:	3.8

7.86 DIMDSEP system variable

7.86.1 Decimal separator

Specifies a new decimal separator character.

Type:	String
Saved in:	Drawing

7.87 DIMEXE system variable

7.87.1 Ext line ext

Specifies the extension of the extension lines beyond the dimension line.

Type:	Real
Saved in:	Drawing
Default value:	.18

7.88 DIMEXO system variable

7.88.1 Ext line offset

Specifies the offset of extension lines from the origin points.

Type:	Real
Saved in:	Drawing
Default value:	0.625



7.89 DIMFIT system variable

7.89.1 Dimension text fit (Obsolete)

Replaced by DIMATFIT and DIMTMOVE.

Type:	Short
Saved in:	Drawing
Default value:	3

7.90 DIMFRAC system variable

7.90.1 Fractional type

Specifies the fraction format for Architectural (DIMLUNIT = 4) or Fractional (DIMLUNIT = 5) linear dimensions.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Horizontal 1: Diagonal 2: Not stacked

7.91 DIMFXL system variable

7.91.1 Ext line fixed length

Specifies the total length of the extension lines.

Type:	Real
Saved in:	Drawing
Default value:	1.0



7.92 DIMFXLON system variable

7.92.1 Ext line fixed

Specifies whether extension lines are set to a fixed length.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't use fixed length extension lines On (1): Use fixed length extension lines

7.93 DIMGAP system variable

7.93.1 Text offset

Specifies the offset distance around the dimension text and the distance between annotation and hook line created using the LEADER command. A negative value for DIMGAP draws a box around the dimension or annotation text.


Type:	Real
Saved in:	Drawing
Default value:	0.09

7.94 DIMJOGANG system variable

7.94.1 Jogged angle

Specifies the angle of the oblique dimension line segment in jogged radius dimensions. Jogged radius dimensions are often created when the center point is located off the page.

Type:	Real
Saved in:	Drawing
Default value:	45.0



7.95 DIMJUST system variable

7.95.1 Horizontal text position

Specifies the horizontal position of dimension text, with respect to the extension lines.

Type:	Short
Saved in:	Drawing
Range:	0 to 4
Default value:	0
Possible values:	0: Text above the dimension line and center-justified between extension lines 1: Text next to the first extension line 2: Text next to the second extension line 3: Text above and aligned with the first extension line 4: Text above and aligned with the second extension line

7.96 DIMLAYER system variable

7.96.1 Default layer for new dimensions

Specifies a default layer for new dimensions.

Type:	String
Saved in:	Drawing
Default value:	.



7.97 DIMLDRBLK system variable

7.97.1 Leader arrow

Specifies the arrowhead block for leaders.

Type:	String
Saved in:	Drawing

7.98 DIMLFAC system variable

7.98.1 Dim scale linear

Specifies the scale factor for linear dimensions. Linear dimensions (incl. radius, diameter and ordinate dimensions), are multiplied by DIMLFAC. Positive values apply to dimensions in both model space and paper space; negative values apply to paper space dimensions only.

Type:	Real
Saved in:	Drawing
Default value:	1.0

7.99 DIMLIM system variable

7.99.1 Tolerance method

Specifies the default text to dimension limits. If DIMLIM is On, DIMTOL is switched Off.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't generate dimension limits as default text On (1): Generate dimension limits as default text

7.100 DIMLTEX1 system variable

7.100.1 Ext line 1 linetype

Specifies the linetype for the first extension line.



Type:	String
Saved in:	Drawing

7.101 DIMTEX2 system variable

7.101.1 Ext line 2 linetype

Specifies the linetype for the second extension line.

Type:	String
Saved in:	Drawing

7.102 DIMTYPE system variable

7.102.1 Dim line linetype

Specifies the linetype for the dimension line.

Type:	String
Saved in:	Drawing

7.103 DIMLUNIT system variable

7.103.1 Dim units

Specifies the primary unit type for linear dimensions.

Type:	Short
Saved in:	Drawing
Range:	1 to 6
Default value:	2



Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural 5: Fractional 6: Windows control panel
------------------	--

7.104 DIMLWD system variable

7.104.1 Dim line linewidth

Specifies the linewidth of dimension lines.

Type:	Short
Saved in:	Drawing
Range:	-3 to 211
Default value:	Bylayer
Possible values:	-3: Default (defined by LWDEFAULT) -2: ByBlock -1: ByLayer 0 - 211: Lineweight value in hundredths of millimeters

7.105 DIMLWE system variable

7.105.1 Ext line LW

Specifies the linewidth of extension lines.

Type:	Short
Saved in:	Drawing
Range:	-3 to 211
Default value:	Bylayer



Possible values:	-3: Default (defined by LWDEFAULT) -2: ByBlock -1: ByLayer 0 - 211: Lineweight value in hundredths of millimeters
------------------	--

7.106 DIMMARKTYPE system variable

7.106.1 Dimension override marking

Automatically displays overridden associative dimensions with a special marking (underline/overline) without database modification.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Not enabled 1: Display overridden dimensions with an underline 2: Display overridden dimensions with an overline

7.107 DIMPOST system variable

7.107.1 Dim prefix/suffix

Specifies a prefix and/or suffix to be added to the dimension text. The general format is just the suffix string or 'prefix <> suffix'. A single linefeed can be inserted with '\\X' (often when alternate units are active). In the DimStyle explorer the variable is split into Dim Prefix and Dim Suffix for editing.

Type:	String
Saved in:	Drawing

7.108 DIMRND system variable

7.108.1 Dim round

Specifies the roundoff rules for linear dimensions. E.g. set DIMRND to 0.1 if you want to round all distances to the nearest 0.1 unit. Set DIMRND to 1 if you want to round distances to the nearest integer.



Remember the number of decimal places is limited by DIMDEC. Angular dimensions are not affected by DIMRND.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.109 DIMSAH system variable

7.109.1 Arrowheads

Specifies whether dimension line arrowhead blocks are set by DIMBLK or by DIMBLK1 and DIMBLK2.
If=0: use the same block for the first and the second arrowhead. The arrowhead block is then defined by DIMBLK. If=1: use different blocks for the first and the second arrowhead. The arrowhead blocks are defined by DIMBLK1 and DIMBLK2

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Arrowhead blocks set by DIMBLK On (1): Arrowhead blocks set by DIMBLK1 and DIMBLK2

7.110 DIMSCALE system variable

7.110.1 Dim scale overall

Specifies the scale factor applied to all dimensioning variables that specify the size of the components of dimension entities, such as text height, distances or offsets. DIMSCALE does not affect measured lengths, coordinates, or angles.

Type:	Real
Saved in:	Drawing
Range:	0 or greater
Default value:	1.0



7.111 DIMSD1 system variable

7.111.1 Dim line 1

Suppresses the display of the first part of the dimension line: from the first extension line to the text origin.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't suppress first dimension line On (1): Suppress first dimension line

7.112 DIMSD2 system variable

7.112.1 Dim line 2

Suppresses the display of second part of the dimension line: from the text origin to the second extension line.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't suppress second dimension line On (1): Suppress second dimension line

7.113 DIMSE1 system variable

7.113.1 Ext line 1

Suppresses the display of the first extension line.

Type:	Boolean
Saved in:	Drawing
Default value:	Off



Possible values:	Off (0): Don't suppress first extension line On (1): Suppress first extension line
------------------	---

7.114 DIMSE2 system variable

7.114.1 Ext line 2

Suppresses the display of the second extension line.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't suppress second extension line On (1): Suppress second extension line

7.115 DIMSHO system variable

7.115.1 Dimension show (Obsolete)

Specifies redefinition of dimension entities while dragging. Has no effect except to preserve the integrity of scripts.

Type:	Boolean
Saved in:	Drawing
Default value:	On

7.116 DIMSOXD system variable

7.116.1 Dim line inside

Suppresses arrowheads outside the extension lines if there is insufficient room inside the extension lines and if DIMTIX is on. If DINTIX is off, DIMSOXD had no effect.

Type:	Boolean
Saved in:	Drawing
Default value:	Off



Possible values:	Off (0): Don't suppress outside arrowheads On (1): Suppress outside arrowheads
------------------	---

7.117 DIMSTYLE system variable

7.117.1 Dimension style

Shows the current dimension style.

Read-only

Type:	String
Saved in:	Drawing
Default value:	Standard

7.118 DIMTAD system variable

7.118.1 Vertical text position

Specifies the vertical position of text with respect to the dimension line. If DIMTAD=1 (Above dimension line), the distance from the dimension line is set by DIMGAP.

Type:	Short
Saved in:	Drawing
Range:	0 to 4
Default value:	0
Possible values:	0: Centered between extension lines 1: Above dimension line, unless DIMTIH is 1 and the dimension line is not horizontal 2: Farthest from defining points 3: Japanese Industrial Standards 4: Below dimension line

7.119 Системная переменная DIMTDEC

7.119.1 Точность допуска

Определяет количество знаков дробной части для основных размерных единиц.



Type:	Short
Saved in:	Drawing
Range:	От 0 до 8
Default value:	4

7.120 DIMTFAC system variable

7.120.1 Tolerance text height

Specifies the scale factor to calculate the text height for dimension fractions and tolerances, relative to the dimension text height, as set by DIMTXT. Only applies if DIMLUNIT=Fractional.

Type:	Real
Saved in:	Drawing
Default value:	1.0

7.121 DIMTFILL system variable

7.121.1 Text fill

Specifies the dimension text background.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: No background or fill 1: Background or fill color matches the background of the drawing window 2: Background or fill color matches the value specified by DIMTFILLCLR

7.122 DIMTFILLCLR system variable

7.122.1 Text fill color

Specifies the dimension text background color when DIMTFILL is set to 2.



Type:	Short
Saved in:	Drawing
Range:	0 to 256
Default value:	0
Possible values:	0: ByBlock 1-255: index 256: ByLayer

7.123 DIMTIH system variable

7.123.1 Text inside align

Specifies the position of dimension text inside the extension lines. DIMTIH does not apply to ordinate dimensions.

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	Off (0): Aligned with dimension line On (1): Horizontal

7.124 DIMTIX system variable

7.124.1 Text inside

Draws text between extension lines, even if there is insufficient room. DIMTIX does not apply to radius and diameter dimensions.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't force text between extension lines On (1): Force text between extension lines



7.125 DIMTM system variable

7.125.1 Tolerance limit lower

Specifies the minimum (lower) tolerance limit for dimension text when DIMTOL or DIMLIM is on.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.126 DIMTMOVE system variable

7.126.1 Text movement

Specifies how dimension text can move.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Move dimension line with dimension text 1: Add leader when dimension text is moved 2: Allow text to be moved freely without a leader

7.127 DIMTOFL system variable

7.127.1 Dim line forced

Specifies whether a dimension line is drawn between the extension lines even when the text is placed outside.

Type:	Boolean
Saved in:	Drawing
Default value:	Off



Possible values:	Off (0): Don't force dimension lines even when text is outside On (1): Force dimension lines even when text is outside
------------------	---

7.128 DIMTOH system variable

7.128.1 Text outside align

Forces the dimension text outside the extension lines to be placed horizontally.

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	Off (0): Aligned with dimension line On (1): Horizontal

7.129 DIMTOL system variable

7.129.1 Tolerance display

Adds tolerances to dimension text.

Type:	Boolean
Saved in:	Drawing
Range:	
Default value:	Off
Possible values:	Off (0): Don't display tolerance On (1): Display tolerance

7.130 DIMTOLJ system variable

7.130.1 Tolerance pos vert

Specifies the vertical position for tolerance values relative to the primary dimension text.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Bottom 1: Middle 2: Top

7.131 DIMTP system variable

7.131.1 Tolerance limit upper

Specifies the maximum (upper) tolerance limit for dimension text when DIMTOL or DIMLIM is on.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.132 DIMTSZ system variable

7.132.1 Dim tick size

Specifies the size of tick marks drawn instead of arrowheads for linear, radius and diameter dimensioning. If the value is zero, arrowheads are drawn.

Type:	Real
Saved in:	Drawing
Default value:	0.0
Possible values:	0: Draw arrowheads >0: Draw oblique strokes instead of arrowheads



7.133 DIMTVP system variable

7.133.1 Text offset vert

Specifies the vertical position of dimension text above or below the dimension line when DIMTAD=0. The offset equals the product of DIMTVP and the height of the dimension text (DIMTXT). Setting DIMTVP to 1.0 is equivalent to DIMTAD=1

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.134 DIMTXSTY system variable

7.134.1 Text style

Specifies the style of the dimension text.

Type:	String
Saved in:	Drawing
Default value:	Standard

7.135 DIMTXT system variable

7.135.1 Text height

Specifies the dimension text height if the text style as defined in DIMTXSTY has no fixed height.

Type:	Real
Saved in:	Drawing
Default value:	.18

7.136 DIMXTDIRECTION system variable

7.136.1 Text direction

Specifies the dimension text reading direction.



Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Left to right On (1): Right to left

7.137 DIMTZIN system variable

7.137.1 Tolerance suppress zeros

Specifies the suppression of zeros in tolerance values. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	0
Possible options:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions

7.138 DIMUNIT system variable

7.138.1 Dim unit type (Obsolete)

Replaced by DIMLUNIT and DIMFRAC.

Type:	Short
Saved in:	Drawing
Range:	1 to 8



Default value:	2
Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural (stacked) 5: Fractional (stacked) 6: Architectural 7: Fractional 8: Windows control panel

7.139 DIMUPT system variable

7.139.1 Place text manually

Allows user-positioned text.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Cursor controls only the dimension line location On (1): Cursor controls both the text position and the dimension line location

7.140 DIMZIN system variable

7.140.1 Suppress dim zeros

Suppresses leading and/or trailing zeros in the primary unit. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	0



Possible options:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions
-------------------	--

7.141 DISPLAYAXES system variable

7.141.1 Display Axes

Controls the display of the axis of linear structural elements such beams and columns.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible options:	Off (0): Do not display axes On (1): Display axes

7.142 DISPLAYAXESFORMEP system variable

7.142.1 Display axes

Controls the display of the MEP element axes.

Type:	Boolean
Saved in:	Registry
Default value:	0

7.143 DISPLAYSCALING system variable

7.143.1 Automatic display scaling

Current display scaling percentage (from system display settings).

BricsCAD only

Read-only



Type:	Short
Saved in:	Not saved
Range:	50 to 1000
Default value:	100

7.144 DISPLAYSIDESANDENDS system variable

7.144.1 Display sides and ends

When ON, the sides and ends of linear solids highlight on hovering if the Quad is ON or bitcode 1 of the SELECTIONPREVIEW system variable is selected. The variable is available in the BIM and Ultimate license level only.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display sides and ends On (1): Display side and ends

7.145 DISPLAYSNAPMARKERINALLVIEWS system variable

7.145.1 Snap marker in all views

Specifies whether the snap marker displays in all viewports.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't display snap marker in all views On (1): Display snap marker in all views



7.146 DISPLAYTOOLTIPS system variable

7.146.1 Snap tooltips

Toggles the display of snap tooltips On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable snap tooltips On (1): Enable snap tooltips

7.147 DISPPAPERBKG system variable

7.147.1 Paper background

Enables or disables displaying of paper sheet in paper space.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display paper background On (1): Display paper background

7.148 DISPPAPERMARGINS system variable

7.148.1 Printable area

Enables or disables displaying of printable area of a drawing.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On




Possible values:	Off (0): Don't display printable area On (1): Display printable area
------------------	---

7.149 DISPSILH system variable

7.149.1 Display silhouette curves

Specifies the display of silhouette curves of solid entities in Wireframe modes (2D and 3D) and whether a mesh is drawn or not when a solid entity is hidden in 2D Wireframe mode. To view changes on existing entities, perform a REGEN.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display silhouette curves On (1): Display silhouette curves



7.150 DISTANCE system variable

7.150.1 Distance

Specifies the last calculated distance by the DIST command.

Read-only

Type:	Real
Saved in:	Not saved

7.151 DMAUDITLEVEL system variable

7.151.1 DMAUDIT command, level of details

Specifies whether certain types of errors are reported by the DMAUDIT command. The value is stored as a bitcode using the sum of the values of all selected options.



BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 3
Default value:	1
Possible options:	1: Ignore dynamic range errors 2: Ignore sliver faces

7.152 DMAUTOUPDATE system variable

7.152.1 3D constraints recalculation mode

Specifies if a model automatically updates when 3D constraints are added or edited. If this setting is switched off, command DMUPDATE must be used to update the model.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't update 3D constraints automatically On (1): Update 3D constraints automatically

7.153 DMCONNECTIONCUTTYPE system variable

7.153.1 Connection type

Specifies the type of connection.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1



Default value:	0
Possible values:	0: Smooth 1: Planar

7.154 DMPUSHPULLSUBTRACT system variable

7.154.1 DMPUSHPULL subtract

Specifies if a solid that intersects with other solids during a PUSH/PULL operation subtracts from the existing solid.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Range:	0 to 1
Default value:	Off
Possible values:	Off (0): Disable DMPUSHPULL subtract On (1): Enable DMPUSHPULL subtract

7.155 DMRECOGNIZE system variable

7.155.1 Automatic 3D geometry constraints recognition

Specifies which geometrical relations between the surfaces are maintained direct modeling operations. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	-1 to 1023
Default value:	0



Possible options:	Negative: Switch off automatic 3D geometry constraints recognition 1: Tangent surfaces 2: Coincident planes 4: Parallel planes 8: Perpendicular planes 16: Cylinders perpendicular to planes 32: Coaxial surfaces 64: Cylinders and spheres of equal radius 128: Vertices between 4 or more faces 256: Edges between coincident faces 512: Fix a constrained plane lying in XY/YZ/ZX (compatibility)
-------------------	--

7.156 DOCKPRIORITY system variable

7.156.1 Docking Priority

Specifies the docking priority of top, left, right and bottom docking bars. Changing this preference will take effect only after restarting the application.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 14
Default value:	1
Possible values:	1: Top, Left, Right, Bottom 2: Top, Bottom, Left, Right 3: Top, Left, Bottom, Right 4: Top, Right, Bottom, Left 5: Left, Right, Top, Bottom 6: Left, Top, Bottom, Right 7: Left, Top, Right, Bottom 8: Left, Bottom, Right, Top 9: Right, Top, Left, Bottom 10: Right, Bottom, Left, Top 11: Right, Top, Bottom, Left 12: Bottom, Left, Right, Top 13: Bottom, Left, Top, Right 14: Bottom, Right, Top, Left



7.157 DOCTABPOSITION system variable

7.157.1 Tabs position

Specifies where to display the document tab control.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	0
Possible values:	0: Top 1: Bottom 2: Left 3: Right

7.158 DONUTID system variable

7.158.1 Donut inside diameter

Stores the default inside diameter of a donut.

Type:	Real
Saved in:	Not saved
Default value:	0.5

7.159 DONUTOD system variable

7.159.1 Donut outside diameter

Stores the default outside diameter of a donut.

Type:	Real
Saved in:	Not saved
Default value:	1.0



7.160 DRAGMODE system variable

7.160.1 Entity dragging

Specifies whether entities display dynamically, e.g. when moved or copied.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: No dragging 1: When requested 2: Whenever possible

7.161 DRAGMODEHIDE system variable

7.161.1 Hide original entity when dragging

Specifies whether the original entity should be visible or not when a drag operation is performed.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	1: Hide original entity in 3D Modeling commands. 2: Hide original entity in 2D Drafting commands.

7.162 DRAGMODEINTERRUPT system variable

7.162.1 Dragging interruption mode

Specifies whether the recalculation/redrawing of the model can be interrupted when mouse cursor is being moved (responsive, but may cause blinking, incomplete or disappearing graphics) or every drag iteration must be completed (slow, but graphics is always valid).

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	0: Disabled 1: Enabled

7.163 DRAGOPEN system variable

7.163.1 Drag open

Specifies if a drawing file that is dragged onto the application inserts into the current drawing or opens as a separate drawing.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Insert file 1: Open file

7.164 DRAGP1 system variable

7.164.1 Regen-drag rate

Specifies the regen-drag input sampling rate.

Type:	Short
Saved in:	Registry
Range:	0 to 32767
Default value:	10



7.165 DRAGP2 system variable

7.165.1 Fast-drag rate

Specifies the fast-drag input sampling rate.

Type:	Short
Saved in:	Registry
Range:	0 to 32767
Default value:	25

7.166 DRAGSNAP system variable

7.166.1 Snap dragged entities

Switches entity snapping of dragged entities on or off.

The DRAGSNAP system variable controls the snap behavior while dragging, providing an increased WYSIWIG experience. DRAGSNAP controls whether rubberband dynamics are displayed at the current cursor location or at the current entity snap location. DRAGSNAP applies to all modify commands that display dynamics, such as COPY, PASTECLIP, PASTEBLOCK, MOVE, ROTATE, MIRROR, SCALE and STRETCH.

When DRAGSNAP is off, snap is only in effect during drawing and editing commands; when DRAGSNAP is on, the cursor also snaps when no command is active.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't snap dragged entities On (1): Snap dragged entities

7.167 DRAWINGPATH system variable

7.167.1 Drawings path

Specifies an additional folder in the file dialog for the OPEN and SAVEAS commands. On the Windows platform: the fifth folder in the open file dialog's Places Bar.



BricsCAD only

Type:	String Standard
Saved in:	Preference

7.168 DRAWINGVIEWASM system variable

7.168.1 Assemblies optimization

Enables the use of assembly data structures to optimize generation of drawing views. Toggles between normal analytical hidden line removal (HLR) and ASM_HLR procedure.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

7.169 DRAWINGVIEWFLAGS system variable

7.169.1 Drawing View Flags

Bit flags for drawing views processing.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	Off (0)
Possible values:	Off (0): Disabled parallel generation and update of drawing views On (1): Enabled parallel generation and update of drawing views

7.170 DRAWINGVIEWPRESET system variable

7.170.1 Drawing view preset

Stores the current preset for the VIEWBASE command, the default value is 'None'. Presets specify the types of generated drawings and their placement in the layout.

BricsCAD only



Type:	String
Saved in:	Registry
Default value:	None

7.171 DRAWINGVIEWPRESETHIDDEN system variable

7.171.1 Drawing view hidden lines preset

Stores the current hidden lines preset for the VIEWBASE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't store the current hidden line preset On (1): Store the current hidden line preset

7.172 DRAWINGVIEWPRESETSCALE system variable

7.172.1 Scale for drawing view preset

Stores the annotation scale for current drawing view preset.

BricsCAD only

Type:	String
Saved in:	Registry

7.173 DRAWINGVIEWPRESETTANGENT system variable

7.173.1 Drawing view tangent lines preset

Stores the current tangent lines preset for VIEWBASE command.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't store the current tangent lines preset On (1): Store the current tangent lines preset

7.174 DRAWINGVIEWPRESETTRAILING system variable

7.174.1 Drawing view trailing lines preset

Stores the current trailing lines preset for VIEWBASE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't store the current trailing lines preset On (1): Store the current trailing lines preset

7.175 DRAWINGVIEWQUALITY system variable

7.175.1 Quality of drawing views

Specifies the quality of drawing views.

You can significantly reduce the time needed to generate drawing views by changing the DRAWINGVIEWQUALITY setting to 0. This enables draft-quality drawing views. Such drawing views are internally represented as 3D solids, which makes it impossible to put annotations on their silhouette edges. However, they look very similar to a precise (high-quality) drawing view and you can use them to quickly create layouts.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1



Possible values:	0: Draft quality 1: High quality
------------------	-------------------------------------

7.176 DRAWORDERCTL system variable

7.176.1 Draworder control

Specifies the default behavior for the display of overlapping entities. Use this setting to limit draw order if some editing operations take slightly longer. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible options:	1: Default display of entities with draw order 2: Draw order inheritance

7.177 DWFFORMAT system variable

7.177.1 Default DWF format

Specifies the default format to DWF or DWFX for 3DDWF command.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: DWF 1: DWFX



7.178 DWFFRAME system variable

7.178.1 DWF frame

Specifies the visibility of DWF or DWFx underlay frames.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Hide DWF frames 1: Display and plot DWF frames 2: Display but do not plot DWF frames

7.179 DWFOSNAP system variable

7.179.1 Dwf entity snap

Enable snapping to entities in DWF underlay files.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable DWF entity snap On (1): Enable DWF entity snap

7.180 DWFVERSION system variable

7.180.1 DWF version

Specifies the dwf version for export in dwf format.

BricsCAD only

Type:	Short
Saved in:	Preference



Range:	1 to 10
Default value:	2
Possible values:	1: 3D DWF v6.01 2: Binary DWF v6.0 3: Zipped Ascii Encoded 2D Stream DWF v6.0 4: Compressed DWF v5.5 5: Binary DWF v5.5 6: Ascii DWF v5.5 7: Compressed DWF v4.2 8: Binary DWF v4.2 9: Ascii DWF v4.2 10: XPS DWFx

7.181 DWGCHECK system variable

7.181.1 Drawing check

Executes an automatic data integrity check when opening a drawing.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: Warn on potential problem 1: Warn on potential problem and on other application 2: Notify on potential problem 3: Notify on potential problem, warn on other application

7.182 DWGCODEPAGE system variable

7.182.1 Drawing codepage

Displays the drawing code-page for text in drawings (same value as SYSCODEPAGE).

Read-only

Type:	String
-------	--------



Saved in:	Drawing
-----------	---------

7.183 DWGGUIDCLOUDAI system variable

7.183.1 Drawing Guid

Unique GUID for this drawing

BricsCAD only

Type:	String
Saved in:	Drawing
Default value:	" "

7.184 DWGNAME system variable

7.184.1 Drawing name

Shows the name of the current drawing.

Read-only

Type:	String
Saved in:	Not saved

7.185 DWGPREFIX system variable

7.185.1 Drawing prefix

Shows the folder path of the current drawing.

Read-only

Type:	String Standard
Saved in:	Not saved

7.186 DWGTITLED system variable

7.186.1 Drawing titled

Specifies if the current drawing has been named.

Read-only



Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Drawing has not been named On (1): Drawing has been named

7.187 DXEVAL system variable

7.187.1 Data extraction update mode

Specifies the notification for data extraction tables. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 511
Default value:	12
Possible options:	0: No notification 1: Notification on open 2: Notification on save 4: Notification on plot 8: Notification on publish 16: Notification on ETRANSMIT or ARCHIVE 32: Notification on save + automatic update 64: Notification on plot + automatic update 128: Notification on publish + automatic update 256: Notification on ETRANSMIT or ARCHIVE + automatic update

7.188 DXFTEXTADJUSTALIGNMENT system variable

7.188.1 Dxf text adjust alignment

Specifies whether alignment is adjusted when text is loaded from DXF file.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't adjust alignment On (1): Adjust alignment

7.189 DYNCONSTRAINTMODE system variable

7.189.1 Dynamic Constraint Mode

Specifies the visibility of hidden dimensional constraints when the constrained entity is selected.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display hidden dimensional constraints when the constrained entities are selected. On (1): Display hidden dimensional constraints when the constrained entities are selected.

7.190 DYNDIGRIP system variable

7.190.1 Show dynamic dimensions

Specifies which dynamic dimensions are shown. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 31
Default value:	31



Possible options:	0: None 1: Resulting length 2: Extended length 4: Absolute angle 8: Relative angle 16: Arc radius
-------------------	--

7.191 DYNDIMAPERTURE system variable

7.191.1 Dynamic dimension aperture

Specifies the radius (in pixels) around cursor. This parameter is used only when DYNMODE flag is 16 'Nearest entity dynamic dimensions'. The nearest entity is looked for between entities which intersect or are inside this radius.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 500
Default value:	20
Unit	pixels

7.192 DYNDIMCOLORHOT system variable

7.192.1 Dynamic dimension hot color

Specifies the color of dynamic dimensions when moving grip points.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	142



7.193 DYNDIMCOLORHOVER system variable

7.193.1 Dynamic dimension hover color

Specifies the color of dynamic dimensions when hovering over a grip point.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	142


7.194 DYNDIMDISTANCE system variable

7.194.1 Dynamic dimension distance

Specifies a factor for the distance between the dynamic dimension line and the grip points being dimensioned (default: 0.0).

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 10.0
Default value:	1.0



7.195 DYNDIMLINETYPE system variable

7.195.1 Dynamic dimension linetype

Specifies the linetype of dynamic dimensions when moving grip points.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	-1 to 2
Default value:	0
Possible values:	-1: Current 0: Continuous 1: Dotted 2: Dashed

7.196 DYNDIVIS system variable

7.196.1 Dynamic dimension visibility

Specifies how many dynamic dimensions are displayed while moving grips.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Only the first dynamic dimension 1: Only the first two dynamic dimensions 2: All dynamic dimensions, as specified by DYNDIGRIP

7.197 DYNINPUTTRANSPARENCY system variable

7.197.1 Transparency of dynamic input fields

Specifies the transparency of dynamic input fields. A value of 0 sets the fields to be fully transparent, and a value of 100 sets the fields to be fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference



Range:	0 to 100
Default value:	90

7.198 DYNMODE system variable

7.198.1 Dynamic input mode

Turns dynamic input features on and off. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	-31 to 31
Default value:	3
Possible options:	Negative: Switch all off temporarily 0: No dynamic input 1: Dynamic input at pointer (not supported) 2: Editable dynamic dimensions 4: Tracking dynamic dimensions 8: Nearest entity by UCS X/Y axes dynamic dimensions 16: Nearest entity dynamic dimensions

7.199 DYNPICOORDS system variable

7.199.1 Default mode for dynamic coordinates input

Specifies the default mode in which coordinates are entered during dynamic input.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Relative 1: Absolute



8. E

8.1 EDGEMODE system variable

8.1.1 Edge mode

Specifies how cutting and boundary edges are checked with the TRIM and EXTEND commands, with or without extension.


Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Use the selected edge without an extension On (1): Extend or trim the selected entity to an imaginary extension of the cutting or boundary edge

8.2 ELEVATION system variable

8.2.1 Elevation

Specifies the current elevation for new entities relative to the current UCS.

Type:	Real
Saved in:	Drawing
Default value:	0.0





8.3 ELEVATIONATBREAKLINECROSSINGS system variable

8.3.1 Elevation at breakline crossings

Defines elevation at breakline crossings (Minimal, Maximal, Average).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Minimal 1: Maximal 2: Average

8.4 ENABLEATTRACTION system variable

8.4.1 Grips attraction

Toggles the magnetism of entity grips.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable grips attraction On (1): Enable grips attraction

8.5 ENABLEBIMBKUPDATE system variable

8.5.1 Enable sections update in background

Defines whether BIMBKUPDATE is enabled.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	0

8.6 ENABLEHYPERLINKMENU system variable

8.6.1 Hyperlink menu

Toggles the hyperlink menu On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable hyperlink menu On (1): Enable hyperlink menu

8.7 ENABLEHYPERLINKTOOLTIP system variable

8.7.1 Hyperlink tooltip

Toggles the display of the hyperlink tooltip On/Off.

BricsCAD only

Type:	Preference
Saved in:	Off
Possible values:	Off (0): Disable hyperlink tooltip On (1): Enable hyperlink tooltip

8.8 ERN0 system variable

8.8.1 Error number

Reports the error type which occurred in a LISP program.

Read-only

Type:	Short
-------	-------



Saved in:	Not saved
Default value:	0

8.9 EXPERT system variable

8.9.1 Expert

Specifies the display of certain prompts. If prompts are suppressed by EXPERT, the operation proceeds as though you entered y(es) at the suppressed prompt. EXPERT can affect scripts, menu macros, LISP and command functions.

Type:	Short
Saved in:	Not saved
Range:	0 to 5
Default value:	0
Possible values:	0: Issue all prompts normally 1: Suppress regen and layer off prompts 2: Also suppress block already defined (BLOCK) and file already exists (SAVE and WBLOCK) prompts 3: Also suppress linetype already loaded prompt 4: Also suppress file already exists (UCS and VPORTS Save) prompts 5: Also suppress dimstyle already exists prompt

8.10 EXPINSALIGN system variable

8.10.1 Explorer Insert Aligned

Align blocks inserted from the Drawing Explorer with selected entities.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't insert blocks aligned On (1): Insert blocks aligned



8.11 EXPINSANGLE system variable

8.11.1 Explorer Insert Angle

Rotation angle used when inserting blocks from the Drawing Explorer.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0
Unit	degrees

8.12 EXPINSFIXANGLE system variable

8.12.1 Explorer Insert Fix Angle

Insert blocks from the Drawing Explorer at a fixed rotation angle.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't insert blocks at fixed angle On (1): Insert blocks at fixed angle

8.13 EXPINSFIXSCALE system variable

8.13.1 Explorer Insert Fix Scale

Insert blocks from the Drawing Explorer at a fixed scale.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



Possible values:	Off (0): Don't insert blocks at fixed scale On (1): Insert blocks at fixed scale
------------------	---

8.14 EXPINSSCALE system variable

8.14.1 Explorer Insert Scale

Scale factor used when inserting blocks from the Drawing Explorer.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	1.0

8.15 EXPLMODE system variable

8.15.1 Explode mode

Specifies whether EXPLODE applies to nonuniformly scaled (NUS) blocks.

Type:	Boolean
Saved in:	Registry
Range:	On
Possible values:	Off (0): Don't explode nonuniformly scaled blocks On (1): Explode nonuniformly scaled blocks

8.16 EXPORT3DPDFWRITER system variable

8.16.1 3D PDF writer

Defines the writer to save 3D PDF files.

Type:	Short
Saved in:	Registry
Default value:	1



Possible values:	0: Communicator 3D PDF writer 1: Internal 3D PDF writer
------------------	--

8.17 EXPORTACISASSEMBLYWRITER system variable

8.17.1 ASAT/ASAB writer

Defines the writer to save ASAT/ASAB files. Internal ASAT/ASAB writer is always used if Communicator is not installed.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Communicator ASAT/ASAB writer 1: Internal ASAT/ASAB writer

8.18 EXPORTACISFORMATVERSION system variable

8.18.1 ACIS export format version

Defines the ACIS file version to export.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0



Possible options:	0: Latest available 1: R18 2: R19 3: R20 4: R21 5: R22 6: R23 7: R24 8: R25 9: 2016 10: 2017 11: 2018 12: 2019 13: 2020 14: 2021
-------------------	--

8.19 EXPORTCATIAV4FORMATVERSION system variable

8.19.1 CATIA V4 export format version

Defines CATIA V4 file version to export.

Type:	Short
Saved in:	Registry
Range:	0 to 6
Default value:	0
Possible values:	0: Latest available 1: 4.1.9 2: 4.2.0 3: 4.2.1 4: 4.2.2 5: 4.2.3 6: 4.2.4

8.20 EXPORTCATIAV5FORMATVERSION system variable

8.20.1 CATIA V5 export format version

Defines CATIA V5 file version to export.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 16
Default value:	0
Possible values:	0: Latest available 1: CATIA V5 R16 2: CATIA V5 R17 3: CATIA V5 R18 4: CATIA V5 R19 5: CATIA V5 R20 6: CATIA V5 R21 7: CATIA V5 R22 8: CATIA V5 R23 9: CATIA V5 R24 10: CATIA V5 R25 11: CATIA V5-6 R2016 12: CATIA V5-6 R2017 13: CATIA V5-6 R2018 14: CATIA V5-6 R2019 15: CATIA V5-6 R2020 16: CATIA V5-6 R2021

8.21 EXPORTGEOMETRYFLAGS system variable

8.21.1 Export Geometry Flags

Controls geometry representation in IGES and STEP formats. The Split Pcurves at G1 Discontinuities flag is currently supported only when exporting without product structure.

Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	0
Possible values:	01: Convert Analytical Curves to Splines 02: Convert Analytical Surfaces to Splines 04: Split Pcurves at G1 Discontinuities 08: Split Periodic Faces



8.22 EXPORTHIDDENPARTS system variable

8.22.1 Hidden parts

Defines hidden parts processing mode.

Entities can be invisible because of:

- The result of the HIDEOBJECTS command.
- Sitting on a hidden layer.
- Owned by an invisible component.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Export and hide if possible: Exports hidden entities. If the target format supports hidden entities, hidden entities in the source document will be hidden also in target document. 1: Do not export: Invisible entities are skipped.

8.23 EXPORTMODELSPACE system variable

8.23.1 Export model space

Specifies what part of the drawing to export from model space to a DWF, DWFx or PDF file.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Display 1: Extents 2: Window

Note: The EXPORTMODELSPACE, EXPORTPAPERSPACE and EXPORTPAGESETUP system variables currently are dummies for .dwf exports.



8.24 EXPORTPAGESETUP system variable

8.24.1 Export page setup

Specifies if the current page setup is used when exporting to a DWF, DWFx or PDF file.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Default 1: Override

Note: The EXPORTMODELSPACE, EXPORTPAPERSPACE and EXPORTPAGESETUP system variables currently are dummies for .dwf exports.

8.25 EXPORTPAPERSPACE system variable

8.25.1 Export paper space

Specifies what part of the drawing to export from paper space to a DWF, DWFx or PDF file.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Current layout 1: All layouts

Note: The EXPORTMODELSPACE, EXPORTPAPERSPACE and EXPORTPAGESETUP system variables currently are dummies for .dwf exports.

8.26 EXPORTPARASOLIDFORMATVERSION system variable

8.26.1 Parasolid export format version

Defines the Parasolid file version to export.



Type:	Short
Saved in:	Registry
Range:	0 to 22
Default value:	0
Possible values:	0: Latest available 1: Parasolid 12 2: Parasolid 13 3: Parasolid 14 4: Parasolid 15 5: Parasolid 16 6: Parasolid 17 7: Parasolid 18 8: Parasolid 19 9: Parasolid 20 10: Parasolid 21 11: Parasolid 22 12: Parasolid 23 13: Parasolid 24 14: Parasolid 25 15: Parasolid 26 16: Parasolid 27 17: Parasolid 28 18: Parasolid 29 19: Parasolid 30 20: Parasolid 31 21: Parasolid 32 22: Parasolid 33

8.27 EXPORTPRODUCTSTRUCTURE system variable

8.27.1 Product structure

Defines if Product structure is exported.

The option [1] is valid for Pro (or higher) license level. It works as [0] otherwise.

Type:	Short
Saved in:	Registry
Range:	0 to 1



Default value:	1
Possible values:	0: No product structure: Exports a flat structure without components in the target document, whether the BricsCAD® document has a product structure or not. 1: Export product structure: Exports the BricsCAD® product structure data (if existing) to the target document.

8.28 EXPORTSTEPFORMATVERSION system variable

8.28.1 STEP export format version

Defines the STEP file version to export.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: AP203 1: AP214 2: AP242

8.29 EXPORTXCGMFORMATVERSION system variable

8.29.1 XCGM export format version

Defines the XCGM file version to export.

Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	0



Possible values:	0: Latest available 1: CGM R2013x 2: CGM R2014 3: CGM R2014x 4: CGM R2015x B1 5: CGM R2015x B5 6: CGM R2015x B5 SP1 7: CGM R2016 1.0 8: CGM R2016 1.1 9: CGM R2017 1.0 10: CGM R2017 1.1 11: CGM R2018 1.0 12: CGM R2018 1.1 13: CGM R2019 1.0 14: CGM R2020 1.0 15: CGM R2021 1.0
------------------	---

8.30 EXTMAX system variable

8.30.1 Extents maximum

Shows the coordinates of the upper-right point of the drawing extents. It increases as new entities are created outside the existing extents.

Read-only

Type:	3D point
Saved in:	Drawing

8.31 EXTMIN system variable

8.31.1 Extents minimum

Shows the coordinates of the lower-left point of the drawing extents.

Read-only

Type:	3D point
Saved in:	Drawing



8.32 EXTNAMES system variable

8.32.1 Extend names

Specifies the parameters for the names of named entities (e.g. linetypes and layers) saved in symbol tables.

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	Off (0): Names up to 31 characters On (1): Names up to 255 characters

8.33 EXTRUDEINSIDE system variable

Resolve intersection with parent entity.

Determines how to modify the parent entity when it intersects with the extruded/revolved entity when the **Auto** option of the EXTRUDE or REVOLVE command is selected. Parent entities are entities that touch the contour from which the extruded/revolved entity is created.

The EXTRUDEINSIDE system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0 - for Workspaces Drafting and Modeling 1 - for Workspaces Mechanical and BIM
Possible options:	0: Do not modify the parent entity. 1: Subtract the created entity from the parent entity. 2: Unite the created entity with the parent entity.

8.34 EXTRUDEOUTSIDE system variable

Resolve touching to parent entity.



Determines how to modify the parent entity when it touches the extruded/revolved entity when the **Auto** option of the EXTRUDE or REVOLVE command is selected. Parent entities are entities that touch the contour from which the extruded/revolved entity is created.

The EXTRUDEOUTSIDE system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0 - for Workspaces Drafting and Modeling 1 - for Workspaces Mechanical and BIM
Possible options:	0: Do not modify the parent entity. 1: Subtract the created entity from the parent entity. 2: Unite the created entity with the parent entity.



9. F

9.1 FACETRATIO system variable

9.1.1 Faceting aspect ratio

Specifies the aspect ratio of faceting for cylindrical and conic ACIS solids.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Creates an N by 1 mesh for cylindrical and conic ACIS solids 1: Creates an N by M mesh for cylindrical and conic ACIS solids

9.2 FACETRES system variable

9.2.1 Facet resolution

Specifies the smoothness of shaded, rendered and hidden lines views. For large values there can be significant impact on memory usage and performance.

Type:	Real
Saved in:	Drawing
Range:	0.01 to 10.0
Default value:	0.5

9.3 FBXEXPORTCAMERAS system variable

9.3.1 Fbx Export Cameras

Specifies whether to export the cameras from model space.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	On
Possible values:	Off (0): Disable export of cameras On (1): Enable export of cameras

9.4 FBXEXPORTENTITIES system variable

9.4.1 Fbx Export Entities

Specifies whether to export the entities from model space.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable export of entities On (1): Enable export of entities

9.5 FBXEXPORTENTITIESSELTYPE system variable

9.5.1 Fbx entities to export

Specifies the type of displayed entities that gets exported.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Visible Entities 1: Selected Entities



9.6 FBXEXPORTLIGHTS system variable

9.6.1 Fbx Export Lights

Specifies whether to export the lights from model space.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable export of lights On (1): Enable export of lights

9.7 FBXEXPORTMATERIALS system variable

9.7.1 Fbx Export Materials

Specifies whether to export the materials from model space.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable export of materials On (1): Enable export of materials

9.8 FBXEXPORTTEXTURES system variable

9.8.1 Fbx Export Textures

Set type for the export of materials.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2



Default value:	0
Possible values:	0: Embed 1: Reference 2: Copy textures to location

9.9 FBXEXPORTTEXTURESPATH system variable

9.9.1 FBX Export Textures path

Specifies the folder path where textures are copied when exporting a model to FBX file format. This setting is only used when the FBXEXPORTTEXTURES system variable is set to 2.

BricsCAD only

Type:	String Standard
Saved in:	Preference

9.10 FEATURECOLORS system variable

9.10.1 Feature colors

Specifies if the solid faces are colored by specified color of related feature.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	ON
Possible options:	On (1): Solid faces are colored by specified color of related feature Off (0): All feature faces are colored with the default 3d solid color.

9.11 FIELDDISPLAY system variable

9.11.1 Field display

Specifies whether a gray fill is used to display a field.

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): No gray background On (1): Gray background

9.12 FIELDEVAL system variable

9.12.1 Field update mode

Specifies the way fields are updated. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 31
Default value:	31
Possible options:	0: Not updated 1: Updated on open 2: Updated on save 4: Updated on plot 8: Updated on use of ETRANSMIT 16: Updated on regeneration

Note: Date fields are only updated by the UPDATEFIELD command; they are not automatically updated based on the FIELDEVAL system variable value.

9.13 FILEDIA system variable

9.13.1 File dialog

Toggles the display of file dialog boxes. If FILEDIA is Off, you can still get a file dialog if you type a tilde (~) at the command prompt. This procedure also counts for LISP functions and command fields in tool definitions.

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't display file dialog boxes On (1): Display file dialog boxes
------------------	---

9.14 FILLETRAD system variable

9.14.1 Fillet radius

The last radius used with the FILLET command.

Type:	Real
Saved in:	Drawing
Default value:	0.5

9.15 FILLETWELDINGCOMBINEADJACENT system variable

9.15.1 Combine adjacent fillet welds

Enables combining adjacent fillet weld segments into one fillet welding feature.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't combine adjacent fillet weld segments. On (1): Combine adjacent fillet weld segments.

9.16 FILLETWELDINGMAXGAPRATIO system variable

9.16.1 Maximal ratio of a gap to a weld size

Sets the default maximal ratio of a gap between welding parts to a fillet weld size.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 0.8



Default value:	0.4
----------------	-----

9.17 FILLETWELDINGZSIZE system variable

9.17.1 Default fillet weld Z size

Sets the default Z-size of the symmetric fillet weld.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 50
Default value:	5

9.18 FILLMODE system variable

9.18.1 Fill mode

Specifies whether multilines, traces, solids, hatches (including solid-fill), and wide polylines are filled in. If FILLMODE is off, all filled entities display and print as outlines, this will also reduce the time it takes to display or print a drawing.

Type:	Boolean
Saved in:	Drawing
Range:	On
Possible values:	Off (0): Entities are not filled On (1): Entities are filled

9.19 FITLINEFITARCMODE system variable

9.19.1 FitLine FitArc mode

The FITLINEFITARCMODE system variable sets the values for the options Use entire drawing, Fit in 3d, and Delete original entities after fitting, that are used by the FITLINE and FITARC commands. The value is stored as a bit code using the sum of the values of all selected options.

Type:	Byte
-------	------



Saved in:	Registry
Range:	0 to 255
Default value:	0
Possible values:	0: None 1: Use entire drawing 2: Fit in 3D 4: Delete original entities after fitting

9.20 FITTINGRADIUSTYPE system variable

9.20.1 Fitting Radius Type

Defines the default flow fitting radius type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

9.21 FITTINGRADIUSVALUE system variable

9.21.1 Fitting Radius Value

Defines the default flow fitting radius value.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1.5



9.22 FONALT system variable

9.22.1 Alternate font

Specifies the font which will be used if a text font cannot be found.

Type:	String
Saved in:	Registry
Default value:	simplex.shx

9.23 FONTMAP system variable

9.23.1 Font mapping file

Specifies the font mapping file.

Type:	String
Saved in:	Registry
Default value:	default.fmp

9.24 FRAME system variable

9.24.1 Frame

Specifies the visibility of frames for external references, images and underlays. It overrides the individual IMAGEFRAME, DWFFRAME, PDFFRAME, DGNFRAME, and XCLIPFRAME settings.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible values:	0: Hide frames 1: Display and plot frames 2: Display but do not plot frames 3: Use individual settings for different underlays, external references and images



9.25 FRAMESELECTION system variable

9.25.1 Frame selection

Specifies whether the hidden frame of an image, underlay, clipped xref, or wipeout can be selected.

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): Hidden frames cannot be selected On (1): Hidden frames can be selected

9.26 FRONTZ system variable

9.26.1 Front clipping plane offset

Specifies the current viewport's front clipping plane offset from the target plane, expressed in drawing units. Clipping planes are used in the CLIPPING option of the DVIEW command.

Type:	Real
Saved in:	Drawing
Default value:	0.0

9.27 FULLOPEN system variable

9.27.1 Full open

Indicates the state of the current drawing: partially opened or fully opened.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Possible values:	0: Drawing is partially open 1: Drawing is fully open



10. G

10.1 GEARTEETHNUMBER system variable

10.1.1 Maximum number of sprocket teeth

Defines the number of teeth for sprocket parts created with the -BMHARDWARE command. Use this option to insert sprockets with simplified or full geometry.

Прим.: This number must be greater or equal to the number of teeth of the inserted sprocket to create a sprocket with full geometry. 1000 is enough to insert any sprocket from the library with a full set of teeth.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	1

10.2 GENERATEASSOCATTRS system variable

10.2.1 Generate associative attributes

Specifies whether associative attributes are generated for 3D entities.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Possible values:	Off (0): Do not generate associative attributes for 3D entities On (1): Generate associative attributes for 3D entities

10.3 GENERATEASSOCVIEWS system variable

10.3.1 Generate associative drawings

Specifies associativity between the 3D model and generated views (VIEWBASE) and calculated drawings (BIMSECTIONUPDATE). As a result dimensions are updated in the associated paperspace viewports and BIM section drawings.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Workspace
Default value:	Off
Possible values:	Off (0): Disable associative dimensions On (1): Enable associative dimensions

10.4 GEOLATLONGFORMAT system variable

10.4.1 Geographic latitude/longitude format

Specifies the format of geographical latitude and longitude values.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Decimal degrees 1: Degrees/minutes/seconds

10.5 GEOMARKERVISIBILITY system variable

10.5.1 Geographic marker visibility

Specifies the visibility of the geographic marker.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Geographic marker is not visible On (1): Geographic marker is visible



10.6 GEOMRELATIONS system variable

10.6.1 Geometric relationship indication

Specified geometric relationships are recognized during dragging 2D entity. And dragged entity is adjusted to satisfy recognized relationship. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	0
Possible options:	1: Recognize tangency relation 2: Recognize perpendicularity relation

10.7 GETSTARTED system variable

10.7.1 Get Started

Specifies whether the Launcher dialog is displayed each time BricsCAD starts up.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show Launcher dialog On (1): Show Launcher dialog

10.8 GFANG system variable

10.8.1 Gradient fill angle

Specifies the angle of a gradient fill.

Type:	Real
-------	------



Saved in:	Not saved
Default value:	0.0

10.9 GFCLR1 system variable

10.9.1 Gradient fill primary color

The first color of a gradient fill.

Type:	String
Saved in:	Not saved
Default value:	5

10.10 GFCLR2 system variable

10.10.1 Gradient fill secondary color

The second color of a gradient fill.

Type:	String
Saved in:	Not saved
Default value:	7

10.11 GFCLRLUM system variable

10.11.1 Gradient fill tint level

Specifies the tint intensity in a one-color gradient fill.

Type:	Real
Saved in:	Not saved
Default value:	1.0



10.12 GFCLRSTATE system variable

10.12.1 Number of colors for a gradient fill

Specifies number of colors (one or two) for a gradient fill.

Type:	Boolean
Saved in:	Not saved
Default value:	0
Possible values:	Off (0): Two colors On (1): One color

10.13 GFNAME system variable

10.13.1 Gradient fill name

Specifies the pattern of a gradient fill.

Type:	Short
Saved in:	Not saved
Range:	1 to 9
Default value:	1
Possible values:	1: LINEAR 2: CYLINDER 3: INVCYLINDER 4: SPHERICAL 5: HEMISPHERICAL 6: CURVED 7: INVSPHERICAL 8: INVHEMISPHERICAL 9: INVCURVED

10.14 GFSHIFT system variable

10.14.1 Gradient fill shift

Specifies whether the pattern in a gradient fill is centered or is shifted up and to the left.



Type:	Boolean
Saved in:	Not saved
Default value:	0
Possible values:	Off (0): Centered On (1): Shifted

10.15 GLSWAPMODE system variable

10.15.1 GL Swap Mode

Specifies the swap method used when drawing with the GL engine. Depending on the used hardware driver, the visual effect may differ by choosing between these options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 4
Default value:	2
Possible values:	0: Call glCopyPixels to copy back to front, don't call glXSwapBuffers. 1: Call glCopyPixels to copy back to front, then call glXSwapBuffers. 2: Call glXSwapBuffers, don't call glCopyPixels. 3: Call glXSwapBuffers, then call glCopyPixels to copy front to back. 4: Do nothing - for testing purposes only.

10.16 GRADIENTCOLORBOTTOM system variable

10.16.1 Background gradient color bottom

Specifies the default bottom color for gradient backgrounds and also the default for solid view backgrounds.

BricsCAD only

Type:	String
Saved in:	Preference



Default value:	RGB:210,210,210"
----------------	------------------

10.17 GRADIENTCOLORMIDDLE system variable

10.17.1 Background gradient color middle

Specifies the default middle color for gradient backgrounds. This only applies if GRADIENTMODE is set to Three-color gradient.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:250,250,250"

10.18 GRADIENTCOLORTOP system variable

10.18.1 Background gradient color top

Specifies the default top color for gradient backgrounds.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White

10.19 GRADIENTMODE system variable

10.19.1 Background gradient mode

Specifies if and how a gradient is to be applied in the default background (this is only used as a default value for the Background dialog).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2



Default value:	0
Possible values:	0: No gradient background 1: Two-color gradient (top/bottom) 2: Three-color gradient (top/middle/bottom)

10.20 GRIDAXISCOLOR system variable

10.20.1 Grid axis color

Specifies the color of the grid axis lines.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	254

10.21 GRIDDISPLAY system variable

10.21.1 Grid display

Specifies how the grid is displayed. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	2
Possible options:	0: Restrict to LIMITS area 1: Display beyond LIMITS area 2: Adaptive grid display 4: Allow subdivision below grid spacing 8: Follow Dynamic UCS



10.22 GRIDMAJOR system variable

10.22.1 Grid major

Specifies the frequency of major versus minor gridlines.

Type:	Short
Saved in:	Drawing
Range:	1 to 100
Default value:	5

10.23 GRIDMAJORCOLOR system variable

10.23.1 Grid major color

Specifies the color of the major grid lines.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Possible values:	251

10.24 GRIDMINORCOLOR system variable

10.24.1 Grid minor color

Specifies the color of the minor grid lines.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	250



10.25 GRIDMODE system variable

10.25.1 Grid mode

Turns the grid on or off.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Grid off On (1): Grid on

10.26 GRIDSTYLE system variable

10.26.1 Grid style

Specifies whether the grid is displayed with dots or lines. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	0
Possible options:	0: Lined grid 1: Dotted grid in 2D model space 2: Dotted grid in Block Editor 4: Dotted grid in Sheet/Layout

10.27 GRIDUNIT system variable

10.27.1 Grid unit

Specifies the X and Y grid spacing for the current viewport.

Type:	2D point
Saved in:	Drawing



Default value:	0.5,0.5
----------------	---------

10.28 GRIDXYZTINT system variable

10.28.1 Grid XYZ tint

Specifies whether the XYZ tints are to be applied over the color of the grid lines. (XYZ tints are stored in COLORX, COLORY, COLORZ variables). The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	1
Possible options:	1: Apply XYZ tint to grid axis lines 2: Apply XYZ tint to major grid lines 4: Apply XYZ tint to minor grid lines

10.29 GRIPBLOCK system variable

10.29.1 Grips in blocks

Specifies the display of grips for entities within a selected block. The insertion point of the block is displayed regardless of this setting.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Doesn't display grips of entities within the block On (1): Displays grips of entities within the block



10.30 GRIPCOLOR system variable

10.30.1 Grip color

Specifies the color of unselected grips (drawn as box outlines). Values between 1 and 255 are accepted.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	72

10.31 GRIPDYN COLOR system variable

10.31.1 Dynamic grip color

Specifies the color of custom grips for dynamic blocks. Values between 1 and 255 are accepted. (Not yet supported)

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	140

10.32 GRIPHOT system variable

10.32.1 Selected grip color

Specifies the color of selected grips (hot grips), which are drawn as filled boxes.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	240



10.33 GRIPHOVER system variable

10.33.1 Hover grip color

Specifies the fill color of an unselected grip when the cursor pauses over it. Values between 1 and 255 are accepted.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	150

10.34 GRIPOBJLIMIT system variable

10.34.1 Grip object limit

The display of grips is suppressed, if the number of selected entities exceeds the value of this settings variable. If set to 0, grips are always displayed. Values between 0 and 32767 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 32767
Default value:	100

10.35 GRIPS system variable

10.35.1 Grips

Specifies the display of grips on selected entities.

Type:	Short
Saved in:	Registry
Default value:	2



Possible values:	0: Turn off grips 1: Turn on endpoint grips 2: Turn on endpoint and midpoint grips
------------------	--

10.36 GRIPSIZE system variable

10.36.1 Grip size

Specifies the size of the grip box (in pixels). Values between 1 and 255 are accepted.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	4

10.37 GRIPTIPS system variable

10.37.1 Grip tips

Specifies whether grip tips display when the cursor hovers over grips on custom entities or dynamic blocks that support grip tips. (Not yet supported)

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display grip tips On (1): Display grip tips

10.38 GSDEVICETYPE2D system variable

10.38.1 2D graphic system device

Specifies the current graphic system device for wireframe output. The GDI+ option is strongly recommended. Additional options are available only for testing purposes.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: GDI+ 1: OpenGL (not recommended, available only for testing) 2: RedOpenGL (not recommended, available only for testing) 3: GDI (not recommended, available only for testing)

10.39 GSDEVICETYPE3D system variable

10.39.1 3D graphic system device

Set current graphic system device for rendered output for Hidden, Gouraud (with edges) and Flat (with edges) visual styles. Other rendered visual styles (such as modeling, realistic) will always use RedOpenGL device.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: OpenGL 1: RedOpenGL



11. H

11.1 HALOGAP system variable

11.1.1 Halo gap

Specifies whether a gap is to be displayed if an entity is hidden by another entity. To be specified as a percent of one drawing unit, independent of the zoom level. HALOGAP applies to 2D views only.

Type:	Short
Saved in:	Drawing
Range:	0 to 100
Default value:	0

11.2 HANDLES system variable

11.2.1 Publish Handles

Shows whether object handles can be accessed by applications or not.

Read-only

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Handles cannot be accessed by applications On (1): Handles can be accessed by applications

11.3 HANDSEED system variable

11.3.1 Handle seed

Starting handle for creating new entities.

BricsCAD only

Read-only

Type:	String
-------	--------



Saved in:	Not saved
Default value:	25

11.4 HIDEPRECISION system variable

11.4.1 Hide and shade precision

Specifies the accuracy of hides and shades. If set to 1 (double precision) more memory is needed, which might affect performance.

Type:	Short
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Double precision off On (1): Double precision on

11.5 HIDESYSTEMPRINTERS system variable

11.5.1 Hide system printers

Specifies whether system printers are shown.

Type:	Boolean
Saved in:	Preference
Default value:	Off

11.6 HIDETEXT system variable

11.6.1 Hide text on HIDE

Specifies whether the HIDE command processes text entities.

Type:	Short
Saved in:	Drawing
Range:	0 to 1



Default value:	1
Possible values:	0: Text is not hidden and does not hide other entities 1: Text is hidden but does hide other entities

11.7 HIDEXREFSCALES system variable

11.7.1 Hide xref scales

Hides scales that come from external references.

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Don't hide xref scales On (1): Hide xref scales

11.8 HIGHLIGHT system variable

11.8.1 Highlight

Specifies if entities highlight on screen when selected.

Note: Does not affect entities selected with grips.

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Entity selection highlighting off On (1): Entity selection highlighting on

11.9 HIGHLIGHTCOLOR system variable

11.9.1 Selection Highlight Color

Specifies which highlight color to be used when GLSelectionHighlightStyle is set to "Use a different color for highlight".

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	142

11.10 HIGHLIGHTEFFECT system variable

11.10.1 Selection Highlight Style

Specifies which highlight method to be used.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: Use line stipple for highlight (default). 1: Use a different color for highlight. 2: Use a thickened line for highlight. 3: Use a different color and thickened line for highlight.

11.11 HORIZONBKG_ENABLE system variable

11.11.1 Horizon background

Specifies whether horizon background should be enabled for perspective views.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable horizon background On (1): Enable horizon background



11.12 HORIZONBKG_GROUNDHORIZON system variable

11.12.1 Ground horizon

Specifies the color of the ground horizon.

Type:	String
Saved in:	Preference
Default value:	RGB:67,74,80"

11.13 HORIZONBKG_GROUNDORIGIN system variable

11.13.1 Ground origin

Specifies the color of the ground origin.

Type:	String
Saved in:	Preference
Default value:	RGB:95,103,112"

11.14 HORIZONBKG_SKYHIGH system variable

11.14.1 Sky high

Specifies the color of the higher regions of the sky.

Type:	String
Saved in:	Preference
Default value:	RGB:204,229,234"

11.15 HORIZONBKG_SKYHORIZON system variable

11.15.1 Sky horizon

Specifies the color at the lowest part of the sky at the horizon. This effect can be very subtle. This color is also used as the color of the "sky" when the camera would look below the earth.

Type:	String
-------	--------



Saved in:	Preference
Default value:	RGB:238,248,250"

11.16 HORIZONBKG_SKYLOW system variable

11.16.1 Sky low

Specifies the color of the lower regions of the sky.

Type:	String
Saved in:	Preference
Default value:	RGB:238,248,250"

11.17 HOTKEYASSISTANT system variable

11.17.1 Hotkey Assistant

Specifies whether to display the Hotkey Assistant widget or not.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show Hotkey Assistant widget On (1): Show Hotkey Assistant widget

11.18 HPANG system variable

11.18.1 Hatch pattern angle

Stores the hatch pattern angle.

Type:	Real
Saved in:	Not saved
Default value:	0.0



11.19 HPANNOTATIVE system variable

11.19.1 Hatch pattern annotative

Specifies whether a new hatch pattern is annotative.

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Hatch pattern is not annotative On (1): Hatch pattern is annotative

11.20 HPASSOC system variable

11.20.1 Hatch pattern associativity

Specifies whether new hatch patterns and gradient fills are associative or not. Associative hatches and gradient fills are updated automatically when their boundaries change.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't associate hatch patterns and gradient fills with their boundaries On (1): Associate hatch patterns and gradient fills with their boundaries

11.21 HPBACKGROUNDCOLOR system variable

11.21.1 Hatch background default color

The background color of a hatch. Enter '.' for none.

Type:	String
Saved in:	Drawing
Default value:	.



11.22 HPBOUND system variable

11.22.1 Hatch pattern boundary

Specifies the entity type (region or polyline) created by BHATCH and BOUNDARY.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	1
Possible values:	0: Region 1: Polyline

11.23 HPBOUNDRETAIN system variable

11.23.1 Hatch pattern boundary retain

Specifies whether HATCH/BHATCH commands will create boundary entities.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: do not create boundary entities 1: create boundary entities

11.24 HPCOLOR system variable

11.24.1 Hatch default color

The foreground color of a hatch. Enter '' to use the current color, as defined in CECOLOR.

Type:	String
Saved in:	Drawing



Default value:	.
----------------	---

11.25 HPDOUBLE system variable

11.25.1 Hatch pattern doubling

Specifies whether user-defined patterns create a single hatch or a cross hatch.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Hatch pattern doubling off On (1): Hatch pattern doubling on

11.26 HPDRAWORDER system variable

11.26.1 Hatch pattern draw order

Specifies the draw order of hatches and gradient fills. The Draw Order setting from the Hatch and Gradient dialog is saved here.

Type:	Short
Saved in:	Not saved
Range:	0 to 4
Default value:	3
Possible values:	0: None 1: Send to back 2: Bring to front 3: Send behind boundary 4: Bring in front of boundary

11.27 HPGAPTOL system variable

11.27.1 Hatch pattern gap tolerance

Specifies a tolerance to be used when entities are not completely closed when generating a boundary for BHATCH or BOUNDARY. The Tolerance setting from the Hatch and Gradient dialog is saved here. The



default value is 0: the tolerance is set by the application, based on the current view size. When zoomed in closely, boundary detection will fail; when zooming out further so the contour 'looks' closed, the boundary will become detected. Values greater than 0 define the maximum gap in drawing units.

Type:	Real
Saved in:	Registry
Range:	0 or greater
Default value:	0.0

11.28 HPISLANDDETECTION system variable

11.28.1 Hatch pattern island detection

Specifies islands processing within the hatch boundary.

Type:	Short
Saved in:	Not saved
Range:	0 to 2
Default value:	0
Possible values:	0: Nested. Hatches areas within islands. 1: Outer. Hatches areas outside of islands. 2: Ignore. Hatches whole the boundary.

11.29 HPLAYER system variable

11.29.1 Default layer for new hatches

Stores the default layer for new hatches.

Type:	String
Saved in:	Drawing
Default value:	0



11.30 HPLINETYPE system variable

11.30.1 Hatch pattern linetype

Specifies the display of non-continuous linetypes for hatch patterns.

When turned off, lines in the hatch pattern display as continuous, even if a non-continuous linetype is applied to the hatch entity. When turned on, lines in the hatch pattern display with the linetype that's applied to the hatch entity. This is not recommended because it can impact performance. Instead, you can choose a hatch pattern that is predefined with a non-continuous linetype.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): Don't apply non-continuous linetypes to hatch entities On (1): Apply non-continuous linetypes to hatch entities

11.31 HPMAXAREAS system variable

11.31.1 Fill mode for sparse hatches

Specifies how sparse hatches are filled.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Sparse hatches are left blank 1: Sparse hatches are changed to solid fills

11.32 HPMAXCONTOURPOINTS system variable

11.32.1 Maximum number of points on a hatch contour

Specifies the maximum number of points on a contour (outline) that a hatch entity can contain and still be rendered. Hatches do not render if the number of points exceeds the specified value. Values between 0 and 10000000 are accepted. The default value of this variable is 100000. Setting to 0 disables the check, i.e. variable is not used.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 10000000
Default value:	100000

11.33 HPNAME system variable

11.33.1 Hatch pattern name

Stores the default hatch pattern name.

Type:	String
Saved in:	Not saved

11.34 HPOBJWARNING system variable

11.34.1 Hatch pattern object warning

Specifies how many hatch boundary entities can be selected before a warning message appears.

Type:	Long
Saved in:	Registry
Range:	1 to 100000000
Default value:	10000

11.35 HPORIGIN system variable

11.35.1 Hatch pattern origin

Stores the origin point for new hatches, relative to the current UCS.

Type:	2D point
Saved in:	Drawing



Default value:	0,0
----------------	-----

11.36 HPSCALE system variable

11.36.1 Hatch pattern scale

Stores the hatch pattern scale factor.

Type:	Real
Saved in:	Not saved
Default value:	1.0

11.37 HPSEPARATE system variable

11.37.1 Hatch pattern separate

Specifies whether the HATCH command creates a single hatch pattern object or separate entities when several hatch boundaries are selected.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): Don't create separate hatches On (1): Create separate hatches

11.38 HPSPACE system variable

11.38.1 Hatch pattern spacing

Specifies the hatch pattern line spacing for user-defined hatch patterns.

Type:	Real
Saved in:	Not saved
Default value:	1.0



11.39 HPTRANSPARENCY system variable

11.39.1 Default transparency for new hatches

Specifies the default transparency level for new hatches.

Type:	String
Saved in:	Drawing
Default value:	.
Possible values:	.: Use current ByLayer: Apply the layer's transparency ByBlock: Apply the block's transparency 0: Apply no transparency (fully opaque) 0-90: Apply transparency percentage from least (1) to most (90) transparent

11.40 HYPERLINKBASE system variable

11.40.1 Hyperlink base

Specifies the path for relative hyperlinks in the drawing.

Type:	String Standard
Saved in:	Drawing



12. I

12.1 IFCCREATEUNIQUEGUID system variable

12.1.1 Export with unique guids

Defines whether a unique guid for nested elements should be generated.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	1: Inside classified blocks 2: Inside classified xrefs

12.2 IFCEXplodeEXTERNALREFERENCES system variable

12.2.1 Explode external references in IFC spatial structure

Explode external references in IFC spatial structure.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

12.3 IFCEXPORTBASEQUANTITIES system variable

12.3.1 Export base quantities

Export derived base quantities from BIM entities.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	0
----------------	---

12.4 IFCEXPORTELEMENTSONOFFANDFROZENLAYER system variable

12.4.1 Export elements on OFF and FROZEN layers

Export elements on OFF and FROZEN layers.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1

12.5 IFCEXPORTMAPPINGPATH system variable

12.5.1 Export mapping file path

Export mapping file path.

Type:	String
Saved in:	Registry
Default value:	" "

12.6 IFCEXPORTMULTIPLYELEMENTSASAGGREGATED system variable

12.6.1 Export multi-ply elements as aggregated elements

Export multi-ply elements as aggregated elements.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0



12.7 IFCEXPORTPROFILECENTEROFGRAVITY system variable

12.7.1 Export profile center of gravity

Only for IFC2x3. Exporting the center of gravity may cause a wrong positioning of the linear solids in certain IFC viewers. The center of gravity is never exported to IFC4 or higher.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

12.8 IFCEXPORTSWEPTSOLIDASBREP system variable

12.8.1 Always export swept solids as BRep

All extrusions, revolutions, swept 3D solids with clippings and subtractions will be exported using a boundary representation.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

12.9 IFCEXPORTTESSELATION system variable

12.9.1 Level of tessellation

Controls the level of tessellation of exported geometry. When the **Current** faceting option is chosen, no regeneration is required, the faceting as set by FacetRes or Modeler Properties is used. Choosing the **Low**, **Medium**, or **High** options causes corresponding regeneration of facets, which takes longer.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3



Default value:	0
Possible values:	0: Current 1: Low 2: Medium 3: High

12.10 IFCEXPORTVERIFYMODEL system variable

12.10.1 Apply IFC model verification

Check that IFC model complies with its schema rules. The problems will be reported in export log next to ifc file. Evaluation takes extra time and can slow down export of big IFC files.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

12.11 IFCIMPORTBIMDATA system variable

12.11.1 Import BIM Data

Import BIM data.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1

12.12 IFCIMPORTBREPGEOMETRYASMESHES system variable

12.12.1 Import BREP geometry as meshes

Import BREP geometry as meshes.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	0

12.13 IFCIMPORTMAPPINGPATH system variable

12.13.1 Import mapping file path

Import mapping file path.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	" "

12.14 IFCIMPORTMODELORIGIN system variable

12.14.1 Import model position

Defines how to position the imported IFC model in the world coordinate system (WCS).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: WCS matches IFC Global Coordinate system 1: WCS matches IFC Project Location 2: WCS matches IFC Site Location

12.15 IFCIMPORTPARAMETRICCOMPONENTS system variable

12.15.1 Import Parametric Components

Import windows and doors as parametric components.

BricsCAD only



Type:	Boolean
Saved in:	Registry
Default value:	0

12.16 IFCIMPORTPROJECTSTRUCTUREASXREFS system variable

12.16.1 Import IFC project structure as xrefs

Import IFC project structure as xrefs.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	0

Прим.: When IFCIMPORTPROJECTSTRUCTUREASXREFS system variable is ON (1), an IFC file cannot be opened with drag and drop in a saved drawing, but the IMPORT command should be used. A warning message is displayed.

12.17 IFCIMPORTSPACES system variable

12.17.1 Import Spaces

Import spaces.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1



12.18 IFCIMPORTUSESUBDMESH system variable

12.18.1 Import IFC meshes as subdivision meshes

If the value is off, the application will use Polyface meshes to import meshes from IFC. Polyface mesh has a limitation of 32767 faces or vertices, while subdivision mesh has no limitation.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

12.19 IFCMATCHIMPORTEDPROFILESGEOMETRICALLY system variable

12.19.1 Import: use profiles from databases with corresponding geometry

During import, profiles will consecutively be compared with the project and central database based on their geometry. In case of a match, the parameters defined in the project/central database (profile name, size and standard) will be used instead of the imported parameters.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	0

12.20 IFCTESSELATEBSPLINECURVESANDSURFACES system variable

12.20.1 Tesselate complex curves and surfaces

Tesselate BSpline curves and surfaces in IFC4 and IFC4.1 (BSpline curves are not supported by some software products in IFC import).

Type:	Boolean
Saved in:	Registry
Default value:	0



12.21 IMAGECACHEFOLDER system variable

12.21.1 Image disk cache folder

Specifies the folder where temporary image cache files are stored.

BricsCAD only

Type:	String Standard
Saved in:	Preference
Default value:	{User}AppData/Local/Temp/ImageCache

12.22 IMAGECACHEMAXMEMORY system variable

12.22.1 Maximum used memory

Maximum size of in-memory image cache, in MiB (mebibyte).

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	160

12.23 IMAGEDISKCACHE system variable

12.23.1 Image disk cache

Enable image disk cache.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable image disk cache On (1): Enable image disk cache



12.24 IMAGEFRAME system variable

12.24.1 Image frame

Specifies the visibility of image frames.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Hide image frames 1: Display and plot image frames 2: Display but do not plot image frames

12.25 IMAGEHLT system variable

12.25.1 Image highlight

Specifies whether the entire raster image highlights or only the raster image frame when selected.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't highlight entire raster image On (1): Highlight entire raster image

12.26 IMAGENOTIFY system variable

12.26.1 Image notify

Enables/disables the notification about missing raster images when opening the parent drawing.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	Off
Possible values:	Off (0): Disable image notification On (1): Enable image notification

12.27 IMPORTACISWITHBRICSCAD system variable

12.27.1 Import ACIS using built-in importer

Defines importing ACIS formats using embedded routines even if Communicator is installed.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

12.28 IMPORTCATIAV5REPRESENTATION system variable

12.28.1 Import representation

Defines which data representation Communicator should import. Preview graphics is only imported and shown if CommunicatorBackgroundMode is on.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible options:	0: Graphics 1: Geometry 2: Geometry with preview graphics

12.29 IMPORTCATIAV5EDGEATTRIBUTES system variable

12.29.1 Import edge attributes mode

Defines set of edges whose attributes (such as edge color) to read during import.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible options:	0: None 1: Edges that are parts of wire entities 2: Edges that are owners of part PMI 3: All edges

12.30 IMPORTCATIAV5SEARCHPATHSPREFERENCE system variable

12.30.1 Search paths preference

Defines priority order of search paths.

Прим.: This option is taken into account only when import in background is enabled (CommunicatorBackgroundMode system variable is ON).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

12.31 IMPORTCREOCONFIGURATION system variable

12.31.1 Import Creo configuration

Specifies the name of the Creo configuration that should be imported. If no configuration name is specified, then the part's default configuration will be imported.

BricsCAD only



Type:	String
Saved in:	Registry

12.32 IMPORTCREOALTERNATESEARCHPATHS system variable

12.32.1 Alternate search paths

Defines the list of alternate file system paths to search when importing.

Прим.: Paths must be absolute (fully qualified) and separated with a semicolon.

BricsCAD only

Type:	String
Saved in:	Registry

12.33 IMPORTIGESSTITCH system variable

12.33.1 Perform stitching

Enables automatic DMSTITCH operation on imported IGES model. If turned on, it supersedes IMPORTSTITCH setting on IGES models.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1

12.34 IMPORTINVENTORSEARCHPATHSPREFERENCE system variable

12.34.1 Search paths preference

Defines priority order of search paths.

Прим.: This option is taken into account only when import in background is enabled (CommunicatorBackgroundMode system variable is ON).

BricsCAD only

Type:	Short
-------	-------



Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

12.35 IMPORTNXCONFIGURATION system variable

12.35.1 Import NX configuration

Specifies the name of the NX configuration that should be imported. If no configuration name is specified, then the part's default configuration will be imported.

BricsCAD only

Type:	String
Saved in:	Registry

12.36 IMPORTNXSEARCHPATHSPREFERENCE system variable

12.36.1 Search paths preference

Defines priority order of search paths.

Прим.: This option is taken into account only when import in background is enabled (CommunicatorBackgroundMode system variable is ON).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first



12.37 IMPORTJTREPRESENTATION system variable

12.37.1 Import representation

Defines which data representation Communicator should import. This option is only taken into account when import in background is enabled.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Graphics 1: Geometry 2: Geometry with preview graphics

12.38 IMPORTCOLORS system variable

12.38.1 Translate colors

Defines color conversion on import.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: To RGB: All entity colors will be converted to RGB, regardless of the current palette. 1: To RGB if no matching palette index: If the entity color is found in the palette, the entity gets an index color. Otherwise, it is given a true color. 2: To nearest palette index: For any true color of the imported entity, the nearest match is searched in the palette and this index color is assigned to the entity.

12.39 IMPORTCUIFILEEXISTS system variable

12.39.1 Import cui file exists

Specifies what to do when a CUI file exists already while importing a MNU or CUIX file.



BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0 to 2
Possible values:	0: Prompt 1: Overwrite 2: Rename

12.40 IMPORTHIDDENPARTS system variable

12.40.1 Hidden parts

Defines the hidden parts processing mode.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Import and hide: All entities are imported; invisible entities are hidden. Note that currently there are no user tools to make these hidden entities visible again. 1: Import and set visible: All entities are imported and visible, regardless of the visibility in the source file. 2: Do not import: Hidden entities in the source file are not imported.

12.41 IMPORTIGESSIMPLIFY system variable

12.41.1 Perform simplification

Enables automatic DMSIMPLIFY operation on imported IGES model. If turned on, it supersedes the ImportSimplify setting on IGES models.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	1
----------------	---

12.42 IMPORTINVENTORALTERNATESEARCHPATHS system variable

12.42.1 Alternate search paths

Defines the list of alternate file system paths to search for missing assembly references when importing.

Прим.: Paths must be absolute (fully qualified) and separated with semicolon.

BricsCAD only

Type:	String
Saved in:	Registry

12.43 IMPORTNXALTERNATESEARCHPATHS system variable

12.43.1 Alternate search paths

Defines the list of alternate file system paths to search when importing.

Прим.: Paths must be absolute (fully qualified) and separated with semicolon.

BricsCAD only

Type:	String
Saved in:	Registry

12.44 IMPORTPMI system variable

12.44.1 Product and manufacturing information

Enables importing product and manufacturing information. Currently, such information is imported as exploded data (lines, text, ...) instead of compound entities (e.g. annotations).

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1



12.45 IMPORTPRODUCTSTRUCTURE system variable

12.45.1 Product structure

Defines the way Product structure is represented in the imported model. The option [2] performs automatic BMMECH operation after import and is valid for Pro or higher license level. Otherwise, it works as [1]

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	<p>0: None: Creates a flat structure without blocks in the model space of the target database, regardless of whether the imported data have an assembly structure or not.</p> <p>1: As blocks: The imported data have an assembly structure, which will be converted into a hierarchy of plain blocks; so the structure will be preserved, while the assembly metadata are lost. If the imported data is composed of entities only, they are placed in the modelspace of the target database.</p> <p>2: As mechanical components: In this mode, data will be translated to BricsCAD® assembly data, the structure and its properties (physical materials – BLMATERIALS command). If the imported file has no assembly data, a mechanical component will nevertheless be created in the BricsCAD® target document root.</p>

12.46 IMPORTREPAIR system variable

12.46.1 Repair model on import

The DMAUDITALL command is executed when importing a model. 3D geometry is analyzed and problems are fixed automatically, in order to improve the quality of the imported geometry. Geometry modeled in CAD systems which use a kernel different from ACIS, often needs to be healed because of possible flaws.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off



Possible values:	Off (0): The DMAUDITALL command is not executed when importing a model On (1): The DMAUDITALL command is executed when importing a model
------------------	---

12.47 IMPORTSIMPLIFY system variable

12.47.1 Perform simplification

Enables automatic DMSIMPLIFY operation on imported model:

- Convert imported splines into canonical surfaces.
- Simplify topology (remove imprinted edges) if possible.

Прим.: Also check the IMPORTIGESSIMPLIFY setting, which can set an override for the IGES file format.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

12.48 IMPORTSOLIDEDGEALTERNATESEARCHPATHS system variable

12.48.1 Alternate search paths

Defines the list of alternate file system paths to search when importing.

Прим.: Paths must be absolute (fully qualified) and separated with semicolon.

BricsCAD only

Type:	String
Saved in:	Registry

12.49 IMPORTSOLIDEDGESEARCHPATHSPREFERENCE system variable

12.49.1 Search paths preference

Defines priority order of search paths.

Прим.: This option is taken into account only when import in background is enabled (CommunicatorBackgroundMode system variable is ON).

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

12.50 IMPORTSOLIDWORKSALTERNATESEARCHPATHS system variable

12.50.1 Alternate search paths

Defines the list of alternate file system paths to search when importing.

Прим.: Paths must be absolute (fully qualified) and separated with a semicolon.

BricsCAD only

Type:	String
Saved in:	Registry

12.51 IMPORTSOLIDWORKSCONFIGURATION system variable

12.51.1 Import SolidWorks configuration

Specifies the name of the SolidWorks configuration that should be imported. If no configuration name is specified, then the part's default configuration will be imported.

BricsCAD only

Type:	String
Saved in:	Registry

12.52 IMPORTSOLIDWORKSREPRESENTATION system variable

12.52.1 Import representation

Defines which data representation Communicator should import. This option is only taken into account when import in background is enabled.



Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Graphics 1: Geometry 2: Geometry with preview graphics

12.53 IMPORTSOLIDWORKSROTATEYZ system variable

12.53.1 Map SolidWorks Y to current Z axis

Enables conversion of SolidWorks coordinate system to current coordinate system.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0) On (1)

12.54 IMPORTSOLIDWORKSSEARCHPATHSPREFERENCE system variable

12.54.1 Search paths preference

Defines priority order of search paths.

ПРИМ.: This option is taken into account only when import in background is enabled (CommunicatorBackgroundMode system variable is ON).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3



Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

12.55 IMPORTSTEPROTATEYZ system variable

12.55.1 Map Y to current Z axis

Enables conversion of STEP coordinate system to current coordinate system.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0) On (1)

12.56 IMPORTSTITCH system variable

12.56.1 Perform stitching

Enables automatic DMSTITCH operation on imported model.

In some cases, imported geometry represents solid geometry as a set of separate surfaces. Use the DMSTITCH command to work with solid operations on the imported geometry . If IMPORTSTITCH is set to ON, the DMSTITCH command is executed automatically when the geometry is imported.

Прим.:

- Stitch operations are time-consuming when importing large files.
- Check the IMPORTIGESSTITCH setting, which can set an override for the IGES file format.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0



12.57 INCLUDEPLOTSTAMP system variable

12.57.1 Include Plot Stamp

Specifies whether to include the plot stamp when printing.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't include Plot Stamp On (1): Include Plot Stamp

12.58 INDEXCTL system variable

12.58.1 Index control

Specifies whether layer and/or spatial indexes are created and saved. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	0
Possible options:	0: No indexes 1: Layer index 2: Spatial index

12.59 INETLOCATION system variable

12.59.1 Internet location

Default website for the BROWSER command.

Type:	String
Saved in:	Registry



Default value:	"http://www.bricsys.com"
----------------	--------------------------

12.60 INSBASE system variable

12.60.1 Insertion base point

Stores the drawing's insertion point when inserted into other drawings. INSBASE is set by the BASE command and expressed as a UCS coordinate for the current space.

Type:	3D point
Saved in:	Drawing
Default value:	0,0,0

12.61 INSMODEAUTO system variable

12.61.1 Insertion mode Auto

During insertion with the INSERT command, insertion mode is determined automatically.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Default value:	0
Possible options:	0: Insertion mode is not determined automatically 1: Insertion mode is determined automatically

12.62 INSNAME system variable

12.62.1 Insertion name

Stores the default block name for the INSERT command.

Type:	String
Saved in:	Drawing
Default value:	



12.63 INSUNITS system variable

12.63.1 Insertion units

Specifies a drawing-units value for automatic scaling when inserting or attaching blocks, images, or xrefs. When both INSUNITS and PROPUNITS are on, length, area, volume and/or inertia properties will be formatted with their unit.

Type:	Short
Saved in:	Drawing
Range:	0 to 24
Default value:	1
Possible values:	<p>0: Unspecified (No units) 1: Inches 2: Feet 3: Miles 4: Millimeters 5: Centimeters 6: Meters 7: Kilometers 8: Microinches 9: Mils 10: Yards 11: Ångströms 12: Nanometers 13: Microns 14: Decimeters 15: Decameters 16: Hectometers 17: Gigameters 18: Astronomical Units 19: Light-years 20: Parsecs 21: US Survey Feet 22: US Survey Inch 23: US Survey Yard 24: US Survey Mile</p>



12.64 INSUNITSDEFSOURCE system variable

12.64.1 Insertion units default source

Specifies the source content units value. If INSUNITS in the source drawing is Unspecified, INSUNITSDEFSOURCE is used instead.

Type:	Short
Saved in:	Registry
Range:	0 to 24
Default value:	0
Possible values:	<p>0: Unspecified (No units) 1: Inches 2: Feet 3: Miles 4: Millimeters 5: Centimeters 6: Meters 7: Kilometers 8: Microinches 9: Mils 10: Yards 11: Ångströms 12: Nanometers 13: Microns 14: Decimeters 15: Decameters 16: Hectometers 17: Gigameters 18: Astronomical Units 19: Light-years 20: Parsecs 21: US Survey Feet 22: US Survey Inch 23: US Survey Yard 24: US Survey Mile</p>

12.65 INSUNITSDEFTARGET system variable

12.65.1 Insertion units default target

Specifies the target drawing units value if INSUNITS is zero. Values between 0 and 24 are accepted.



Type:	Short
Saved in:	Registry
Range:	0 to 24
Default value:	0
Possible values:	0: Unspecified (No units) 1: Inches 2: Feet 3: Miles 4: Millimeters 5: Centimeters 6: Meters 7: Kilometers 8: Microinches 9: Mils 10: Yards 11: Ångströms 12: Nanometers 13: Microns 14: Decimeters 15: Decameters 16: Hectometers 17: Gigameters 18: Astronomical Units 19: Light-years 20: Parsecs 21: US Survey Feet 22: US Survey Inch 23: US Survey Yard 24: US Survey Mile

12.66 INSUNITSSCALING system variable

12.66.1 Insertion units scaling

Specifies how INSUNITS scaling is applied when inserting, importing and pasting data.

BricsCAD only

Type:	Short
Saved in:	Registry



Range:	0 to 3
Default value:	1
Possible values:	1: Enable INSUNITS scaling. When inserting or attaching Xrefs, Blocks or images the inserted content is scaled with respect to the value of INSUNITS in the target and source drawing. If INSUNITS in the source drawing is Unspecified, INSUNITSDEFSOURCE is used instead. If INSUNITS in the target drawing is Unspecified, INSUNITSDEFTARGET is used instead. 2: Use paper size unit instead of INSUNITS for insertions in paper space.

12.67 INTERFERECOLOR system variable

12.67.1 Interference color

Specifies the color of interference entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer

12.68 INTERFERELAYER system variable

12.68.1 Interference layer

Specifies the layer of interference entities.

BricsCAD only

Type:	String
Saved in:	Registry
Range:	
Default value:	"Interferences"

12.69 INTERFERENCELEVEL system variable

12.69.1 Interference Check Level

Controls the degree to which interferences between copied details and between details and the rest of the model are checked.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: No interference checking 1: Check overlap of detail volumes 2: Full interference checking without considering background spatial elements 3:Full interference checking

12.70 INTERFERE objs system variable

12.70.1 Interference object visual style

Specifies the interference object visual style.

Type:	String
Saved in:	Drawing
Default value:	

12.71 INTERFREVpvs system variable

12.71.1 Interference viewport visual style

Specifies the interference checking visual style for the viewport.

Type:	String
Saved in:	Drawing
Default value:	



12.72 INTERIORELEVATIONMINLENGTH system variable

12.72.1 Interior Elevation Minimum Length

Minimum length of a wall for an Interior Elevation to be generated.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	20 for MEASUREMENT=0 (inches) 500 for MEASUREMENT=1 (millimeters)

12.73 INTERIORELEVATIONOFFSET system variable

12.73.1 Interior Elevation Offset Distance

Interior Elevation volume box offset distance from wall surfaces.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	2 for MEASUREMENT=0 (inches) 50 for MEASUREMENT=1 (millimeters)

12.74 INTERSECTEDENTITIES system variable

Resolve intersection.

Determines how to modify entities that intersect with the extruded/revolved entity when the **Auto** option of the EXTRUDE or REVOLVE command is selected.

The INTERSECTEDENTITIES system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2



Default value:	0 - for Workspaces Drafting and Modeling 1 - for Workspaces Mechanical and BIM
Possible options:	0: Do not modify the parent entity. 1: Subtract the created entity from the parent entity. 2: Unite the created entity with the parent entity.

12.75 INTERSECTIONCOLOR system variable

12.75.1 Intersection color

Specifies the polyline color at the intersection of 3D surfaces in 2D Wireframe views if INTERSECTIONDISPLAY is on. (Not supported yet)

Type:	Short
Saved in:	Drawing
Range:	0 to 257
Default value:	257
Possible values:	0: ByBlock 1 - 255: index 256: ByLayer 257: ByEntity

12.76 INTERSECTIONDISPLAY system variable

12.76.1 Intersection display

Toggles the display of polylines at the intersection of 3D surfaces in 2D Wireframe views. (Not supported yet)

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display intersection polylines On (1): Display intersection polylines



12.77 ISAVEBAK system variable

12.77.1 Incremental save backup

Specifies the creation of a backup file (BAK). Improves the speed of incremental saves if switched off, especially for large drawings.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't create BAK file On (1): Create BAK file

12.78 ISAVEPERCENT system variable

12.78.1 Save percent

Specifies the amount of wasted space tolerated in a drawing file expressed as a percentage of the total file size. If the estimate of wasted space exceeds the value set by ISAVEPERCENT, the next save will be a full save, which resets the wasted space estimate to 0. If set to zero, each save is a full save. Values between 0 and 100 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 100
Default value:	50

12.79 ISOLINES system variable


12.79.1 Isolines

Specifies the number of isolines (contour lines) on curved surfaces. To view changes on existing entities, perform a REGEN.


Type:	Short
Saved in:	Drawing




Range:	0 to 2047
Default value:	4



ISOLINES: 4



ISOLINES: 8



ISOLINES: 18



13. J



14. K



15. L

15.1 LASTANGLE system variable

15.1.1 Last angle

Specifies the end angle of the last arc drawn.

Read-only

Type:	Real
Saved in:	Not saved

15.2 LASTPOINT system variable

15.2.1 Last point

Specifies the coordinates of the last point entered. This is the value which is used when entering the '@' symbol at the Command line. Expressed as a UCS coordinate for the current space.

Type:	3D point
Saved in:	Not saved

15.3 LASTPROMPT system variable

15.3.1 Last prompt

Shows the last string echoed to the Command line.

Read-only

Type:	String
Saved in:	Not saved

15.4 LATITUDE system variable

15.4.1 Latitude

Specifies the latitude of the drawing in decimal format. Positive values represent northern latitudes and negative values represent southern latitudes.

Type:	Real
-------	------



Saved in:	Drawing
Range:	-90.0 to 90.0
Default value:	37.795

15.5 LAYERFILTEREXCESS system variable

15.5.1 Layer Filter Excess

Specifies the maximum number of layer filters allowed in a drawing before suggesting some be removed. You can create any number of layer filters. However, if the number of layer filters exceeds this value and exceeds the number of layers, a message dialog displays the next time you open the drawing. It recommends deleting all layer filters to improve performance. When set to 0, the message is never displayed.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	250

15.6 LAYERPMODE system variable

15.6.1 Layer previous mode

Specifies tracking of changes made to layer settings.

Type:	Boolean
Saved in:	Registry
Range:	On
Possible values:	Off (0): Doesn't allow tracking of layer settings modification and enables LAYERP command On (1): Allows tracking of layer settings modification and enables LAYERP command



15.7 LAYLOCKFADECTL system variable

15.7.1 Locked layer fade control

Specifies the fading level for entities on locked layers to contrast them with entities on unlocked layers and reduces the visual complexity of a drawing. Entities on locked layers are still visible for reference and for object snapping. Non-positive values disable fading.

Type:	Short
Saved in:	Registry
Range:	-90 to 90
Default value:	50

15.8 LAYOUTREGENCTL system variable

15.8.1 Layout regeneration control

Specifies how the display of the Model tab and layout tabs is updated. If performance is poor in general or when switching between tabs, setting LAYOUTREGENCTL to 1 or 0 might improve performance.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Always regenerate 1: Suppress regeneration for Model tab and last layout made current 2: Regenerate first time only

15.9 LAYOUTTAB system variable

15.9.1 Layout and model tabs

Specifies the display of Layout and Model tabs.

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Don't show layout and model tabs On (1): Show layout and model tabs

15.10 LEGACYCODESEARCH system variable

15.10.1 Legacy code search mode

Specifies how BricsCAD searches for executable code in drawing folders.

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Disable unsafe searching for executable code On (1): Enable unsafe searching for executable code

15.11 LENGTHSAMPLINGINTERVAL system variable

15.11.1 Sampling interval for straight segments

Defines the length of the sampling interval which is used for the sampling of straight segments.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1.00

15.12 LENGTHUNITS system variable

15.12.1 Length units

Specifies a list of units used for displaying lengths when the length bit of PROPUNITS is on. If empty, all lengths are displayed in the current drawing unit.

BricsCAD only



Type:	String
Saved in:	Registry
Default value:	"in ft mi μm mm cm m km"

15.13 LENSLENGTH system variable

15.13.1 Lens length

Specifies the current viewport's lens length (in millimeters) used in perspective viewing.

Read-only

Type:	Real
Saved in:	Drawing
Range:	
Default value:	50.0
Unit	mm

15.14 LEVELOFTDETAIL system variable

15.14.1 Length units

Controls the level of detail.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Low. Composition plies do not display. 2: High. Composition plies display.



15.15 LICFLAGS system variable

15.15.1 Licensed components

Specifies whether certain components are licensed or not. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 7
Default value:	0
Possible options:	0: No components licensed 1: VBA is licensed 2: Acis editing is licensed 4: Pro

15.16 LIGHTGLYPHCOLOR system variable

15.16.1 Color for light glyph

Specifies the color for light glyphs. Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	30

15.17 LIGHTGLYPHDISPLAY system variable

15.17.1 Light glyph display

Specifies the display of light glyphs. A light glyph is a graphic symbol that represents point, spot, and web lights.



Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't display light glyphs On (1): Display light glyphs

15.18 LIGHTINGUNITS system variable

15.18.1 Lighting units

Specifies if generic or photometric lighting is used, and sets the lighting units type.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Generic lighting - this obsolete option can no longer be set but may exist in older drawings 1: Photometric lighting using American units (foot-candles) 2: Photometric lighting using International units (lux)

15.19 LIGHTWEBGLYPHCOLOR system variable

15.19.1 Color for web light glyph

Specifies the color for web light glyph. Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	1



15.20 LIMCHECK system variable

15.20.1 Limits check

Specifies whether entities can be created outside the drawing limits or not.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Can create entities outside limits On (1): Cannot create entities outside limits

15.21 LIMMAX system variable

15.21.1 Limits maximum

Specifies the upper-right corner of the drawing limits, expressed in world coordinates.

Type:	2D point
Saved in:	Drawing
Default value:	12,9

15.22 LIMMIN system variable

15.22.1 Limits minimum

Specifies the lower-left corner of the drawing limits, expressed in world coordinates.

Type:	2D point
Saved in:	Drawing
Default value:	0,0



15.23 LINEARBRIGHTNESS system variable

15.23.1 Linear brightness

Specifies a scaling factor for the intensity of lights. A value between -10 and 10 is accepted. The default value of 0 results in no scaling. Smaller values decrease light intensity and bigger values increase light intensity. This setting can be specified per viewport.

Type:	Short
Saved in:	Drawing
Range:	-10 to 10
Default value:	0

15.24 LINEARCONTRAST system variable

15.24.1 Linear contrast

Specifies ambient light intensity. A value between -10 and 10 is accepted. A value of -10 results in maximum ambient light. A value of 10 results in no ambient light. This setting only has effect on materials that have a non-black ambient color. This setting can be specified per viewport.

Type:	Short
Saved in:	Drawing
Range:	-10 to 10
Default value:	0

15.25 LISPINIT system variable

15.25.1 LISP init

Specifies whether LISP variables and functions are preserved between drawings.

Type:	Short
Saved in:	Registry
Range:	0 to 1



Default value:	1
Possible values:	0: Preserved from drawing to drawing 1: Valid in current drawing only

15.26 LOADMECHANICAL2D system variable

15.26.1 Mechanical 2D enablers

Specifies whether or not demand loading of Mechanical 2D enablers is permitted.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Loading of Mechanical 2D enablers is not permitted On (1): Loading of Mechanical 2D enablers is permitted

Note: Changing the value of this variable will take effect after restarting the application.

15.27 LOCALE system variable

15.27.1 Locale

Shows the ISO language code of the current BricsCAD version.

Read-only

Type:	String
Saved in:	Not saved
Default value:	"en_US"

15.28 LOCALROOTPREFIX system variable

15.28.1 Local root prefix

Stores the full path to the root folder where local files for the current user, such as templates, were installed. The Template and Textures folders are in this location, and you can add any customizable



files that you do not want to roam on the network. See ROAMABLEROOTPREFIX for the location of the roamable files.

Read-only

Type:	String Standard
Saved in:	Registry

15.29 LOCKUI system variable

15.29.1 Lock user interface elements

Specifies which user interface elements are locked to prevent accidental dragging. To override press the Ctrl (Windows) or Cmd (Mac) key while dragging. The value is stored as a bitcode using the sum of the values of all selected options.



Type:	Short
Saved in:	Registry
Range:	-7 to 7
Default value:	0
Possible options:	1: Lock docked toolbars 2: Lock docked panels 4: Lock floating panels and toolbars

15.30 LOFTANG1 system variable

15.30.1 Loft angle 1

Specifies the draft angle through a loft operation's first cross section.

Type:	Real
Saved in:	Drawing
Range:	0.0 to 360.0
Default value:	90.0




15.31 LOFTTANG2 system variable

15.31.1 Loft angle 2

Specifies the draft angle through a loft operation's ending cross section.

Type:	Real
Saved in:	Drawing
Range:	0.0 to 360.0
Default value:	90.0




15.32 LOFTMAG1 system variable

15.32.1 Loft magnitude 1

Specifies the draft angle magnitude through a loft operation's first cross section.

Type:	Real
Saved in:	Drawing
Default value:	0.0






15.33 LOFTMAG2 system variable

15.33.1 Loft magnitude 2

Specifies the draft angle magnitude through a loft operation's second cross section.

Type:	Real
Saved in:	Drawing
Default value:	0.0



15.34 LOFTNORMALS system variable

15.34.1 Loft normals

Specifies the normals of lofted entities as they pass through cross sections.

Type:	Short
Saved in:	Drawing
Range:	0 to 6
Default value:	1
Possible values:	<ul style="list-style-type: none">0: Ruled surface1: Smooth surface2: Surface is normal to the first cross section3: Surface is normal to the last cross section4: Surface is normal to the first and last cross sections5: Surface is normal to all cross sections6: Surface uses draft angle and magnitude



15.35 LOFTPARAM system variable

15.35.1 Loft param

Specifies the shape of lofted surfaces and solids. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	7
Possible options:	0: No parameters 1: No twist between cross sections 2: Align directions of cross sections 4: Create simple surfaces and solids 8: Close between the starting and ending cross sections

15.36 LOGFILEMODE system variable

15.36.1 Log file mode

Specifies whether a logfile is maintained or not. A logfile contains each executed command. These logfiles are saved in the folder specified by the LOGFILEPATH system variable.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't maintain log file On (1): Maintain log file

15.37 LOGFILENAME system variable

15.37.1 Log file name

Specifies the name of the log file.

Read-only



Type:	String
Saved in:	Not saved

15.38 LOGFILEPATH system variable

15.38.1 Log file path

Specifies the path of the log file.

Type:	String Standard
Saved in:	Registry

15.39 LOGGEDIN system variable

15.39.1 Logged in

Specifies if you are logged in to your Bricsys account.

BricsCAD only

Read-only

Type:	Boolean
Saved in:	Registry

15.40 LOGINNAME system variable

15.40.1 Login name

Shows the Windows login name which is saved with the file properties statistics of the drawing.

Read-only

Type:	String
Saved in:	Not saved

15.41 LONGITUDE system variable

15.41.1 Longitude

Specifies the longitude of the drawing in decimal format. Positive values represent east longitudes.



Type:	Real
Saved in:	Drawing
Range:	-180.0 to 180.0
Default value:	-122.394


15.42 LOOKFROMDIRECTIONMODE system variable

15.42.1 LookFrom direction mode

Specifies how many view directions can be selected in isometric mode. Holding the Ctrl (Windows) or Cmd (Mac) key switches from top-down to bottom-up directions.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	1
Possible values:	0: orthogonal only (6 directions) 1: no flat view at corners (14 directions) 2: 4 top/down corners(18 directions) 3: 8 top/down corners(26 directions)



15.43 LOOKFROMFEEDBACK system variable

15.43.1 LookFrom feedback

Specifies whether the LookFrom control displays messages in tooltips or on the status bar.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Preference
Range:	
Default value:	1
Possible values:	0: No tooltips 1: Tooltips next to the Look From control 2: Tooltips in the status bar

15.44 LOOKFROMZOOMEXTENTS system variable

15.44.1 LookFrom zoom extents

Specifies whether LookFrom will zoom extents whenever a view direction is selected.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	On
Possible values:	Off (0): Zoom extents off On (1): Zoom extents on

15.45 LTGAPSELECTION system variable

15.45.1 Linetype gap selection

Specifies whether selection or snapping to the gaps on entities defined with non-continuous linetype is possible.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): No selection or snapping within gaps (legacy behavior) On (1): Selection or snapping within gaps



15.46 LTSCALE system variable

15.46.1 Linetype scale

Stores the global linetype scale factor.

Type:	Real
Saved in:	Drawing
Default value:	1.0

15.47 LUNITS system variable

15.47.1 Linear unit type

Specifies linear units for creating entities.

Type:	Short
Saved in:	Drawing
Range:	1 to 5
Default value:	2
Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural 5: Fractional

15.48 LUPREC system variable

15.48.1 Linear unit precision

Specifies the number of decimal places displayed for linear units.

Type:	Short
Saved in:	Drawing
Range:	0 to 8



Default value:	4
Possible values:	0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000

15.49 LWDEFAULT system variable

15.49.1 Default linewidth

Specifies the default linewidth (in hundredths of millimeters).

Type:	Short
Saved in:	Registry
Range:	0 to 211
Default value:	25
Possible values:	-3: Default (defined by LWDEFAULT) -2: ByBlock -1: ByLayer 0 - 211: Lineweight value in hundredths of millimeters

15.50 LWDISPLAY system variable

15.50.1 Lineweight display

Specifies whether or not lineweights display in the Model or Layout tab.

Type:	Boolean
Saved in:	Drawing
Range:	Off



Possible values:	Off (0): Don't display linewidth On (1): Display linewidth
------------------	---

15.51 LWDISPSCALE system variable

15.51.1 Lineweight display scale

Specifies the display scale of lineweights in the Model tab.

BricsCAD only

Type:	Real
Saved in:	Registry
Range:	0.0 to 1.0
Default value:	0.55

15.52 LWUNITS system variable

15.52.1 Lineweight units

Specifies the unit in which lineweights are displayed: inches or millimeters.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Inches 1: Millimeters



16. M

16.1 MACROREC system variable

16.1.1 Macro recording

Specifies whether a macro is being recorded.

BricsCAD only

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Macro is not being recorded On (1): Macro is being recorded

16.2 MAKEBAK system variable

16.2.1 Make backup (Obsolete)

Replaced by ISAVEBAK. Has no effect except to preserve the integrity of scripts. Removed 02/12/2010.

BricsCAD only

Type:	Boolean
Saved in:	Registry

16.3 MANIPULATOR system variable

16.3.1 Manipulator

Specifies the display of the Manipulator upon selection of items.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2



Possible values:	0: Manipulator is not displayed upon selection of items. The manipulator can be displayed manually through the Quad. 1: Display Manipulator automatically whenever entities are selected 2: Display Manipulator if left mouse button was pressed longer than MANIPULATORDURATION.
------------------	---


16.4 MANIPULATORCOLORTHEME system variable

16.4.1 Color theme of Manipulator

Specifies the color theme of the Manipulator.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Monochrome color theme 1: Classic color theme





16.5 MANIPULATORDURATION system variable

16.5.1 Manipulator duration

Specifies how long (in milliseconds) the left mouse button should be pressed during entity selection to trigger the display of the Manipulator.

BricsCAD only

Type:	Long
Saved in:	Registry
Range:	100 to 10000
Default value:	250

16.6 MANIPULATORHANDLE system variable

16.6.1 Manipulator handle

Specifies the behavior of the anchor handle of the Manipulator. The handle can be used for unconstrained move and copy operations. Unconstrained meaning: not along an axis or constrained to a plane.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Handle moves the Manipulator itself 1: Handle moves the selected entities unrestricted

16.7 MANIPULATORSIZE system variable

16.7.1 Size of Manipulator

Specifies the size of the Manipulator relative to the default. Acceptable range is [0.5 - 2.0]. Initial value is 1.0.

BricsCAD only



Type:	Real
Saved in:	Preference
Range:	0.5 to 2
Default value:	1

16.8 MASSPREC system variable

16.8.1 Mass precision

Specifies the number of decimal places displayed for masses when the mass bit of PROPUNITS is on. If negative, LUPREC (Linear Unit Precision) is used.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-1 to 8
Default value:	-1
Possible values:	-1: Use LUPREC 0: 0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000 8: 0.00000000

16.9 MASSPROPACCURACY system variable

16.9.1 Mass properties calculation relative accuracy

Specifies the accuracy to be used for mass properties calculations. This accuracy is relative: the accuracy of the result depends on the magnitude of the calculated value. Acceptable value Range: 2 - 12 (0.01 to 0.000000000001, or 1.e-2 to 1.e-12).

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	2 to 12
Default value:	2
Possible values:	2: 0.01 3: 0.001 4: 0.0001 5: 0.00001 6: 0.000001 7: 0.0000001 8: 0.00000001 9: 0.000000001 10: 0.0000000001 11: 0.00000000001 12: 0.000000000001

16.10 MASSUNITS system variable

16.10.1 Mass units

Specifies a list of units used for displaying mass when the mass bit of PROPUNITS is on. If empty, all masses are displayed without units.

The MASSUNITS setting affects the mass values only. Other mass properties such as density or moments of inertia are formatted in SI units for the metric system and in imperial units for the imperial system, regardless of the MASSUNITS setting.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	oz lb st mg g kg t

16.11 MAXACTVP system variable

16.11.1 Maximum active viewports

Specifies the maximum number of viewports that can be active simultaneously in a layout. Has no effect on the number of viewports that are plotted.



Type:	Short
Saved in:	Drawing
Default value:	64

16.12 MAXHATCH system variable

16.12.1 Maximum hatch dashes

Specifies the maximum number of dashes in a hatch pattern. Hatches of which the number of dashes exceeds the maximum number of dashes cannot be created. Values between 100 and 10000000 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	100 to 10000000
Default value:	100000

16.13 MAXSORT system variable

16.13.1 Maximum sort

Specifies the maximum number of symbol names, file names, block names or layer names in listing commands. If the number of items exceeds this value, the items are not sorted into alphabetical order.

Type:	Short
Saved in:	Registry
Range:	200

16.14 MAXTHREADS system variable

16.14.1 Maximum number of threads

Specifies the maximum number of threads used for display and loading of drawings, in case one of the Multi-Threading flags has been set. Value 0 means the program will choose the optimal number of threads.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 16
Default value:	0

16.15 MBSTATE system variable

16.15.1 Mechanical browser state

Specifies whether the mechanical browser is visible or not.

BricsCAD only

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	1
Possible values:	0: Mechanical browser is invisible 1: Mechanical browser is visible

16.16 MBUTTONPAN system variable

16.16.1 Middle button pan

Specifies how the middle mouse button or wheel responds.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1



Possible values:	0: Support action defined in menu file 1: Support panning
------------------	--

16.17 MEASUREINIT system variable

16.17.1 Measurement initial

Specifies drawing units as Imperial or metric for new drawings. It also controls whether ANSI or ISO hatch pattern and linetype files are used.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Imperial (use ANSI Hatch and ANSI Linetype) 1: Metric (use ISO Hatch and ISO Linetype)

16.18 MEASUREMENT system variable

16.18.1 Measurement

Sets drawing units as Imperial or Metric for the current drawing. It also controls whether ANSI or ISO hatch pattern and linetype files are used.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Imperial (use ANSI Hatch and ANSI Linetype) 1: Metric (use ISO Hatch and ISO Linetype)

16.19 MECH2DSAVEFORMAT system variable

16.19.1 Mechanical 2D save format

Specifies the save format of Mechanical 2D entities.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	2013 to 2018
Default value:	2018
Possible values:	2013: 2013 Mechanical 2D 2014: 2014 Mechanical 2D 2015: 2015 Mechanical 2D 2016: 2016 Mechanical 2D 2018: 2018 Mechanical 2D

16.20 Системная переменная MECHANICALBLOCKS

16.20.1 Механические блоки (экспериментально)

Включает или отключает механические блоки (экспериментальная функция) в качестве альтернативы механическим компонентам.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

16.21 MECHANICALBROWSERSETTINGS system variable

16.21.1 Mechanical browser options

Sets default mechanical browser options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 255



Default value:	51
Possible options:	1: Expressions of constraints 2: Components parameters 4: Expressions of components parameters 8: Sub-components of standard parts 16: Arrays 32: Block and External References 64: Always synchronize selection 128: Keep values list order

16.22 MENUBAR (EXCEPT OS X) system variable

16.22.1 Menu bar

Specifies whether the menu bar is shown or hidden.

Type:	Boolean
Saved in:	Workspace
Range:	0 to 1
Default value:	On
Possible values:	Off (0): Don't show menubar On (1): Show menubar

16.23 MENUCTL system variable

16.23.1 Menu control

Specifies whether screen menu switches pages in response to keyboard command entry.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Screen menu doesn't switch pages in response to keyboard command entry On (1): Screen menu switches pages in response to keyboard command entry



16.24 MENUCHO system variable

16.24.1 Menu echo

Specifies menu echo and prompt control. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Not saved
Range:	0 to 15
Default value:	0
Possible options:	1: Suppress menu item echo 2: Suppress system prompts during menu 4: Disable ^P toggle 8: Display input/output strings (DIESEL macros debugging)

16.25 MENUNAME system variable

16.25.1 Menu name

Shows path and name of the menu file.

Read-only

Type:	String
Saved in:	Registry

16.26 MESHTYPE system variable

16.26.1 Mesh type

Specifies the type of mesh that is created by REVsurf, TABSURF, RULESURF and EDGESURF. (Not yet supported)

Type:	Short
Saved in:	Drawing
Range:	0 to 1



Default value:	1
Possible values:	0: Create legacy polygon or polyface mesh 1: Create full-featured mesh entities (recommended)

16.27 MIDDLECLICKCLOSE system variable

16.27.1 Middle click close (Mac & Linux)

Allows a tab to be closed by middle button click on tab bar On/Off

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	true

16.28 MILLISECS system variable

16.28.1 Milliseconds

Counts the number of milliseconds that have passed since system startup.

Read-only

Type:	Long
Saved in:	Not saved

16.29 MIRRHATCH system variable

16.29.1 Hatch pattern mirroring

Determines whether the MIRROR command mirrors hatch patterns.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't mirror hatch patterns On (1): Mirror hatch patterns




16.30 MIRRTEXT system variable

16.30.1 Mirror text

Specifies whether text is mirrored by the MIRROR command or not.

Type:	Boolean
Saved in:	Drawing
Range:	On
Possible values:	Off (0): Don't mirror text On (1): Mirror text



16.31 MLEADERSCALE system variable

16.31.1 Multileader scale

Specifies the overall width scale factor for multileaders. The scale must have a positive value.

Type:	Real
Saved in:	Drawing
Default value:	1.0

16.32 MODEMACRO system variable

16.32.1 Mode macro

Displays a text string on the status line, such as the name of the current drawing, time/date stamp or special modes. Used to help debug Diesel programming.

Type:	String
-------	--------



Saved in:	Not saved
-----------	-----------

16.33 MSLTSCALE system variable

16.33.1 Model space linetype scale

Scales linetypes displayed on the model tab by the annotation scale. When changing MSLTSCALE, REGEN or REGENALL is needed to update the display.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: No special linetype scaling by the annotation scale 1: Linetypes are scaled by the annotation scale

16.34 MSOLESCALE system variable

16.34.1 Model space OLE scale

Specifies the size of an OLE (Object Linking & Embedding) object containing text when pasted into model space. This only affects the initial size, entities already placed in the drawing are not affected when MSOLESCALE is modified. If set to zero, scales by DIMSCALE value.

Type:	Real
Saved in:	Drawing
Range:	0.0 or greater
Default value:	1.0

16.35 MTEXTCOLUMN system variable

16.35.1 Multiline text column setting

Specifies default column setting for multi-line text.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: No columns 1: Dynamic columns with auto height 2: Dynamic columns with manual height

16.36 MTEXTDETECTSPACE system variable

16.36.1 Space detection for creating lists in mtext editor

Recognize spaces from the keyboard spacebar in a special meaning (like a tabulation) for creating lists in the mtext editor.

Type:	Boolean
Saved in:	Registry
Range:	On
Possible values:	Off (0): Don't allow spaces for mtext editor lists On (1): Allow spaces for mtext editor lists

16.37 MTEXTED system variable

16.37.1 Multiline text editor

Specifies the primary and secondary text editors to use for multiline text entities.

Type:	String
Saved in:	Registry

16.38 MTEXTFIXED system variable

16.38.1 Multiline text fixed

Specifies whether BricsCAD zooms, rotates and/or pans the view to fit the multiline text being edited.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Do nothing when mtext editor is opened 1: Do nothing when mtext editor is opened 2: Rotate / zoom / pan view to fit multiline text

16.39 MTEXTTOOLBAR system variable

16.39.1 MText Formatting toolbar

Specifies displaying of the Text Formatting toolbar in the mtext editor.

Type:	Boolean
Saved in:	Registry
Range:	On
Possible values:	Off (0): Don't show formatting toolbar On (1): Show formatting toolbar

16.40 MTFLAGS system variable

16.40.1 Multi-Threading Flags

Bit flags for parallel processing of display and loading. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 4095
Default value:	3015



Possible options:	0: No parallel processing 1: Parallelized regeneration of display. 2: Parallelized redraw of display. 4: Parallelized loading of drawings. 8: Parallelized calculation of hidden line removal. 16: Parallelized generation of BIM sections to separate destination files. 32: Parallelized generation of BIM sections to the same destination file. 64: Parallelized computations in Direct Modeling commands and operations. 128: Parallelized computations in Assembly commands and operations. 256: Parallelized computations in Sheet Metal commands and operations. 512: Parallelized interference checking 1024: Delayed XREF loading 2048: Parallelized point cloud operations
-------------------	---

16.41 MULTISELECTANGULARTOLERANCE system variable

16.41.1 BimMultiSelect angular tolerance

Specifies the maximum angle between two linear solids' axes at which these solids are still considered parallel.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 90
Default value:	3

16.42 MYDOCUMENTSPREFIX system variable

16.42.1 MyDocuments root prefix

Stores the full path to the user documents root folder.

Read-only

Type:	String Standard
Saved in:	Registry




17. N

17.1 NAVVCUBEDISPLAY system variable

17.1.1 LookFrom display

Specifies whether the LookFrom control is shown on the current viewport.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	On
Possible values:	Off (0): Don't display the LookFrom control On (1): Display the LookFrom control



17.2 NAVVCUBELOCATION system variable

17.2.1 LookFrom location

Specifies where to display the LookFrom control.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0



Possible values:	0: Top right corner 1: Top left corner 2: Bottom left corner 3: Bottom right corner
------------------	--

17.3 NAVVCUBEOPACITY system variable

17.3.1 LookFrom opacity

Specifies the opacity of the LookFrom control while inactive.

Type:	Short
Saved in:	Registry
Range:	0 to 100
Default value:	50

17.4 NAVVCUBEORIENT system variable

17.4.1 LookFrom orientation

Specifies whether the LookFrom control reflects the current WCS or UCS.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: WCS 1: UCS

17.5 NEARESTDISTANCE system variable


17.5.1 Nearest Distance

Specifies nearest distance dimension between pair of selected entities. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	1
Possible options:	<ul style="list-style-type: none">1: Show nearest distance dimension2: Show OX aligned nearest distance dimension4: Show OY aligned nearest distance dimension8: Show OZ aligned nearest distance dimension



17.6 NOMUTT system variable

17.6.1 No muttering

Toggles the suppression of message display (muttering). When on, the Command line will stop prompting all the options and actions.

Type:	Boolean
Saved in:	Not saved
Default value:	Off



Possible values:	Off (0): Don't suppress muttering On (1): Suppress muttering
------------------	---

17.7 NORTHDIRECTION system variable

17.7.1 North direction

Specifies the angle of the sun from north, in the context of the world coordinate system (WCS).

Type:	Real
Saved in:	Drawing
Default value:	0.0



18. O

18.1 OBJECTISOLATIONMODE system variable

18.1.1 Object Isolation Mode

Specifies whether entities that are temporarily hidden with HIDEOBJECTS or ISOLATEOBJECTS remain hidden after saving and reopening the drawing.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	<p>0: Entities are temporarily hidden for the current session. Interfered solids are selected together with the interference solids.</p> <p>1: Entities remain hidden between sessions. Interfered solids are selected together with the interference solids.</p> <p>2: Entities are temporarily hidden for the current session. Interfered solids are not selected together with the interference solids.</p> <p>3: Entities remain hidden between sessions. Interfered solids are not selected together with the interference solids.</p>

18.2 OBSCUREDCOLOR system variable

18.2.1 Obscured color

Specifies the color of obscured lines. This setting is visible only if OBSCUREDLTYPE is set to a value other than 0.

Type:	Short
Saved in:	Drawing
Range:	0 to 257
Default value:	257
Possible values:	<p>0: ByBlock</p> <p>1 - 255: index</p> <p>256: ByLayer</p> <p>257: ByEntity</p>



18.3 OBSCUREDLTYPE system variable

18.3.1 Obscured linetype

Specifies the linetype of obscured lines. Unlike regular linetypes, obscured linetypes are zoom level independent.

Type:	Short
Saved in:	Drawing
Range:	0 to 11
Default value:	0
Possible values:	 0: Off 1: Solid 2: Dashed 3: Dotted 4: Short Dash 5: Medium Dash 6: Long Dash 7: Double Short Dash 8: Double Medium Dashsettings 9: Double Long Dash 10: Medium Long Dash 11: Sparse Dot

18.4 OFFSETDIST system variable

18.4.1 Offset distance

Stores the last distance used with the OFFSET command.

Type:	Real
Saved in:	Not saved
Range:	-1.0
Possible values:	<0: draws a parallel copy of an entity through a specified point



18.5 OFFSETERASE system variable

18.5.1 Offset erase

Specifies whether the OFFSET command erases the source entity or not.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): Offset erase off On (1): Offset erase on

18.6 OFFSETGAPTYPE system variable

18.6.1 Offset gap type

Specifies how possible gaps in parallel copies of closed polylines are filled.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Extend polyline segments 1: Filleted arc segments 2: Chamfered line segments



18.7 OLEFRAME system variable

18.7.1 OLE frame

Specifies the display of a frame around an OLE (Object Linking & Embedding) entity.



Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: No OLE frames 1: Display and plot OLE frames 2: Display but do not plot OLE frames

18.8 OLEHIDE system variable

18.8.1 OLE hide

Specifies the visibility of OLE (Object Linking & Embedding) entities for both screen display and plotting.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: All OLE entities are visible and plot 1: OLE entities are visible and plot in paper space only 2: OLE entities are visible and plot in model space only 3: No OLE entities are visible or plot

18.9 OLEQUALITY system variable

18.9.1 OLE quality

Specifies the default plot quality of OLE (Object Linking & Embedding) entities. When set to 3 (Automatic), the quality level is assigned automatically depending on the entity e.g. photographs are set to High.

Type:	Short
Saved in:	Registry
Range:	0 to 3



Default value:	3
Possible values:	0: Monochrome 1: Low graphics 2: High graphics 3: Automatically Select

18.10 OLESTARTUP system variable

18.10.1 OLE startup

Specifies whether or not the OLE (Object Linking & Embedding) entity source application is launched when plotting.

Type:	Boolean
Saved in:	Drawing
Range:	Off
Possible values:	Off (0): Don't load OLE source application when plotting On (1): Load OLE source application when plotting

18.11 OPMSTATE system variable

18.11.1 Properties bar state

Specifies whether the properties bar is visible or not.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	1
Possible values:	0: Properties bar is invisible 1: Properties bar is visible



18.12 ORBITAUTOTARGET system variable

18.12.1 Orbit Auto Target

Specifies how the target point is acquired for the RTROT command.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Off. The target point is located where you clicked to start orbiting 1: On. The target point is located at the center of the entities displayed or selected on screen.

18.13 ORTHOMODE system variable

18.13.1 Orthogonal mode

Specifies whether cursor movement is constrained to the perpendicular. When on, the cursor can be moved horizontally or vertically only, relative to the current UCS and grid rotation angle as defined by SNAPANG.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Orthogonal mode off On (1): Orthogonal mode on

18.14 OSMODE system variable

18.14.1 Entity snap mode

Specifies running entity snap modes. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 32767
Possible options:	4135
Possible values:	<p>0: None 1: Endpoint 2: Midpoint 4: Center 8: Node 16: Quadrant 32: Intersection 64: Insertion 128: Perpendicular 256: Tangent 512: Nearest 1024: Geometric center 2048: Apparent intersection 4096: Extension 8192: Parallel 16384: Turn off all snaps</p>

18.15 OSNAPCOORD system variable

18.15.1 Entity snap coordinates

Specifies whether running entity snaps override keyboard coordinate entry.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	<p>0: Entity snap settings override keyboard coordinate entry 1: Keyboard entry overrides entity snap settings 2: Keyboard entry overrides entity snap settings except in scripts</p>



18.16 OSNAPZ system variable

18.16.1 Ignore entity snap elevation

Replaces the Z coordinate of the entity snapping point with the current value of the ELEVATION system variable.

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Don't replace Z value with current elevation On (1): Replace Z value with current elevation

18.17 OSOPTIONS system variable

18.17.1 Entity snap options

Suppresses entity snaps on certain entity types: hatches and/or dimension extension lines or negative z-values in dynamic UCS mode. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	7
Possible options:	1: Entity snap ignores hatches 2: Entity snap ignores negative Z values in Dynamic UCS mode 4: Entity snap ignores end points of dimension extension lines

18.18 OVERKILLAYER system variable

18.18.1 Duplicate Entities Layer

This is the layer to which entities are moved when using the option to Move duplicates to Duplicate Entities layer in the OVERKILL command.

BricsCAD only



Type:	String
Saved in:	Registry
Default value:	"Duplicate Entities"



19. P

19.1 PANBUFFER system variable

19.1.1 Pan buffer

Specifies whether faster panning is enabled, especially in complex drawings.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable faster panning On (1): Enable faster panning

19.2 PANELBUTTONSIZE system variable

19.2.1 Panelset icon button size

Preferred size of panelset icon buttons.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	1
Default value:	0 to 2
Possible values:	0: Small buttons 1: Large buttons 2: Extra-large buttons

19.3 PAPERUPDATE system variable

19.3.1 Paper update

About automatic papersize adaption when switching printers in print dialog. If ON, existing papersize is maintained. If the printer has no close match, the size will be displayed as 'previous paper size'. On print,



user confirmation is required before substitution by default values. When OFF, always assigns the default papersize of the selected printer.

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	Off (0): Retain papersize when switching printers On (1): Use configured paper size of the plotter configuration file

19.4 PARAMETERCOPYMODE system variable

19.4.1 Parameter copy mode

Specifies copying of constraints and related parameters when entities are copied.

Type:	Short
Saved in:	Registry
Range:	0 to 4
Default value:	3
Possible values:	0: Do not copy 2D constraints 1: Replace all expressions with constants 2: Use existing parameters, if parameter is missing replace it with constant 3: Use existing parameters, create new parameter if it is missing 4: Use existing parameters, create new parameter if it is missing or has different value

19.5 PARAMETRICBLOCKS2DPATH system variable

19.5.1 Parametric blocks 2D directory path

Specifies the folder(s) in which BricsCAD should look for user created Parametric Blocks 2D files.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
-----------	----------

19.6 PDFCACHE system variable

19.6.1 PDF cache

Enables/disables the pdf cache. A multi-resolution persistent image cache is used to display attached Pdf underlays, enabling (very) fast zoom and pan operations. The highest cached resolution is 5000 x 5000 pixels. Still, when zooming in very close, the display of the Pdf underlay will become pixelated. So a hybrid modus can be used which switches to real-time generation of crisp Pdf underlay display when zooming in very close. The initial generation of the image cache may take a few seconds, from then on processing gets (very) fast, and remains like that in subsequent sessions.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: No caching, always real time generation 1: Use pdf cache, only use real time generation when zooming in close 2: Always use pdf cache

19.7 PDFEMBEDDEDTTF system variable

19.7.1 Pdf embedded fonts

Enable embedding of True Type fonts into PDF files.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable embedded TTF fonts On (1): Enable embedded TTF fonts



19.8 PDFEXPORTHYPERLINKS system variable

19.8.1 Export hyperlinks

Enables export of entity hyperlinks.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disables export of entity hyperlinks On (1): Enables export of entity hyperlinks

19.9 PDFFRAME system variable

19.9.1 PDF frame

Specifies the visibility of PDF underlay frames.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Hide PDF frames 1: Display and plot PDF frames 2: Display but do not plot PDF frames

19.10 PDFIMAGEANTIALIAS system variable

19.10.1 Image anti-aliasing

Enables anti-aliasing for images that require upscaling when exporting.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	On
Possible values:	Off (0): Disables anti-aliasing for images On (1): Enables anti-aliasing for images

19.11 PDFIMAGECOMPRESSION system variable

19.11.1 Image compression

Compression used for exported images.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: None 1: JPEG

19.12 PDFIMAGEDPI system variable

19.12.1 Image DPI

When a raster image is exported this value controls the minimal resolution for the image. Cannot exceed PdfVectorResolutionDPI value.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	300

19.13 PDFIMPORTAPPLYLINEWEIGHT system variable

19.13.1 Apply linewidth properties

Retains or ignores the linewidth properties of the imported entities.

BricsCAD only



Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Ignore the linewidth properties of the imported entities On (1): Retain the linewidth properties of the imported entities

19.14 PDFIMPORTASBLOCK system variable

19.14.1 Import as block

Imports the PDF file as a block instead of directly into modelspace.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't import PDF files as a block On (1): Import PDF files as a block

19.15 PDFIMPORTCHARSPACEFACTOR system variable

19.15.1 Inter-character space factor

Specifies the factor for the width of the space between characters in a word. If the distance between the text objects in the string is less than the width of the space taken from the font metric multiplied by this factor, the text objects are combined into one word. It is used only if the PDFIMPORTCOMBINETEXTOBJECTS system variable is turned on.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.6



19.16 PDFIMPORTCOMBINETEXTOBJECTS system variable

19.16.1 Combine text objects

Controls whether text objects that use the same font and are on the same line are combined.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Text objects are not combined. On (1): Text objects are combined.

19.17 PDFIMPORTCONVERTSOLIDSTOHATCHES system variable

19.17.1 Convert solid fills to hatches

Converts 2D solid entities into solid-filled hatches.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't convert solid fills to hatches from imported PDF files On (1): Convert solid fills to hatches from imported PDF files

19.18 PDFIMPORTIMAGEPATH system variable

19.18.1 Raster Images Folder

Location for saving raster images when importing a pdf file containing rasters. The path can be absolute or relative. If PDFIMPORTIMAGEPATH is relative the pdf raster image path will be calculated relative to the folder of the current drawing file. If the path is left empty the folder of the current drawing will be used. The default value is a subfolder "PDF Images" of the current drawing. If the drawing has not yet been saved, rasters will be placed next to the pdf file being imported.

Type:	String
-------	--------



Saved in:	Registry
Default value:	"PDF Images"

19.19 PDFIMPORTJOINLINEANDARCSEGMENTS system variable

19.19.1 Join line and arc segments

Joins contiguous segments into a polyline where possible.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	On
Possible values:	Off (0): Don't join the line and arc segments from imported PDF files On (1): Join the line and arc segments from imported PDF files

19.20 PDFIMPORTLAYERSUSETYPE system variable

19.20.1 Layers

Specifies to which layers the entities are imported. It's possible to import to layers which match the PDF layers, to create layers for each PDF entity type, or to just collect all imported entities on the current layer.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: Use PDF Layers 1: Layer per Entity Type 2: Use current layer



19.21 PDFIMPORTRASTERIMAGES system variable

19.21.1 Raster Images

Extract raster images to PNG files and attach these to the current drawing. The images are stored in a folder controlled by PDFIMPORTIMAGEPATH system variable.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	Off
Possible values:	Off (0): Don't extract the raster images On (1): Extract the raster images

19.22 PDFIMPORTSOLIDFILLS system variable

19.22.1 Solid fills

Ignore or import solid-filled areas. If these filled areas were originally exported into PDF format from AutoCAD, the solid areas would include solid-filled hatches, 2D solids, wipeout entities, wide polylines, and triangular arrowheads.

Note: Solid-filled hatches are assigned a 50% transparency so that entities on top or underneath can be easily seen.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Ignore solid-filled areas. On (1): Import solid-filled areas.

19.23 PDFIMPORTSPACEFACTOR system variable

19.23.1 Inter-word space factor

Defines the factor for the width of the space between words on a line. If the distance between the text objects in the string is greater than the width of the space between characters in a word (specified by the



PDFIMPORTCHARSPACEFACTOR system variable), but less than the width of the space taken from the font metrics multiplied by this factor, the text objects are combined into one word. It is used only if the PDFIMPORTCOMBINETEXTOBJECTS system variable is turned on.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	1.5

19.24 PDFIMPORTTRUETYPETEXT system variable

19.24.1 TrueType text

Import TrueType text as TrueType text with its text style named after the font.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import the TrueType text On (1): Import the TrueType text

19.25 PDFIMPORTTRUETYPETEXTASGEOMETRY system variable

19.25.1 Import True Type text as geometry

Specifies whether to import True Type text from a PDF file as geometry.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't import TrueType text as geometry On (1): Import TrueType text as geometry



19.26 PDFIMPORTUSECLIPPING system variable

19.26.1 Apply clipping

Controls whether clipping is applied to objects on import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Clipping is not applied to objects on import. On (1): Clipping is applied to objects on import.

19.27 PDFIMPORTUSEGEOMETRYOPTIMIZATION system variable

19.27.1 Import geometry with optimization

Specifies whether to optimize geometry when importing from a PDF file.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import geometry with optimization On (1): Import geometry with optimization

19.28 PDFIMPORTUSEIMAGECLIPPING system variable

19.28.1 Clip images

Controls whether images are clipped on import. Clipping means that the clipped part of the image becomes transparent. It has effect only if the PDFIMPORTUSECLIPPING system variable is on.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	Off
Possible values:	Off (0): Images are not clipped on import. On (1): Images are clipped on import.

19.29 PDFIMPORTUSEPAGEBORDERCLIPPING system variable

19.29.1 Apply clipping at page border

Controls whether clipping at page border is applied on import. It has effect only if the PDFIMPORTUSECLIPPING system variable is on.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Clipping at page border is not applied on import. On (1): Clipping at page border is applied on import.

19.30 PDFIMPORTVECTORGEOMETRY system variable

19.30.1 Vector geometry

Ignore or Import vector geometry. PDF geometric data types include linear paths, Beziér curves, and solid-filled areas, which are imported as polylines, and 2D solids or solid-filled hatches. Within a tolerance, curves that resemble arcs, circles, and ellipses are interpolated as such. Patterned hatches are imported as many separate entities.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import vector geometry On (1): Import vector geometry



19.31 PDFLAYERSSETTING system variable

19.31.1 Pdf layer support

Specifies the use of layers in the target PDF document (PDF v1.5 feature).

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	1
Possible values:	0: Don't use layers 1: Use all layers with visible entities 2: Use all layers with entities, including OFF and FROZEN layers.

19.32 PDFLAYOUTSTOEXPORT system variable

19.32.1 Pdf layouts to export

Define layout(s) to be exported.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: Active 1: All in multi-sheet file 2: All in single-sheet files

19.33 PDFMERGECONTROL system variable

19.33.1 Pdf Merge Control

Specifies the appearance of lines that cross.

Lines Overwrite Uses the last plotted line to obscure the lines under it. Only the topmost line is visible at the intersection.

Lines Merge Merges the colors of crossing lines.



BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: Lines Overwrite 1: Lines Merge

19.34 PDFNOTIFY system variable

19.34.1 PDF notify

Enables/disables the notification about missing or modified PDF documents when opening the parent drawing.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Disable PDF notification On (1): Enable PDF notification

19.35 PDFOSNAP system variable

19.35.1 PDF entity snap

Enable snapping to entities in the PDF underlay files.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable PDF entity snap On (1): Enable PDF entity snap



19.36 PDFPAPERHEIGHT system variable

19.36.1 Pdf overridden paper height

Paper height to use in the papersize override, in millimeters.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	297

19.37 PDFPAPERSIZE OVERRIDE system variable

19.37.1 Pdf papersize override

Enables papersize override. If On, the papersize as defined in the BricsCAD Print settings is overridden.

The papersize width and height defined by **PdfPaperWidth** and **PdfPaperHeight** are used instead.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Disable papersize override On (1): Enable papersize override

19.38 PDFPAPERWIDTH system variable

19.38.1 Pdf overridden paper width

Paper width to use in the papersize override, in millimeters.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	210



19.39 PDFPRCCOMPRESSION system variable

19.39.1 PRC Compression

Specifies the compression for PRC 3D data.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: No compression 1: Medium compression 2: High compression

19.40 PDFPRCEXPORT system variable

19.40.1 PRC Export Mode

Specifies the export mode for PRC 3D data. **Export as BREP** is an experimental mode which may work incorrectly. We recommend using **Export as Mesh** mode.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: No export 1: Export as BREP (Experimental) 2: Export as Mesh

19.41 PDFPRCPROJECTION system variable

19.41.1 PRC Projection

PRC Projection for PRC 3D data.



BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: Orthogonal 1: Perspective

19.42 PDFPRCVIEWMODE system variable

19.42.1 PRC View mode

PRC view mode for export of PRC 3D data controls whether the 2D entities are exported separate from 3D entities as standard PDF or whether all entities are exported using PRC. In addition the setting allows to export 3D entities as separate 3D objects or as one unified 3D object.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: All entities in single view 1: Only 3D entities in single view 2: Only 3D entities in multiple views

19.43 PDFSHXTEXTASGEOMETRY system variable

19.43.1 Pdf SHX text as geometry

Enable the conversion of SHX font text to geometry. This might be necessary if the receiving party does not have the same SHX fonts on their computer.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	Off
Possible values:	Off (0): Don't convert SHX text to geometry On (1): Convert SHX text to geometry

19.44 PDFSIMPLEGEOMOPTIMIZATION system variable

19.44.1 Pdf simple geometry optimization

Enable simple geometry optimization (separate segments to one polyline, use of Bezier curve control points).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable simple geometry optimization On (1): Enable simple geometry optimization

19.45 PDFTTFFTEXTASGEOMETRY system variable

19.45.1 Pdf TTF text as geometry

Enable the conversion of True Type font text to geometry. This is useful for when the TTF files are covered by a license that prohibits sharing, or you want to make it harder to extract text.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't convert TTF text to geometry On (1): Convert TTF text to geometry



19.46 PDFUSEPLOTSTYLES system variable

19.46.1 Pdf use plotstyles

Enables usage of plotstyles. If On, the plotstyle of the layout controls the color and linewidth in the PDF export.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disables usage of plotstyles On (1): Enables usage of plotstyles

19.47 PDFVECTORRESOLUTIONDPI system variable

19.47.1 Vector Resolution DPI

Resolution of vector graphics when exporting. Values between 72 and 40000 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	72 to 40000
Default value:	2400

19.48 PDFZOOMTOEXTENTSMODE system variable

19.48.1 Pdf zoom to extents mode

If exporting model space, zoom to extents first, if the current model space view is zoomed in/out. This zooms the layout geometry to the papersize. When Off (0): use scale and papersize from page setup data instead.

BricsCAD only

Type:	Boolean
-------	---------




Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't zoom to extents On (1): Zoom to extents

19.49 PDMODE system variable

19.49.1 Point display mode

Specifies the display style for point entities. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
	0 to 100
Default value:	0
Possible options:	1: none 0: . 2: + 3: x 4: ' 32: circle 64: square



19.50 PDSIZE system variable

19.50.1 Point display size

Specifies the display size for point entities.

Type:	Real
Saved in:	Drawing
Default value:	0.0
Possible values:	0: 5 percent of the drawing area height >0: Absolute size <0: Percentage of the viewport size

19.51 PEDITACCEPT system variable

19.51.1 Polyline edit accept

Specifies the display of the 'Entity Selected Is Not a Polyline' prompt in PEDIT. When the prompt is suppressed, the selected entity is automatically converted to a polyline.

Type:	Boolean
Saved in:	Registry




Default value:	0
Possible values:	Off (0): Display prompt On (1): Suppress prompt

19.52 PELLIPSE system variable

19.52.1 Polyline ellipse

Specifies the entity type created with the ELLIPSE command real ellipses or polyline representations of an ellipse.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Create real ellipses On (1): Create polyline representations of an ellipse



19.53 PERIMETER system variable

19.53.1 Last perimeter

Specifies the last perimeter calculated by AREA, LIST, or DBLIST.

Read-only

Type:	Real
Saved in:	Not saved

19.54 PERSPECTIVE system variable

19.54.1 Perspective

Specifies whether the current viewport is displayed in perspective view.



Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Perspective view off On (1): Perspective view on

19.55 PFACEVMAX system variable

19.55.1 Polyface mesh maximum vertices

Specifies the maximum number of vertices for each face.

Read-only

Type:	Short
Saved in:	Not saved
Range:	3 or greater
Default value:	4

19.56 PICKADD system variable

19.56.1 Pick add

When Off (0): the most recently selected entities become the selection set. Press and hold SHIFT to add entities.

When On newly selected entities are added to the selection set. Press and hold SHIFT to remove entities.

Type:	Boolean
Saved in:	Registry
Range:	
Default value:	On
Possible values:	Off (0): Don't add selected entities to current selection set On (1): Add selected entities to current selection set



19.57 PICKAUTO system variable

19.57.1 Pick automatic

Specifies automatic window selection (inside or crossing) while selecting entities. The value is stored as a bitcode using the sum of the values of all the selected options. A negative value is the same as 0, but helps storing the earlier value.

Type:	Short
Saved in:	Registry
Range:	-7 to 7
Default value:	5
Possible options:	Negative: disables window selection 1: Draws a selection window if the mouse is not over any entity when clicked 2: Draws a selection window if the mouse is clicked and dragged over an entity 4: Draws a selection lasso if the mouse is not over any entity when clicked

19.58 PICKBOX system variable

19.58.1 Pick box

Specifies the size (in pixels) of the small square at the end of the selection cursor (the entity selection target). If you select an entity by clicking, the Pick Box must touch or overlap the entity. Values between 0 and 50 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 50
Default value:	4
Unit	pixels



19.59 PICKDRAG system variable

19.59.1 Pick drag

Specifies the drawing method for the selection window.

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Draw selection window using two points On (1): Draw selection window using dragging

19.60 PICKFIRST system variable

19.60.1 Pick first

Allows to select entities first, then issue a command or vice versa.

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): First issue a command, then select entities On (1): First select entities, then issue a command

19.61 PICKSTYLE (EXCEPT OS X) system variable

19.61.1 Pick style

Specifies the selection of groups and associative hatches. The value of PICKSTYLE is stored as a bitcode using the sum of the values of all selected options.

Ctrl-H toggles PICKSTYLE 0/1 if 0 or 1 and 2/3 if 2 or 3.

Type:	Short
Saved in:	Registry
Range:	0 to 3



Default value:	1
Possible options:	0: No group selection or associative hatch selection 1: Group selection if a member of a selectable group is selected, all members of the group are selected 2: Associative hatch selection the hatch and its boundary are selected, no matter what is picked (the hatch or the boundary). 3: Group selection and associative hatch selection

19.62 PICTUREEXPORTSCALE system variable

19.62.1 Picture format export scale factor

This is the scaling factor that controls the output resolution for exporting to picture formats (WMF, EMF, BMP). The output view size is current viewsize (in pixels) multiplied by this factor.

Used in commands EXPORT, WMFOUT, COPYCLIP, CUTCLIP and in COM/VBA function

AcadDocument.Export. WARNING scale values of 10 or more may cause slow system response.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 or greater
Default value:	1.0

19.63 PLACESBARFOLDER1 system variable

19.63.1 First folder (Windows)

Specifies the first folder in the places bar of the nonstandard open file dialog. This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	0



Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents
------------------	---

19.64 PLACESBARFOLDER2 system variable

19.64.1 Second folder (Windows)

Specifies the second folder in the places bar of the nonstandard open file dialog. This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	1
Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents

19.65 PLACESBARFOLDER3 system variable

19.65.1 Third folder (Windows)

Specifies the third folder in the places bar of the nonstandard open file dialog. This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5



Default value:	3
Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents

19.66 PLACESBARFOLDER4 system variable

19.66.1 Fourth folder (Windows)

Specifies the fourth folder in the places bar of the nonstandard open file dialog. This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	5
Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents

19.67 PLATFORM system variable

19.67.1 Platform

Displays the current version of the Operating System.

Read-only

Type:	String
Saved in:	Not saved



19.68 PLINECACHE system variable

19.68.1 Polyline cache

Specifies creation of a cache of polyline vertices when a database file is opened.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Disable polyline cache On (1): Enable polyline cache

19.69 PLINECONVERTMODE system variable

19.69.1 Polyline convert mode


Specifies how to convert splines to polylines.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Create polylines with linear segments 1: Create polylines with arc segments


19.70 PLINEGEN system variable

19.70.1 Polyline generation

Linetypes are normally generated from vertex to vertex (0). Polylines of which the vertices are very close together might be rendered as a continuous line, if the linetype pattern does not fit between two subsequent vertices. When set to 1, the linetype is drawn from one end of the polyline to the other end, instead of from vertex to vertex.



Polyline starts and ends with a dash at each vertex. The linetype will not display on parts that are too small.



The linetype displays in a continuous pattern around the polyline vertices.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Polylines start and end with a dash at each vertex On (1): Linetype in a continuous pattern around the polyline vertices

19.71 PLINETYPE system variable

19.71.1 Polyline type

Specifies the usage of optimized 2D polylines when creating polylines and the conversion of polylines in older drawings. It saves disk space and memory by using the optimized format.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Polylines in older drawings are not converted; PLINE creates old-format polylines 1: Polylines in older drawings are not converted; PLINE creates optimized polylines 2: Polylines in older drawings are converted; PLINE creates optimized polylines



19.72 PLINEWID system variable

19.72.1 Polyline width

Specifies the default width for new polylines.

Type:	Real
Saved in:	Drawing
Default value:	0.0

19.73 PLOTCFGPATH system variable

19.73.1 Plotter configuration path

Specifies the paths to the Plotter configuration folders. When printing a layout, the available paper size settings are controlled by a Plotter Configuration File. The Printer/Plotter Configuration list is composed of all printer drivers that are installed on your computer. The Printer Configuration are the files in the folder which is specified by the Plotter Configuration Path. If this is set to a large folder with many files and subfolders, then the entire folder and subfolders are searched for appropriate files. This might cause the print dialog to take a long time to open.

BricsCAD only

Type:	String
Saved in:	Preference

19.74 PLOTID system variable

19.74.1 Plot id (Obsolete)

Has no effect except to preserve the integrity of old scripts and LISP routines.

Type:	String
Saved in:	Registry

19.75 PLOTOUTPUTPATH system variable

19.75.1 Plot output path

Specifies the default path for creation of plot files.

BricsCAD only



Type:	String
Saved in:	Preference

19.76 PLOTSTYLEPATH system variable

19.76.1 Plot styles path

Specifies the path to the Plot styles folders.

BricsCAD only

Type:	String
Saved in:	Preference

19.77 PLOTTER system variable

19.77.1 Plotter (Obsolete)

Has no effect except to preserve the integrity of older scripts and LISP routines.

Type:	Short
Saved in:	Registry

19.78 PLOTTRANSPARENCY OVERRIDE system variable

19.78.1 Plot transparency override

Specifies whether transparencies are enabled when printing.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Transparencies are disabled 1: Value from page setup dialog is used 2: Transparencies are enabled



19.79 PLQUIET system variable

19.79.1 Plot quiet

Specifies whether optional dialog boxes and nonfatal errors display when batch plotting or running scripts.

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Display plot dialog boxes and nonfatal errors On (1): Log nonfatal errors and don't display plot-related dialog boxes

19.80 POINTCLOUD2DVSDISPLAY system variable

19.80.1 Point cloud toggle show/hide bounding box in 2D wireframe mode

Point clouds are only displayed in 3D visual style. Otherwise, a bounding box and a warning message are displayed in 2D wireframe mode. This setting provides a way to hide this bounding box and message.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Display point cloud bounding box and warning message that point clouds are not displayed in 2D wireframe visual style 1: Hide bounding box and warning message

19.81 POINTCLOUDADAPTIVEDISPLAY system variable

19.81.1 Point cloud toggle adaptive vs. fixed point sizes

Point clouds are by default displayed using adaptive point sizes (visually more realistic). However, for point snapping, fixed point sizes are sometimes better.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: Use fixed point sizes (all points have the same size) 1: Use adaptive point sizes (point sizes are adjusted for a better visual appearance)

19.82 POINTCLOUDBOUNDARY system variable

19.82.1 Point cloud point boundary

Show the edges of the point cloud bounding box.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Don't show 1: Only when selected 2: Always show

19.83 POINTCLOUDCACHEFOLDER system variable

19.83.1 Point Cloud disk cache folder

Specifies the folders where point cloud cache files are stored. Multiple paths are supported. The first one will be used for adding new cached/preprocessed data.

BricsCAD only

Type:	String Standard
Saved in:	Preference
Default value:	{User}AppData/Local/Temp/PointCloudCache



19.84 POINTCLOUDHSPC system variable

19.84.1 Point Cloud format (hspc/bcad)

Specifies the format used for processing point clouds (hspc or bcad).

Прим.: The HSPC file format (Hexagon Smart Point Cloud) is a proprietary format developed by Hexagon VCH (Visual Computing Hub). Using this format enables storing per point information which will be used to have more point cloud functionalities (in the future).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Use bcad format. On (1): Use HSPC format

19.85 POINTCLOUDIGNOREGEOTAGS system variable

19.85.1 Point Cloud ignore geo tags in source data

Specifies whether geo tags should be ignored in source data or not.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't ignore geo tags in source data On (1): Ignore geo tags in source data

19.86 POINTCLOUDPOINTMAX system variable

19.86.1 Point cloud max points

Maximum number of points displayed per point cloud. Values between 500 000 and 50 000 000 are accepted. This is independent of the number of points present in the dataset, which can be hundreds of billions.



Type:	Short
Saved in:	Registry
Range:	500000 to 50000000
Default value:	4000000

19.87 POINTCLOUDPOINTSIZE system variable

19.87.1 Point cloud point size

Point cloud point display size.


Type:	Short
Saved in:	Drawing
Range:	1 to 10
Default value:	2

19.88 POLARADDANG system variable

19.88.1 Polar add angles

Contains a list of user-defined polar snap angles. Up to 10 angles, up to 25 characters each, separated with semicolons (;). Requires POLARMODE flag 0x04 to be set (Use additional polar tracking angles). The AUNITS system variable sets the format for display of angles. Unlike POLARANG, POLARADDANG angles do not result in multiples of their values.

Type:	String
Saved in:	Registry
Default value:	



19.89 POLARANG system variable

19.89.1 Polar angle

Specifies the increment for polar angles (in degrees).

Type:	Real
Saved in:	Registry
Default value:	90.0
Unit	degrees

19.90 POLARDIST system variable

19.90.1 Polar distance

Specifies the snap increment for polar snap (SNAPTYPE set to 1).

Type:	Real
Saved in:	Registry
Default value:	0.0

19.91 POLARMODE system variable

19.91.1 Polar mode

Specifies the settings for entity snap tracking and polar snap tracking. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 15
Default value:	1
Possible options:	1: Relative 2: Use polar tracking settings in entity snap tracking 4: Use additional polar tracking angles 8: Press SHIFT to acquire entity snap tracking points

19.92 POLYSIDES system variable

19.92.1 Polygon sides

Stores the number of sides last used with the POLYGON command. Values between 3 and 1024 are accepted.

Type:	Short
Saved in:	Not saved
Range:	3 to 1024
Default value:	4

19.93 POPUPS system variable

19.93.1 Popups

Shows the status of the currently configured display driver.

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Don't support dialog boxes, the menu bar, and icon menus On (1): Support dialog boxes, the menu bar, and icon menus



19.94 PREVIEWDELAY system variable

19.94.1 Delay to preview selection

Specifies how many milliseconds to wait before highlighting the (sub)entity(ies) under the cursor.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1000
Default value:	30

19.95 PREVIEWEFFECT system variable

19.95.1 Selection preview effect

Specifies how selection preview is displayed. (Not yet supported)

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Dashed lines 1: Thickened lines 2: Dashed and thickened lines

19.96 PREVIEWFILTER system variable

19.96.1 Selection preview filter

Specifies which entity types are excluded from selection previewing. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry



Range:	to 63
Default value:	1
Possible options:	1: Exclude entities on locked layers 2: Exclude entities in xrefs 4: Exclude tables 8: Exclude multiline text entities 16: Exclude hatch entities 32: Exclude entities in groups

19.97 PREVIEWTYPE system variable

19.97.1 Preview type

Specifies which view is used for drawing preview thumbnails. (Not yet supported)

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Last saved view 1: Home view

19.98 PREVIEWWNDINOPENDLG system variable

19.98.1 Preview window in open dialog

Specifies if the the preview pane is displayed in the Open dialog box.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	On
Possible values:	Off (0): Don't display preview in the Open dialog box On (1): Display preview in the Open dialog box



19.99 PRINTFILE system variable

19.99.1 Print file

Specifies the alternate name for plot files.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	.

19.100 PRINTPDFPREVIEW system variable

19.100.1 Print As PDF Preview

Specifies whether Print As PDF preview uses a system default PDF viewer or an internal program window.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: Use BricsCAD window 1: Use external viewer

19.101 PRODUCT system variable

19.101.1 Product

Displays the product name.

Read-only

Type:	String
Saved in:	Not saved
Default value:	"BricsCAD"



19.102 PROFILEOFFSETBEHAVIOR system variable

19.102.1 Profile offset behavior

Allows to keep the position of the solid or its axis when changing the profile offset.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Keep axis 1: Keep solid

19.103 PROGBAR system variable

19.103.1 Progress bar

Specifies the display of the progress bar.

BricsCAD only

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Don't show progress bar On (1): Show progress bar

19.104 PROGRAM system variable

19.104.1 Program

Displays the program name.

Read-only

Type:	String
Saved in:	Not saved



Default value:	"BricsCAD"
----------------	------------

19.105 PROJECTIONTYPE system variable


19.105.1 Drawing views position scheme

Switches between first and third angle projection types. These angle projections are a way to represent 3D entities in 2D drawing views. These projection types will show the same views but the difference between the two types is the position of these views (top, right, left, bottom). See Generated drawing views to learn more about it.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: First angle projection type (Europe). 1: Third angle projection type (United States, Canada, Australia).



Projection	Symbol
First angle	
Third angle	





19.106 PROJECTNAME system variable

19.106.1 Project name

Gives a project name to the current drawing. Project names help to keep track of Xrefs and images easier by assigning additional support paths specific to the project only.

Type:	String
Saved in:	Drawing
Default value:	

19.107 PROJECTSEARCHPATHS system variable

19.107.1 Project search paths

Stores a list of project names, each holding a list of folders to be searched. If external references and images are not found in the saved path, the project search paths are used to find the external references and images.

BricsCAD only

Type:	String
Saved in:	Preference

19.108 PROJMODE system variable

19.108.1 Projection mode

Specifies the projection mode for the TRIM and EXTEND commands. If the cutting entity is not in the same plane as the entity you want to TRIM/EXTEND, this system variable defines how the intersection is to be calculated.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1



Possible values:	0: True 3D mode (no projection) 1: Project to the XY plane of the current UCS 2: Project to the current view plane
------------------	--

19.109 PROMPTMENU system variable

19.109.1 Prompt menu

Specifies the command prompt menu mode.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 5
Default value:	0
Possible values:	0: Don't display prompt menu 1: Display prompt menu 2: Display prompt menu at top left corner 3: Display prompt menu at top right corner 4: Display prompt menu at bottom left corner 5: Display prompt menu at bottom right corner

19.110 PROMPTMENUFLAGS system variable

19.110.1 Prompt menu flags

Options to finetune the behavior of prompt menus. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 7
Default value:	0



Possible options:	1: Show hidden options. Hidden options display in italics. 2: Hide prompt menu during selection 4: Disable selection options in the prompt menu
-------------------	---

19.111 PROMPTOPTIONFORMAT system variable

19.111.1 Prompt option format

Specifies how command options are displayed in the Command line prompt. A command option has a keyword, a description and a shortcut. The shortcut is the keyword without lower case characters (a-z). e.g. the third option of the CIRCLE command:

Keyword = TanTanRad

Description = Tangent-Tangent-Radius

Shortcut = TTR

Note: The PROMPTOPTIONTRANSLATEKEYWORDS user preference controls whether translations of command option keywords are loaded or not. If disabled, the local keyword will be a copy of the global (English) keyword. As a result global shortcuts can be used without an underscore.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 4
Default value:	0



Possible values:	<p>0: Show description only, adjust casing to mark shortcut Select center of circle or [2 Point/3 Point/Tangent-Tangent-Radius/turn Arc into circle/Multiple circles]: This is the default prompt option format in the English version. In other versions the default prompt option format depends on local standards.</p> <p>1: Show keyword only Select center of circle or [2Point/3Point/TanTanRad/Arc/Multiple]:</p> <p>2: Show description and keyword in brackets Select center of circle or [2 Point(2Point)/3 Point(3Point)/Tangent-Tangent-Radius(TanTanRad)/Turn arc into circle(Arc)/Multiple circles(Multiple)]:</p> <p>3: Show description and shortcut in brackets Select center of circle or [2 Point(2P)/3 Point(3P)/Tangent-Tangent-Radius(TTR)/Turn arc into circle(A)/Multiple circles(M)]:</p> <p>4: Show local keyword and global keyword in brackets (relevant in localized versions only) Select center of circle or [2Point/3Point/TanTanRad/Arc/Multiple]:</p>
------------------	---

19.112 PROMPTOPTIONTRANSLATEKEYWORDS system variable

19.112.1 Prompt option translate keywords

Specifies whether translations of command option keywords are loaded or not. If disabled, the local keyword will be a copy of the global (English) keyword. As a result global shortcuts can be used without underscore.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't load translations of keywords On (1): Load translations of keywords

19.113 PROPAGATESEARCHSPACE system variable

19.113.1 Search space

Controls an extra prompt in which propagates ask for a search space. With this search space selection, the places that will be propagated to can be limited.

BricsCAD only



Type:	Boolean
Saved in:	Registry
Default value:	0 (OFF)

19.114 PROPAGATETOLERANCE system variable

19.114.1 Position tolerance

The tolerance with which propagate evaluates the equality of positions when mapping details on a target location. Expressed in drawing units.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.00001

19.115 PROPERTYPREVIEW system variable

19.115.1 Property preview

Specifies whether selected entities will immediately show property changes when hovering combobox list values in the Properties panel.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Selected entities won't show property changes when hovering combobox list values in the Properties panel On (1): Selected entities will show property changes when hovering combobox list values in the Properties panel

19.116 PROPERTYPREVIEWDELAY system variable

19.116.1 Property Preview Delay

Specifies how many milliseconds to wait before preview the hovered property value.



BricsCAD only

Type:	Short
Saved in:	Preference
Range:	100 to 10000
Default value:	500

19.117 PROPERTYPREVIEWOBJLIMIT system variable

19.117.1 Property Preview Object Limit

Specifies the maximum number of entities for Property Preview (no Property Preview if more is selected).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 30000
Default value:	500

19.118 PROPPREVTIMEOUT system variable

19.118.1 Property Preview Timeout

Specifies the time (in seconds) allowed for Property Preview generation, before it is canceled.

Type:	Short
Saved in:	Preference
Range:	1 to 5
Default value:	1



19.119 PROPUNITS system variable

19.119.1 Property units

Specifies whether certain types of property values are automatically formatted (e.g. mm²/cm²/m² for areas), when INSUNITS is not zero.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 255
Default value:	47
Possible values:	1: Format length properties 2: Format area properties 4: Format volume properties 8: (Reserved) 16: Format dynamic dimensions 32: Format mass properties

19.120 PROXYGRAPHICS system variable

19.120.1 Proxy graphics

Specifies whether images of proxy entities are saved in the drawing. If switched off, a bounding box displays instead.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't save images with the drawing On (1): Save images with the drawing

19.121 PROXYNOTICE system variable

19.121.1 Proxy notice

Displays a notice when you open a drawing containing custom entities created by an application that is not present.



Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display proxy warning On (1): Display proxy warning

19.122 PROXYSHOW system variable

19.122.1 Proxy show

Specifies how proxy entities display in a drawing.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Proxy entities are not displayed 1: Graphic images are displayed for all proxy entities 2: Only the bounding box is displayed for all proxy entities

19.123 PROXYWEBSEARCH system variable

19.123.1 Proxy web search

Specifies whether the program checks for object enablers.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Prevent checking for object enablers 1: Check for object enablers only if a live Internet connection is present



19.124 PSLTSCALE system variable

19.124.1 Paper space linetype scale

Specifies the linetype scaling in paper space. If On or 1, the length of the dashes is based on paper space drawing units. Linetypes display identically, in various viewports which are scaled differently. This means that the linetype scaling is independent from the viewport scale. When changing PSLTSCALE, REGEN or REGENALL is needed to update the display.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: No special linetype scaling 1: Viewport scaling governs linetype scaling

19.125 PSOLHEIGHT system variable

19.125.1 Polysolid height

Specifies the default height, in drawing units, used by the POLYSOLID command, for swept solid entities.

Type:	Real
Saved in:	Drawing
Default value:	80.0

19.126 PSOLWIDTH system variable

19.126.1 Polysolid width

Specifies the default width, in drawing units, used by the POLYSOLID command, for swept solid entities.

Type:	Real
Saved in:	Drawing
Default value:	5.0



19.127 PSTYLEMODE system variable

19.127.1 Plot style mode

Indicates the plot style mode of the current drawing: Color-Dependent or Named-Plot-Style. To convert the current drawing to use named or color-dependent plot styles, use CONVERTPSTYLES.

Read-only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Named plot style tables 1: Color-dependent plot style tables

19.128 PSTYLEPOLICY system variable

19.128.1 Plot style policy

Specifies whether the color of an entity is associated with its plot style. If PSTYLEPOLICY is 0, the plot style for new entities is set to the default, defined in DEFPLSTYLE and the plot style for new layers is set to the default, defined in DEFLPLSTYLE.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: No association between color and plot style 1: Associate an entity's plot style with its color

19.129 PSVPSCALE system variable

19.129.1 Paper space viewport scale

Specifies the scale factor for new viewports. The view scale factor is used with the VPORTS command. The view scale factor is defined by comparing the ratio of units in paper space to the units in newly created



model space viewports. The view scale factor you set is used with the VPORTS command. A value of 0 means the scale factor is Scaled to Fit.

Type:	Real
Saved in:	Drawing
Default value:	0.0

19.130 PUBLISHALLSHEETS system variable

19.130.1 Publish all sheets

Specifies whether to load the contents of the active document or of all open documents in the Publish dialog box.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Only the contents of the current document automatically load On (1): The contents of all open documents automatically load

19.131 PUBLISHCOLLATE system variable

19.131.1 Collate published sheets

Specifies whether to combine published sheets with equal output configurations into single multi-page plot job.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0 (OFF)

19.132 PUCSBASE system variable

19.132.1 Paper space UCS base

Specifies the name of the UCS that defines the orthographic UCS in paper space.



Read-only

Type:	String
Saved in:	Drawing

19.133 PDFANIMATIONFPS system variable

19.133.1 Frames per second

Frames per second for an animation.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	24



20. Q

20.1 QAFLAGS system variable

20.1.1 Quality Assurance flags

Internal system variable with flags for Quality Assurance and testing. The value is stored as a bitcode using the sum of the values of all selected options.

Attention: this is subject to change, and not intended for regular use. Some of these options could have unpredictable or unwanted side-effects.

Type:	Short
Saved in:	Registry
Range:	0 to 32767
Default value:	0
Possible options:	<p>1: Red device: no low quality draw 2: No pause during text screen listings 4: No 'alert' dialogs (text display instead) 8: Have Warnings act as Errors and stop scripts 16: Minimal audit report 32: Disable window recreation on switch between 2d and rendered visual styles. 64: Enable various performance measurements printed as info prompts 128: Parallel vectorization: EnableSchedulerLogOutput 256: Cmd message enable 512: Dcl take screenshot 1024: Print time on statusbar 2048: No crash dump file 4096: Create assert log file 8192: Create RED files during rendering 16384: Parallel vectorization performance measurement</p>

20.2 QTEXTMODE system variable

20.2.1 Quick text mode

Specifies how text entities are displayed. When On: this turns on quick text mode, rendering all text – text, mtext, attributes, dimension text, and zo on—as rectangles. When Off (0): this turns off quick text mode, returning text to its normal display. This is useful when drawings contain much text, thereby slowing down





the display of the drawing, but you still need to see the location of the text. The rectangles display the color of the text as well. To view changes on existing entities, perform a REGEN.

Type:	Boolean
Saved in:	Drawing
Range:	Off
Possible values:	Off (0): Don't display box in place of text On (1): Display box in place of text



ZONE 1 is smaller than ZONE 2

The area of ZONE 3 is equal
to the area of ZONE 1





20.3 QUADCOMMANDLAUNCH system variable

20.3.1 Quad default command launch

Enables launching the default quad command without requiring to click on the button. The default quad command depends on which command from the quad is used last.

When 0: hover over an entity to see the quad and click on the command button to launch the command.

When 1: hover over an entity to see the quad and right-click on the entity to launch the command, instead of clicking on the command button first.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Launch default quad command only by pressing button 1: Launch default quad command on mouse right-click when quad is displayed

20.4 QUADDISPLAY system variable

20.4.1 Quad display

Specifies when to display the quad. When the value is 8: suppress the quad when hovering over entities that are not in the current selection set; set **Show Quad on right-click**ON to display the Quad. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-15 to 15
Default value:	5



Possible options:	negative: Switch off quad 1: Display the quad when the cursor hovers on an entity 2: Display the quad when entities are selected 4: Display the quad on right click 8: Suppress the quad on hover when entities are selected
-------------------	--

20.5 QUADEXPANDDELAY system variable

20.5.1 Quad expand delay

Specifies the delay after which the quad will expand after mouse-enter.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	160

20.6 QUADEXPANDTABDELAY system variable

20.6.1 Quad expand tab delay

Specifies the delay after which hovering over a quad tab will expand the underlying buttons.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	50

20.7 QUADGOTRANSPARENT system variable

20.7.1 Quad go transparent

Specifies if the quad starts should go transparent while the mouse is moving away from it.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	Off
Possible values:	Off (0): Don't go transparent On (1): Go transparent

20.8 QUADHIDEDELAY system variable

20.8.1 Quad hide delay

Specifies how many milliseconds to wait before the quad is hidden as soon as the mouse stops moving while it's in the QuadHideMargin zone.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	350

20.9 QUADHIDEMARGIN system variable

20.9.1 Quad hide margin

Specifies the width of a margin around the quad. As long as the mouse keeps moving inside this margin, the quad will stay visible. It will gradually go transparent if QuadGoTransparent is on. As soon as the mouse movement stops, or when the mouse is moved beyond the margin, the quad will disappear.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	50

20.10 QUADICONSIZE system variable

20.10.1 Quad icon size

Specifies the size of the quad tool buttons.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Workspace
Default value:	1
Possible values:	0: Small icons 1: Large icons 2: Extra-large icons


Small Icons



Large Icons



Extra Large Icons




20.11 QUADICONSPACE system variable

20.11.1 Quad icon space

Specifies the margin around the icons.

Narrow




Normal





Wide



BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Narrow 1: Normal 2: Wide

20.12 QUADMOSTRECENTITEMS system variable

20.12.1 Quad most recent items

Specifies how many most recent items should be displayed in the top bar of the quad. The remaining slots are filled with intelligent suggestions depending on the user context.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 16
Default value:	4

20.13 QUADPOPUPCORNER system variable

20.13.1 Quad popup corner

Specifies where the quad will popup relative to the current cursor position.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Upper right 1: Middle right 2: Lower right

20.14 QUADROLLOVERDELAY system variable

20.14.1 Quad rollover delay

Specifies the delay after which rollover properties appear on the quad.

Note: This is ignored in rollover-only mode (when QUADDISPLAY is off and ROLLOVERTIPS is on - in that case, the rollover properties are always shown immediately)

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 10000
Default value:	0

20.15 QUADSHOWDELAY system variable

20.15.1 Quad show delay

Specifies how many milliseconds to wait before the quad is shown when highlighting a (sub)entity.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	150



20.16 QUADWIDTH system variable

20.16.1 Quad width

Specifies in how many columns the quad icons are arranged.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	4 to 16
Default value:	6



21. R

21.1 R12SAVEACCURACY system variable

21.1.1 R12 Save accuracy

Specifies the number of segments between spline control segments or on 90 degrees elliptical arcs for saving ellipses and splines to R12.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	8

21.2 R12SAVEDEVIATION system variable

21.2.1 R12 Save deviation

Specifies the deviation for saving ellipses and splines to R12.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.0

21.3 RASTERPREVIEW system variable

21.3.1 Raster preview

Specifies whether or not a preview image is saved with the drawing. This image is displayed by file managers and other programs.

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't create preview image On (1): Create preview image
------------------	---

21.4 RE_INIT system variable

21.4.1 Reinitialize Aliases

Reinitializes the digitizer, digitizer port and/or reloads PGP file (command aliases). The value is stored as a bitcode using the sum of the values of all selected options.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 21
Default value:	0
Possible options:	1: Digitizer input/output port reinitialization 4: Digitizer reinitialization 16: PGP file reinitialization (reload)

21.5 REALTIMESPEEDUP system variable

21.5.1 Realtime speedup

Specifies the number of mouse messages that are skipped during Realtime Pan operations.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 10
Default value:	5

21.6 REALWORLDSCALE system variable

21.6.1 Real world scale

Specifies the rendering of materials with units set to real-world scale.



Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't render real-world scale materials On (1): Render real-world scale materials

21.7 RECENTFILES system variable

21.7.1 Recent file list max count

Specifies the maximum number of files shown in the "Recent Files" section in the File menu (MRU's).

Values between 0 and 60 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 60
Default value:	12

21.8 RECENTPATH system variable

21.8.1 Recent path

Shows the most recently used path.

BricsCAD only

Type:	String Standard
Saved in:	Preference

21.9 REDHILITE_DUCSLOCKED_FACE_ALPHA system variable

21.9.1 Face opacity

Specifies the transparency of the highlighted face to which the Dynamic UCS has been locked by pressing the Shift key. 0 is fully transparent and 100 is fully opaque.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	25 to 100
Default value:	25

21.10 REDHILITE_DUCSLOCKED_FACE_COLOR system variable

21.10.1 Face color

Specifies the highlight color of a face to which the Dynamic UCS has been locked by pressing the Shift key.
BricsCAD only

Type:	String
Saved in:	Preference
Default value:	#007AFF

21.11 REDHILITE_HIDDENEDGE_ALPHA system variable

21.11.1 Edge opacity

Specifies the transparency of the edge. 0 is fully transparent and 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	50

21.12 REDHILITE_HIDDENEDGE_COLOR system variable

21.12.1 Edge color

Specifies the color of the edge.

BricsCAD only



Type:	String
Saved in:	Preference
Default value:	White (Settings dialog) #FFFFFF (Command line)

21.13 REDHILITEFULL_EDGE_ALPHA system variable

21.13.1 Edge opacity

Specifies the transparency of the edge. 0 is fully transparent and 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	100

21.14 REDHILITEFULL_EDGE_COLOR system variable

21.14.1 Edge color

Specifies the color of the edge.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	0, 122, 255 (Settings dialog) #007AFF (Command line)

21.15 REDHILITEFULL_EDGE_SHOWHIDDEN system variable

21.15.1 Hidden edges

Specifies whether hidden edges should be displayed.

BricsCAD only



Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't show hidden edges On (1): Show hidden edges

21.16 REDHILITEFULL_EDGE_SMOOTHING system variable

21.16.1 Edge smoothing

Specifies whether to display smooth (anti-aliased) lines.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Smooth edges off On (1): Smooth edges on

21.17 REDHILITEFULL_EDGE_THICKNESS system variable

21.17.1 Edge thickness

Specifies the thickness of the edge (in pixels).

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 20.0
Default value:	2.0



21.18 REDHILITEFULL_FACE_ALPHA system variable

21.18.1 Face opacity

Specifies the transparency of the face. 0 is fully transparent and 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	10

21.19 REDHILITEFULL_FACE_COLOR system variable

21.19.1 Face color

Specifies the color of the face.

BricsCAD only

Type:	String
Saved in:	Preference
Possible values:	0, 122, 255 (Settings dialog) #007AFF (Command line)

21.20 REDHILITEPARTIAL_SELECTEDEDGE_ALPHA system variable

21.20.1 Edge opacity

Specifies the transparency of the edge. 0 is fully transparent and 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	100



21.21 REDHILITEPARTIAL_SELECTEDEDGE_COLOR system variable

21.21.1 Edge color

Specifies the color of the edge.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	255, 128, 0 (Settings dialog) #FF8000 (Command line)

21.22 REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable

21.22.1 Glow

Specifies whether a second line below the primary line is shown, which can be used for glow effect.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show glow On (1): Show glow

21.23 REDHILITEPARTIAL_SELECTEDEDGE_SMOOTHING system variable

21.23.1 Edge smoothing

Specifies whether to display smooth (anti-aliased) lines.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



Possible values:	Off (0): Smooth edges off On (1): Smooth edges on
------------------	--

21.24 REDHILITEPARTIAL_SELECTEDEDGE_THICKNESS system variable

21.24.1 Edge thickness

Specifies the thickness of the edge (in pixels).

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 20.0
Default value:	2.0

21.25 REDHILITEPARTIAL_SELECTEDEDGEGLOW_ALPHA system variable

21.25.1 Glow opacity

Specifies the transparency of the glow. 0 is fully transparent and 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	75

21.26 REDHILITEPARTIAL_SELECTEDEDGEGLOW_COLOR system variable

21.26.1 Glow color


Specifies the color of the glow.

BricsCAD only

Type:	String
-------	--------



Saved in:	Preference
Default value:	White (Settings dialog) #FFFFFF (Command line)



21.27 REDHILITEPARTIAL_SELECTEDEDGEGLOW_SMOOTHING system variable

21.27.1 Glow smoothing

Specifies whether to display smooth (anti-aliased) lines for glow.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Smooth glow lines off On (1): Smooth glow lines on

21.28 REDHILITEPARTIAL_SELECTEDEDGEGLOW_THICKNESS system variable

21.28.1 Glow thickness


Specifies the thickness of the glow (in pixels).

BricsCAD only

Type:	Real
-------	------



Saved in:	Preference
Range:	0.0 to 20.0
Default value:	3.0



21.29 REDHILITEPARTIAL_SELECTEDFACE_ALPHA system variable

21.29.1 Face opacity

Specifies the transparency of the face. 0 is fully transparent and 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	10

21.30 REDHILITEPARTIAL_SELECTEDFACE_COLOR system variable

21.30.1 Face color

Specifies the color of the face.

BricsCAD only

Type:	String
-------	--------



Saved in:	Preference
Default value:	#007AFF

21.31 REDHILITEPARTIAL_UNSELECTEDEDGE_SHOWHIDDEN system variable

21.31.1 Hidden edges

Specifies whether hidden edges should be displayed.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show hidden edges On (1): Show hidden edges

21.32 REDSDKLINESMOOTHING system variable

21.32.1 Line smoothing

Specifies whether line smoothing is enabled for 3d rendering modes. Has no effect if anti-aliasing is on.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Line smoothing off On (1): Line smoothing on

21.33 REDUCELENGTHTYPE system variable

21.33.1 Reduce Length Type

Defines the default flow fitting reduce length type.

BricsCAD only



Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

21.34 REDUCELENGTHVALUE system variable

21.34.1 Reduce Length Value

Defines the default flow fitting reduce length value.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.5

21.35 REFEDITLOCKNOTINWORKSET system variable

21.35.1 Refedit lock

Specifies whether entities that are not in the working set will be locked during the **RefEdit** command.

Locked entities are seen, but cannot be edited.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Lock entities not in working set off On (1): Lock entities not in working set on



21.36 REFEDITNAME system variable

21.36.1 Refedit name

Shows the name of the currently edited reference.

Read-only

Type:	String
Saved in:	Not saved
Default value:	

21.37 REFPATHTYPE system variable

21.37.1 Default path type of reference files

Controls whether reference files store a full, relative or no path upon attachment.

Type:	Short
Saved in:	Registry
Default value:	1
	0: No path 1: Relative path 2: Full path

Прим.: Reference files that are already attached are not affected.

21.38 REGENMODE system variable

21.38.1 Regeneration mode

Toggles the automatic regeneration of the drawing On/Off. BricsCAD will regenerate the display automatically when REGENMODE is On, but in a few cases a forced regeneration of the drawing might be necessary. This is done by the REGEN command.

Type:	Boolean
Saved in:	Drawing
Default value:	On



Possible values:	Off (0): Turn off REGENAUTO command On (1): Turn on REGENAUTO command
------------------	--

21.39 REGEXPAND system variable

21.39.1 Registry paths expanding type

Specifies type of storing paths in a registry (absolute or expandable). The new value is applied after application re-start.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't store paths in a portable format using environment variables On (1): Store paths in a portable format using environment variables

21.40 REMEMBERFOLDERS system variable

21.40.1 Remember folders

Specifies the default path for the standard file selection dialog boxes.

When 0: When you start the program by double-clicking a shortcut icon, if a Start In path is specified for the icon, that path is used as the default for all standard file selection dialog boxes.

When 1: The default path in each standard file selection dialog box is the last path used in that dialog box. The Start In folder specified for the shortcut icon is not used.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Use Start In path 1: Use last path used



21.41 RENDERCOMPOSITIONMATERIAL system variable

21.41.1 Render composition material

Controls whether composition materials in a BIM model are rendered or not in the **BIM**, **Modeling**, **Realistic** or **X-Ray** visual style.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0-1 (On-Off)
Default value:	0
Possible values:	0: Do not render the materials of compositions and their plies. 1: Render the materials of compositions and their plies.

Прим.:

The RENDERCOMPOSITIONMATERIAL system variable is only available for BIM and Ultimate license levels.

21.42 RENDERMATERIALDOWNLOAD system variable

21.42.1 Download missing resources for render materials

Specifies whether some missing resources for render materials are downloaded automatically.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't download missing resources for render materials On (1): Download missing resources for render materials

21.43 RENDERMATERIALSPATH system variable

21.43.1 Render materials directory path

Specifies the folder(s) in which BricsCAD should look for user created render material files.



BricsCAD only

Type:	String
Saved in:	Registry

21.44 RENDERUSINGHARDWARE system variable

21.44.1 Render using hardware

Specifies if rendering should use the hardware. Switch this off if you encounter rendering problems caused by graphic card or driver. The application might need to be restarted after changing this setting.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	1
Possible values:	0: Use software only (slower) 1: Prefer hardware (faster) 2: Prefer software (only for testing purposes) 3: Use hardware only (only for testing purposes)

21.45 REPORTPANELMODE system variable

21.45.1 Report panel mode

Specifies the mode of report panel. Applicable only for commands which support it.

- Classic: Report panel has its classic appearance as dockable window.
- Modern: Report panel is a transparent window.
- Hidden: Report panel is a transparent window that is hidden into the status bar.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2



Default value:	2
Possible values:	0: Classic 1: Modern 2: Hidden

21.46 REPOSITORYFOLDER system variable

21.46.1 Repository folder

Specifies the path to the current repository.

BricsCAD only

Type:	String Standard
Saved in:	Registry

21.47 RESTORECONNECTIONS system variable

21.47.1 Restore Connections

Controls the restoring of structural connections after commands.

Type:	Boolean
Saved in:	Registry
Default value:	1

21.48 RESTORELOSTFOCUS system variable

21.48.1 Restore lost focus (Linux)

Specifies whether to restore a lost focus. Depending on window manager, focus may be lost by using short-lived windows like quad, tipsto.

Type:	Boolean
Saved in:	Registry
Possible values:	Off (0): Do not try to recover from focus loss. On (1): Attempt automatic recovery from focus loss.



21.49 RETAINEDGRAPHICS system variable

21.49.1 Retained Graphics

Toggle the use of retained graphics. Retained graphics can improve the performance of certain operations (for example rotating and panning the camera).


Type:	Boolean
Saved in:	Preference
Default value:	1
Possible values:	Off (0): Don't use retained graphics. On (1): Use retained graphics

21.50 REVCLLOUDARCSTYLE system variable


21.50.1 Revision cloud default arc style

Specifies the default arc style for revision clouds: Normal or Calligraphy.

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Normal 1: Calligraphy



Normal



Calligraphy




21.51 REVCLLOUDCREATEMODE system variable

21.51.1 Revision cloud creation mode

Specifies the default mode for creating revision clouds.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Freehand 1: Rectangular 2: Polygonal



Freehand

Rectangular

Polygonal

21.52 REVCLLOUDGRIPS system variable

21.52.1 Revision cloud grips

Specifies how grips are displayed for revision cloud entities.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Displays grips on every arc segment On (1): Displays only the most relevant grips



21.53 REVCLODMAXARCLENGTH system variable

21.53.1 Revision cloud default maximum arc length

Specifies the default maximum arc length for revision clouds. The maximum arc length is multiplied by the value of the DIMSCALE variable.

Type:	Real
Saved in:	Registry
Default value:	0.375

21.54 REVCLODMINARCLENGTH system variable

21.54.1 Revision cloud default minimum arc length

Specifies the default minimum arc length for revision clouds. The minimum arc length is multiplied by the value of the DIMSCALE variable.

Type:	Real
Saved in:	Registry
Default value:	0.375

21.55 RHINOVERSION system variable

21.55.1 Rhino version

Version of the 3dm file (open-source 3D modal format).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	2 to 60
Default value:	60



Possible values:	2: Rhino 2 3: Rhino 3 4: Rhino 4 50: Rhino 5 60: Rhino 6
------------------	--

21.56 RIBBONDOCKEDHEIGHT system variable

21.56.1 Ribbon docked height

Stores the preferred height of the ribbon bar. The height can have values between 0 and 500. For automatic height calculation set value to 0.

Type:	Short
Saved in:	Registry
Range:	0 to 500
Default value:	0

21.57 RIBBONPANELMARGIN system variable

21.57.1 Panel margin

Size, in pixels, of blank space at ribbon panel edges.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 50
Default value:	8

21.58 RIBBONSTATE system variable

21.58.1 Ribbon state

Indicates whether the ribbon bar is shown or not. The ribbon can be closed with the RIBBONCLOSE command and can be displayed with the RIBBON command.

Read-only



Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't show ribbon bar Registry On (1): Show ribbon bar

21.59 RIBBONTOOLSIZEx system variable

21.59.1 Ribbon tool size

Specifies the size of the ribbon tool buttons.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0
Possible values:	0: Small buttons 1: Large buttons 2: Extra-large buttons

21.60 ROAMABLEROOTPREFIX system variable

21.60.1 Roamable root prefix

Stores the full path to the root folder where roamable files for the current user, such as menus and plotstyles, were installed.

Read-only

Type:	String Standard
Saved in:	Registry



21.61 ROLLOVEROPACITY system variable

21.61.1 Rollover opacity

Specifies a degree of opacity for the quad when it's in rollover state. Between 10 (very transparent) and 100 (fully opaque).

Type:	Short
Saved in:	Registry
Range:	10 to 100
Default value:	100

21.62 ROLLOVERSELECTIONSET system variable

21.62.1 Rollover selection set

Specifies if/how the rollover tips show properties of hovered selection set. (setting the value to 2 can be slow on large selection sets).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	2
Possible values:	0: No selection set properties 1: General selection set properties 2: Properties shared by all selected entities

21.63 ROLLOVERTIPS system variable

21.63.1 Rollover tips

Specifies whether entity properties are displayed in the quad while hovering.

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Don't show properties on hover On (1): Show properties on hover

21.64 RTDISPLAY system variable

21.64.1 Realtime display

Specifies whether raster images and OLE entities fully display during Realtime ZOOM or PAN or as outlines only.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Display raster images and OLE content 1: Display outlines only

21.65 RTROTATIONSPEEDFACTOR system variable

21.65.1 Realtime Rotation Speed Factor

Specifies the rotation speed for the Look and Walk tools (rtlook and rtwalk commands) [0.01 - 100].

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.01 to 100.
Default value:	1

21.66 RUBBERBANDCOLOR system variable

21.66.1 Rubberband color

Specifies the color for the Rubberband line. Values between 1 and 255 are accepted.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	40

21.67 RUBBERBANDSTYLE system variable

21.67.1 Rubberband dashed style

Enables or disables the dashed visualization for the rubberband.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Dashed style off On (1): Dashed style on

21.68 RUBBERSHEET (for OS X) system variable

21.68.1 Rubbersheet Touchpad

Specifies whether to allow simultaneous zoom/rotate/pan by dual finger move on touchpad.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Dual finger touch simultaneously zooms/rotates/pans off On (1): Dual finger touch simultaneously zooms/rotates/pans on



21.69 RUBBERSHEETSENSIBILITY (FOR OS X) system variable

21.69.1 Rubbersheet gesture activation sensibility

Specifies how easy touchpad gestures are activated.

Type:	Short
Saved in:	Registry
Range:	0 to 10
Default value:	5

21.70 RULERDISPLAY system variable

21.70.1 Ruler Display

Specifies the display of the ruler when moving objects using the manipulator or the DMPUSHPULL command.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Do not display ruler On (1): Display ruler when objects are moved using the manipulator or the DMPUSHPULL command.

21.71 RULERTEXTCOLOR system variable

21.71.1 Ruler Text Color

Specifies the color of the text on the ruler if the RULERDISPLAY system variable is on.

Type:	String
Saved in:	Registry
Default value:	#c8c8c8



Possible values:	RGB color code Hex color code Index color code
------------------	--

A new value for the variable can be entered in the command bar.

21.72 RUNASLEVEL system variable

21.72.1 Run as license level

Specifies at which license level to run BricsCAD. The new level will be in use after restarting. If the purchased license level is lower than RUNASLEVEL, RUNASLEVEL is ignored.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 5
Default value:	5
Possible values:	0: Lite 1: Pro 2: Platinum (Obsolete) 3: BIM 4: Mechanical 5: Ultimate

21.73 RVTRFALEVELOFDETAIL system variable

21.73.1 Level of detail

Specifies the level of detail for RVT and RFA Import.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	1 to 3
Default value:	3



Possible values:	1: Coarse 2: Medium 3: Fine
------------------	-----------------------------------

21.74 RVTVALIDATEBREP system variable

21.74.1 Validate BREP geometry

Disabling this may import more geometry without checking its integrity.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	0: Off (Disable) 1: ON (Enable)



22. S

22.1 SAFEMODE system variable

22.1.1 Safe mode

Specifies if executable code can be loaded and executed in the current session. Starting in a clean environment can help to eliminate potential causes of a crash.

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Allows executable code run On (1): Does not allow executable code to run

22.2 SAVECHANGETOLAYOUT system variable

22.2.1 Save changes to layout

Specifies whether to save changes the user makes in print dialog to the layout.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On

22.3 SAVEFIDELITY system variable

22.3.1 Save fidelity

Specifies whether the drawing is saved with visual fidelity. Controls whether the current display of the drawing is preserved when opened in a program that does not support annotative entities.

Type:	Boolean
Saved in:	Registry



Range:	0 to 1
Default value:	On
Possible values:	Off (0): Don't save with visual fidelity On (1): Save with visual fidelity

22.4 SAVEFILE system variable

22.4.1 Save file name

Specifies the current automatic save file name.

Read-only

Type:	String
Saved in:	Not saved

22.5 SAVEFILEPATH system variable

22.5.1 Save file path

Specifies the path to the folder where automatic saves and temporary files are stored.

Type:	String Standard
Saved in:	Registry

22.6 SAVEFORMAT system variable

22.6.1 Save format

Specifies the default save format for a drawing.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 39
Default value:	4



Possible values:	1: DWG 2018 2: DXF 2018 3: Binary DXF 2018 4: DWG 2013 5: DXF 2013 6: Binary DXF 2013 7: DWG 2010 8: DXF 2010 9: Binary DXF 2010 10: DWG 2007 11: DXF 2007 12: Binary DXF 2007 13: DWG 2004 14: DXF 2004 15: Binary DXF 2004 16: DWG 2000 17: DXF 2000 18: Binary DXF 2000 19: DWG R14 20: DXF R14 21: Binary DXF R14 22: DWG R13 23: DXF R13 24: Binary DXF R13 25: DWG R11/R12 26: DXF R11/R12 27: Binary DXF R11/R12 28: DXF R10 29: Binary DXF R10 30: DXF R9
------------------	--

22.7 SAVELAYERSAPSHOT system variable

22.7.1 Save Layer Snapshot with view

Specifies whether to save the layer settings with newly created views.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



22.8 SAVENAME system variable

22.8.1 Saved drawing name

Shows the file name and folder path of the current drawing.

Read-only

Type:	String
Saved in:	Not saved

22.9 SAVEONDOCSWITCH system variable

22.9.1 Save on document switch

Specifies whether the drawing is saved automatically when another document is activated.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't save on doc switch On (1): Save on doc switch

22.10 SAVEROUNDTRIP system variable

22.10.1 Save roundtrip

Specifies the saving of information in a database file to allow round-tripping of entity types not supported in the save file format.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On



22.11 SAVETIME system variable

22.11.1 Save time interval

Specifies the interval, in minutes, for automatic saves. If set to zero, automatic saves are turned off. Values between 0 and 240 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 240
Default value:	60
Possible values:	0: Turn off automatic saving 1 - 240: Saves the drawing at intervals specified (in minutes)

22.12 SCREENBOXES system variable

22.12.1 Screen menu boxes

Contains the number of boxes displayed in the screen menu. If the screen menu is turned off the value is zero.

Read-only

Type:	Short
Saved in:	Not saved

22.13 SCREENMODE system variable

22.13.1 Screen mode

Stores the graphic/text state of the program display.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 3



Possible values:	0: Text screen is displayed 1: Drawing area is displayed 2: Dual-screen display is configured
------------------	---

22.14 SCREENSIZE system variable

22.14.1 Screen size

Shows the size of the current viewport in pixels (width x height).

Read-only

Type:	2D point
Saved in:	Not saved

22.15 SCRLHIST system variable

22.15.1 Scroll history

Specifies the number of Command lines to track in the Command line.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 or greater
Default value:	256

22.16 SDI system variable

22.16.1 Single-document interface (Windows)

Specifies whether a drawing is opened in a new BricsCAD instance or an existing instance. Partially implemented: SDI variable controls double-click behavior for drawings but it is still possible to open multiple documents in each BricsCAD instance. SDI setting 2 and 3 are Not saved. If SDI is set to 3, the program switches it back to 1 when the application that doesn't support multiple drawings is unloaded.

Type:	Short
Saved in:	Registry



Range:	0 to 3
Default value:	0
Possible values:	<p>0: Multiple-drawing interface 1: Single-drawing interface 2: (Read-only) Multiple-drawing interface is disabled because an application has been loaded that does not support multiple drawings 3: (Read-only) Multiple-drawing interface is disabled because the user has set SDI to 1 and the program has loaded an application that does not support multiple drawings. (SDI was set to 1 before the application was loaded)</p>

22.17 SECTIONRESULTINTERVAL system variable

22.17.1 Section result interval

The distance between generated section blocks in model space.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	10000

22.18 SECTIONSCALE system variable

22.18.1 Section scale

Scale of the viewport created as the result of section generation.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.02



22.19 SECTIONSETTINGSSEARCHPATH system variable

22.19.1 Section settings search path

Specifies the folder(s) in which BricsCAD® should look for BIM section styles, BIM tag styles and drawing customizations. Search paths are separated by a semicolon (;).

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	" "

22.20 SECTIONSHEETSETTEMPLATEIMPERIAL system variable

22.20.1 Section sheet set template imperial

Sets the sheetset file (dst) that will be used as a template when a new sheetset is created on generating sections when MEASUREMENT is 0 (imperial). The default file is BIM-section-imperial.dst, which can be found in the {SheetSetTemplatePath} folder.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	BIM-section-imperial.dst

Прим.: The SECTIONSHEETSETTEMPLATEIMPERIAL system variable is only available for **BIM** and **Ultimate** license levels.

22.21 SECTIONSHEETSETTEMPLATEMETRIC system variable

22.21.1 Section sheet set template metric

Sets the sheetset file (dst) that will be used as template when a new sheetset is created on generating sections when MEASUREMENT is 1 (metric). The default file is BIM-section-metric.dst, which can be found in the {SheetSetTemplatePath} folder.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
Default value:	BIM-section-metric.dst

Прим.: The SECTIONSHEETSETTEMPLATEMETRIC system variable is only available for **BIM** and **Ultimate** license levels.

22.22 SECURELOAD system variable

22.22.1 Executable file security policy

Specifies security policy for loading executable files.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 2
Default value:	0
Possible values:	0: No security policy 1: Warn if loading from untrusted location 2: Load only from trusted locations

22.23 SELECTIONANNODISPLAY system variable

22.23.1 Show all annotation scales on selection

Specifies if all scale representations for selected annotative entities are displayed.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable annotation scales display On (1): Enable annotation scales display



22.24 SELECTIONAREA system variable

22.24.1 Selection area

Specifies the display of selection area effects.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show selection area effects On (1): Show selection area effects

22.25 SELECTIONAREAOPACITY system variable

22.25.1 Selection area opacity

Specifies the transparency of the selection area (lower value = more transparent). This is only in effect when SELECTIONAREA setting is On.

Type:	Short
Saved in:	Registry
Range:	0 to 100
Default value:	25

22.26 SELECTIONMODES system variable

22.26.1 Selection modes

Specifies which subentities or detected boundaries, should be highlighted in selection preview. The value is stored as a bitcode using the sum of the values of all selected options. While in selection preview, you can use the TAB key to cycle through the included subentity types and detected boundaries.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 15



Default value:	0
Possible options:	1: Select edges 2: Select faces 4: Select detected boundaries 8: Select vertices

22.27 SELECTIONPREVIEW system variable

22.27.1 Selection preview display

Specifies in which cases entities are highlighted when the pickbox cursor hovers over them: when no commands are active or when a command prompts for entity selection. The value is stored as a bitcode using the sum of the values of all selected options.

When QUADDISPLAY is on, the value of the SELECTIONPREVIEW option 'When no commands are active' will be overruled, and treated as 'ON'.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible options:	1: When no commands are active 2: When a command prompts for entity selection

22.28 SELECTSIMILARMODE system variable

22.28.1 Match options for SELECTSIMILAR

Specifies which properties must match for an entity of the same type to be selected with SELECTSIMILAR. For this command to operate as intended, at least one property must be turned on. When all properties are turned off, this command selects only the entity(ies) you pick at the 'Select entities' prompt. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 255



Default value:	130
Possible options:	0: Object type 1: Color 2: Layer 4: Linetype 8: Linetype scale 16: Lineweight 32: Plot style 64: Object style 128: Name

22.29 SETBYLAYERMODE system variable

22.29.1 Options for SETBYLAYERMODE

Specifies which layer properties would be applied by SETBYLAYER command.

Type:	Short
Saved in:	Registry
Range:	0 to 255
Default value:	255
Possible values:	0: None 1: Color 2: Linetype 4: Lineweight 8: Material 16: Plot style 32: ByBlock 64: Blocks 128: Transparency

22.30 SHADEDGE system variable

22.30.1 Shading edges

Specifies how faces and edges display in rendered views.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible values:	0: Faces shaded, edges not highlighted 1: Faces shaded, edges drawn in background color 2: Faces not filled, edges in entity color 3: Faces in entity color, edges in background color

22.31 SHADEDIF system variable

22.31.1 Shading diffusion

Specifies the ratio of diffuse reflective light to ambient light as a percentage of diffuse reflective light when SHADEDGE is set to 0 or 1.

Type:	Short
Saved in:	Drawing
Range:	0 to 100
Default value:	70

22.32 SHEETNUMBERLEADINGZEROES system variable

22.32.1 Sheet number leading zeroes

Specifies how to format the 'Number' value of new sheets.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 8
Default value:	1



Possible values:	1: 1 (1, 2, 3, ...) 2: 2 (01, 02, 03, ...) 3: 3 (001, 002, 003, ...) 4: 4 (0001, 0002, 0003, ...) 5: 5 (00001, 00002, 00003, ...) 6: 6 (000001, 000002, 000003, ...) 7: 7 (0000001, 0000002, 0000003, ...) 8: 8 (00000001, 00000002, 00000003, ...)
------------------	--

22.33 SHEETSETAUTOBACKUP system variable

22.33.1 Sheet set automatic backup

Specifies whether a backup file is created whenever a sheet set file is opened. The backup files have the same name as the sheet set file but with a '*.ds\$' extension.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't create backup files On (1): Create backup files

22.34 SHEETSETTEMPLATEPATH system variable

22.34.1 Sheet Set template path

Specifies the path to the Sheet Set Templates folder. The default path is: \Users\<user name>\AppData\Local\Bricsys\BricsCAD\V23x64\en_US\Templates

Type:	String
Saved in:	Preference

22.35 SHORTCUTMENU system variable

22.35.1 Shortcut menus

Specifies the status of the DEFAULT, EDIT and COMMAND shortcut menus. The value is stored as a bitcode using the sum of the values of all selected options.



Type:	Short
Saved in:	Registry
Range:	0 to 31
Default value:	19
Possible options:	0: Disable all Default, Edit, and Command mode shortcut menus 1: Enable Default mode shortcut menus 2: Enable Edit mode shortcut menus 4: Enable Command mode shortcut menus (available whenever a command is active) 8: Enable Command mode shortcut menus only when command options are currently available from the Command line 16: Enable display of a shortcut menu when the right button on the pointing device is held down longer

22.36 SHORTCUTMENUDURATION system variable

22.36.1 Shortcut menu duration

Specifies how long the right button on a pointing device must be pressed to display a shortcut menu.

Type:	Long
Saved in:	Registry
Range:	100 to 10000
Default value:	250

22.37 SHOWDOCTABS system variable

22.37.1 Tabs visibility

Toggles showing of the document tabs On/Off. You can make the drawing area larger by hiding the document tabs from the user interface.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Don't make tabs visible On (1): Make tabs visible

22.38 SHOWFULLPATHINTITLE system variable

22.38.1 Display full path in title

Specifies whether the title bar displays the full path of a drawing, or only the file name.

Type:	Boolean
Saved in:	Preference
Default value:	Off

22.39 SHOWLAYERUSAGE system variable

22.39.1 Layer Usage

Shows information about layer usage in the layer presentation panel. In the column **Current**, the **Layer Usage** icons indicate when viewport settings for the current layout and paper space viewport are different from model space settings:

: Current layer with viewport overrides.

: Layer with viewport overrides.

: Empty layer with viewport overrides.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Do not display Layer Usage On (1): Display Layer Usage

22.40 SHOWSCROLLBUTTONS system variable

22.40.1 Scroll buttons (Mac & Linux)

With this style, left and right scroll buttons are displayed On/Off.



BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show scroll buttons On (1): Show scroll buttons

22.41 SHOWTABCLOSEBUTTON system variable

22.41.1 Close button on tabs (Mac & Linux)

Toggles showing of close button on the tab bars On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't show close button on tabs On (1): Show close button on tabs

22.42 SHOWTABCLOSEBUTTONACTIVE system variable

22.42.1 Close button on active tab (Mac & Linux)

Toggles showing of close button on the active tab only On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't show close button on the active tab only On (1): Show close button on the active tab only



22.43 SHOWTABCLOSEBUTTONALL system variable

22.43.1 Close button on all tabs (Mac & Linux)

Toggles showing of close button on all tabs On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show close button on all tabs On (1): Show close button on all tabs

22.44 SHOWWINDOWLISTBUTTON system variable

22.44.1 Window list button (Mac & Linux)

With this style, a drop-down list of windows is available On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show window list button On (1): Show window list button

22.45 SHPNAME system variable

22.45.1 Shape name

Stores a default shape name according to naming conventions. Type a period (.) to set no default. Shapes are an early version of blocks that were efficient, but difficult to code. Shapes are rarely used anymore.

Type:	String
Saved in:	Not saved
Default value:	



22.46 SIGWARN system variable

22.46.1 Signature warning

Controls display of dialog with signature content when drawing with digital signature is opened.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Dialog is displayed only if drawing has invalid signature On (1): Dialog is displayed if drawing has a signature

22.47 SINGLETONMODE system variable

22.47.1 Singleton mode

Switch to control whether one or more instances of BricsCAD can run simultaneously. When set to Off, only a single instance of BricsCAD can run. When set to On, you can launch two or more copies of BricsCAD at the same time.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Singleton mode off On (1): Singleton mode on

22.48 SKETCHINC system variable

22.48.1 Sketch increment

Stores the record increment for the SKETCH command.

Type:	Real
Saved in:	Drawing
Default value:	1.0




22.49 SKPOLY system variable

22.49.1 Sketch poly

Specifies the entity type (lines or polylines) created by the SKETCH command.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Generate lines On (1): Generate polylines



22.50 SKYSTATUS system variable

22.50.1 Sky status

Specifies whether sky illumination is computed at render time. (Not yet supported)

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: No sky 1: Sky background 2: Sky background and illumination



22.51 SMASSEMBLYEXPORTMODE system variable

22.51.1 Modification of exported assemblies

Specifies whether the original assembly is modified after running the SMASSEMBLYEXPORT command.

BricsCAD only

Type:	Short
Saved in:	Registry
Possible values:	0: Do not change external components 1: Keep recognized features on sheet metal/poor sheet metal parts

22.52 SMASSEMBLYEXPORTREPORTPATHTYPE system variable

22.52.1 Report file path type

Determines whether absolute or relative path to files will be used in the reports generated by the command.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Relative paths 1: Absolute paths

22.53 SMASSEMBLYEXPORTSOLIDTYPESINREPORTS system variable

22.53.1 Solid types in reports

Determines which types of solids will be present in command reports. Each solid belongs to one of four types: sheet metal, poor sheet metal, non sheet metal or standard part component solid. Sheet metal and poor sheet metal solids are always present in the reports.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 3
Default value:	0
Possible values:	1: Non sheet metal solids 2: Standard part component solids

22.54 SMATTRIBUTESLAYERCOLOR system variable

22.54.1 Color of the attributes layer

Defines a color which will be assigned to layer containing attributes after SmUnfold and SmExport2d.
BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	7

22.55 SMATTRIBUTESLAYERTEXTHEIGHT system variable

22.55.1 Height of the text

Height of the text from Attributes Layer.
BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.01

22.56 SMATTRIBUTESLAYERTEXTHEIGHTTYPE system variable

22.56.1 Type of the text height

Determines type of the text height: bounding box ratio or absolute value.
BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Bounding box ratio 1: Absolute value

22.57 SMBENDANNOTATIONSLAYERCOLOR system variable

22.57.1 Color of the bend annotations text layer

Defines a color which will be assigned to layer containing bend annotations after SmUnfold and SmExport2d.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	5

22.58 SMBENDANNOTATIONSLAYERTEXTHEIGHT system variable

22.58.1 Height of the text

Height of the text from Bend Annotation Text Layer.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.01



22.59 SMBENDANNOTATIONSLAYERTEXTHEIGHTTYPE system variable

22.59.1 Type of the text height

Determines type of the text height: bounding box ratio or absolute value.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Bounding box ratio 1: Absolute value

22.60 SMBENDLINESDOWNLAYERCOLOR system variable

22.60.1 Color of the bend down lines layer

Defines a color which will be assigned to layer containing bend down lines after SmUnfold and SmExport2d.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	1

22.61 SMBENDLINESDOWNLAYERLINETYPE system variable

22.61.1 Linetype of the bend down lines layer

Determines the linetype of the bend down lines layer entities.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
Default value:	CONTINUOUS

22.62 SMBENDLINESDOWNLAYERLINEWEIGHT system variable

22.62.1 Lineweight of the bend down layer

Determines the linewidth of the bend down layer. Values between -3 and 211 are accepted. -1=ByLayer, -2=ByBlock, -3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

22.63 SMBENDLINESUPLAYERCOLOR system variable

22.63.1 Color of the bend up lines layer

Defines a color which will be assigned to layer containing bend up lines after SmUnfold and SmExport2d.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	1

22.64 SMBENDLINESUPLAYERLINETYPE system variable

22.64.1 Linetype of the bend up lines layer

Determines the linetype of the bend up lines layer entities.

BricsCAD only



Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

22.65 SMBENDLINESUPLAYERLINEWEIGHT system variable

22.65.1 Lineweight of the bend up layer

Determines the lineweight of the bend up layer. Values between -3 and 211 are accepted. -1=ByLayer, -2=ByBlock, -3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

22.66 SMBEVELFEATURECOLOR system variable

22.66.1 Color of the bevel features layer

Defines a color which will be assigned to layer containing bevel features after SmUnfold and SmExport2d.
BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	6

22.67 SMCOLORBEND system variable

22.67.1 Bend relief feature color

Visual color of entities related to bend reliefs.

BricsCAD only



Type:	String
Saved in:	Registry
Default value:	#FFDC50

22.68 SMCOLORBENDRELIEF system variable

22.68.1 Bend relief feature color

Visual color of entities related to bend reliefs.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#64D296

22.69 SMCOLORBEVEL system variable

22.69.1 Bevel feature color

Visual color of entities related to bevels.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#64D296

22.70 SMCOLORCORNERRELIEF system variable

22.70.1 Corner relief feature color

Visual color of entities related to corner reliefs.

BricsCAD only

Type:	String
Saved in:	Registry



Default value:	#64D296
----------------	---------

22.71 SMCOLORFLANGE system variable

22.71.1 Flange feature color

Visual color of entities related to flanges.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#90A4AE

22.72 SMCOLORFLANGEREFERENCESIDE system variable

22.72.1 Flange feature reference side color

Visual color of entities related to faces on reference side of flange.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#68A4AE

22.73 SMCOLORFORM system variable

22.73.1 Form feature color

Visual color of entities related to forms.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#8791E1



22.74 SMCOLORHEM system variable

22.74.1 Hem feature color

Visual color of entities related to hems.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#FCAED6

22.75 SMCOLORJOG system variable

22.75.1 Jog feature color

Visual color of entities related to jogs.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#CC7722

22.76 SMCOLORJUNCTION system variable

22.76.1 Junction feature color

Visual color of entities related to junctions.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#FF6E40

22.77 SMCOLORLOFTEDBEND system variable

22.77.1 Lofted bend feature color

Visual color of entities related to lofted bends.



BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#A0DCFA

22.78 SMCOLORMITER system variable

22.78.1 Miter feature color

Visual color of entities related to miters.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#AF46D8

22.79 SMCOLORROLLEDEDGE system variable

22.79.1 Rolled edge feature color

Visual color of entities related to rolled edges.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#8791E1

22.80 SMCOLORTAB system variable

22.80.1 Tab feature color

Visual color of entities related to tabs.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
Default value:	#FDA542

22.81 SMCOLORWRONGBEND system variable

22.81.1 Wrong bend feature color

Visual color of entities related to wrong bends.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#FF3300

22.82 SMCOLORWRONGFLANGE system variable

22.82.1 Wrong flange feature color

Visual color of entities related to wrong flange.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#A82000

22.83 SMCONTOURSLAYERCOLOR system variable

22.83.1 Color of the contour layer

Defines a color which will be assigned to layer in 2D dxf containing unfolded geometry after SmUnfold and SmExport2d.

BricsCAD only

Type:	Short
Saved in:	Registry



Range:	1 to 255
Default value:	7

22.84 SMCONTOURSLAYERLINETYPE system variable

22.84.1 Linetype of the contour layer

Determines the linetype of the contour layer entities.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

22.85 SMCONTOURSLAYERLINEWEIGHT system variable

22.85.1 Lineweight of the contour layer

Determines the linewidth of the Contour layer. Values between -3 and 211 are accepted. -1=ByLayer, -2=ByBlock, -3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	30

22.86 SMCONVERTMAXIMALBEVELANGLE system variable

22.86.1 Maximal angle of bevel

Determines maximal angle of bevel.

BricsCAD only

Type:	Real
-------	------



Saved in:	Drawing
Range:	0 to 90
Default value:	80

22.87 SMCONVERTMINIMALBEVELANGLE system variable

22.87.1 Minimal angle of bevel

Determines minimal angle of bevel.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 90
Default value:	1

22.88 SMCONVERTPREFERFORMFEATURES system variable

22.88.1 Prefer form features to flanges and bends

Controls which set of features has to be recognized on solid faces if they can be described by single form feature or set of flanges and bends (i.e. bridge-like insert on large flange).

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	0: Off 1: On



22.89 SMCONVERTPREFERHEMFEATURES system variable

22.89.1 Prefer hem features to flanges and bends

Controls which set of features has to be recognized on solid faces if they can be described by single hem feature or by bend and flange.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	0: Off 1: On

22.90 SMCONVERTPREFERZEROBENDFEATURES system variable

22.90.1 Prefer zero bend features to wrong bends

Controls which set of features has to be recognized on solid faces if they can be described by zero bend feature or by wrong bend feature.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	0: Off 1: On

22.91 SMCONVERTRECOGNIZEHOLES system variable

22.91.1 Recognize holes

If turned on, holes on the flanges will be recognized as features.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Drawing
Default value:	Off
Possible values:	0: Off 1: On

22.92 SMCONVERTRECOGNIZERIBCONTROLCURVES system variable

22.92.1 Recognize rib control curves

Controls recognition of 2D control curves for rib features.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	0: Off 1: On

22.93 SMCONVERTWRONGFEATURETHICKNESSDEVIATIONTYPE system variable

22.93.1 Type of deviation of wrong feature thickness

Determines whether deviation value is treated as ratio to model thickness or absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value



22.94 SMCONVERTWRONGFEATURETHICKNESSDEVIATIONVALUE system variable

22.94.1 Deviation value of wrong feature thickness

Determines allowed deviation between model thickness of given wrong feature.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 1e6
Default value:	0.2

22.95 SMDEFAULTBENDLINEEXTENTTYPE system variable

22.95.1 Bend line extent type

Determines if bend line extent is thickness ratio or absolute value. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	1: Thickness ratio 2: Absolute value

22.96 SMDEFAULTBENDLINEEXTENTVALUE system variable

22.96.1 Bend line extent value

Controls how much bend lines stretch out of contour (if the value is positive), do not reach it (if the value is negative), or just touch it (if the value is zero). Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
-------	------



Saved in:	Drawing
Range:	-1000000 to 1000000
Default value:	0.25

22.97 SMDEFAULTBENDRADIUSTYPE system variable

22.97.1 Bend radius type

Determines whether bend radius value is to be treated as ratio to thickness or absolute value. The first switch toggles Thickness ratio/Absolute value. The second switch controls whether Sheet Metal context bend radius setting has to be taken from SMDEFAULTBENDRADIUSVALUE or from the recognized model.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	2
Possible values:	1: Absolute value 2: Override bend radius in SMCONVERT

22.98 SMDEFAULTBENDRADIUSVALUE system variable

22.98.1 Bend radius value

Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1



22.99 SMDEFAULTBENDRELIEFWIDTHTYPE system variable

22.99.1 Bend relief type

Determines whether the bend relief width value will be treated as ratio to thickness or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.100 SMDEFAULTBENDRELIEFWIDTHVALUE system variable

22.100.1 Bend relief width value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.5

22.101 SMDEFAULTBEVELFEATUREUNFOLDMODE system variable

22.101.1 Bevel unfolding mode

Determines appearance of bevels in unfolded part. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	2



Possible values:	0: Keep 1: Remove 2: Annotate
------------------	-------------------------------------

22.102 SMDEFAULTCORNERRELIEFDIAMETERVALUE system variable

22.102.1 Corner relief diameter value

Set to -1.0 for automatic determination of least feasible for given corner relief. The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	-1.0

22.103 SMDEFAULTFLANGESPLITEXTENSIONTYPE system variable

22.103.1 Miter extension type

Determines whether miter extension will be treated as ratio to thickness or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.104 SMDEFAULTFLANGESPLITEXTENSIONVALUE system variable

22.104.1 Miter extension value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	0.1

22.105 SMDEFAULTFLANGESPLITGAPTYPE system variable

22.105.1 Miter gap type

Determines whether miter gap is to be treated as ratio to thickness or absolute value. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.106 SMDEFAULTFLANGESPLITGAPVALUE system variable

22.106.1 Miter gap value

Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1



22.107 SMDEFAULTFORMFEATUREUNFOLDMODE system variable

22.107.1 Form feature unfolding mode

Determines appearance of form features in unfolded part. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	4
Possible values:	0: Keep 1: Remove 2: Project 3: Contour 4: Symbol 5: Project without center mark 6: Contour without center mark

22.108 SMDEFAULTGUSSETDEPTHVALUE system variable

22.108.1 Gusset depth value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	8

22.109 SMDEFAULTGUSSETDEPTHTYPE system variable

22.109.1 Gusset depth type

Determines whether the gusset depth value is to be treated as ratio to thickness or absolute value. The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.110 SMDEFAULTGUSSETFILLETRADIUSVALUE system variable

22.110.1 Gusset fillet radius value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1

22.111 SMDEFAULTGUSSETFILLETRADIUSTYPE system variable

22.111.1 Gusset fillet radius type

Determines whether the gusset fillet radius value is to be treated as ratio to thickness or absolute value.

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value



22.112 SMDEFAULTGUSSETTYPE system variable

22.112.1 Gusset type

Determines whether the gusset will be round or flat. The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	1 to 2
Default value:	1
Possible values:	1: Round 2: Flat

22.113 SMDEFAULTGUSSETWIDTHVALUE system variable

22.113.1 Gusset width value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	6

22.114 SMDEFAULTGUSSETWIDTHTYPE system variable

22.114.1 Gusset width type

Determines whether the gusset width value is to be treated as ratio to thickness or absolute value. The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing



Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.115 SMDEFAULTHEMGAPTYPE system variable

22.115.1 Open Hem gap type

Determines whether the corresponding hem feature gap is to be treated as ratio to thickness or absolute value. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.116 SMDEFAULTHEMGAPVALUE system variable

22.116.1 Open Hem gap value (in addition to the thickness)

Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0.1



22.117 SMDEFAULTHEMRELATIVEBENDDEDUCTION system variable

22.117.1 Hem relative bend deduction value

Sets relative to thickness bend deduction value used for closed hem unfolding. Value ranges from 0 which leads to hem lengthening to 10 which means shortening bend zone by a value equal to 8 * thickness. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 10
Default value:	2.4

22.118 SMDEFAULTJUNCTIONALIGNMENTTORELIEF system variable

22.118.1 Junction alignment to relief

Forces junction faces to align adjacent relief faces. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Disabled 1: Enabled

22.119 SMDEFAULTJUNCTIONGAPTYPE system variable

22.119.1 Junction gap type

Determines whether junction gap is to be treated as ratio to thickness or absolute value. Value will be used to initialize sheet metal settings in the document.

BricsCAD only



Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.120 SMDEFAULTJUNCTIONGAPVALUE system variable

22.120.1 Junction gap value

Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.001

22.121 SMDEFAULTKFACTOR system variable

22.121.1 K-Factor value

Sets location ratio of the neutral surface, for example surface not stretched or squeezed when the sheet is bent, to the material thickness. Value ranges from 0 for internal bend radius to 1 for the external bend radius. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 1
Default value:	0.27324



22.122 SMDEFAULTLOFTEDBENDNUMBERSAMPLES system variable

22.122.1 Lofted bend subdivisions

Sets the default value for lofted bend subdivisions. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	10

22.123 SMDEFAULTRELIEFEXTENSIONTYPE system variable

22.123.1 Relief extension type

Determines whether bend relief width value will be treated as ratio to thickness or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.124 SMDEFAULTRELIEFEXTENSIONVALUE system variable

22.124.1 Relief extension value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1



22.125 SMDEFUALTRIBFILLETRADIUSTYPE system variable

22.125.1 Bead fillet radius type

Determines whether bead fillet radius to be treated as ratio to profile radius or absolute value. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Profile radius ratio 1: Absolute value

22.126 SMDEFUALTRIBFILLETRADIUSVALUE system variable

22.126.1 Bead fillet radius value

Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	5

22.127 SMDEFUALTRIBPROFILERADIUSTYPE system variable

22.127.1 Bead profile radius type

Determines whether bead profile radius to be treated as ratio to thickness or absolute value. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0



Possible values:	0: Thickness ratio 1: Absolute value
------------------	---

22.128 SMDEFALTRIBPROFILERADIUSVALUE system variable

22.128.1 Bead profile radius value

Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	2

22.129 SMDEFALTRIBROUNDRADIUSTYPE system variable

22.129.1 Bead round radius type

Determines whether bead round radius to be treated as ratio to thickness or absolute value. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.130 SMDEFALTRIBROUNDRADIUSVALUE system variable

22.130.1 Bead round radius value

Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
-------	------



Saved in:	Drawing
Default value:	1

22.131 SMDEFAULTSHARPBENDRADIUSLIMITRATIO system variable

22.131.1 Sharp bend radius limit ratio

The default sharp bend radius limit ratio to the thickness. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	5

22.132 SMDEFAULTTABCHAMFERDISTANCETYPE system variable

22.132.1 Tab chamfer distance type

Determines whether tab chamfer distance will be treated as ratio to profile radius or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.133 SMDEFAULTTABCHAMFERDISTANCEVALUE system variable

22.133.1 Tab chamfer distance value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	0.1

22.134 SMDEFAULTTABCLEARANCETYPE system variable

22.134.1 Tab clearance type

Determines whether tab clearance will be treated as ratio to profile radius or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.135 SMDEFAULTTABCLEARANCEVALUE system variable

22.135.1 Tab clearance value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1

22.136 SMDEFAULTTABDISTANCETYPE system variable

22.136.1 Tab distance type

Determines whether tab distance will be treated as ratio to profile radius or absolute value. The value will be used to initialize sheet metal settings in the document.



Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.137 SMDEFAULTTABDISTANCEVALUE system variable

22.137.1 Tab distance value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	20

22.138 SMDEFAULTTABEDGE TYPE system variable

22.138.1 Tab edge type

Determines whether tab will have sharp, round or chamfer edges. Value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Sharp edges 1: Fillet edges 2: Chamfer edges



22.139 SMDEFAULTTABFILLETRADIUSTYPE system variable

22.139.1 Tab fillet radius type

Determines whether tab fillet radius will be treated as ratio to thickness or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.140 SMDEFAULTTABFILLETRADIUSVALUE system variable

22.140.1 Tab fillet radius value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1

22.141 SMDEFAULTTABHEIGHTTYPE system variable

22.141.1 Tab height type

Determines whether tab height will be treated as ratio to profile radius or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1



Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.142 SMDEFAULTTABHEIGHTVALUE system variable

22.142.1 Tab height value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1

22.143 SMDEFAULTTABLENGTHTYPE system variable

22.143.1 Tab length type

Determines whether tab length will be treated as ratio to profile radius or absolute value. The value will be used to initialize sheet metal settings in the document.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

22.144 SMDEFAULTTABLENGTHVALUE system variable

22.144.1 Tab length value

The value will be used to initialize sheet metal settings in the document.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	4

22.145 SMDEFAULTTABSLOTNUMBER system variable

22.145.1 Tab slot number

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	2

22.146 SMDEFAULTTHICKNESS system variable

22.146.1 Thickness value

Value will be used to initialize sheet metal settings in the document. Value is given in units of current document (see INSUNITS).

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	2.0 for INSUNITS=4 0.07874 for INSUNITS=1

22.147 SMEXPORTOSMAPPROXIMATIONACCURACY system variable

22.148 SMEXPORTOSMMINIMALEDGELENGTH system variable

22.149 SMFORMFEATURESDOWNCOLOR system variable

22.149.1 Color of the form features down layer

Defines a color which will be assigned to layer containing form features after SmUnfold and SmExport2d.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	6

22.150 SMFORMFEATURESDOWNLAYERLINETYPE system variable

22.150.1 Linetype of the form features down layer

Determines the linetype of the form feature layer entities.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

22.151 SMFORMFEATURESDOWNLAYERLINEWEIGHT system variable

22.151.1 Lineweight of the form features down layer

Determines the linewidth of form feature layer. Values between -3 and 211 are accepted. -1=ByLayer, -2=ByBlock, -3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

22.152 SMFORMFEATURESUPCOLOR system variable

22.152.1 Color of the form features up layer

Defines a color which will be assigned to layer containing form features after SmUnfold and SmExport2d.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	6

22.153 SMFORMFEATURESPLAYERLINETYPE system variable

22.153.1 Linetype of the form features up layer

Determines the linetype of the form feature layer entities.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

22.154 SMFORMFEATURESPLAYERLINEWEIGHT system variable

22.154.1 Lineweight of the form features up layer

Determines the linewidth of form feature layer. Values between -3 and 211 are accepted. -1=ByLayer, -2=ByBlock, -3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

22.155 SMJUNCTIONCREATEHEALCOINCIDENT system variable

22.155.1 Heal coincident junction faces

Controls recognition of junction design with coincident faces and its conversion to regular junctions



BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off

22.156 SMOOTHMESHCONVERT system variable

22.156.1 Mesh conversion mode

Specifies mesh to 3d solid or surface conversion mode, used by commands CONVTOSOLID or CONVTOSURFACE. Currently we support conversion only to faceted models, so values 0 and 1, corresponding to conversion to smooth models, are not accessible.

Type:	Short
Saved in:	Not saved
Range:	2 to 3
Default value:	2
Possible values:	2: Conversion result is faceted and optimized 3: Conversion result is faceted and not optimized

22.157 SMOVEALLANNOTATIONSLAYERCOLOR system variable

22.157.1 Color of the overall dimensions annotations layer

Defines a color which will be assigned to layer containing overall dimensions annotations after SmUnfold and SmExport2d.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	3



22.158 SMOVERALLANNOTATIONSLAYERLINETYPE system variable

22.158.1 Linetype of the overall annotation layer

Determines the linetype of the overall annotation layer entities.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

22.159 SMOVERALLANNOTATIONSLAYERLINEWEIGHT system variable

22.159.1 Lineweight of the overall annotation layer

Determines the linewidth of bend annotation layer. Values between -3 and 211 are accepted. -1=ByLayer, -2=ByBlock, -3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

22.160 SMPARAMETRIZEHOLES PARAMETRIZATION system variable

22.160.1 Hole parametrization

Controls parametrization for straight holes. If **Convert holes to array** is on, holes on flanges will be checked to be grouped into parametric rectangular array. If **Parametrize holes** is on, holes which are not included to arrays will be constrained.

BricsCAD only

Type:	Short
Saved in:	Drawing
	0 to 3



Default value:	3
Possible values:	0: Does not parametrize holes 1: Parametrize holes 2: Convert holes to array

22.161 SMREPAIRLOFTEDBENDMERGE system variable

22.161.1 Merge lofted bends

If turned on, adjacent lofted bends with tangential connection will be merged to single lofted bend.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off

22.162 SMSMARTFEATURES system variable

22.162.1 Automatically update sheet metal features

Controls whether sheet metal features are rebuilt automatically when sheet metal commands have been executed. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	3
Possible options:	1: Allow rebuilding sheet metal features 2: Allow automatic edges imprint after rebuild 4: Allow automatic creation of junctions after creating bends



22.163 SMSPLITAMBIGUOUSINPUT system variable

22.163.1 Ambiguous input behavior

Controls command behavior to resolve situations when command can't unequivocally deduce face or entity to which input point or 2D curve relates to.

BricsCAD only

Type:	Short
Saved in:	Drawing
	0 to 1
Default value:	0
Possible values:	0: Prompt user 1: Command fail

22.164 SMSPLITCONVERTBENDTOJUNCTION system variable

22.164.1 Convert bend to junction

If enabled, split turns corner residue bend after split to junction.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On

22.165 SMSPLITHEALCOINCIDENT system variable

22.165.1 Heal coincident miter faces

Controls appearance of coincident miter faces healing option in command prompt.

BricsCAD only

Type:	Boolean
Saved in:	Drawing



Default value:	Off
----------------	-----

22.166 SMSPLITORTHOGONALBENDSPLIT system variable

22.166.1 Orthogonal bend split

Determines split behavior when split curve touches bend. If enabled, split direction for bend will be orthogonal to bend axis. If disabled, split direction will be tangential to split curve.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off

22.167 SMTARGETCAM system variable

22.167.1 Target CAM

Defines a target CAM system for processing sheet metal parts unfolded with BricsCAD using SmUnfold command.

BricsCAD only

Type:	String
Saved in:	Registry

22.168 SNAPANG system variable

22.168.1 Snap angle

Specifies the rotation of snap, grid and crosshairs for the current viewport relative to the current UCS.

Type:	Real
Saved in:	Drawing
Default value:	0.0



22.169 SNAPBASE system variable

22.169.1 Snap base

Specifies the origin point of snap and grid in the current viewport relative to the current UCS.

Type:	2D point
Saved in:	Drawing
Default value:	0,0

22.170 SNAPCOLOR system variable

22.170.1 Snap color (Obsolete)

Replaced by SNAPMARKERCOLOR.

BricsCAD only


Type:	Short
Saved in:	Registry

22.171 SNAPSOPAIR system variable

22.171.1 Snap isometric pair

Specifies the current viewport's isometric plane (left, top or right), used if SNAPSTYL is isometric. Press **F5** function key to set the appropriate drawing plane: **Left**, **Top** or **Right**.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Left 1: Top 2: Right



22.172 SNAPMARKERCOLOR system variable

22.172.1 Snap marker color

Specifies the color of the snap marker. Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	20

22.173 SNAPMARKERSIZE system variable

22.173.1 Snap marker size

Specifies the size of the snap marker.

BricsCAD only

Type:	Short
Saved in:	Preference



Default value:	6
----------------	---

22.174 SNAPMARKERTHICKNESS system variable

22.174.1 Snap marker thickness

Specifies the thickness of the snap marker.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	2

22.175 SNAPMODE system variable

22.175.1 Snap mode

Toggles snap On or Off for the current viewport. This setting is overridden when SNAPTYPE is set to **Adaptive Grid Snap**.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Snap off (for current viewport) On (1): Snap on (for current viewport)

22.176 SNAPSIZE system variable

22.176.1 Snap size (Obsolete)

Replaced by SNAPMARKERSIZE.

BricsCAD only

Type:	Short
Saved in:	Registry



22.177 SNAPSTYL system variable

22.177.1 Snap style

Specifies whether the snap style for the current viewport is rectangular or isometric.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Rectangular snap 1: Isometric snap

22.178 SNAPTHICKNESS system variable

22.178.1 Snap thickness (Obsolete)

Replaced by SNAPMARKERTHICKNESS.

BricsCAD only

Type:	Short
Saved in:	Registry

22.179 SNAPTYPE system variable

22.179.1 Snap type

Specifies the snap type for the current viewport: grid snap, polar snap or adaptive grid snap.

During **Adaptive Grid Snap**, the snap spacing is calculated depending on the ratio of the current drawing units per displayed pixel and the AdaptiveGridStepSize setting. This option overrides SNAPMODE.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2



Possible values:	0: Grid snap 1: Polar snap 2: Adaptive Grid Snap
------------------	--

22.180 SNAPUNIT system variable

22.180.1 Snap unit

Specifies the current viewport's snap spacing and specifies the spacing between snap points. If SNAPSTYL is 1 (isometric snap), the SNAPUNIT X value will adjust itself automatically to reflect the isometric snap. There is no snap in the Z direction.

Type:	2D point
Saved in:	Drawing
Default value:	0.5,0.5

22.181 SOLIDCHECK system variable

22.181.1 Solid check

Toggles the 3D solid validation for the current BricsCAD session.

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Solid validation off On (1): Solid validation on

22.182 SORTENTS system variable

22.182.1 Sort entities

Specifies the entity display sort order. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing



Range:	0 to 127
Default value:	127
Possible options:	0: Off 1: Entity selection 2: Entity snap 4: Redraws 8: Mslide slide creation 16: Regens 32: Plotting 64: PostScript output

22.183 SPAADJUSTMODE system variable

22.183.1 Adjust mode

The adjustment mode is used for triangle smoothing. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: None (Leave everything alone) 1: Non grid (Adjust points surrounded by triangles by moving nodes in the center of surrounding nodes) 2: All (Also adjusts grid nodes)

22.184 SPACHECKLEVEL system variable

22.184.1 Check level

Check level used in AUDIT and SOLIDEDIT for checking ACIS entities. Value 10 is the lowest, used for fast checking. Value 70 is the maximum, used for comprehensive time consuming check. Audit is used to repair drawings that are open. SolidEdit edits the faces, edges and bodies of 3D solids and 2D regions. Spa is short for Spatial, the maker of ACIS.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	0 to 70
Default value:	10
Possible values:	<p>0: Basic transformation consistency, basic pointer and fatal topology checks.</p> <p>10: Basic geometry checks. Cellular topology checks.</p> <p>20: Data sharing checks. Face area and loop orientation check. Medium checks of curve geometry.</p> <p>30: General surface checks. Check for sliver faces.</p> <p>40: Degenerate spline surface check. Compatibility check between surface and pcurve's surface. Check that COEDGE has a partner on a single-sided face.</p> <p>50: Body containment checks. Compatibility check between pcurve location and (non-tolerant) coedge location.</p> <p>60: Convexity points check.</p> <p>70: Lump and shell containment checks. Face-face intersection checks. Curve parametrization check.</p>

22.185 SPAGRIDASPECTRATIO system variable

22.185.1 Grid aspect ratio

Grid aspect ratio specifies the approximate aspect ratio of each cell in the grid. If the value is close to 1, then the cell is close to a square. This does not guarantee the aspect ratio of the facet, which may consist of only a part of a cell. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0



22.186 SPAGRIDMODE system variable

22.186.1 Grid mode

Specifies how grids are used in the mesh process. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	1
Possible values:	0: No grids at all 1: Grids in interior 2: Allow grid to divide model edges 3: Grid only in one direction, u or v

22.187 SPAMAXFACETEDGELENGTH system variable

22.187.1 Maximum facet edge length

Specifies the maximum length of a facet side. The recommended, and default, value of 0 allows the software to determine and use an optimal value. Specifying a length that is too small can lead to high memory consumption and poor performance. This variable is ignored if SPAUSEFACETRES is used.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

22.188 SPAMAXNUMGRIDLINES system variable

22.188.1 Maximum number of grid lines

The maximum grid lines specifies the maximum number of grid subdivisions. This prevents the facet data of a face from getting too big. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only



Type:	Long
Saved in:	Preference
Default value:	512

22.189 SPAMINUGRIDLINES system variable

22.189.1 Minimum number of U grid lines

Specifies the minimum number of U grid lines. At least this number of grid lines are generated in U direction. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Long
Saved in:	Preference
Default value:	0

22.190 SPAMINVGRIDLINES system variable

22.190.1 Minimum number of V grid lines

Specifies the minimum number of V grid lines. At least this number of grid lines are generated in V direction. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Long
Saved in:	Preference
Default value:	0

22.191 SPANORMALTOL system variable

22.191.1 Normal tolerance

The normal tolerance specifies the maximum normal deviation allowed between two normals on two adjacent facet nodes in degrees. The proper value is usually independent of the model size. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only



Type:	Real
Saved in:	Preference
Default value:	15.0

22.192 SPASURFACETOL system variable

22.192.1 Surface tolerance

The surface tolerance specifies the maximum distance between a facet edge and the true surface. The proper value is dependent on the model size. This variable is ignored for output to STL and PDF if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	-1.0

22.193 SPATRIANGMODE system variable

22.193.1 Triangulation mode

Triangulation mode identifies what portion of the mesh is to be triangulated. This variable is ignored if FACETRES is used. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	1



Possible values:	0: No triangulation 1: Triangulate everywhere 2: Triangulate against the boundary 3: Also triangulate first grid level 4: Triangulate to 3 levels of fringe 5: Triangulate to 4 levels of fringe
------------------	---

22.194 SPAUSEFACETRES system variable

22.194.1 Use FACETRES system variable

Specifies whether the FACETRES system variable will be used instead of normal tolerance. Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On

22.195 SPLFRAME system variable

22.195.1 Spline frame

Specifies whether the control frame for helixes.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display control frame for helixes. On (1): Display control frame for helixes.

22.196 SPLINESEGS system variable

22.196.1 Spline segments

Specifies how many line segments are to be generated for each spline-fit polyline (spline option of the PEDIT command). Values between -32768 and 32768 are accepted. With a negative value a fit-type curve



is applied. A fit-type curve is composed of arc-segments, which yields a smoother curve, but it takes longer to generate.

Type:	Short
Saved in:	Drawing
Range:	-32768 to 32767
Default value:	8

22.197 SPLINETYPE system variable

22.197.1 Spline type

Specifies the curve type to be generated by the Spline option of the PEDIT command: Quadratic B-spline or Cubic B-spline.

Type:	Short
Saved in:	Drawing
Range:	5 to 6
Default value:	6
Possible values:	5: Quadratic B-spline 6: Cubic B-spline



22.198 SRCHPATH system variable

22.198.1 Support file search path

Specifies the folder(s) in which BricsCAD should look for text fonts, customization files, plug-ins, drawings to insert, linetypes, and hatch patterns that are not in the current folder. Search paths are separated by semicolons (:).

BricsCAD only



Type:	String
Saved in:	Registry

22.199 SSAUTOSAVE system variable

22.199.1 Sheet set autosave

Specifies whether changes to sheet sets should be autosaved.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Doesn't autosave changes to sheet sets. On (1): Autosaves changes to sheet sets.

22.200 SSFOUND system variable

22.200.1 Sheet set found

Displays the sheet set file name and path that is associated with the current drawing file (if it is currently open).

Read-only

Type:	String
Saved in:	Not saved

22.201 SSLOCATE system variable

22.201.1 Sheet set locate

Specifies whether BricsCAD will try to locate and open a sheet set for the drawing that is being opened.

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't open a drawing's sheet set with the drawing On (1): Open a drawing's sheet set with the drawing
------------------	---

22.202 SSMAUTOOPEN system variable

22.202.1 Sheet set manager auto open

Specifies whether or not BricsCAD displays the Sheet Set Manager when a drawing is opened that is associated with a sheet set. SSMAUTOOPEN and SSLOCATE must both be switched on to display the sheet set automatically.

Type:	Boolean
Saved in:	Workspace
Default value:	On
Possible values:	Off (0): Don't open sheet set panel automatically On (1): Open sheet set panel automatically

22.203 SSMPOLTIME system variable

22.203.1 Sheet set manager poll time

Specifies the time interval between automatic refreshes of the status data in a sheet set.
SSMSHEETSTATUS must be set to 2 for the timer to operate.

Type:	Short
Saved in:	Registry
Range:	10 to 600
Default value:	15

22.204 SSMSHEETSTATUS system variable

22.204.1 Sheet set manager status

Specifies how the status data in a sheet set is refreshed.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Don't automatically refresh status 1: Refresh status when sheet set is loaded or updated 2: Refresh status when sheet set is loaded or updated, and at time interval by SSMPOLTIME

22.205 SSMSTATE system variable

22.205.1 Sheet set manager state

Specifies if the Sheet Set Manager is active or not.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Sheet Set Manager is not active 1: Sheet Set Manager is active

22.206 STACKPANELTYPE system variable

22.206.1 Stack panel type

Style of stacked docking panel containers.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	1
Default value:	0 to 2



Possible values:	0: Fixed resizable panelset with horizontal text tab buttons 1: Flyout panelset with an icon tab strip 2: Collapsible panelset with vertical icon tab buttons (unless docked at top or bottom)
------------------	--

22.207 STAMPFONTSIZE system variable

22.207.1 Font Size

Specifies the font size for the plot stamp.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.2

22.208 STAMPFONTSTYLE system variable

22.208.1 Font Style

Specifies the font style for the plot stamp.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	Arial

22.209 STAMPFOOTER system variable

22.209.1 Footer

Specifies the footer for the plot stamp.

BricsCAD only

Type:	String
Saved in:	Preference



22.210 STAMPFOOTEROFFSETX system variable

22.210.1 Stamp footer X offset

Specifies the offset of the plot stamp footer from the left of the printable area.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

22.211 STAMPFOOTEROFFSETY system variable

22.211.1 Stamp footer Y offset

Specifies the offset of the plot stamp footer from the bottom of the printable area.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

22.212 STAMPHEADER system variable

22.212.1 Header

Specifies the header for the plot stamp.

BricsCAD only

Type:	String
Saved in:	Preference

22.213 STAMPHEADEROFFSETX system variable

22.213.1 Stamp header X offset

Specifies the offset of the plot stamp header from the left of the printable area.

BricsCAD only



Type:	Real
Saved in:	Preference
Default value:	0.0

22.214 STAMPHEADEROFFSETY system variable

22.214.1 Stamp header Y offset

Specifies the offset of the plot stamp header from the top of the printable area.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

22.215 STAMPUNITS system variable

22.215.1 Units

Specifies units in which the font size of the plot stamp is displayed.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Inches 1: Millimeters

22.216 STANDARDOPTIONS system variable

22.216.1 Standards validation options

Options to control the procedure of checking standards. The value is stored as a bitcode using the sum of the values of all selected options.



Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible options:	1: Fix non-standard object properties automatically 2: Show ignored problems

22.217 STANDARDSVIOLATION system variable

22.217.1 Standards Violation Notification

Specifies how a user is notified of standards violations.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible options:	0: Notification is off 1: An alert dialog is displayed 2: An icon is displayed in the status bar

22.218 STARTUP system variable

22.218.1 Startup

Specifies the display of the Create New Drawing and Startup dialog boxes.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3



Possible values:	0: Display the Select Template dialog box, or use a default drawing template file (set in the BASEFILE system variable) 1: Display the Startup and the Create New Drawing dialog boxes 2: Display the Start page 3: Display the Start page (with ribbon preloaded)
------------------	---

22.219 STARTUPTODAY system variable

22.219.1 Startup today (Obsolete)

Specifies whether or not the Today window is used.

Type:	Boolean
Saved in:	Registry
Possible values:	Off (0): Display Traditional startup dialog box On (1): Display Today window

22.220 STATUSBAR system variable

22.220.1 Window status bar

Specifies the display of the status bar. The only reason to turn off the status bar is to gain a bit more drawing area. It is far more useful to leave it on.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show status bar On (1): Show status bar

22.221 STEPSIZE system variable

22.221.1 Step size

Specifies the size of each step, in drawing units, in walk or fly mode.

Type:	Real
-------	------



Saved in:	Drawing
Range:	1e-6 to 1e+6
Default value:	50.0

22.222 STEPSPERSEC system variable

22.222.1 Steps per second

Specifies the number of steps taken per second in walk or fly mode.

Type:	Real
Saved in:	Drawing
Range:	1.0 to 30.0
Default value:	24.0

22.223 STLPOSITIVEQUADRANT system variable

22.223.1 STL export coordinates adjustment

Move coordinates to all-positive octant.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	1
Possible values:	0: Off 1: On

22.224 STORYBAR system variable

22.224.1 Display Story Bar

Controls the visibility and position of the **Story Bar**.

BricsCAD only



Type:	Short
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Turns the story bar off. Right (1): Turns the story bar visible on the right side of the model space. Left (2): Turns the story bar visible on the left side of the model space.

22.225 STRUCTURETREECONFIG system variable

22.225.1 Structure Tree Configuration

Name of the active Structure Tree configuration file. SRCHPATH is used for finding the file. Loading a different CST file than the default file changes the way that the STRUCTUREPANEL command presents drawing data.

BricsCAD only

Type:	String
Saved in:	Workspace
Default value:	"default.cst"

22.226 SURFTAB1 system variable

22.226.1 Surface tabulation 1

Specifies the number of tabulations to be created for RULESURF and TABSURF. Also defines the mesh density in the M direction for REVsurf and EDGESURF.

When extruding entities with arc segments: the SURFTAB1 system variable divides them in a number of equal length intervals.

When revolving entities: the SURFTAB1 variable controls the number of segments of the revolution surface.

Type:	Short
Saved in:	Drawing
Default value:	6



22.227 SURFTAB2 system variable

22.227.1 Surface tabulation 2

Specifies the mesh density in the N direction for REVsurf and EDGESURF. The SURFTAB2 variable controls the number of segments of each arc segment in the revolved entity.

Type:	Short
Saved in:	Drawing
Default value:	6

22.228 SURFTYPE system variable

22.228.1 Surface-fitting type

Specifies the surface-fitting type to be used when the Smooth option of the PEDIT command is executed.

Type:	Short
Saved in:	Drawing
Range:	5 to 8
Default value:	6
Possible values:	5: Quadratic B-spline surface 6: Cubic B-spline surface 8: Bezier surface

22.229 SURFU system variable

22.229.1 Surface U

Specifies the surface density in the M direction and the U isolines density on surface entities when the Smooth option of the PEDIT command is executed.

Type:	Short
Saved in:	Drawing
Default value:	6



22.230 SURFV system variable

22.230.1 Surface V

Specifies the surface density in the N direction and the V isolines density on surface entities when the Smooth option of the PEDIT command is executed.

Type:	Short
Saved in:	Drawing
Default value:	6

22.231 SVGBLENDEDGRADIENTS system variable

22.231.1 Svg Blended Gradients

Use blended gradients for complex gradient fill. The use of complex gradient fills makes the file size larger.
BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't use blended gradients. On (1): Use blended gradients.

22.232 SVGDEFAULTIMAGEEXTENSION system variable

22.232.1 Svg Default Image Extension

Specifies the default extension for images.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	.png



22.233 SVGGENERICFONTFAMILY system variable

22.233.1 Svg Generic Font Family

Font to substitute if the correct one is missing.

The following generic font families are supported in SVG: **serif, sans-serif, cursive, fantasy, monospace**.

- Sans-serif - fonts without serifs, like Arial
- Serif - fonts with serifs, like Times Roman
- Cursive - fonts that look handwritten
- Fantasy - unusual fonts
- Monospace - fonts where each character takes up the same space (non-proportional spacing), such as Courier

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: sans-serif 1: serif 2: cursive 3: fantasy 4: monospace

22.234 SVGIMAGEBASE system variable

22.234.1 Svg Image base path

Path where to copy images (if not set, absolute file paths are written to svg).

BricsCAD only

Type:	String Standard
Saved in:	Preference

22.235 SVGIMAGEURL system variable

22.235.1 Svg Image Url

Prefix, to prepend to image name (eg: "http://www.mysite.com/images/", or "to/images/").

BricsCAD only



Type:	String Standard
Saved in:	Preference

22.236 SVGLINEWEIGHTSCALE system variable

22.236.1 Svg Line Weight Scale

Size of pixel in device units, used for scaling lineweights.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	1.0

22.237 SVGOUTPUTHEIGHT system variable

22.237.1 Svg Output Height (in pixels)

Output Height (in pixels).Valid only if SVGSCALEFACTOR is zero.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	768

22.238 SVGOUTPUTWIDTH system variable

22.238.1 Svg Output Width (in pixels)

Output Width (in pixels).Valid only if SvgScaleFactor is zero.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	1024



22.239 SVGPRECISION system variable

22.239.1 Svg Floating Point Precision

Specifies the precision in terms of decimal digits in doubles (as in printf("%.9g",...) - 9 digits).

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	6

22.240 SVGSCALEFACTOR system variable

22.240.1 Svg Scale Factor

1 Drawing unit = X Svg pixels.

If set to zero, it will scale the current view to fit within the page size of SvgOutputWidth x SvgOutputHeight.

If set to a positive value, the SVG page size is calculated automatically to correspond to the required scale, when one drawing unit is equal to the specified number of SVG pixels.

E.g. 96dpi / 25.4 = 3.7795 - the corresponding scale factor for the conversion of 1 dwg unit into 1 mm Svg.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

22.241 SYSCODEPAGE system variable

22.241.1 System code page

Displays the system code page, determined by the operating system.

Read-only

Type:	String
Saved in:	Not saved



23. T

23.1 TABCONTROLHEIGHT system variable

23.1.1 Tab control height in pixels (Mac & Linux)

Sets the height of the document tab control in pixels.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 or greater
Default value:	25

23.2 TABMODE system variable

23.2.1 Tablet mode

Specifies the use of a tablet. Use the TABLET command for configuring a tablet.

Type:	Boolean
Saved in:	Not saved
Range:	Off
Possible values:	Off (0): Command selection mode On (1): Digitizing mode

23.3 TABSFIXEDWIDTH system variable

23.3.1 Tabs fixed width (Mac & Linux)

With this style, all tabs have the same width On/Off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off



Possible values:	Off (0): All tabs have fixed width off On (1): All tabs have fixed width on
------------------	--

23.4 TANGENTLENGTHTYPE system variable

23.4.1 Tangent Length Type

Defines the default flow fitting tangent length type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

23.5 TANGENTLENGTHVALUE system variable

23.5.1 Tangent Length Value

Defines the default flow fitting tangent length value.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0

23.6 TARGET system variable

23.6.1 Target

Specifies the current viewport's location of the target point.

Read-only

Type:	3D point
Saved in:	Drawing



23.7 TDCREATE system variable

23.7.1 Time/Date create

Shows the time and date the drawing was created (in Julian Day format).

Read-only

Type:	Real
Saved in:	Drawing

23.8 TDINDWG system variable

23.8.1 Time/Date in drawing

Shows the total editing time of the current drawing in days. Format: >number of days<. >decimal fraction of a day<

Read-only

Type:	Real
Saved in:	Drawing

23.9 TDUCREATE system variable

23.9.1 Time/Date universal create

Shows the universal time and date the drawing was created (in Julian Day format).

Read-only

Type:	Real
Saved in:	Drawing

23.10 TDUPDATE system variable

23.10.1 Time/Date update

Shows the local time and date the drawing was last saved or updated (in Julian Day format).

Read-only

Type:	Real
Saved in:	Drawing



23.11 TDUSRTIMER system variable

23.11.1 Time/Date user timer

Shows the user-elapsed timer. You can start, stop and reset the timer with the TIME command.

Read-only

Type:	Real
Saved in:	Drawing

23.12 TDUUPDATE system variable

23.12.1 Time/Date universal update

Shows the universal time and date the drawing was last saved or updated (in Julian Day format).

Read-only

Type:	Real
Saved in:	Drawing

23.13 TEETANGENTLENGTHTYPE system variable

23.13.1 Tee Length Type

Defines the default tee tangent length type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

23.14 TEETANGENTLENGTHVALUE system variable

23.14.1 Tee Length Value

Defines the default tee tangent length value.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	0.5

23.15 TEMPLATEPATH system variable

23.15.1 Template path

Specifies the path to the Templates folder.

BricsCAD only

Type:	String Standard
Saved in:	Preference

23.16 TEMPPREFIX system variable

23.16.1 Temporary prefix

Contains the folder name for temporary files.

Type:	String Standard
Saved in:	Registry

23.17 TEXTANGLE system variable

23.17.1 Text angle

Stores the angle of the last added text entity.

BricsCAD only

Type:	Real
Saved in:	Not saved

23.18 TEXTED system variable

23.18.1 Text editor for single line text entities

Specifies the type of the editor to work with single line text entities.



Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: in-place editor 1: pop up dialog 2: in-place editor with repeated input

23.19 TEXTEDITMODE system variable

23.19.1 Text edit mode

Specifies whether text editing commands (DDEDIT) automatically repeat entity selection or not.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Multiple edit mode (command repeats until canceled) 1: Single edit mode (command ends after editing one text entity) 2: Automatic edit mode (single if editing preselected text, multiple otherwise)

23.20 TEXTEVAL system variable

23.20.1 Text evaluation

Specifies the method of evaluation for the Command line text strings. When the TEXTEVAL system variable is set to 1, this command evaluates LISP expressions:

Text: (* pi 2)

The result of the equation ($\pi \times 2$) is placed as text: 6.283185

Type:	Short
Saved in:	Not saved



Range:	0 to 1
Default value:	0
Possible values:	0: All responses to prompts for text strings and attribute values are taken literally 1: Text starting with '(' or ')' is evaluated as an lisp expression, as for nontextual input

23.21 TEXTFILL system variable

23.21.1 Text fill

Specifies whether TrueType fonts are either filled or outlined when exporting with the PSOUT command and in renderings.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Display text as outlines 1: Display text as filled images



23.22 TEXTQLTY system variable

23.22.1 Text quality (Mac & Linux)

Specifies the smoothness of TrueType fonts for plotting and rendering.

Type:	Short
Saved in:	Not saved
Range:	0 to 100



Default value:	50
Possible values:	0: No effort to refine the smoothness of the text 100: Maximum effort to smooth text characters

23.23 TEXTSIZE system variable

23.23.1 Text size

Specifies the default height for new text entities. TEXTSIZE has no effect if the current text style has a fixed height.

Type:	Real
Saved in:	Drawing
Default value:	2.5

23.24 TEXTSTYLE system variable

23.24.1 Text style

Stores the name of the current text style.

Type:	String
Saved in:	Drawing
Default value:	Standard

23.25 TEXTUREMAPPATH system variable

23.25.1 Texture map path

Specifies the path(s) to the texture maps folder(s).

BricsCAD only

Type:	String
Saved in:	Preference



23.26 THICKNESS system variable

23.26.1 Thickness

Stores the current 3D thickness.

Type:	Real
Saved in:	Drawing
Default value:	0.0

23.27 THREADDISPLAY system variable

23.27.1 Thread representation

Defines the thread display for parts created with the -BMHARDWARE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0) On (1): Thread Display

23.28 THUMBSIZE system variable

23.28.1 Thumbnail preview image size

Specifies the maximum generated size for thumbnail previews in pixels.

Type:	Short
Saved in:	Registry
Range:	0 to 8
Default value:	3



Possible values:	0: 64x64 1: 128x128 2: 256x256 3: 512x512 4: 1024x1024 5: 1440x1440 6: 1600x1600 7: 1920x1920 8: 2560x2560
------------------	--

23.29 TILEMODE system variable

23.29.1 Tile mode

Activates the Model tab or the most recently used layout tab.

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	0: Activate last active layout tab (paper space) 1: Activate Model tab

23.30 TILEMODELIGHTSYNCH system variable

23.30.1 Tile mode light synch

Specifies the synchronization of lighting in all model space viewports. (Internal use only)

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't synchronize lighting On (1): Synchronize lighting



23.31 TIMEZONE system variable

23.31.1 Timezone

Specifies the time zone for the sun in the drawing. Setting a geographic location also sets the time zone.

Type:	Short
Saved in:	Drawing
Range:	-12000 to 13000
Default value:	-8000



Possible values:	-12000: (GMT-12:00) International Date Line West -11000: (GMT-11:00) Midway Island, Samoa -10000: (GMT-10:00) Hawaii -9000: (GMT-09:00) Alaska -8000: (GMT-08:00) Pacific Time (US & Canada); Tijuana -7000: (GMT-07:00) Mountain Time (US & Canada) -7001: (GMT-07:00) Arizona -7002: (GMT-07:00) Chihuahua, La Paz, Mazatlan -6000: (GMT-06:00) Central Time (US & Canada) -6001: (GMT-06:00) Central America -6002: (GMT-06:00) Guadalajara, Mexico City, Monterrey -6003: (GMT-06:00) Saskatchewan -5000: (GMT-05:00) Eastern Time (US & Canada) -5001: (GMT-05:00) Indiana (East) -5002: (GMT-05:00) Bogota, Lima, Quito -4000: (GMT-04:00) Atlantic Time (Canada) -4001: (GMT-04:00) Caracas, La Paz -4002: (GMT-04:00) Santiago -3300: (GMT-03:30) Newfoundland -3000: (GMT-03:00) Brasilia -3001: (GMT-03:00) Buenos Aires, Georgetown -3002: (GMT-03:00) Greenland -2000: (GMT-02:00) Mid-Atlantic -1000: (GMT-01:00) Azores -1001: (GMT-01:00) Cape Verde Is. 0: (UTC) Universal Coordinated Time 1: (GMT) Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London 2: (GMT) Casablanca, Monrovia 1000: (GMT+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna 1001: (GMT+01:00) Brussels, Copenhagen, Madrid, Paris 1002: (GMT+01:00) Belgrade, Bratislava, Budapest, Ljubljana, Prague 1003: (GMT+01:00) Sarajevo, Skopje, Warsaw, Zagreb 1004: (GMT+01:00) West Central Africa 2000: (GMT+02:00) Athens, Beirut, Istanbul, Minsk 2001: (GMT+02:00) Bucharest 2002: (GMT+02:00) Cairo 2003: (GMT+02:00) Harare, Pretoria 2004: (GMT+02:00) Helsinki, Kyiv, Riga, Sofia, Tallinn, Vilnius 2005: (GMT+02:00) Jerusalem 3000: (GMT+03:00) Moscow, St. Petersburg, Volgograd 3001: (GMT+03:00) Kuwait, Riyadh 3002: (GMT+03:00) Baghdad 3003: (GMT+03:00) Nairobi 3300: (GMT+03:30) Tehran 4000: (GMT+04:00) Abu Dhabi, Muscat 4001: (GMT+04:00) Baku, Tbilisi, Yerevan 4300: (GMT+04:30) Kabul 5000: (GMT+05:00) Ekaterinburg 5001: (GMT+05:00) Islamabad, Karachi, Tashkent 5300: (GMT+05:30) Chennai, Kolkata, Mumbai, New Delhi 5450: (GMT+05:45) Kathmandu 6000: (GMT+06:00) Almaty, Novosibirsk 6001: (GMT+06:00) Astana, Dhaka 6002: (GMT+06:00) Sri Jayawardenepura 6200: (GMT+06:30) Bangkok
------------------	---



23.32 TOOLBARMARGIN system variable

23.32.1 Toolbar margin

Margin, in pixels, separating rows of toolbar buttons.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 63
Default value:	0

23.33 TOOLBUTTONSIZE system variable

23.33.1 Tool button size

Specifies the size of the toolbar buttons.


Small



Large



Extra Large



BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0



Possible values:	0: Small buttons 1: Large buttons 2: Extra-large buttons
------------------	--

23.34 TOOLICONPADDING system variable

23.34.1 Tool icon padding

Size, in pixels, of blank space around toolbar icons

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 15
Default value:	0

23.35 TOOLPALETTEPATH system variable

23.35.1 Tool palettes path

Specify the path(s) to the Tool Palettes folder(s).

Type:	String
Saved in:	Registry

23.36 TOOLTIPDELAY system variable

23.36.1 Tooltip delay

Specifies the delay after which tooltips appear (in milliseconds).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 or greater
Default value:	500



23.37 TOOLTIPS system variable

23.37.1 Tooltips

Toggles the display of tooltips for toolbars, ribbon, quad and properties.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display tooltips On (1): Display tooltips

23.38 TPSTATE system variable

23.38.1 Tool Palettes bar state

Specifies whether the tool palettes bar is visible or not.

Read-only

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Tool Palettes bar is invisible 1: Tool Palettes bar is visible

23.39 TRACEWID system variable

23.39.1 Trace width

Specifies the default width for new traces.

Type:	Real
Saved in:	Drawing
Default value:	1.0



23.40 TRACKPATH system variable

23.40.1 Track path

Specifies the display of polar and entity snap tracking paths.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: Display full-screen entity snap tracking path 1: Display entity snap tracking path only between the alignment point and the From point to the cursor location 2: Do not display polar tracking path 3: Do not display polar or entity snap tracking paths

23.41 TRANSPARENCYDISPLAY system variable

23.41.1 Transparency display

Specifies whether entity transparencies are displayed on-screen.

Type:	Boolean
Saved in:	Registry
Default value:	On

23.42 TRAYICONS system variable

23.42.1 Tray icons

Toggles the display of notification icons in the status bar.

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't display tray On (1): Display tray
------------------	---

23.43 TRAYNOTIFY system variable

23.43.1 Tray notify

Toggles the display of notification balloons for the running services in the status bar tray.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display notifications On (1): Display notifications

23.44 TRAYTIMEOUT system variable

23.44.1 Tray timeout

Specifies the display time (in seconds) for service notifications.

Type:	Short
Saved in:	Registry
Range:	0 to 60
Default value:	0

23.45 TREEDEPTH system variable

23.45.1 Tree depth

Specifies the maximum number of times the index can be divided into branches to enhance performance.

When set to zero, entities are always processed in database order, with no performance benefit from spatial indexing.

When set to a positive value, spatial indexing is applied and supports up to five digits. The first three digits are for model space and the remaining digits are for paper space.



When set to a negative value, the Z coordinates of all entities are ignored, whether in model space or paper space. Because z coordinates are ignored, a negative value is most appropriate and efficient for 2D drawings.

Type:	Short
Saved in:	Drawing
Default value:	3020
Possible values:	0: Suppress spatial indexing >0: Apply spatial indexing <0: Ignore Z coordinates

23.46 TREEMAX system variable

23.46.1 Tree maximum

When regenerating a drawing TREEMAX limits the use of memory by limiting the number of nodes in the spatial index (oct-tree). By imposing a fixed limit with TREEMAX, you can load drawings created on systems with more memory than your system and with a larger TREEDEPTH than your system can handle. These drawings, if left unchecked, have an oct-tree large enough to eventually consume more memory than is available to your computer. TREEMAX also provides a safeguard against experimentation with inappropriately high TREEDEPTH values.

Type:	Long
Saved in:	Registry
Default value:	10000000

23.47 TRIMMODE system variable


23.47.1 Trim mode

Specifies whether the length of the selected entities or polyline segments for chamfers and fillets are adjusted (trimmed or lengthened).

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't trim selected edges to the endpoints of chamfer lines and fillet arcs On (1): Trim selected edges to the endpoints of chamfer lines and fillet arcs
------------------	---



23.48 TRUSTEDPATHS system variable

23.48.1 Trusted executable file locations

Folders from which executable files may be loaded.

Read-only

Type:	String
Saved in:	Not saved
Default value:	

23.49 TSPACEFAC system variable

23.49.1 Text space factor

Specifies the line spacing distance of multiline text measured as a factor of text height. Values between 0.25 and 4 are accepted.

Type:	Real
Saved in:	Not saved
Range:	0.25 to 4.0
Default value:	1.0



23.50 TSPACETYPE system variable

23.50.1 Text space type

Specifies the type of line spacing used for multiline text.

- At least: adjusts line spacing based on the tallest character(s) in a line.
- Exactly: uses the specified line spacing, regardless of individual character sizes.

Note: The mtexts created with the MLEADER command are also influenced by this system variable's value.

Type:	Short
Saved in:	Registry
Range:	1 to 2
Default value:	1
Possible values:	1: At least 2: Exactly

23.51 TSTACKALIGN system variable

23.51.1 Text stack align

Specifies the vertical alignment of stacked text: bottom, center or top.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Align bottom 1: Align center 2: Align top



23.52 TSTACKSIZE system variable

23.52.1 Text stack size

Specifies the percentage at which the stacked text fraction height is relative to the current height of the selected text. Values between 25 and 125 are accepted.

Type:	Short
Saved in:	Drawing
Range:	25 to 125
Default value:	70

23.53 TTFASTEXT system variable

23.53.1 TrueType Text displaying mode

Flags controlling whether TrueType text is drawn as vectorized graphics or as text.

Type:	Short
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Displays text as vectorized graphics On (1): Displays text as text



24. U

24.1 UCSAXISANG system variable

24.1.1 UCS axis angle

Specifies the default angle, in degrees, for rotating the UCS around its X, Y, or Z axis, using the UCS command.

Type:	Real
Saved in:	Registry
Range:	5 to 180
Default value:	90

24.2 UCSBASE system variable

24.2.1 UCS base

Specifies the name of the UCS which defines the orthographic UCS.

Type:	String
Saved in:	Drawing
Default value:	"WORLD"

24.3 UCSDETECT system variable

24.3.1 UCS detect

Specifies the dynamic UCS. The dynamic UCS is a temporary UCS that is automatically activated when the cursor hovers over a 3D solid's face or 2D entity. A negative value is the same as 0, but helps in storing the earlier value. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	-3 to 3
Default value:	1



Possible options:	negative: Disable dynamic UCS 1: Enable for faces of 3D solid and regions. 2: Enable for 2D entities
-------------------	--

24.4 UCSFOLLOW system variable

24.4.1 UCS follow

Specifies whether a plan view (A top view zoomed to extents) is generated automatically whenever the UCS changes. It is recommended to switch UCSDETECT off in this case.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't show plan view when changing UCS On (1): Show plan view when changing UCS

24.5 UCSICON system variable

24.5.1 UCS icon

Specifies the display and position of the UCS icon for the current viewport. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Drawing
Default value:	3
Possible options:	0: No icon 1: Show icon 2: at origin

24.6 UCSICONPOS system variable

24.6.1 UCS icon position

Specifies the non-origin location of the UCS Icon.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	0: Lower right 1: Lower left 2: Upper right 3: Upper left

24.7 UCSNAME system variable

24.7.1 UCS name

Specifies the name of the UCS for the current viewport in the current working space.

Read-only

Type:	String
Saved in:	Drawing

24.8 UCSORG system variable

24.8.1 UCS origin

Stores the current coordinate system's origin point for the current viewport.

Read-only

Type:	3D point
Saved in:	Drawing
Default value:	0,0,0



24.9 UCSORTHO system variable

24.9.1 UCS orthographic

Specifies whether or not the related orthographic UCS setting is activated automatically when selecting an orthographic view with the -VIEW command or the LookFrom widget (unless NAVVCUBEORIENT is set to UCS).

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): When an orthographic view is selected, don't automatically activate the related orthographic UCS On (1): When an orthographic view is selected, automatically activate the related orthographic UCS

24.10 UCSVIEW system variable

24.10.1 UCS view

Specifies whether or not the current UCS will be saved with a named view.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't save current UCS with named view On (1): Save current UCS with named view

24.11 UCSVP system variable

24.11.1 UCS viewports

Specifies whether the UCS in all viewports is fixed or changes to reflect the currently active viewport's UCS.

Type:	Boolean
Saved in:	Drawing



Default value:	On
Possible values:	Off (0): Not locked (UCS stored in viewport) On (1): Locked (UCS stored in viewport)

24.12 UCSXDIR system variable

24.12.1 UCS X direction

Stores the current coordinate system's X direction for the current viewport.

Read-only

Type:	3D point
Saved in:	Drawing
Default value:	1,0,0

24.13 UCSYDIR system variable

24.13.1 UCS Y direction

Stores the current coordinate system's Y direction for the current viewport.

Read-only

Type:	3D point
Saved in:	Drawing
Default value:	0,1,0

24.14 UNDOCTL system variable

24.14.1 Undo control

Specifies the state of the UNDO command. The value is stored as a bitcode using the sum of the values of all selected options.

Read-only

Type:	Short
Saved in:	Not saved



Default value:	5
Possible options:	0: Undo off 1: Undo on 2: Only one command can be undone 4: Auto is turned on 8: A group is currently active

24.15 UNDOMARKS system variable

24.15.1 Undo marks

Shows the current number of marks placed in the Undo control using the MARK option. The MARK and BACK options are not available if a group is currently active.

Read-only

Type:	Short
Saved in:	Not saved

24.16 UNITESURFACES system variable

Unite adjacent surfaces.

Determines whether adjacent extruded/revolved surfaces are united or not.

The UNITESURFACES system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Short
Saved in:	Workspace
Default value:	0 - for Workspaces Drafting and Modeling 1 - for Workspaces Mechanical and BIM
Possible options:	Off (0): Unite adjacent surfaces On (1): Do not unite adjacent surfaces

24.17 UNITMODE system variable

24.17.1 Unit mode

Specifies how Imperial units are displayed.



Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't remove spaces when converting distances or angles to text On (1): Remove spaces when converting distances or angles to text

24.18 USECOMMUNICATOR system variable

24.18.1 Use Communicator

Indicates that a Communicator license was activated. If the license is changed, the new level comes into effect after restarting the program.

- 0: no license, Communicator import and export formats are not available.
- 1: trial, runs Communicator in trial mode, expiring after 30 days.
- 2: full, runs the full communicator import-export set.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Not using Communicator 1: Using Communicator Trial 2: Using Communicator

24.19 USENEWRIBBON system variable

24.19.1 Use the new Ribbon

Controls whether the new Ribbon is used.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	Off
Possible values:	Off (0): Disable the new Ribbon On (1): Enable the new Ribbon after restart

24.20 USERI1 system variable

24.20.1 User integer 1

First of 5 variables that can be used by the user to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

24.21 USERI2 system variable

24.21.1 User integer 2

Second of 5 variables that can be used by the user to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

24.22 USERI3 system variable

24.22.1 User integer 3

Third of 5 variables that can be used by the user to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0



24.23 USERI4 system variable

24.23.1 User integer 4

Fourth of 5 variables that can be used by the user to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

24.24 USERI5 system variable

24.24.1 User integer 5

Fifth of 5 variables that can be used by the user to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

24.25 USERR1 system variable

24.25.1 User real 1

First of 5 variables that can be used by the user to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0

24.26 USERR2 system variable

24.26.1 User real 2

Second of 5 variables that can be used by the user to store real numerical values.

Type:	Real
-------	------



Saved in:	Drawing
Default value:	0.0

24.27 USERR3 system variable

24.27.1 User real 3

Third of 5 variables that can be used by the user to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0

24.28 USERR4 system variable

24.28.1 User real 4

Fourth of 5 variables that can be used by the user to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0

24.29 USERR5 system variable

24.29.1 User real 5

Fifth of 5 variables that can be used by the user to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0



24.30 USERS1 system variable

24.30.1 User string 1

First of 5 variables that can be used by the user to store string values.

Type:	String
Saved in:	Not saved

24.31 USERS2 system variable

24.31.1 User string 2

Second of 5 variables that can be used by the user to store string values.

Type:	String
Saved in:	Not saved

24.32 USERS3 system variable

24.32.1 User string 3

Third of 5 variables that can be used by the user to store string values.

Type:	String
Saved in:	Not saved

24.33 USERS4 system variable

24.33.1 User string 4

Fourth of 5 variables that can be used by the user to store string values.

Type:	String
Saved in:	Not saved

24.34 USERS5 system variable

24.34.1 User string 5

Fifth of 5 variables that can be used by the user to store string values.



Type:	String
Saved in:	Not saved

24.35 USESTANDARDOPENFILEDIALOG system variable

24.35.1 Use standard open file dialog (Windows)

Specifies whether to show an additional folder in the file dialog for the open, save as and insert commands.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off



25. V

25.1 VBAMACROS system variable

25.1.1 Enable macros

Specifies whether macros are enabled when loading a VBA-project.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable macros on loading VBA-project On (1): Enable macros on loading VBA-project

25.2 VENDORNAME system variable

25.2.1 Vendor name

Shows the vendor name.

BricsCAD only

Read-only

Type:	String
Saved in:	Not saved
Default value:	"Bricsys"

25.3 VERBOSEBIMSECTIONUPDATE system variable

25.3.1 Additional diagnostics while section update

Defines whether BIMSECTIONUPDATE prints additional diagnostics.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	1
----------------	---

25.4 VERSIONCONTROLCONFIGPATH system variable

25.4.1 Version Control config path

Specifies the folder where version control settings are configured.

BricsCAD only

Type:	String
Saved in:	Registry

25.5 VERSIONCONTROLDOWNLOADPATH system variable

25.5.1 Version Control download path

Specifies the folder where version control projects should be saved by default.

BricsCAD only

Type:	String
Saved in:	Registry

25.6 VERSIONCUSTOMZABLEFILES system variable

25.6.1 Version customizable files

Current version of the CUI and PGP files.

Read-only

Type:	String
Saved in:	Preference

25.7 VIEWCTR system variable

25.7.1 View center

Specifies the current viewport's center of view, expressed in UCS coordinates.

Read-only

Type:	3D point
-------	----------



Saved in:	Drawing
-----------	---------

25.8 VIEWDIR system variable

25.8.1 View direction

Specifies the current viewport's viewing direction, expressed in UCS coordinates.

Read-only

Type:	3D point
Saved in:	Drawing

25.9 VIEWMODE system variable

25.9.1 View mode

Specifies the current viewport's View mode. The value is stored as a bitcode using the sum of the values of all selected options. If 'Front clip not at eye' (16) is on, the front clip distance (FRONTZ) sets the front clipping plane. If off, the front clipping plane passes through the camera point (vectors behind the camera are not displayed). This flag is ignored if the front-clipping bit (2) is off.

Read-only

Type:	Short
Saved in:	Drawing
Range:	0 to 31
Possible options:	0: Turned off 1: Perspective view active 2: Front clipping on 4: Back clipping on 8: UCS Follow mode on 16: Front clip not at eye

25.10 VIEWSIZE system variable

25.10.1 View size

Specifies the view height, measured in drawing units, for the current viewport.

Read-only



Type:	Real
Saved in:	Drawing
Default value:	0.0

25.11 VIEWTWIST system variable

25.11.1 View twist

Specifies the view twist angle, measured relative to the WCS, for the current viewport.

Read-only

Type:	Real
Saved in:	Drawing

25.12 VIEWUPDATEAUTO system variable

25.12.1 Automatically update drawing views

Specifies whether model documentation drawing views are updated automatically when the source model changes. When turned off, the **ViewUpdate** command manually updates the drawing views created by **ViewBase** and **ViewSection** commands. This only works in paper space.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't update drawing views automatically On (1): Update drawing views automatically

25.13 VISRETAIN system variable

25.13.1 Visibility retain

Specifies the visibility, color, linetype, linewidth, and, if PSTYLEPOLICY is set to OFF (0), plotstyles of xref-dependent layers. It also specifies whether nested xref path changes are saved.

If Off (0): Changes made to xref-dependent layers in the current drawing are valid in the current session only and are Not saved with the drawing. When the current drawing is reopened, the layer table is reloaded



from the reference drawing and the current drawing reflects those settings. The layer settings affected are: On, Off, Freeze, Thaw, Color, Ltype, LWeight, and PStyle (if PSTYLEPOLICY is set to 0).

If On (1): Layer settings are saved with the current drawing's layer table and persist from session to session.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Off, the layer table, as stored in the reference drawing (Xref) takes precedence 1: On, Xref-dependent layer changes made in the current drawing take precedence

25.14 VOLUMEPREC system variable

25.14.1 Volume precision

Specifies the number of decimal places displayed for volumes when the volume bit of PROPUNITS is on. If negative, LUPREC (Linear Unit Precision) is used.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-1 to 8
Default value:	-1



Possible values:	-1: Use LUPREC 0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000 8: 0.00000000
------------------	---

25.15 VOLUMEUNITS system variable

25.15.1 Volume units

Specifies a list of units used for displaying volumes when the volume bit of PROPUNITS is on. If empty, all volumes are displayed in the current drawing unit. When one or more units are selected in the VolumeUnits dialog box, the program uses the unit that is the best fit. The Format Volume Properties bit of the Property Units variable must be turned on.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	"in ft mi µm mm cm m km"

25.16 VPMAXIMIZEDSTATE system variable

25.16.1 Viewport maximized

Displays a value to indicate whether the viewport is maximized. You cannot plot or publish when the viewport is maximized.

AutoCAD only

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	Off



Possible values:	Off (0): Viewport is not maximized On (1): Viewport is maximized
------------------	---

25.17 VPROTATEASSOC system variable

25.17.1 Rotate view

Allow rotation of a view within a viewport when a viewport is rotated.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Rotate view off On (1): Rotate view on

25.18 VSMAX system variable

25.18.1 Virtual screen maximum

Shows the coordinates of the upper-right corner of the current viewport's virtual screen.

Read-only

Type:	3D point
Saved in:	Drawing

25.19 VSMIN system variable

25.19.1 Virtual screen minimum

Shows the coordinates of the lower-left corner of the current viewport's virtual screen.

Read-only

Type:	3D point
Saved in:	Drawing



25.20 VTDURATION system variable

25.20.1 View transition duration

Specifies the duration of animated view transitions in milliseconds.

Type:	Short
Saved in:	Registry
Range:	0 to 5000
Default value:	750

25.21 VTENABLE system variable

25.21.1 Enable view transitions

Specifies whether animated view transitions are enabled for zoom/pan and/or for view rotation operations. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	3
Possible options:	1: For zoom/pan 2: For rotation 4: For unattended mode

25.22 VTFPS system variable

25.22.1 View transition minimum FPS

Specifies the minimum FPS (frames per second) required for enabling animated view transitions. That is 7 by default, which means that the redraw time should take less than 143 (=1000/7) milliseconds. If the computer is not capable to redraw the view fast enough, no animation will be available.

Type:	Short
Saved in:	Registry



Range:	1 to 30
Default value:	7



26. W

26.1 WARNINGMESSAGES system variable

26.1.1 Warning messages

Specifies whether warning messages are displayed in certain situations. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Long
Saved in:	Preference
Default value:	1048575
Possible options:	<ul style="list-style-type: none">1: Selecting 3D context with hardware rendering off2: Modifying tool property in Customize dialog4: Deleting sheet custom property8: Moving entities to frozen or off layer16: Saving to previous version not supporting some entities32: Detecting modified attachments when opening the parent drawing64: Creating new layer not matching the current layer filter128: Render: Tile sizes between 4 and 127 are processed as 128256: Expanding category mass in properties panel512: Deleting an item in Customize dialog1024: Publish: Save sheet list2048: Delete layouts in Page Setup Explorer4096: Mass properties calculation takes long time8192: Array editing state16384: Incompatible units32768: Modified block definition will cause all related block references update65536: A Data Link has changed, Any tables using this link may need to be updated131072: VIEWBASE usage for architectural drawings262144 Expanding a closed category in properties panel524288: Empty category in properties panel is removed

26.2 WHIPARC system variable

26.2.1 Whip arcs

Specifies whether circles and circular arcs display as true circles or as a series of vectors.



Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Display circles and arcs as a series of vectors 1: Display as true circles and arcs

26.3 WHIPTHREAD system variable

26.3.1 Whip thread

Specifies whether regen and redraw will be done multithreaded, if the machine has multiple processors. Not supported yet. When multithreaded processing is used for redraw operations (value 2 or 3), the order of entities specified with the DRAWORDER command is not guaranteed to be preserved for display but is preserved for plotting. The value is stored as a bitcode using the sum of the values of all selected options.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible options:	0: No multithreaded processing 1: Regeneration multithreaded processing 2: Redraw multithreaded processing

26.4 WINDOWAREACOLOR system variable

26.4.1 Window area color

Specifies the color for window selection areas. In effect only when SELECTIONAREA setting is on.

Type:	Short
Saved in:	Registry
Range:	1 to 255



Default value:	150
----------------	-----

26.5 WIPEOUTFRAME system variable

26.5.1 Wipeout frame

Specifies the display of frames for wipeout entities. If 0: frames are temporarily displayed for entity selection and selection preview.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Hide wipeout frames 1: Display and plot wipeout frames 2: Display but do not plot wipeout frames

26.6 WMFBKGND system variable

26.6.1 Windows Meta File background

Specifies how the background of a WMF (Windows Meta File) or Copy Clip is created and displayed in other applications.

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Transparent background; foreground depends on WMFFOREGND On (1): Current background color; foreground remains unchanged

26.7 WMFFOREGND system variable

26.7.1 Windows Meta File foreground

Specifies how the foreground of a WMF (Windows Meta File) or Copy Clip is created and displayed in other applications. WMFFOREGND applies only when WMFBKGND is set to 0.



Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Ensure foreground color is darker than background color On (1): Ensure foreground color is lighter than background color

26.8 WNDLMAIN system variable

26.8.1 Main window state

Stores the state of the main graphics window.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Normal 1: Minimized 2: Maximized

26.9 WNDLSCRL system variable

26.9.1 Window scrollbars (Windows)

Specifies the display of scrollbars on the main graphics window.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Default value:	Off
Possible values:	Off (0): Don't show scrollbars On (1): Show scrollbars



26.10 WNDLTEXT system variable

26.10.1 Text window state

Stores the state of the text window.

BricsCAD only

Type:	Short
Saved in:	Registry
Possible values:	0: Hidden 1: Normal 2: Minimized 3: Maximized

26.11 WNDPMAIN system variable

26.11.1 Main window top left

Stores the top left position of the main graphics window.

BricsCAD only

Type:	2D point
Saved in:	Registry

26.12 WNDPTEXT system variable

26.12.1 Text window top left

Stores the top left position of the text window.

BricsCAD only

Type:	2D point
Saved in:	Registry

26.13 WNDSMAIN system variable

26.13.1 Main window size

Stores the size of the main graphics window.

BricsCAD only



Type:	2D point
Saved in:	Registry

26.14 WNDSTEXT system variable

26.14.1 Text window size

Stores the size of the text window.

BricsCAD only

Type:	2D point
Saved in:	Registry

26.15 WORLDUCS system variable

26.15.1 World UCS

Specifies whether or not the UCS is the same as the WCS.

Read-only

Type:	Boolean
Saved in:	Not saved
Possible values:	Off (0): UCS doesn't match the WCS On (1): UCS matches the WCS

26.16 WORLDVIEW system variable

26.16.1 World view

Specifies whether the current UCS changes to the WCS during DVIEW or VPOINT commands.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1



Possible values:	0: UCS remains unchanged 1: UCS changes to the WCS for the duration of the command; the command input is relative to the current UCS
------------------	---

26.17 WRITESTAT system variable

26.17.1 Write status

Shows the state in which a drawing is opened: read-only or that it can be written to. This variable is used in lisp to determine the write status of drawing.

Read-only

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Can't write to the drawing On (1): Can write to the drawing

26.18 WSAUTOSAVE system variable

26.18.1 Workspace autosave

Specifies whether changes made to a workspace are automatically saved.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't save automatically On (1): Save automatically

26.19 WSCURRENT system variable

26.19.1 Current workspace

The name of the current workspace.

Type:	String
-------	--------



Saved in:	Registry
-----------	----------



27. X

27.1 XCLIPFRAME system variable

27.1.1 Xref clipping frame

Specifies the display of xref clipping boundaries. The FRAME system variable overrides the XCLIPFRAME setting.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Hide clipping boundaries 1: Display and plot clipping boundaries 2: Display but do not plot clipping boundaries

27.2 XDWGFADECTL system variable

27.2.1 Xref database fade control

Specifies the fading level for XREF inserts. Non-positive values disable fading.

Type:	Short
Saved in:	Registry
Range:	-90 to 90
Default value:	70

27.3 XEDIT system variable

27.3.1 Xref editable

Specifies the in-place editing of the current drawing if referenced by another drawing.

Type:	Boolean
Saved in:	Drawing



Default value:	On
Possible values:	Off (0): Can't use in-place reference editing On (1): Can use in-place reference editing

27.4 XFADECTL system variable

27.4.1 Reference editing fade control

Specifies the fading level for references which are edited in-place. This setting affects only the entities that are not being edited in the reference. Values between 0 and 90 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 90
Default value:	50

27.5 XLOADCTL system variable

27.5.1 Xref load control

Not supported yet. Specifies xref demand-loading and determines whether a copy or the original drawing is opened.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Turn off demand-loading; the entire drawing is loaded 1: Turn on demand-loading; referenced drawings are kept open and locked 2: Turn on demand-loading; copies of referenced drawings are opened and locked; referenced drawings are not locked



27.6 XLOADPATH system variable

27.6.1 Xref load path

Specifies a path to store temporary copies of demand-loaded xrefs (see also Xref load control).

Type:	String Standard
Saved in:	Registry

27.7 XNOTIFYTIME system variable

27.7.1 Xnotify time

Specifies a number of minutes between checking for modified xrefs, images and PDF documents. This is if XREFNOTIFY, IMAGENOTIFY and/or PDFNOTIFY is ON.

Type:	Short
Saved in:	Registry
Range:	0 to 10080
Default value:	5

27.8 XREFCTL system variable

27.8.1 Xref control

Toggles the creation of external reference log files (XLG) on/off.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): Don't write log files On (1): Write log files

27.9 XREFNOTIFY system variable

27.9.1 Xref notify

Enables/disables the notification about missing xrefs when opening the parent drawing.



Type:	Boolean
Saved in:	Registry
Possible values:	Off (0): Disable xref notification On (1): Enable xref notification

27.10 XREFOVERRIDE system variable

27.10.1 Xref override

Specifies the display of entity visual properties (such as color, linetype, linewidth, transparency, or plot style) on referenced layers.

If Off (0): When the properties of the entities on the XREF drawing are set to ByLayer, any changes to the xref layer properties are displayed in the current drawing.

If On (1): When the properties of the entities on the XREF drawing are not set to ByLayer, entities on xref layers are treated as if their properties are set to ByLayer. And every external reference layer can have its own set of layer overrides.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	Off (0): Only ByLayer properties of the entities in the XREF drawing can be changed On (1): All properties of entities in the XREF drawing can be changed by its original layer property



28. Y



29. Z

29.1 ZOOMFACTOR system variable

29.1.1 Zoom factor

Specifies the incremental change in zoom with each mouse-wheel action, whether forward or backward.

When zooming in, the incremental step decreases gradually allowing to focus on a particularly detail easily. Values between 3 and 100 are accepted. The higher the number, the more the change.

Type:	Short
Saved in:	Registry
Range:	3 to 100
Default value:	40

29.2 ZOOMWHEEL system variable

29.2.1 Mouse wheel zoom direction

Toggles mouse wheel zoom direction.

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Move wheel forward zooms in; move wheel back zooms out 1: Move wheel forward zooms out; move wheel back zooms in