



Bricsys®

System variable reference (V25)

Product documentation





Contents

1.	System variable reference	62
1.1	System variable data types	62
1.2	System variables save location	62
1.3	Editing system variables	63
1.4	Searching for variables	63
2.		64
2.1	_QUADTABFLAGS system variable	64
2.1.1	Quad tab flags	64
2.2	_VERNUM system variable	64
2.2.1	Version number (Read Only)	64
3.	2	65
3.1	2DCONSTRAINTFLAGS system variable	65
3.1.1	2D Constraint Flags	65
4.	3	66
4.1	3DCOMPAREMODE system variable	66
4.1.1	Compare mode	66
4.2	3DOSMODE system variable	66
4.2.1	3D entity snap mode	66
4.3	3DSNAPMARKERCOLOR system variable	67
4.3.1	3d snap marker color	67
5.	A	68
5.1	ACADLSPASDOC system variable	68
5.1.1	on_start.lsp for each doc	68
5.2	ACADPREFIX system variable	68
5.2.1	Program folder path (Read only)	68
5.3	ACADVER system variable	68
5.3.1	AutoCAD version (Read Only)	68
5.4	ACISHLRRESOLUTION system variable	68
5.4.1	Hidden line removal resolution	68
5.5	ACISSAVEASMODE system variable	69
5.5.1	Acis save as mode	69
5.6	ACISOUTVER system variable	69
5.6.1	Acisout version	69
5.7	ADAPTIVEGRIDSTEPSENSE system variable	69
5.7.1	Adaptive grid step size	69
5.8	AFLAGS system variable	70
5.8.1	Attribute options	70
5.9	ALIGNDIMENSIONONISOMETRIC system variable	70
5.9.1	Dimension alignment	70
5.10	ALLOWEDBENDANGLES system variable	71
5.10.1	Allowed bend angles	71
5.11	ALLOWTABEXTERNALMOVE system variable	71
5.11.1	Move tabs externally (Mac & Linux)	71
5.12	ALLOWTABMOVE system variable	71
5.12.1	Move tabs (Mac & Linux)	71
5.13	ALLOWTABSPLIT system variable	72
5.13.1	Split tabs (Mac & Linux)	72



Contents

5.14	AMPOWERDIMDISPLAY system variable	72
5.14.1	Mechanical 2D Editor	72
5.15	AMSYMSCALE system variable	73
5.15.1	Mechanical2D annotation scaling	73
5.16	ANGBASE system variable	73
5.16.1	Angle base	73
5.17	ANGDIR system variable	73
5.17.1	Angle direction	73
5.18	ANNOALLVISIBLE system variable	74
5.18.1	Annotation visibility	74
5.19	ANNOAUTOSCALE system variable	74
5.19.1	Annotation scaling	74
5.20	ANNOMONITOR system variable	75
5.20.1	Annotation monitor	75
5.21	ANNOTATEDWG system variable	75
5.21.1	Annotative drawing	75
5.22	ANTIALIASRENDER system variable	76
5.22.1	Anti-alias amount for render	76
5.23	ANTALIASSCREEN system variable	76
5.23.1	Anti-alias amount for screen	76
5.24	APBOX system variable	77
5.24.1	Entity snap aperture box	77
5.25	APERTURE system variable	77
5.25.1	Entity snap sensitivity	77
5.26	AREA system variable	78
5.26.1	Area (Read Only)	78
5.27	AREAPREC system variable	78
5.27.1	Area precision	78
5.28	AREAUNITS system variable	79
5.28.1	Area units	79
5.29	ARRAYASSOCIATIVITY system variable	79
5.29.1	Associative arrays	79
5.30	ARRAYEDITSTATE system variable	79
5.30.1	Array edit state (Read Only)	79
5.31	ARRAYTYPE system variable	80
5.31.1	Array type	80
5.32	ATTDIA system variable	80
5.32.1	Attribute dialog	80
5.33	ATTFULLUPDATE system variable	80
5.33.1	Reset attributes when editing a block parameter	80
5.34	ATTMODE system variable	81
5.34.1	Attribute display mode	81
5.35	ATTRACTONDISTANCE system variable	81
5.35.1	Grips attraction distance	81
5.36	ATTREQ system variable	81
5.36.1	Insertion default settings	81
5.37	AUDITCTL system variable	82
5.37.1	Audit control	82



Contents

5.38	AUDITERRORCOUNT system variable	82
5.38.1	Audit Error Count (Read Only)	82
5.39	AUNITS system variable	82
5.39.1	Angular unit type	82
5.40	AUPREC system variable	83
5.40.1	Angular unit precision	83
5.41	AUTOCOMPLETEDELAY system variable	83
5.41.1	Auto complete delay	83
5.42	AUTOCOMPLETEMODE system variable	84
5.42.1	Auto complete mode	84
5.43	AUTOMATICCONNECTION system variable	84
5.43.1	Automatic connection	84
5.44	AUTOMATICSTAIRSECTIONBEHAVIOR system variable	85
5.44.1	Automatic stair section behavior	85
5.45	AUTOMATICTEES system variable	85
5.45.1	Automatic tees	85
5.46	AUTORESETSCALES system variable	85
5.46.1	Purge unused scales	85
5.47	AUTOSAVECHECKSONLYFIRSTBITDBMOD system variable	86
5.47.1	Ignore all but first bit of DBMOD for autosave	86
5.48	AUTOSNAP system variable	86
5.48.1	AutoSnap	86
5.49	AUTOTRACKINGVECCOLOR system variable	87
5.49.1	Auto tracking vector color	87
5.50	AUTOVPFITTING system variable	87
5.50.1	Automatically resize viewports	87
6.	B	88
6.1	BACKGROUNDPLOT system variable	88
6.1.1	Background plotting	88
6.2	BACKZ system variable	88
6.2.1	Back clipping plane offset	88
6.3	BASEFILE system variable	88
6.3.1	Template	88
6.4	BCFSOURCEURL system variable	89
6.4.1	BCF source url	89
6.5	BEDITASSOCMODE system variable	89
6.5.1	Associative identifiers in BEDIT	89
6.6	BILLOFMATERIALSSETTINGS system variable	89
6.6.1	Bill of materials defaults	89
6.7	BIMDEFAULTPROPERTIESPATH system variable	90
6.7.1	Default properties path	90
6.8	BIMMATCHPROP system variable	90
6.8.1	Match BIM Properties	90
6.9	BIMOSMODE system variable	90
6.9.1	BIM snap mode	90
6.10	BIMPROFILESTANDARDS system variable	91
6.10.1	Profile's standards	91
6.11	BINDTYPE system variable	91



Contents

6.11.1	Xref bind type	91
6.12	BKGCOLOR system variable	92
6.12.1	Background color	92
6.13	BKGCOLORPS system variable	92
6.13.1	Paper space background color	92
6.14	BLIPMODE system variable	92
6.14.1	Blip mode	92
6.15	BLOCKEDITLOCK system variable	93
6.15.1	Block editor lock	93
6.16	BLOCKEDITOR system variable	93
6.16.1	Block editor (Read Only)	93
6.17	BLOCKIFYMODE system variable	93
6.17.1	Blockify settings	93
6.18	BLOCKIFYTOLERANCE system variable	94
6.18.1	Blockify tolerance	94
6.19	BLOCKLEVELOFDETAIL system variable	94
6.19.1	Block Level of detail	94
6.20	BLOCKSPATH system variable	95
6.20.1	Blocks path	95
6.21	BMAUTOUUPDATE system variable	95
6.21.1	Update external components	95
6.22	BMEXTERNALIZEILLEGALSYMBOLS system variable	95
6.22.1	Illegal symbols treatment	95
6.23	BMFORMTEMPLATEPATH system variable	96
6.23.1	BMFORM template path	96
6.24	BMTOOLPATH system variable	96
6.24.1	Assembly Inspect tool search paths	96
6.25	BMUPDATEMODE system variable	96
6.25.1	Assembly components update mode	96
6.26	BOLTINGASMDEFAULTLENGTHINCREMENT system variable	97
6.26.1	Default length increment	97
6.27	BOLTINGASMDEFAULTNUT system variable	97
6.27.1	Default nut	97
6.28	BOLTINGASMDEFAULTNUTSNUMBER system variable	97
6.28.1	Default nuts number	97
6.29	BOLTINGASMDEFAULTSTUD system variable	98
6.29.1	Default stud	98
6.30	BOMFILTERSETTINGS system variable	98
6.30.1	Default BOM filter settings	98
6.31	BOMPROPERTYSET system variable	99
6.31.1	Default BOM property set	99
6.32	BOMTEMPLATE system variable	99
6.32.1	Default template	99
6.33	BOMTHUMBNAILHEIGHT system variable	100
6.33.1	Default thumbnail height, px	100
6.34	BOMTHUMBNAILWIDTH system variable	100
6.34.1	Default thumbnail width, px	100
6.35	BOUNDARYCOLOR system variable	100



Contents

6.35.1	Detected Boundary Color	100
6.36	BSYSLIBCOPYOVERWRITE system variable	101
6.36.1	Bsylib copy overwrite	101
6.37	BV MODE system variable	101
6.37.1	Block Visibility Mode (Read Only)	101
7.	C	102
7.1	CACHELAYOUT system variable	102
7.1.1	Cache layout	102
7.2	CAMERADISPLAY system variable	102
7.2.1	Camera display	102
7.3	CAMERAHEIGHT system variable	102
7.3.1	Camera height	102
7.4	CANNOSCALE system variable	103
7.4.1	Annotation scale name	103
7.5	CANNOSCALEVALUE system variable	103
7.5.1	Annotation scale value (Read Only)	103
7.6	CDATE system variable	103
7.6.1	Calendar date (Read Only)	103
7.7	CECOLOR system variable	103
7.7.1	Entity color	103
7.8	CELSCALE system variable	104
7.8.1	Entity linetype scale	104
7.9	CELTTYPE system variable	104
7.9.1	Entity linetype	104
7.10	CELWEIGHT system variable	104
7.10.1	Entity linewidth	104
7.11	CENTERCROSSGAP system variable	105
7.11.1	Center mark cross gap	105
7.12	CENTERCROSSSIZE system variable	105
7.12.1	Center mark cross size	105
7.13	CENTEREXE system variable	106
7.13.1	Centerline extension length	106
7.14	CENTERLAYER system variable	106
7.14.1	Default layer for center mark or centerline	106
7.15	CENTERLTSCALE system variable	107
7.15.1	Linetype scale for center mark or centerline	107
7.16	CENTERLTYPE system variable	107
7.16.1	Center mark/centerline linetype	107
7.17	CENTERLTYPEFILE system variable	107
7.17.1	Linetype file for center mark or centerline	107
7.18	CENTERMARKEXE system variable	108
7.18.1	Automatic extension for center mark or centerline	108
7.19	CETRANSPARENCY system variable	108
7.19.1	Transparency	108
7.20	CHAMFERA system variable	109
7.20.1	Chamfer first distance	109
7.21	CHAMFERB system variable	109
7.21.1	Chamfer second distance	109



Contents

7.22	CHAMFERC system variable	109
7.22.1	Chamfer length	109
7.23	CHAMFERD system variable	109
7.23.1	Chamfer angle	109
7.24	CHAMMODE system variable	110
7.24.1	Chamfer mode	110
7.25	CHECKDWLPRESENT system variable	110
7.25.1	Check DWL file existence before open	110
7.26	CIRCLERAD system variable	111
7.26.1	Circle radius	111
7.27	CIRCULARARROWHEADLENGTH system variable	111
7.27.1	Default head length	111
7.28	CIRCULARARROWHEADWIDTH system variable	111
7.28.1	Default head width	111
7.29	CIRCULARARROWLEADERRADIUS system variable	112
7.29.1	Default leader radius	112
7.30	CIRCULARARROWLEADERROTATION system variable	112
7.30.1	Default leader rotation	112
7.31	CIRCULARARROWTHICKNESS system variable	113
7.31.1	Default thickness	113
7.32	CLAYER system variable	113
7.32.1	Current layer	113
7.33	CLEANSCREENOPTIONS system variable	113
7.33.1	Clean screen options	113
7.34	CLEANSCREENSTATE system variable	114
7.34.1	Clean screen state (Read Only)	114
7.35	CLIPBOARDFORMAT system variable	114
7.35.1	Clipboard DWG format	114
7.36	CLIPBOARDFORMATS system variable	115
7.36.1	Clipboard Formats	115
7.37	CLIPROMPTLINES system variable	115
7.37.1	Prompt Lines	115
7.38	CLISTATE system variable	116
7.38.1	Command line state (Read Only)	116
7.39	CLOSECHECKSONLYFIRSTBITDBMOD system variable	116
7.39.1	Ignore all but first bit of DBMOD for close	116
7.40	CLOUDDOWNLOADPATH system variable	116
7.40.1	Cloud download path	116
7.41	CLOUDLOG system variable	117
7.41.1	Cloud log	117
7.42	CLOUDLOGVERBOSE system variable	117
7.42.1	Cloud log verbose	117
7.43	CLOUDONMODIFIED system variable	117
7.43.1	Cloud on modified	117
7.44	CLOUDSERVER system variable	118
7.44.1	Cloud server	118
7.45	CLOUDSSOCLIENTID system variable	118
7.45.1	Cloud SSO Client ID	118



Contents

7.46	CLOUDSSOSCOPE system variable	119
7.46.1	Cloud SSO Scope	119
7.47	CLOUDTEMPFOLDER system variable	119
7.47.1	Cloud temporary folder	119
7.48	CLOUDUPLOADDEPENDENCIES system variable	119
7.48.1	Cloud upload dependencies	119
7.49	CMATERIAL system variable	120
7.49.1	Current material	120
7.50	CMDACTIVE system variable	120
7.50.1	Active command (Read Only)	120
7.51	CMDDIA system variable	120
7.51.1	Command dialogs	120
7.52	CMDECHO system variable	121
7.52.1	Command echo	121
7.53	CMDLINEEDITBGCOLOR system variable	121
7.53.1	Command line edit background color	121
7.54	CMDLINEEDITFGCOLOR system variable	121
7.54.1	Command line edit foreground color	121
7.55	CMDLINEFADINGLOGBGCOLOR system variable	122
7.55.1	Command line fade log background color	122
7.56	CMDLINEFADINGLOGFADEDelay system variable	122
7.56.1	Command line fading log fade delay	122
7.57	CMDLINEFADINGLOGFGCOLOR system variable	122
7.57.1	Command line fade log foreground color	122
7.58	CMDLINEFADINGLOGTRANSPARENCY system variable	123
7.58.1	Command line fade log transparency	123
7.59	CMDLINEFONTNAME system variable	123
7.59.1	Command line font name	123
7.60	CMDLINEFONTSIZE system variable	123
7.60.1	Command line font size	123
7.61	CMDLINEFRAMEACTIVETRANSPARENCY system variable	124
7.61.1	Command line frame transparency when active	124
7.62	CMDLINEFRAMEINACTIVETRANSPARENCY system variable	124
7.62.1	Command line frame transparency when inactive	124
7.63	CMDLINEFRAMEUSETEXTSCR system variable	125
7.63.1	Command line frame TEXTSCR	125
7.64	CMDLINELISTBGCOLOR system variable	125
7.64.1	Command line list background color	125
7.65	CMDLINELISTFGCOLOR system variable	125
7.65.1	Command line list foreground color	125
7.66	CMDLINEOPTIONBGCOLOR system variable	126
7.66.1	Command line option background color	126
7.67	CMDLINEOPTIONSHORTCUTCOLOR system variable	126
7.67.1	Command line option shortcut color	126
7.68	CMDLINEUSEMINIFRAME system variable	126
7.68.1	Command line mini floating frame	126
7.69	CMDLNTEXT system variable	127
7.69.1	Prompt prefix	127



Contents

7.70	CMDNAMES system variable	127
7.70.1	Active Command Name (Read Only)	127
7.71	CMLEADERSTYLE system variable	127
7.71.1	Multileader style	127
7.72	CMLJUST system variable	127
7.72.1	Multiline justification	127
7.73	CMLSCALE system variable	128
7.73.1	Multiline scale	128
7.74	CMLSTYLE system variable	128
7.74.1	Multiline style	128
7.75	CMPCLRMISST system variable	128
7.75.1	Color of missing entities - DWGCOMPARE	128
7.76	CMPCLRMOD1 system variable	129
7.76.1	Color of modified entities- DWGCOMPARE	129
7.77	CMPCLRMOD2 system variable	129
7.77.1	Color of modified entities in the second drawing- DWGCOMPARE	129
7.78	CMPCLRNEW system variable	129
7.78.1	Color of new entities in - DWGCOMPARE	129
7.79	CMPDIFFLIMIT system variable	130
7.79.1	Maximum number of entities - DWGCOMPARE	130
7.80	CMPFADECTL system variable	130
7.80.1	Fade - DWGCOMPARE	130
7.81	CMPLOG system variable	131
7.81.1	Log control - DWGCOMPARE	131
7.82	COLORBOOKPATH system variable	131
7.82.1	Color book file search path	131
7.83	COLORPICKBOX system variable	131
7.83.1	Pickbox color	131
7.84	COLORTHEME system variable	132
7.84.1	UI color theme	132
7.85	COLORX system variable	132
7.85.1	X axis color	132
7.86	COLORY system variable	132
7.86.1	Y axis color	132
7.87	COLORZ system variable	133
7.87.1	Z axis color	133
7.88	COMACADCOMPATIBILITY system variable	133
7.88.1	COM Acad compatibility	133
7.89	COMBINETEXTMODE system variable	133
7.89.1	Combined text mode	133
7.90	COMMANDASSIST system variable	134
7.90.1	AI Assist command line	134
7.91	COMMUNICATORBACKGROUNDMODE system variable	134
7.91.1	Perform import and export in background	134
7.92	COMMUNICATORPATH system variable	135
7.92.1	Communicator path (Mac & Linux)	135
7.93	COMPASS system variable	135
7.93.1	Compass	135



Contents

7.94	COMPONENTSCONFIG system variable	135
7.94.1	Library Panel Configuration	135
7.95	COMPONENTSPATH system variable	136
7.95.1	Library directory path	136
7.96	CONSTRAINTBARDISPLAY system variable	136
7.96.1	Constraint Display	136
7.97	CONTINUOUSMOTION system variable	136
7.97.1	Continuous motion	136
7.98	CONVERTODMAX system variable	137
7.98.1	Maximal multiplier for an outer diameter	137
7.99	CONVERTODMIN system variable	137
7.99.1	Minimal multiplier for an outer diameter	137
7.100	CONVERTTHMAX system variable	137
7.100.1	Maximal multiplier for a thickness	137
7.101	CONVERTTHMIN system variable	137
7.101.1	Minimal multiplier for a thickness	137
7.102	COORDS system variable	138
7.102.1	Coordinates	138
7.103	COPYGUIDED3DDISPLAYSOURCEFACES system variable	138
7.103.1	COPYGUIDED3D source faces	138
7.104	COPYMODE system variable	139
7.104.1	Copy mode	139
7.105	CPLOTSTYLE system variable	139
7.105.1	Current plot style	139
7.106	CPROFILE system variable	139
7.106.1	Current profile (Read Only)	139
7.107	CRASHREPORTSENDING system variable	140
7.107.1	Crash report sending (Windows)	140
7.108	CREATESKETCHFEATURE system variable	140
7.108.1	Sketch based feature (experimental)	140
7.109	CREATETHUMBNAilonTHEFLY system variable	141
7.109.1	Create preview thumbnail on the fly	141
7.110	CREATEVIEWPORTS system variable	141
7.110.1	Automatic viewport creation	141
7.111	CROSSHAIRDRAWMODE system variable	142
7.111.1	Crosshair rendering mode	142
7.112	CROSSINGAREACOLOR system variable	142
7.112.1	Crossing area color	142
7.113	CTAB system variable	143
7.113.1	Current tab	143
7.114	CTABLESTYLE system variable	143
7.114.1	Current table style	143
7.115	CTRL3DMOUSE system variable	143
7.115.1	3D mouse mode	143
7.116	CTRLMBUTTON system variable	144
7.116.1	Middle Button Click	144
7.117	CTRLMOUSE system variable	144
7.117.1	Mouse shortcuts	144



Contents

7.118	CURSORMODE system variable	145
7.118.1	Crosshair displaying mode	145
7.119	CURSORSIZE system variable	145
7.119.1	Crosshair size	145
7.120	CVALLOWBREAKLINECROSSINGS system variable	145
7.120.1	Allow breakline crossings	145
7.121	CVANGLESAMPLINGINTERVAL system variable	146
7.121.1	Angle sampling interval	146
7.122	CVARCTESSELLATIONGRADING system variable	146
7.122.1	Arc approximation mid-ordinate distance	146
7.123	CVARCTESSELLATIONSURFACE system variable	146
7.123.1	Arc approximation mid-ordinate distance	146
7.124	CVARCTESSELLATIONTEMPLATEELEMENT system variable	147
7.124.1	Template Element arc approximation mid-ordinate distance	147
7.125	CVASSOCIATIVITY system variable	147
7.125.1	Associativity	147
7.126	CVDEFAULTCURVETYPEHA system variable	147
7.126.1	Default curve type for horizontal alignment	147
7.127	CVDEFAULTCURVETYPEVA system variable	148
7.127.1	Default curve type for vertical alignments	148
7.128	CVELEVATIONATBREAKLINECROSSINGS system variable	148
7.128.1	Elevation at breakline crossings	148
7.129	CVERSIONCONTROLPATH system variable	149
7.129.1	Current version control path	149
7.130	CVGRADEUNIT system variable	149
7.130.1	Format	149
7.131	CVGRADEUNITPREC system variable	149
7.131.1	Precision	149
7.132	CVLENGTHSAMPLINGINTERVAL system variable	150
7.132.1	Sampling interval for straight segments	150
7.133	CVPORT system variable	150
7.133.1	Current viewport	150
7.134	CVSLOPEUNIT system variable	151
7.134.1	Format	151
7.135	CVSLOPEUNITPREC system variable	151
7.135.1	Precision	151
7.136	CVSTATIONUNIT system variable	152
7.136.1	Station delimiter position	152
7.137	CVSTATIONUNITPREC system variable	152
7.137.1	Precision	152
8.	D	154
8.1	DATACOLLECTION system variable	154
8.1.1	Diagnostics and usage data collection	154
8.2	DATACOLLECTIONENABLED system variable	154
8.2.1	Current state of data collection (Read Only)	154
8.3	DATACOLLECTIONLOGINTYPE system variable	155
8.3.1	Latest type of login for data collection (Read Only)	155
8.4	DATACOLLECTIONOPTIONS system variable	155



Contents

8.4.1	Data Collection Options	155
8.5	DATALINKNOTIFY system variable	156
8.5.1	Data link Notifications	156
8.6	DATE system variable	156
8.6.1	Current date (Read Only)	156
8.7	DBCSTATE system variable	156
8.7.1	DbConnect state (Read Only)	156
8.8	DBLCLKEDIT system variable	157
8.8.1	Double click editing	157
8.9	DBMOD system variable	157
8.9.1	Modification status (Read Only)	157
8.10	DCTCUST system variable	157
8.10.1	Custom spelling dictionary	157
8.11	DCTMAIN system variable	158
8.11.1	Main spelling dictionary	158
8.12	DEFAULTBSYSLIBIMPERIAL system variable	158
8.12.1	Default Bsystlib imperial	158
8.13	DEFAULTBSYSLIBMETRIC system variable	158
8.13.1	Default Bsystlib metric	158
8.14	DEFAULTLIGHTING system variable	159
8.14.1	Default lighting	159
8.15	DEFAULTLIGHTSHADOWBLUR system variable	159
8.15.1	Default light shadow blur	159
8.16	DEFAULTNEWSHEETTEMPLATE system variable	159
8.16.1	Default new sheet template	159
8.17	DEFAULTPLOTTSTYLETABLE system variable	160
8.17.1	Default plot style table	160
8.18	DEFAULTSPACEHEIGHT system variable	160
8.18.1	Default Space Height	160
8.19	DEFAULTSTORYNAMINGSSCHEME system variable	160
8.19.1	Default Story Naming Scheme	160
8.20	DEFAULTSTYLEPIPECROSS system variable	161
8.20.1	Default style for pipe cross	161
8.21	DEFAULTSTYLEPIPEECCENTRICREDUCER system variable	161
8.21.1	Default style for pipe eccentric reducer	161
8.22	DEFAULTSTYLEPIPEELBOW45 system variable	161
8.22.1	Default style for pipe elbow (45 deg)	161
8.23	DEFAULTSTYLEPIPEELBOW90 system variable	161
8.23.1	Default style for pipe elbow (90 deg)	161
8.24	DEFAULTSTYLEPIPEREDUCER system variable	162
8.24.1	Default style for pipe reducer	162
8.25	DEFAULTSTYLEPIPESEGMENT system variable	162
8.25.1	Default style for pipe segment	162
8.26	DEFAULTSTYLEPIPETEE system variable	162
8.26.1	Default style for pipe tee	162
8.27	DEFPLLSTYLE system variable	163
8.27.1	Default layer plot style	163
8.28	DEFPLSTYLE system variable	163



Contents

8.28.1	Default entity plot style	163
8.29	DELETETOOL system variable	163
8.29.1	Delete tool	163
8.30	DELOBJ system variable	164
8.30.1	Delete source entity	164
8.31	DEMANDLOAD system variable	164
8.31.1	Demand load	164
8.32	DETAILSPATH system variable	165
8.32.1	Details directory path	165
8.33	DGNEXPXREFMODE system variable	165
8.33.1	Export Conversion of XRefs	165
8.34	DGNFRAME system variable	166
8.34.1	DGN frame	166
8.35	DGNIMP2DCLOSEDBSPLINECURVEIMPORTMODE system variable	166
8.35.1	2D closed B-spline curve import mode	166
8.36	DGNIMP2DELLIPSEIMPORTMODE system variable	167
8.36.1	2D ellipse import mode	167
8.37	DGNIMP2DSHAPEIMPORTMODE system variable	167
8.37.1	2D shape import mode	167
8.38	DGNIMP3DCLOSEDBSPLINECURVEIMPORTMODE system variable	167
8.38.1	3D closed B-spline curve import mode	167
8.39	DGNIMP3DELLIPSEIMPORTMODE system variable	168
8.39.1	3D ellipse import mode	168
8.40	DGNIMP3DOBJECTIMPORTMODE system variable	168
8.40.1	3D entity import mode	168
8.41	DGNIMP3DSHAPEIMPORTMODE system variable	169
8.41.1	3D shape import mode	169
8.42	DGNIMPBREAKDIMENSIONASSOCIATION system variable	169
8.42.1	Break dimension association	169
8.43	DGNIMP CONVERTDGNCOLORINDICESTOTRUECOLORS system variable	170
8.43.1	Convert DGN color indices to true colors	170
8.44	DGNIMP CONVERTEMPTYDATAFIELDSTOSPACES system variable	170
8.44.1	Convert empty data fields to spaces	170
8.45	DGNIMPERASEUNUSEDRESOURCES system variable	171
8.45.1	Erase unused resources	171
8.46	DGNIMPEXPLODETEXTNODES system variable	171
8.46.1	Explode text nodes	171
8.47	DGNIMP IMPORTACTIVEMODELTOMODELSPACE system variable	171
8.47.1	Import active model to Model Space	171
8.48	DGNIMP IMPORTDGTEXTSASDBMTEXTS system variable	172
8.48.1	Import Texts as MTexts	172
8.49	DGNIMP IMPORTINVISIBLEELEMENTS system variable	172
8.49.1	Import invisible elements	172
8.50	DGNIMP IMPORTPAPERSPACEMODELS system variable	173
8.50.1	Import Paper Space models	173
8.51	DGNIMP IMPORTVIEWINDEX system variable	173
8.51.1	Import view index	173
8.52	DGNIMP RECOMPUTEDIMENSIONS AFTERR IMPORT system variable	173



Contents

8.52.1	Recompute dimensions after import	173
8.53	DGNIMPSYMBOLRESOURCEFILES system variable	174
8.53.1	Symbol resource files	174
8.54	DGNIMPXREFIMPORTMODE system variable	174
8.54.1	External references import mode	174
8.55	DGNOSNAP system variable	175
8.55.1	DGN entity snap	175
8.56	DIASTAT system variable	175
8.56.1	Dialog state (Read Only)	175
8.57	DIMADEC system variable	175
8.57.1	Dim Angle Precision	175
8.58	DIMALT system variable	176
8.58.1	Alt units	176
8.59	DIMALTD system variable	176
8.59.1	Alt precision	176
8.60	DIMALTF system variable	176
8.60.1	Alt multiplier	176
8.61	DIMALTRND system variable	177
8.61.1	Alt roundoff	177
8.62	DIMALTTD system variable	177
8.62.1	Alt tolerance precision	177
8.63	DIMALTTZ system variable	177
8.63.1	Alt tolerance suppress zeros	177
8.64	DIMALTU system variable	178
8.64.1	Alt unit type	178
8.65	DIMALTZ system variable	178
8.65.1	Alt suppress zeros	178
8.66	DIMANNO system variable	179
8.66.1	Style is annotative (Read Only)	179
8.67	DIMAPOST system variable	179
8.67.1	Alt units prefix/suffix	179
8.68	DIMARCSYM system variable	179
8.68.1	Arc symbol	179
8.69	DIMASO system variable	180
8.69.1	Associativity (obsolete)	180
8.70	DIMASSOC system variable	180
8.70.1	Associativity	180
8.71	DIMASZ system variable	180
8.71.1	Arrow size	180
8.72	DIMATFIT system variable	181
8.72.1	Arrow and text fit	181
8.73	DIMAUNIT system variable	181
8.73.1	Dim angle units	181
8.74	DIMAZIN system variable	182
8.74.1	Suppress angle zeros	182
8.75	DIMBLK system variable	182
8.75.1	Arrow	182
8.76	DIMBLK1 system variable	182



Contents

8.76.1	Arrow 1	182
8.77	DIMBLK2 system variable	183
8.77.1	Arrow 2	183
8.78	DIMCEN system variable	183
8.78.1	Center mark	183
8.79	DIMCLRD system variable	183
8.79.1	Dim line color	183
8.80	DIMCLRE system variable	184
8.80.1	Ext line color	184
8.81	DIMCLRT system variable	184
8.81.1	Text color	184
8.82	DIMCONTINUEMODE system variable	185
8.82.1	Dim continue mode	185
8.83	DIMDEC system variable	185
8.83.1	Dim precision	185
8.84	DIMDLE system variable	185
8.84.1	Dim line ext	185
8.85	DIMDLI system variable	186
8.85.1	Dim baseline spacing	186
8.86	DIMDSEP system variable	186
8.86.1	Decimal separator	186
8.87	DIMEXE system variable	186
8.87.1	Ext line ext	186
8.88	DIMEXO system variable	187
8.88.1	Ext line offset	187
8.89	DIMFIT system variable	187
8.89.1	Dim fit (obsolete)	187
8.90	DIMFRAC system variable	187
8.90.1	Fractional type	187
8.91	DIMFXL system variable	188
8.91.1	Ext line fixed length	188
8.92	DIMFXLON system variable	188
8.92.1	Ext line fixed	188
8.93	DIMGAP system variable	188
8.93.1	Text offset	188
8.94	DIMJOGANG system variable	189
8.94.1	Jogged angle	189
8.95	DIMJUST system variable	189
8.95.1	Text Position Horizontal	189
8.96	DIMLAYER system variable	190
8.96.1	Default layer for new dimensions	190
8.97	DIMLDRBLK system variable	190
8.97.1	Leader arrow	190
8.98	DIMLFAC system variable	190
8.98.1	Dim Scale Linear	190
8.99	DIMLIM system variable	190
8.99.1	Tolerance method	190
8.100	DIMTEX1 system variable	191



Contents

8.100.1	Ext line 1 linetype	191
8.101	DIMLTEX2 system variable	191
8.101.1	Ext line 2 linetype	191
8.102	DIMLTYPE system variable	191
8.102.1	Dim line linetype	191
8.103	DIMLUNIT system variable	191
8.103.1	Dim units	191
8.104	DIMLWD system variable	192
8.104.1	Dim line LW	192
8.105	DIMLWE system variable	192
8.105.1	Ext line LW	192
8.106	DIMMARKTYPE system variable	193
8.106.1	Dimension override marking	193
8.107	DIMPOST system variable	193
8.107.1	Dim prefix/suffix	193
8.108	DIMRND system variable	194
8.108.1	Dim round	194
8.109	DIMSAH system variable	194
8.109.1	Arrowheads	194
8.110	DIMSCALE system variable	194
8.110.1	Dim scale overall	194
8.111	DIMSD1 system variable	195
8.111.1	Dim line 1	195
8.112	DIMSD2 system variable	195
8.112.1	Dim line 2	195
8.113	DIMSE1 system variable	195
8.113.1	Ext line 1	195
8.114	DIMSE2 system variable	196
8.114.1	Ext line 2	196
8.115	DIMSHO system variable	196
8.115.1	Dimension show (Obsolete)	196
8.116	DIMSOXD system variable	196
8.116.1	Dim line inside	196
8.117	DIMSTYLE system variable	197
8.117.1	Dimension style (Read Only)	197
8.118	DIMTAD system variable	197
8.118.1	Text Position Vert	197
8.119	DIMTDEC system variable	198
8.119.1	Tolerance precision	198
8.120	DIMTFAC system variable	198
8.120.1	Tolerance text height	198
8.121	DIMTFILL system variable	198
8.121.1	Text fill	198
8.122	DIMTFILLCLR system variable	199
8.122.1	Text fill color	199
8.123	DIMTIH system variable	199
8.123.1	Text inside align	199
8.124	DIMTIX system variable	199



Contents

8.124.1	Text inside	199
8.125	DIMTM system variable	200
8.125.1	Tolerance limit lower	200
8.126	DIMTMOVE system variable	200
8.126.1	Text movement	200
8.127	DIMTOFL system variable	201
8.127.1	Dim line forced	201
8.128	DIMTOH system variable	201
8.128.1	Text outside align	201
8.129	DIMTOL system variable	201
8.129.1	Tolerance display	201
8.130	DIMTOLJ system variable	202
8.130.1	Tolerance pos vert	202
8.131	DIMTP system variable	202
8.131.1	Tolerance limit upper	202
8.132	DIMTSZ system variable	202
8.132.1	Dim tick size	202
8.133	DIMTVP system variable	203
8.133.1	Text offset vertical	203
8.134	DIMTXSTY system variable	203
8.134.1	Text style	203
8.135	DIMTXT system variable	203
8.135.1	Text height	203
8.136	DIMXTDIRECTION system variable	204
8.136.1	Text direction	204
8.137	DIMTZIN system variable	204
8.137.1	Tolerance suppress zeros	204
8.138	DIMUNIT system variable	204
8.138.1	Dim unit type (obsolete)	204
8.139	DIMUPT system variable	205
8.139.1	Place text manually	205
8.140	DIMZIN system variable	205
8.140.1	Suppress dim zeros	205
8.141	DISPLAYAXES system variable	206
8.141.1	Display Axes	206
8.142	DISPLAYAXESFORMEP system variable	206
8.142.1	Display axes	206
8.143	DISPLAYSCALING system variable	206
8.143.1	Automatic display scaling (Read Only)	206
8.144	DISPLAYSIDESANDENDS system variable	207
8.144.1	Display Sides and Ends	207
8.145	DISPLAYSNAPMARKERINALLVIEWS system variable	207
8.145.1	Snap marker in all views	207
8.146	DISPLAYTOOLTIPS system variable	208
8.146.1	Snap tooltips	208
8.147	DISPLAYTRUEDIMENSION system variable	208
8.147.1	Default dimension type	208
8.148	DISPPAPERBKG system variable	208



Contents

8.148.1	Paper background	208
8.149	DISPPAPERMARGINS system variable	209
8.149.1	Printable area	209
8.150	DISPSILH system variable	209
8.150.1	Display silhouette curves	209
8.151	DISTANCE system variable	210
8.151.1	Distance (Read Only)	210
8.152	DMAUDITLEVEL system variable	210
8.152.1	DMAUDIT command, level of detail	210
8.153	DMAUTOUPDATE system variable	211
8.153.1	3D constraints recalculation mode	211
8.154	DMCONNECTIONCUTTYPE system variable	212
8.154.1	Connection type	212
8.155	DMPUSHPULLSUBTRACT system variable	212
8.155.1	DMPUSHPULL subtract	212
8.156	DMRECOGNIZE system variable	213
8.156.1	Automatic 3D geometry constraints recognition	213
8.157	DOCKPRIORITY system variable	213
8.157.1	Docking Priority	213
8.158	DOCTABPOSITION system variable	214
8.158.1	Tabs position	214
8.159	DONUTID system variable	214
8.159.1	Donut inside diameter	214
8.160	DONUTOD system variable	215
8.160.1	Donut outside diameter	215
8.161	DRAGMODE system variable	215
8.161.1	Entity drag mode	215
8.162	DRAGMODECONSTRAINTS system variable	215
8.162.1	Solve 3D constraints dynamically	215
8.163	DRAGMODEFACES system variable	216
8.163.1	MOVE face	216
8.164	DRAGMODEHIDE system variable	216
8.164.1	Hide during drag	216
8.165	DRAGMODEINTERRUPT system variable	217
8.165.1	Drag interruption mode	217
8.166	DRAGOPEN system variable	217
8.166.1	Drag open	217
8.167	DRAGP1 system variable	217
8.167.1	Regen-drag rate	217
8.168	DRAGP2 system variable	218
8.168.1	Fast-drag rate	218
8.169	DRAGSNAP system variable	218
8.169.1	Snap dragged entities	218
8.170	DRAWINGPATH system variable	219
8.170.1	Drawings path	219
8.171	DRAWINGVIEWASM system variable	219
8.171.1	Assemblies optimization	219
8.172	DRAWINGVIEWENTS system variable	219



Contents

8.172.1	Additional entities	219
8.173	DRAWINGVIEWFLAGS system variable	220
8.173.1	Drawing View Flags	220
8.174	DRAWINGVIEWPRESET system variable	220
8.174.1	Drawing view preset	220
8.175	DRAWINGVIEWPRESETHIDDEN system variable	221
8.175.1	Drawing view hidden lines preset	221
8.176	DRAWINGVIEWPRESETSCALE system variable	221
8.176.1	Scale for drawing view preset	221
8.177	DRAWINGVIEWPRESETTANGENT system variable	221
8.177.1	Drawing view tangent lines preset	221
8.178	DRAWINGVIEWPRESETTRAILING system variable	222
8.178.1	Drawing view trailing lines preset	222
8.179	DRAWINGVIEWQUALITY system variable	222
8.179.1	Quality of drawing views	222
8.180	DRAWORDERCTL system variable	222
8.180.1	Draworder control	222
8.181	DWFFORMAT system variable	223
8.181.1	Default DWF format	223
8.182	DWFFRAME system variable	223
8.182.1	DWF frame	223
8.183	DWFOSNAP system variable	224
8.183.1	DWF entity snap	224
8.184	DWFVERSION system variable	224
8.184.1	DWF version	224
8.185	DWGCHECK system variable	225
8.185.1	Drawing check	225
8.186	DWGCODEPAGE system variable	225
8.186.1	Drawing codepage (Read Only)	225
8.187	DWGGUIDCLOUDAI system variable	226
8.187.1	Drawing Guid	226
8.188	DWGNNAME system variable	226
8.188.1	Drawing name (Read Only)	226
8.189	DWGPREFIX system variable	226
8.189.1	Drawing prefix (Read Only)	226
8.190	DWGTITLED system variable	226
8.190.1	Drawing titled (Read Only)	226
8.191	DXEVAL system variable	227
8.191.1	Data extraction update mode	227
8.192	DXFTEXTADJUSTALIGNMENT system variable	227
8.192.1	DXF text adjust alignment	227
8.193	DYNCONSTRAINTMODE system variable	228
8.193.1	Dynamic Constraint Mode	228
8.194	DYNDIGRIP system variable	228
8.194.1	Show dynamic dimensions	228
8.195	DYNDIMAPERTURE system variable	228
8.195.1	Dynamic dimension aperture	228
8.196	DYNDIMCOLORHOT system variable	229



Contents

8.196.1	Dynamic dimension hot color	229
8.197	DYNDIMCOLORHOVER system variable	229
8.197.1	Dynamic dimension hover color	229
8.198	DYNDIMDISTANCE system variable	230
8.198.1	Dynamic dimension distance	230
8.199	DYNDIMLINETYPE system variable	230
8.199.1	Dynamic dimension linetype	230
8.200	DYNDIVIS system variable	231
8.200.1	Dynamic dimension visibility	231
8.201	DYNINPUTTRANSPARENCY system variable	231
8.201.1	Transparency of dynamic input fields	231
8.202	DYNMODE system variable	232
8.202.1	Dynamic input mode	232
8.203	DYNPICOORDS system variable	232
8.203.1	Default mode for dynamic coordinates input	232
9.	E	233
9.1	EDGEMODE system variable	233
9.1.1	Edge mode	233
9.2	ELEVATION system variable	233
9.2.1	Elevation	233
9.3	ENABLEATTRACTION system variable	234
9.3.1	Grips attraction	234
9.4	ENABLEBIMBKUPDATE system variable	234
9.4.1	Enable section update in background	234
9.5	ENABLEHYPERLINKMENU system variable	234
9.5.1	Hyperlink menu	234
9.6	ENABLEHYPERLINKTOOLTIP system variable	235
9.6.1	Hyperlink tooltip	235
9.7	ERRNO system variable	235
9.7.1	Error number (Read Only)	235
9.8	EXPERIMENTALMODE system variable	235
9.8.1	Enable experimental features	235
9.9	EXPERIMENTALONSTARTPAGE system variable	236
9.9.1	Experimental features on start page	236
9.10	EXPERT system variable	236
9.10.1	Expert	236
9.11	EXPINSALIGN system variable	237
9.11.1	Explorer Insert Aligned	237
9.12	EXPINSANGLE system variable	237
9.12.1	Explorer Insert Angle	237
9.13	EXPINSFIXANGLE system variable	237
9.13.1	Explorer Insert Fix Angle	237
9.14	EXPINSFIXSCALE system variable	238
9.14.1	Explorer Insert Fix Scale	238
9.15	EXPINSSCALE system variable	238
9.15.1	Explorer Insert Scale	238
9.16	EXPLMODE system variable	238
9.16.1	Explode mode	238



Contents

9.17	EXPORT3DPDFWRITER system variable	239
9.17.1	3D PDF writer	239
9.18	EXPORTACISASSEMBLYWRITER system variable	239
9.18.1	ASAT/ASAB writer	239
9.19	EXPORTACISFORMATVERSION system variable	240
9.19.1	ACIS export format version	240
9.20	EXPORTCATIAV4FORMATVERSION system variable	240
9.20.1	CATIA V4 export format version	240
9.21	EXPORTCATIAV5FORMATVERSION system variable	241
9.21.1	CATIA V5 export format version	241
9.22	EXPORTGEOMETRYFLAGS system variable	242
9.22.1	Export Geometry Flags	242
9.23	EXPORTHIDDENPARTS system variable	242
9.23.1	Hidden parts	242
9.24	EXPORTMODELSPACE system variable	243
9.24.1	Export model space	243
9.25	EXPORTPAGESETUP system variable	243
9.25.1	Export page setup	243
9.26	EXPORTPAPERSPACE system variable	244
9.26.1	Export paper space	244
9.27	EXPORTPARASOLIDFORMATVERSION system variable	244
9.27.1	Parasolid export format version	244
9.28	EXPORTPRODUCTSTRUCTURE system variable	245
9.28.1	Product structure	245
9.29	EXPORTSTEPFORMATVERSION system variable	246
9.29.1	STEP export format version	246
9.30	EXPORTXCGMFORMATVERSION system variable	246
9.30.1	XCGM export format version	246
9.31	EXTMAX system variable	247
9.31.1	Extents maximum (Read Only)	247
9.32	EXTMIN system variable	247
9.32.1	Extents minimum (Read Only)	247
9.33	EXTNAMES system variable	248
9.33.1	Extend names	248
9.34	EXTRUDEINSIDE system variable	248
9.34.1	Extrude behavior inside	248
9.35	EXTRUDEOUTSIDE system variable	249
9.35.1	Extrude behavior outside	249
10.	F	250
10.1	FACTRATIO system variable	250
10.1.1	Faceting aspect ratio	250
10.2	FACETRES system variable	250
10.2.1	Facet resolution	250
10.3	FBXEXPORTCAMERAS system variable	250
10.3.1	FBX Export Cameras	250
10.4	FBXEXPORTENTITIES system variable	251
10.4.1	FBX Export Entities	251
10.5	FBXEXPORTENTITIESSELTYPE system variable	251



Contents

10.5.1	FBX entities to export	251
10.6	FBXEXPORTLIGHTS system variable	252
10.6.1	FBX Export Lights	252
10.7	FBXEXPORTMATERIALS system variable	252
10.7.1	FBX Export Materials	252
10.8	FBXEXPORTTEXTURES system variable	252
10.8.1	FBX Export Textures	252
10.9	FBXEXPORTTEXTURESPATH system variable	253
10.9.1	Fbx Export Textures path	253
10.10	FEATURECOLORS system variable	253
10.10.1	Feature colors	253
10.11	FIELDDISPLAY system variable	253
10.11.1	Field display	253
10.12	FIELDEVAL system variable	254
10.12.1	Field update mode	254
10.13	FILEDIA system variable	254
10.13.1	File dialog	254
10.14	FILLETRAD system variable	255
10.14.1	Fillet radius	255
10.15	FILLETWELDINGCOMBINEADJACENT system variable	255
10.15.1	Combine adjacent fillet welds	255
10.16	FILLETWELDINGMAXGAPRATIO system variable	255
10.16.1	Maximal ratio of a gap to a weld size	255
10.17	FILLETWELDINGZSIZE system variable	256
10.17.1	Default fillet weld Z size	256
10.18	FILLMODE system variable	256
10.18.1	Fill mode	256
10.19	FITLINEFITARCMODE system variable	256
10.19.1	FitLine FitArc mode	256
10.20	FITTINGRADIUSTYPE system variable	257
10.20.1	Fitting Radius Type	257
10.21	FITTINGRADIUSVALUE system variable	257
10.21.1	Fitting Radius Value	257
10.22	FLANGEASMDEFAULTGASKET system variable	258
10.22.1	Default gasket	258
10.23	FONTALT system variable	258
10.23.1	Alternate font	258
10.24	FONTMAP system variable	258
10.24.1	Font mapping file	258
10.25	FRAME system variable	258
10.25.1	Frame	258
10.26	FRAMESELECTION system variable	259
10.26.1	Frame selection	259
10.27	FRONTZ system variable	259
10.27.1	Front clipping plane offset	259
10.28	FULLOPEN system variable	260
10.28.1	Full open (Read Only)	260



Contents

11.	G	261
11.1	GEARTEETHNUMBER system variable	261
11.1.1	Maximum number of sprocket teeth	261
11.2	GENERATEASSOCATTRS system variable	261
11.2.1	Generate associative attributes	261
11.3	GENERATEASSOCVIEWS system variable	261
11.3.1	Generate associative drawings	261
11.4	GEOCSMAPPRIORITY system variable	262
11.4.1	CSMAP priority	262
11.5	GEOLATLONGFORMAT system variable	262
11.5.1	Geographic latitude/longitude format	262
11.6	GEOMARKERVISIBILITY system variable	263
11.6.1	Geographic marker visibility	263
11.7	GEOMRELATIONS system variable	263
11.7.1	Geometric relationship indication	263
11.8	GETSTARTED system variable	263
11.8.1	Get Started	263
11.9	GFANG system variable	264
11.9.1	Gradient fill angle	264
11.10	GFCLR1 system variable	264
11.10.1	Gradient fill primary color	264
11.11	GFCLR2 system variable	264
11.11.1	Gradient fill secondary color	264
11.12	GFCLRLUM system variable	265
11.12.1	Gradient fill tint level	265
11.13	GFCLRSTATE system variable	265
11.13.1	Number of colors for a gradient fill	265
11.14	GFNAME system variable	265
11.14.1	Gradient fill name	265
11.15	GFSHIFT system variable	266
11.15.1	Gradient fill shift	266
11.16	GLSWAPMODE system variable	266
11.16.1	GL Swap Mode	266
11.17	GRADIENTCOLORBOTTOM system variable	267
11.17.1	Background gradient color bottom	267
11.18	GRADIENTCOLORMIDDLE system variable	267
11.18.1	Background gradient color middle	267
11.19	GRADIENTCOLORTOP system variable	267
11.19.1	Background gradient color top	267
11.20	GRADIENTMODE system variable	268
11.20.1	Background gradient mode	268
11.21	GRIDAXISCOLOR system variable	268
11.21.1	Grid axis color	268
11.22	GRIDDISPLAY system variable	269
11.22.1	Grid display	269
11.23	GRIDMAJOR system variable	269
11.23.1	Grid major	269
11.24	GRIDMAJORCOLOR system variable	269



Contents

11.24.1	Grid major color	269
11.25	GRIDMINORCOLOR system variable	270
11.25.1	Grid minor color	270
11.26	GRIDMODE system variable	270
11.26.1	Grid mode	270
11.27	GRIDSTYLE system variable	270
11.27.1	Grid style	270
11.28	GRIDUNIT system variable	271
11.28.1	Grid unit	271
11.29	GRIDXYZTINT system variable	271
11.29.1	Grid XYZ tint	271
11.30	GRIPBLOCK system variable	272
11.30.1	Grips in blocks	272
11.31	GRIPCOLOR system variable	272
11.31.1	Grip color	272
11.32	GRIPDYNCOLOR system variable	272
11.32.1	Dynamic grip color	272
11.33	GRIPHOT system variable	273
11.33.1	Selected grip color	273
11.34	GRIPHOVER system variable	273
11.34.1	Hover grip color	273
11.35	GRIPOBJLIMIT system variable	273
11.35.1	Grip entity limit	273
11.36	GRIPS system variable	274
11.36.1	Grips	274
11.37	GRIPSIZE system variable	274
11.37.1	Grip size	274
11.38	GRIPTIPS system variable	274
11.38.1	Grip tips	274
11.39	GSDEVICETYPE2D system variable	275
11.39.1	2D graphic system device	275
11.40	GSDEVICETYPE3D system variable	275
11.40.1	3D graphic system device	275
12.	H	277
12.1	HALOGAP system variable	277
12.1.1	Halo gap	277
12.2	HANDLES system variable	277
12.2.1	Publish Handles (Read Only)	277
12.3	HANDSEED system variable	277
12.3.1	Handle seed (Read Only)	277
12.4	HEALTHADVISOR system variable	278
12.4.1	Health Advisor	278
12.5	HIDEPRECISION system variable	278
12.5.1	Hide and shade precision	278
12.6	HIDESYSTEMPRINTERS system variable	278
12.6.1	Hide system printers	278
12.7	HIDETEXT system variable	279
12.7.1	Hide text on HIDE	279



Contents

12.8	HIDEINDEXREFSCALES system variable	279
12.8.1	Hide xref scales	279
12.9	HIGHLIGHT system variable	279
12.9.1	Highlight	279
12.10	HIGHLIGHT_ALPHA system variable	280
12.10.1	Highlighted area transparency	280
12.11	HIGHLIGHTCOLOR system variable	280
12.11.1	Selection Highlight Color	280
12.12	HIGHLIGHTEFFECT system variable	280
12.12.1	Selection Highlight Style	280
12.13	HORIZONBKG_ENABLE system variable	281
12.13.1	Horizon background	281
12.14	HORIZONBKG_GROUNDHORIZON system variable	281
12.14.1	Ground horizon	281
12.15	HORIZONBKG_GROUNDOORIGIN system variable	282
12.15.1	Ground origin	282
12.16	HORIZONBKG_SKYHIGH system variable	282
12.16.1	Sky high	282
12.17	HORIZONBKG_SKYHORIZON system variable	282
12.17.1	Sky horizon	282
12.18	HORIZONBKG_SKYLOW system variable	282
12.18.1	Sky low	282
12.19	HOTKEYASSISTANT system variable	283
12.19.1	Hotkey Assistant	283
12.20	HPANG system variable	283
12.20.1	Hatch pattern angle	283
12.21	HPANNOTATIVE system variable	283
12.21.1	Hatch pattern annotative	283
12.22	HPASSOC system variable	284
12.22.1	Hatch pattern associativity	284
12.23	HPBACKGROUNDCOLOR system variable	284
12.23.1	Hatch background default color	284
12.24	HPBOUND system variable	284
12.24.1	Hatch pattern boundary	284
12.25	HPBOUNDRETAIN system variable	285
12.25.1	Hatch pattern boundary retain	285
12.26	HPCOLOR system variable	285
12.26.1	Hatch default color	285
12.27	HPDOUBLE system variable	286
12.27.1	Hatch pattern doubling	286
12.28	HPDRAWORDER system variable	286
12.28.1	Hatch pattern draw order	286
12.29	HPGAPTOL system variable	287
12.29.1	Hatch pattern gap tolerance	287
12.30	HPISLANDDETECTION system variable	287
12.30.1	Hatch pattern island detection	287
12.31	HPLAYER system variable	287
12.31.1	Default layer for new hatches	287



Contents

12.32	HPLINETYPE system variable	288
12.32.1	Hatch pattern linetype	288
12.33	HPMAXAREAS system variable	288
12.33.1	Fill mode for sparse hatches	288
12.34	HPMAXCONTOURPOINTS system variable	289
12.34.1	Maximum number of points on a hatch contour	289
12.35	HPNAME system variable	289
12.35.1	Hatch pattern name	289
12.36	HPOBJWARNING system variable	289
12.36.1	Hatch pattern entity warning	289
12.37	HPORIGIN system variable	290
12.37.1	Hatch pattern origin	290
12.38	HPSCALE system variable	290
12.38.1	Hatch pattern scale	290
12.39	HPSEPARATE system variable	290
12.39.1	Hatch pattern separate	290
12.40	HPSPACE system variable	290
12.40.1	Hatch pattern spacing	290
12.41	HPTRANSPARENCY system variable	291
12.41.1	Default transparency for new hatches	291
12.42	HYPERLINKBASE system variable	291
12.42.1	Hyperlink base	291
13.	I	292
13.1	IFCCREATEUNIQUEGUID system variable	292
13.1.1	Export with unique guids	292
13.2	IFCEXplodeExternalReferences system variable	292
13.2.1	Explode external references in IFC spatial structure	292
13.3	IFCEXPORTAUTHOR system variable	292
13.3.1	Export Author Name	292
13.4	IFCEXPORTAUTHORIZATION system variable	293
13.4.1	Export Authorization	293
13.5	IFCEXPORTBASEQUANTITIES system variable	293
13.5.1	Export base quantities	293
13.6	IFCEXPORTELEMENTSONOFFANDFROZENLAYER system variable	293
13.6.1	Export elements on Off and Frozen layers	293
13.7	IFCEXPORTIDSPROPERTIESONLY system variable	294
13.7.1	Export IDS Properties Only	294
13.8	IFCEXPORTMAPPINGPATH system variable	294
13.8.1	Export mapping file path	294
13.9	IFCEXPORTMULTIPLYELEMENTSASAGGREGATED system variable	294
13.9.1	Export multi-ply elements as aggregated elements	294
13.10	IFCEXPORTORGANIZATION system variable	295
13.10.1	Export Organization Name	295
13.11	IFCEXPORTPROFILECENTEROFGRAVITY system variable	295
13.11.1	Export profile center of gravity	295
13.12	IFCEXPORTSUBTRACTOPENINGS system variable	295
13.12.1	Subtracts the openings from the host geometry before export	295
13.13	IFCEXPORTSWEPTSOLIDSBREP system variable	296



Contents

13.13.1	Always export swept solids as BRep	296
13.14	IFCEXPORTTESSELATION system variable	296
13.14.1	Level of tessellation	296
13.15	IFCEXPORTVALIDATEMODEL system variable	297
13.15.1	Apply IFC model validation	297
13.16	IFCIMPORTSETTINGSCONFIG system variable	297
13.16.1	IFC import settings configuration	297
13.17	IFCTESSELEATESPLINECURVESANDSURFACES system variable	297
13.17.1	Tessellate complex curves and surfaces	297
13.18	IMAGECACHEFOLDER system variable	298
13.18.1	Image disk cache folder	298
13.19	IMAGECACHEMAXMEMORY system variable	298
13.19.1	Maximum used memory	298
13.20	IMAGEDISKCACHE system variable	298
13.20.1	Image disk cache	298
13.21	IMAGEFRAME system variable	299
13.21.1	Image frame	299
13.22	IMAGEHLT system variable	299
13.22.1	Image highlight	299
13.23	IMAGENOTIFY system variable	300
13.23.1	Image notify	300
13.24	IMPORTCATIAV5EDGEATTRIBUTES system variable	300
13.24.1	Import edge attributes mode	300
13.25	IMPORTCATIAV5REPRESENTATION system variable	300
13.25.1	Import representation	300
13.26	IMPORTCATIAV5SEARCHPATHSPREFERENCE system variable	301
13.26.1	Search path preference	301
13.27	IMPORTCOLORS system variable	301
13.27.1	Translate colors	301
13.28	IMPORTCREOALTERNATESEARCHPATHS system variable	302
13.28.1	Alternate search paths	302
13.29	IMPORTCREOCONFIGURATION system variable	302
13.29.1	Import configuration	302
13.30	IMPORTCUFILEEXISTS system variable	303
13.30.1	Import cui file exists	303
13.31	IMPORTHIDDENPARTS system variable	303
13.31.1	Hidden parts	303
13.32	IMPORTIGESSIMPLIFY system variable	303
13.32.1	Perform simplification	303
13.33	IMPORTGESSTITCH system variable	304
13.33.1	Perform stitching	304
13.34	IMPORTINVENTORALTERNATESEARCHPATHS system variable	304
13.34.1	Alternate search paths	304
13.35	IMPORTINVENTORSEARCHPATHSPREFERENCE system variable	304
13.35.1	Search paths preference	304
13.36	IMPORTJTREPRESENTATION system variable	305
13.36.1	Import representation	305
13.37	IMPORTNXALTERNATESEARCHPATHS system variable	305



Contents

13.37.1	Alternate search paths	305
13.38	IMPORTNXCONFIGURATION system variable	306
13.38.1	Import configuration	306
13.39	IMPORTNXSEARCHPATHSPREFERENCE system variable	306
13.39.1	Search paths preference	306
13.40	IMPORTPMI system variable	307
13.40.1	Product and manufacturing information	307
13.41	IMPORTPRODUCTSTRUCTURE system variable	307
13.41.1	Product structure	307
13.42	IMPORTREPAIR system variable	308
13.42.1	Repair model on import	308
13.43	IMPORTSIMPLIFY system variable	308
13.43.1	Perform simplification	308
13.44	IMPORTSOLIDEDGEALTERNATESEARCHPATHS system variable	308
13.44.1	Alternate search paths	308
13.45	IMPORTSOLIDGESEARCHPATHSPREFERENCE system variable	309
13.45.1	Search paths preference	309
13.46	IMPORTSOLIDWORKSALTERNATESEARCHPATHS system variable	309
13.46.1	Alternate search paths	309
13.47	IMPORTSOLIDWORKSCONFIGURATION system variable	310
13.47.1	Import configuration	310
13.48	IMPORTSOLIDWORKSREPRESENTATION system variable	310
13.48.1	Import representation	310
13.49	IMPORTSOLIDWORKSROTATEYZ system variable	310
13.49.1	Map SolidWorks Y to current Z axis	310
13.50	IMPORTSOLIDWORKSSEARCHPATHSPREFERENCE system variable	311
13.50.1	Search paths preference	311
13.51	IMPORTSTEPROTATEYZ system variable	311
13.51.1	Map Y to current Z axis	311
13.52	IMPORTSTITCH system variable	312
13.52.1	Perform stitching	312
13.53	INCLUDEPLOTPATTERN system variable	312
13.53.1	Include Plot Pattern	312
13.54	INDEXCTL system variable	312
13.54.1	Index control	312
13.55	INETLOCATION system variable	313
13.55.1	Internet location	313
13.56	INSBASE system variable	313
13.56.1	Insertion base point	313
13.57	INSNAME system variable	313
13.57.1	Insertion name	313
13.58	INSUNITS system variable	314
13.58.1	Insertion units	314
13.59	INSUNITSDEF SOURCE system variable	315
13.59.1	Insertion units default source	315
13.60	INSUNITSDEFTARGET system variable	316
13.60.1	Insertion units default target	316
13.61	INSUNITSSCALING system variable	317



Contents

13.61.1	Insertion units scaling	317
13.62	INTERFERECOLOR system variable	318
13.62.1	Interference color	318
13.63	INTERFERELAYER system variable	318
13.63.1	Interference layer	318
13.64	INTERFERENCELEVEL system variable	318
13.64.1	Interference Check Level	318
13.65	INTERFEROBJVS system variable	319
13.65.1	Interference entity visual style	319
13.66	INTERFEREVPPS system variable	319
13.66.1	Interference viewport visual style	319
13.67	INTERIORELEVATIONMINLENGTH system variable	319
13.67.1	Interior Elevation Minimum Length	319
13.68	INTERIORELEVATIONOFFSET system variable	320
13.68.1	Interior Elevation Offset Distance	320
13.69	INTERSECTEDENTITIES system variable	320
13.69.1	Resolve intersection	320
13.70	INTERSECTIONCOLOR system variable	320
13.70.1	Intersection color	320
13.71	INTERSECTIONDISPLAY system variable	321
13.71.1	Intersection display	321
13.72	ISAVEBAK system variable	321
13.72.1	Incremental save backup	321
13.73	ISAVEPERCENT system variable	322
13.73.1	Save percent	322
13.74	ISOLINES system variable	322
13.74.1	Isolines	322
14.	J	324
15.	K	325
15.1	KEEPCONNECTIONS system variable	325
15.1.1	Solve interferences and gaps	325
16.	L	326
16.1	LASTANGLE system variable	326
16.1.1	Last angle (Read Only)	326
16.2	LASTPOINT system variable	326
16.2.1	Last point	326
16.3	LASTPROMPT system variable	326
16.3.1	Last prompt (Read Only)	326
16.4	LATITUDE system variable	326
16.4.1	Latitude	326
16.5	LAYERFILTEREXCESS system variable	327
16.5.1	Layer Filter Excess	327
16.6	LAYERPMODE system variable	327
16.6.1	Layer previous mode	327
16.7	LAYLOCKFADECTL system variable	328
16.7.1	Locked layer fade control	328
16.8	LAYOUTREGENCTL system variable	328
16.8.1	Layout regeneration control	328



Contents

16.9	LAYOUTTAB system variable	328
16.9.1	Layout and model tabs	328
16.10	LEGACYCODESEARCH system variable	329
16.10.1	Legacy code search mode (Read Only)	329
16.11	LENGTHUNITS system variable	329
16.11.1	Length units	329
16.12	LENSLENGTH system variable	329
16.12.1	Lens length (Read Only)	329
16.13	LEVELOFLDETAIL system variable	330
16.13.1	Composition Level of detail	330
16.14	LICFLAGS system variable	330
16.14.1	Licensed components (Read Only)	330
16.15	LIGHTGLYPHCOLOR system variable	331
16.15.1	Color for light glyph	331
16.16	LIGHTGLYPHDISPLAY system variable	331
16.16.1	Light display	331
16.17	LIGHTINGUNITS system variable	331
16.17.1	Lighting units	331
16.18	LIGHTWEBGLYPHCOLOR system variable	332
16.18.1	Color for web light glyph	332
16.19	LIMCHECK system variable	332
16.19.1	Limits check	332
16.20	LIMMAX system variable	333
16.20.1	Limits maximum	333
16.21	LIMMIN system variable	333
16.21.1	Limits minimum	333
16.22	LINEARARROWHEADLENGTH system variable	333
16.22.1	Default head length	333
16.23	LINEARARROWHEADWIDTH system variable	333
16.23.1	Default head width	333
16.24	LINEARARROWTHICKNESS system variable	334
16.24.1	Default thickness	334
16.25	LINEARBRIGHTNESS system variable	334
16.25.1	Linear brightness	334
16.26	LINEARCONTRAST system variable	335
16.26.1	Linear contrast	335
16.27	LINETYPE3DPLINE system variable	335
16.27.1	3D Polyline linetype	335
16.28	LISPINIT system variable	335
16.28.1	LISP init	335
16.29	LOADMECHANICAL2D system variable	336
16.29.1	Mechanical 2D Editor	336
16.30	LOCALE system variable	336
16.30.1	Locale (Read Only)	336
16.31	LOCALROOTPREFIX system variable	336
16.31.1	Local root prefix (Read Only)	336
16.32	LOCKUI system variable	337
16.32.1	Lock user interface elements	337



Contents

16.33	LOFTANG1 system variable	337
16.33.1	Loft angle 1	337
16.34	LOFTANG2 system variable	338
16.34.1	Loft angle 2	338
16.35	LOFTMAG1 system variable	339
16.35.1	Loft magnitude 1	339
16.36	LOFTMAG2 system variable	340
16.36.1	Loft magnitude 2	340
16.37	LOFTNORMALS system variable	340
16.37.1	Loft normals	340
16.38	LOFTPARAM system variable	341
16.38.1	Loft param	341
16.39	LOGFILEMODE system variable	341
16.39.1	Log file mode	341
16.40	LOGFILENAME system variable	342
16.40.1	Log file name (Read Only)	342
16.41	LOGFILEPATH system variable	342
16.41.1	Log file path	342
16.42	LOGGEDINSTATUS system variable	342
16.42.1	Logged in (Read Only)	342
16.43	LOGINNAME system variable	342
16.43.1	Login name (Read Only)	342
16.44	LONGITUDE system variable	343
16.44.1	Longitude	343
16.45	LOOKFROMDIRECTIONMODE system variable	343
16.45.1	LookFrom direction mode	343
16.46	LOOKFROMFEEDBACK system variable	344
16.46.1	LookFrom feedback	344
16.47	LOOKFROMZOOMEXTENTS system variable	344
16.47.1	LookFrom zoom extents	344
16.48	LTGAPSELECTION system variable	345
16.48.1	Linetype gap selection	345
16.49	LTSCALE system variable	345
16.49.1	Linetype scale	345
16.50	LUNITS system variable	345
16.50.1	Linear unit type	345
16.51	LUPREC system variable	346
16.51.1	Linear unit precision	346
16.52	LWDEFAULT system variable	346
16.52.1	Default linewidth	346
16.53	LWDISPLAY system variable	347
16.53.1	Lineweight display	347
16.54	LWDISPSCALE system variable	347
16.54.1	Lineweight display scale	347
16.55	LWUNITS system variable	347
16.55.1	Lineweight units	347
17.	M	349
17.1	MACROREC system variable	349



Contents

17.1.1	Macro recording	349
17.2	MANIPULATOR system variable	349
17.2.1	Manipulator	349
17.3	MANIPULATORCOLORTHEME system variable	349
17.3.1	Color theme of Manipulator	349
17.4	MANIPULATORDURATION system variable	350
17.4.1	Manipulator duration	350
17.5	MANIPULATORHANDLE system variable	351
17.5.1	Manipulator handle	351
17.6	MANIPULATORSIZE system variable	351
17.6.1	Size of Manipulator	351
17.7	MASSPREC system variable	352
17.7.1	Mass precision	352
17.8	MASSPROPACCURACY system variable	352
17.8.1	Mass properties calculation relative accuracy	352
17.9	MASSUNITS system variable	353
17.9.1	Mass units	353
17.10	MAXACTVP system variable	353
17.10.1	Maximum active viewports	353
17.11	MAXHATCH system variable	354
17.11.1	Maximum hatch dashes	354
17.12	MAXSORT system variable	354
17.12.1	Maximum sort	354
17.13	MAXTHREADS system variable	354
17.13.1	Maximum number of threads	354
17.14	MBSTATE system variable	355
17.14.1	Mechanical browser state (Read Only)	355
17.15	MBUTTONPAN system variable	355
17.15.1	Middle button pan	355
17.16	MEASUREINIT system variable	356
17.16.1	Measurement initial	356
17.17	MEASUREMENT system variable	356
17.17.1	Measurement	356
17.18	MECH2DSAVEFORMAT system variable	356
17.18.1	Mechanical 2D save format	356
17.19	MECHANICALBLOCKS system variable	357
17.19.1	Mechanical blocks	357
17.20	MECHANICALBLOCKSOPTIONS system variable	357
17.20.1	Mechanical blocks options	357
17.21	MECHANICALBROWSERSETTINGS system variable	358
17.21.1	Mechanical browser options	358
17.22	MENUBAR (EXCEPT OS X) system variable	358
17.22.1	Menu bar	358
17.23	MENUCTL system variable	359
17.23.1	Menu control	359
17.24	MENUCHO system variable	359
17.24.1	Menu echo	359
17.25	MENUNAME system variable	359



Contents

17.25.1	Menu name (Read Only)	359
17.26	MESHTYPE system variable	360
17.26.1	Mesh type	360
17.27	MIDDLECLICKCLOSE system variable	360
17.27.1	Middle click close (Mac & Linux)	360
17.28	MILLISECS system variable	360
17.28.1	Milliseconds (Read Only)	360
17.29	MIRRHATCH system variable	361
17.29.1	Mirror hatch patterns	361
17.30	MIRRTEXT system variable	361
17.30.1	Mirror text	361
17.31	MLEADERSCALE system variable	362
17.31.1	Multileader scale	362
17.32	MODEMACRO system variable	362
17.32.1	Mode macro	362
17.33	MSLTSCALE system variable	362
17.33.1	Model space linetype scale	362
17.34	MSOLESCALE system variable	363
17.34.1	Model space OLE scale	363
17.35	MTEXTCOLUMN system variable	363
17.35.1	Multiline text column setting	363
17.36	MTEXTDETECTSPACE system variable	363
17.36.1	Space detection for creating lists in mtext editor	363
17.37	MTEXTED system variable	364
17.37.1	Multiline text editor	364
17.38	MTEXTFIXED system variable	364
17.38.1	Multiline text fixed	364
17.39	MTEXTTOOLBAR system variable	364
17.39.1	MText Formatting toolbar	364
17.40	MTFLAGS system variable	365
17.40.1	Multi-Threading Flags	365
17.41	MULTISELECTANGULARTOLERANCE system variable	365
17.41.1	BimMultiSelect angular tolerance	365
17.42	MYDOCUMENTSPREFIX system variable	366
17.42.1	MyDocuments root prefix (Read Only)	366
18.	N	367
18.1	NAVVCUBEDIPLAY system variable	367
18.1.1	LookFrom display	367
18.2	NAVVCUBELOCATION system variable	367
18.2.1	LookFrom location	367
18.3	NAVVCUBEOPACITY system variable	368
18.3.1	LookFrom opacity	368
18.4	NAVVCUBEORIENT system variable	368
18.4.1	LookFrom orientation	368
18.5	NEARESTDISTANCE system variable	368
18.5.1	Nearest Distance	368
18.6	NOMUTT system variable	369
18.6.1	No muttering	369



Contents

18.7	NORTHDIRECTION system variable	370
18.7.1	North direction	370
19.	O	371
19.1	OBJECTISOLATIONMODE system variable	371
19.1.1	Object Isolation Mode	371
19.2	OBSCUREDCOLOR system variable	371
19.2.1	Obscured color	371
19.3	OBSCUREDLINETYPE system variable	372
19.3.1	Obscured linetype	372
19.4	OFFSETDIST system variable	372
19.4.1	Offset distance	372
19.5	OFFSETERASE system variable	373
19.5.1	Offset erase	373
19.6	OFFSETGAPTYPE system variable	373
19.6.1	Offset gap type	373
19.7	OLEFRAME system variable	373
19.7.1	OLE frame	373
19.8	OLEHIDE system variable	374
19.8.1	OLE hide	374
19.9	OLEQUALITY system variable	374
19.9.1	OLE quality	374
19.10	OLESTARTUP system variable	375
19.10.1	OLE startup	375
19.11	OPMSTATE system variable	375
19.11.1	Properties bar state (Read Only)	375
19.12	ORBITAUTOTARGET system variable	375
19.12.1	Orbit Auto Target	375
19.13	ORTHOMODE system variable	376
19.13.1	Orthogonal mode	376
19.14	OSMODE system variable	376
19.14.1	Entity snap mode	376
19.15	OSNAPCOORD system variable	377
19.15.1	Entity snap coordinates	377
19.16	OSNAPZ system variable	377
19.16.1	Ignore entity snap elevation	377
19.17	OSOPTIONS system variable	378
19.17.1	Entity snap options	378
19.18	OVERKILLAYER system variable	378
19.18.1	Duplicate Entities Layer	378
20.	P	379
20.1	PANBUFFER system variable	379
20.1.1	Pan buffer	379
20.2	PANELBUTTONSIZE system variable	379
20.2.1	Panel control button size	379
20.3	PAPERUPDATE system variable	380
20.3.1	Paper update	380
20.4	PARAMETERCOPYMODE system variable	380
20.4.1	Parameter copy mode	380



Contents

20.5	PARAMETERMATCHMODE system variable	381
20.5.1	Match Parametric Blocks by parameters	381
20.6	PARAMETRICBLOCKS2DPATH system variable	381
20.6.1	Parametric blocks 2D directory path	381
20.7	PARAMETRIZECONNECTIONS system variable	381
20.7.1	Parametrize Connections	381
20.8	PBLOCKREFERENCEOPERATIONSVISUALIZATION system variable	382
20.8.1	Visualize parametric operations on block references	382
20.9	PDFANIMATIONFPS system variable	382
20.9.1	Frames per second	382
20.10	PDFCACHE system variable	382
20.10.1	PDF cache	382
20.11	PDFCREATEBOOKMARKS system variable	383
20.11.1	Create bookmarks	383
20.12	PDFEMBEDDEDTTF system variable	383
20.12.1	Pdf embedded fonts	383
20.13	PDFEXPORTHYPERLINKS system variable	384
20.13.1	Export hyperlinks	384
20.14	PDFFFRAME system variable	384
20.14.1	PDF frame	384
20.15	PDFIMAGEANTIALIAS system variable	385
20.15.1	Image anti-aliasing	385
20.16	PDFIMAGECOMPRESSION system variable	385
20.16.1	Image compression	385
20.17	PDFIMAGEDPI system variable	385
20.17.1	Image DPI	385
20.18	PDFIMPORTAPPLYLINEWEIGHT system variable	386
20.18.1	Apply linewidth properties	386
20.19	PDFIMPORTASBLOCK system variable	386
20.19.1	Import as block	386
20.20	PDFIMPORTCHARSPACEFACTOR system variable	386
20.20.1	Inter-character space factor	386
20.21	PDFIMPORTCOMBINETEXTOBJECTS system variable	387
20.21.1	Combine text entities	387
20.22	PDFIMPORTCONVERTSOLIDSTOHATCHES system variable	387
20.22.1	Convert solid fills to hatches	387
20.23	PDFIMPORTIMAGEPATH system variable	388
20.23.1	Raster Images Folder	388
20.24	PDFIMPORTJOINLINEANDARCSEGMENTS system variable	388
20.24.1	Join line and arc segments	388
20.25	PDFIMPORTLAYERSTYPE system variable	388
20.25.1	Layers	388
20.26	PDFIMPORTRASTERIMAGES system variable	389
20.26.1	Raster Images	389
20.27	PDFIMPORTSOLIDFILLS system variable	389
20.27.1	Solid fills	389
20.28	PDFIMPORTSPACEFACTOR system variable	390
20.28.1	Inter-word space factor	390



Contents

20.29	PDFIMPORTTRUETYPETEXT system variable	390
20.29.1	TrueType text	390
20.30	PDFIMPORTTRUETYPETEXTASGEOMETRY system variable	390
20.30.1	Import True Type text as geometry	390
20.31	PDFIMPORTUSECLIPPING system variable	391
20.31.1	Apply clipping	391
20.32	PDFIMPORTUSEGEOMETRYOPTIMIZATION system variable	391
20.32.1	Import geometry with optimization	391
20.33	PDFIMPORTUSEIMAGECLIPPING system variable	392
20.33.1	Clip images	392
20.34	PDFIMPORTUSEPAGEBORDERCLIPPING system variable	392
20.34.1	Apply clipping at page border	392
20.35	PDFIMPORTVECTORGEOMETRY system variable	392
20.35.1	Vector geometry	392
20.36	PDFLAYERSSETTING system variable	393
20.36.1	PDF layer support	393
20.37	PDFLAYOUTSTOEXPORT system variable	393
20.37.1	PDF layouts to export	393
20.38	PDFMERGECONTROL system variable	394
20.38.1	PDF Merge Control	394
20.39	PDFNOTIFY system variable	394
20.39.1	PDF notify	394
20.40	PDFOPENINVIEWER system variable	394
20.40.1	Open in viewer	394
20.41	PDFOSNAP system variable	395
20.41.1	PDF entity snap	395
20.42	PDFPAPERHEIGHT system variable	395
20.42.1	PDF override - paper height	395
20.43	PDFPAPERSIZE OVERRIDE system variable	395
20.43.1	PDF papersize override	395
20.44	PDFPAPERWIDTH system variable	396
20.44.1	PDF override - paper width	396
20.45	PDFPDFA system variable	396
20.45.1	PDF/A format support	396
20.46	PDFPRCCOMPRESSION system variable	397
20.46.1	PRC Compression	397
20.47	PDFPRCEXPORT system variable	397
20.47.1	PRC Export Mode	397
20.48	PDFPRCPROJECTION system variable	398
20.48.1	PRC Projection	398
20.49	PDFPRCVIEWMODE system variable	398
20.49.1	PRC View mode	398
20.50	PDFSHXTEXTASGEOMETRY system variable	398
20.50.1	PDF SHX text as geometry	398
20.51	PDFSIMPLEGEOMOPTIMIZATION system variable	399
20.51.1	Pdf simple geometry optimization	399
20.52	PDFTTTEXTASGEOMETRY system variable	399
20.52.1	PDF TTF text as geometry	399



Contents

20.53	PDFUSEPLOTTYPES system variable	400
20.53.1	Use PDF plotstyles	400
20.54	PDFVECTORRESOLUTIONDPI system variable	400
20.54.1	Vector Resolution DPI	400
20.55	PDFZOOMTOEXTENTSMODE system variable	400
20.55.1	PDF zoom to extents mode	400
20.56	PDMODE system variable	401
20.56.1	Point display mode	401
20.57	PDSIZE system variable	402
20.57.1	Point display size	402
20.58	PEDITACCEPT system variable	402
20.58.1	Polyline edit accept	402
20.59	PELLIPSE system variable	403
20.59.1	Polyline ellipse	403
20.60	PERIMETER system variable	403
20.60.1	Last perimeter (Read Only)	403
20.61	PERSPECTIVE system variable	403
20.61.1	Perspective	403
20.62	PFACEVMAX system variable	404
20.62.1	Polyface mesh maximum vertices (Read Only)	404
20.63	PICKADD system variable	404
20.63.1	Pick add	404
20.64	PICKAUTO system variable	404
20.64.1	Selection window behavior	404
20.65	PICKBOX system variable	405
20.65.1	Pick box	405
20.66	PICKDRAG system variable	405
20.66.1	Pick drag	405
20.67	PICKFIRST system variable	406
20.67.1	Pick first	406
20.68	PICKSTYLE (EXCEPT OS X) system variable	406
20.68.1	Pick style	406
20.69	PICTUREEXPORTSCALE system variable	407
20.69.1	Picture format export scale factor	407
20.70	PLACESBARFOLDER1 system variable	407
20.70.1	First folder	407
20.71	PLACESBARFOLDER2 system variable	408
20.71.1	Second folder	408
20.72	PLACESBARFOLDER3 system variable	408
20.72.1	Third folder	408
20.73	PLACESBARFOLDER4 system variable	409
20.73.1	Fourth folder (Windows)	409
20.74	PLATFORM system variable	410
20.74.1	Platform (Read Only)	410
20.75	PLINECACHE system variable	410
20.75.1	Polyline cache	410
20.76	PLINECONVERTMODE system variable	410
20.76.1	Polyline convert mode	410



Contents

20.77	PLINEGEN system variable	411
20.77.1	Polyline generation	411
20.78	PLINETYPE system variable	411
20.78.1	Polyline type	411
20.79	PLINEWID system variable	412
20.79.1	Polyline width	412
20.80	PLOTCFGPATH system variable	412
20.80.1	Plotter configuration path	412
20.81	PLOTID system variable	412
20.81.1	Plot id (Obsolete)	412
20.82	PLOTOUTPUTPATH system variable	413
20.82.1	Plot output path	413
20.83	PLOTSTYLEPATH system variable	413
20.83.1	Plot styles path	413
20.84	PLOTTER system variable	413
20.84.1	Plotter (Obsolete)	413
20.85	PLOTRANSPARENCYOVERRIDE system variable	413
20.85.1	Plot transparency override	413
20.86	PLQUIET system variable	414
20.86.1	Plot quiet	414
20.87	POINTCLOUD2DVSDISPLAY system variable	414
20.87.1	Toggle show/hide bounding box in 2d wireframe mode	414
20.88	POINTCLOUDADAPTIVEDISPLAY system variable	415
20.88.1	Toggle adaptive vs. fixed point sizes	415
20.89	POINTCLOUDBOUNDARY system variable	415
20.89.1	Show/hide point cloud extent boundary	415
20.90	POINTCLOUDCACHEFOLDER system variable	415
20.90.1	Disk cache folder	415
20.91	POINTCLOUDEYEDOMELIGHTING system variable	416
20.91.1	Eye dome lighting strength	416
20.92	POINTCLOUDGAPFILLING system variable	416
20.92.1	Gap filling size	416
20.93	POINTCLOUDHSPC system variable	417
20.93.1	Point Cloud format (hspc/bcad)	417
20.94	POINTCLOUDIGNOREGEOTAGS system variable	417
20.94.1	Ignore geo tags in source data (deprecated!)	417
20.95	POINTCLOUDDOLLHOUSE system variable	417
20.95.1	Enable/disable dollhouse render mode	417
20.96	POINTCLOUDNORMALS system variable	418
20.96.1	Normal calculation	418
20.97	POINTCLOUDPOINTMAX system variable	418
20.97.1	Maximum number of points displayed on screen	418
20.98	POINTCLOUDPOINTSIZE system variable	419
20.98.1	Point size	419
20.99	POLARADDANG system variable	419
20.99.1	Polar add angles	419
20.100	POLARANG system variable	420
20.100.1	Polar angle	420



Contents

20.101	POLARDIST system variable	420
20.101.1	Polar distance	420
20.102	POLARMODE system variable	420
20.102.1	Polar mode	420
20.103	POLYSIDES system variable	421
20.103.1	Polygon sides	421
20.104	POPERATIONSCOLOR system variable	421
20.104.1	Parametric operations color	421
20.105	POPUPS system variable	421
20.105.1	Popups (Read Only)	421
20.106	PREVIEWDELAY system variable	422
20.106.1	Delay to preview selection	422
20.107	PREVIEWEFFECT system variable	422
20.107.1	Selection preview effect	422
20.108	PREVIEWFILTER system variable	423
20.108.1	Selection filter	423
20.109	PREVIEWTYPE system variable	423
20.109.1	Preview type	423
20.110	PREVIEWWNDINOPENDLG system variable	423
20.110.1	Preview window in open dialog	423
20.111	PRINTFILE system variable	424
20.111.1	Print file	424
20.112	PRINTPDFPREVIEW system variable	424
20.112.1	Print As PDF Preview	424
20.113	PRODUCT system variable	425
20.113.1	Product (Read Only)	425
20.114	PROFILEOFFSETBEHAVIOR system variable	425
20.114.1	Profile offset behavior	425
20.115	PROGBAR system variable	425
20.115.1	Progress bar	425
20.116	PROGRAM system variable	426
20.116.1	Program (Read Only)	426
20.117	PROJECTIONTYPE system variable	426
20.117.1	Drawing view projection type	426
20.118	PROJECTLOCATIONVISIBILITY system variable	427
20.118.1	Project location marker visibility	427
20.119	PROJECTNAME system variable	428
20.119.1	Project name	428
20.120	PROJECTSEARCHPATHS system variable	428
20.120.1	Project search paths	428
20.121	PROJMODE system variable	428
20.121.1	Projection mode	428
20.122	PROMPTMENU system variable	429
20.122.1	Prompt menu	429
20.123	PROMPTMENUFLAGS system variable	429
20.123.1	Prompt menu flags	429
20.124	PROMPTOPTIONFORMAT system variable	430
20.124.1	Prompt option format	430



Contents

20.125	PROMPTOPTIONTRANSLATEKEYWORDS system variable	431
20.125.1	Prompt option translate keywords	431
20.126	PROPAGATESEARCHSPACE system variable	431
20.126.1	Search space	431
20.127	PROPAGATETOLERANCE system variable	432
20.127.1	Position tolerance	432
20.128	PROPERTYPREVIEW system variable	432
20.128.1	Property Preview	432
20.129	PROPERTYPREVIEWDELAY system variable	432
20.129.1	Property Preview Delay	432
20.130	PROPERTYPREVIEWOBJLIMIT system variable	433
20.130.1	Property Preview Object Limit	433
20.131	PROPOBJLIMIT system variable	433
20.131.1	Properties objects limit	433
20.132	PROPPREVTIMEOUT system variable	433
20.132.1	Property Preview Timeout	433
20.133	PROPUNITS system variable	434
20.133.1	Property units	434
20.134	PROXYGRAPHICS system variable	434
20.134.1	Proxy graphics	434
20.135	PROXYNOTICE system variable	435
20.135.1	Proxy notice	435
20.136	PROXYSERVERENABLED system variable	435
20.136.1	Proxy server	435
20.137	PROXYSERVERHTTP system variable	435
20.137.1	HTTP server	435
20.138	PROXYSERVERHTTPPORT system variable	436
20.138.1	HTTP server port	436
20.139	PROXYSERVERHTTPS system variable	436
20.139.1	HTTPS server	436
20.140	PROXYSERVERHTTPSPORT system variable	436
20.140.1	HTTPS server port	436
20.141	PROXYSERVERPASSWORD system variable	436
20.141.1	User password	436
20.142	PROXYSERVERUSER system variable	437
20.142.1	User name	437
20.143	PROXYSHOW system variable	437
20.143.1	Proxy show	437
20.144	PROXYWEBSEARCH system variable	437
20.144.1	Proxy web search	437
20.145	PSLTSCALE system variable	438
20.145.1	Paper space linetype scale	438
20.146	PSOLHEIGHT system variable	438
20.146.1	Polysolid height	438
20.147	PSOLWIDTH system variable	438
20.147.1	Polysolid width	438
20.148	PSTYLEMODE system variable	439
20.148.1	Plot style mode (Read Only)	439



Contents

20.149	PSTYLEPOLICY system variable	439
20.149.1	Plot style policy	439
20.150	PSVPSCALE system variable	440
20.150.1	Paper space viewport scale	440
20.151	PUBLISHALLSHEETS system variable	440
20.151.1	Publish all sheets	440
20.152	PUBLISHCOLLATE system variable	440
20.152.1	Collate published sheets	440
20.153	PUCSSBASE system variable	441
20.153.1	Paper space UCS base (Read Only)	441
21.	Q	442
21.1	QAFLAGS system variable	442
21.1.1	Quality Assurance flags	442
21.2	QTEXTMODE system variable	442
21.2.1	Quick text mode	442
21.3	QUADCOMMANDLAUNCH system variable	443
21.3.1	Quad default command launch	443
21.4	QUADDISPLAY system variable	444
21.4.1	Quad display	444
21.5	QUADEXPANDELAY system variable	444
21.5.1	Quad expand delay	444
21.6	QUADEXPANDTABDELAY system variable	445
21.6.1	Quad expand tab delay	445
21.7	QUADGOTRANSPARENT system variable	445
21.7.1	Quad go transparent	445
21.8	QUADHIDEDELAY system variable	445
21.8.1	Quad hide delay	445
21.9	QUADHIDEMARGIN system variable	446
21.9.1	Quad hide margin	446
21.10	QUADICONSIZE system variable	446
21.10.1	Quad icon size	446
21.11	QUADICONSPACE system variable	447
21.11.1	Quad icon space	447
21.12	QUADMOSTRECENTITEMS system variable	448
21.12.1	Quad most recent items	448
21.13	QUADPOPUPCORNER system variable	448
21.13.1	Quad popup corner	448
21.14	QUADSHOWDELAY system variable	449
21.14.1	Quad show delay	449
21.15	QUADWIDTH system variable	449
21.15.1	Quad width	449
22.	R	450
22.1	R12SAVEACCURACY system variable	450
22.1.1	R12 Save accuracy	450
22.2	R12SAVEDEVIATION system variable	450
22.2.1	R12 Save deviation	450
22.3	RASTERPREVIEW system variable	450
22.3.1	Raster preview	450



Contents

22.4	RE_INIT system variable	451
22.4.1	Reinitialize Aliases (Read Only)	451
22.5	REALTIMESPEEDUP system variable	451
22.5.1	Realtime speedup	451
22.6	REALWORLDSCALE system variable	451
22.6.1	Real world scale	451
22.7	RECENTFILES system variable	452
22.7.1	Recent file list max count	452
22.8	RECENTPATH system variable	452
22.8.1	Recent path	452
22.9	REDHILITE_DUCSLOCKED_FACE_ALPHA system variable	452
22.9.1	Face opacity	452
22.10	REDHILITE_DUCSLOCKED_FACE_COLOR system variable	453
22.10.1	Face color	453
22.11	REDHILITE_HIDDENEDGE_ALPHA system variable	453
22.11.1	Edge opacity	453
22.12	REDHILITE_HIDDENEDGE_COLOR system variable	454
22.12.1	Hidden edge color	454
22.13	REDHILITEFULL_EDGE_ALPHA system variable	454
22.13.1	Edge opacity	454
22.14	REDHILITEFULL_EDGE_COLOR system variable	454
22.14.1	Edge color	454
22.15	REDHILITEFULL_EDGE_SHOWHIDDEN system variable	455
22.15.1	Hidden edges	455
22.16	REDHILITEFULL_EDGE_SMOOTHING system variable	455
22.16.1	Edge smoothing	455
22.17	REDHILITEFULL_EDGE_THICKNESS system variable	456
22.17.1	Edge thickness	456
22.18	REDHILITEFULL_FACE_ALPHA system variable	456
22.18.1	Face transparency	456
22.19	REDHILITEFULL_FACE_COLOR system variable	456
22.19.1	Face color	456
22.20	REDHILITEPARTIAL_SELECTEDEDGE_ALPHA system variable	457
22.20.1	Edge opacity	457
22.21	REDHILITEPARTIAL_SELECTEDEDGE_COLOR system variable	457
22.21.1	Edge color	457
22.22	REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable	457
22.22.1	Glow	457
22.23	REDHILITEPARTIAL_SELECTEDEDGE_SMOOTHING system variable	458
22.23.1	Edge smoothing	458
22.24	REDHILITEPARTIAL_SELECTEDEDGE_THICKNESS system variable	458
22.24.1	Edge thickness	458
22.25	REDHILITEPARTIAL_SELECTEDEDGEGLOW_ALPHA system variable	459
22.25.1	Glow transparency	459
22.26	REDHILITEPARTIAL_SELECTEDEDGEGLOW_COLOR system variable	459
22.26.1	Glow color	459
22.27	REDHILITEPARTIAL_SELECTEDEDGEGLOW_SMOOTHING system variable	460
22.27.1	Glow smoothing	460



Contents

22.28	REDHILITEPARTIAL_SELECTEDEDGEGLOW_THICKNESS system variable	461
22.28.1	Glow thickness	461
22.29	REDHILITEPARTIAL_SELECTEDFACE_ALPHA system variable	462
22.29.1	Face opacity	462
22.30	REDHILITEPARTIAL_SELECTEDFACE_COLOR system variable	462
22.30.1	Face color	462
22.31	REDHILITEPARTIAL_UNSELECTEDEDGE_SHOWHIDDEN system variable	462
22.31.1	Hidden edges	462
22.32	REDSDKLINESMOOTHING system variable	463
22.32.1	Line smoothing	463
22.33	REDUCELENGTHTYPE system variable	463
22.33.1	Reduce Length Type	463
22.34	REDUCELENGTHVALUE system variable	463
22.34.1	Reduce Length Value	463
22.35	REFEDITLOCKNOTINWORKSET system variable	464
22.35.1	Refedit lock	464
22.36	REFEDITNAME system variable	464
22.36.1	Refedit name (Read Only)	464
22.37	REFPATHTYPE system variable	464
22.37.1	Default path type of reference files	464
22.38	REGENMODE system variable	465
22.38.1	Regeneration mode	465
22.39	REGEXPAND system variable	465
22.39.1	Registry paths expanding type	465
22.40	REMEMBERFOLDERS system variable	466
22.40.1	Remember folders	466
22.41	RENDERCOMPOSITIONMATERIAL system variable	466
22.41.1	Render Composition Material	466
22.42	RENDERMATERIALDOWNLOAD system variable	467
22.42.1	Download missing resources for render materials	467
22.43	RENDERMATERIALSPATH system variable	467
22.43.1	Render materials directory path	467
22.44	RENDERUSINGHARDWARE system variable	467
22.44.1	Render using hardware	467
22.45	REPORTPANELMODE system variable	468
22.45.1	Report panel mode	468
22.46	RESTORECONNECTIONS system variable	468
22.46.1	Restore Connections	468
22.47	RESTORELOSTFOCUS system variable	469
22.47.1	Restore lost focus (Linux)	469
22.48	RETAINEDGRAPHICS system variable	469
22.48.1	Retained Graphics	469
22.49	REVCLOUDARCSTYLE system variable	469
22.49.1	Revision cloud default arc style	469
22.50	REVCLOUDCREATEMODE system variable	470
22.50.1	Revision cloud creation mode	470
22.51	REVCLOUDGRIPS system variable	471
22.51.1	Revision cloud grips	471



Contents

22.52	REVCLODMAXARCLENGTH system variable	471
22.52.1	Revision cloud default maximum arc length	471
22.53	REVCLODMINARCLENGTH system variable	471
22.53.1	Revision cloud default minimum arc length	471
22.54	RHINOVERSION system variable	472
22.54.1	Rhino Export version	472
22.55	RIBBONDOCKEDHEIGHT system variable	472
22.55.1	Ribbon docked height	472
22.56	RIBBONPANELMARGIN system variable	472
22.56.1	Panel margin	472
22.57	RIBBONSETTINGSENABLED system variable	473
22.57.1	Ribbon interface settings control on/off	473
22.58	RIBBONSTATE system variable	473
22.58.1	Ribbon state (Read Only)	473
22.59	ROAMABLEROOTPREFIX system variable	474
22.59.1	Roamable root prefix (Read Only)	474
22.60	ROLLOVEROPACITY system variable	474
22.60.1	Rollover opacity	474
22.61	ROLLOVERPARAMS system variable	474
22.61.1	Rollover parameters	474
22.62	ROLLOVERSELECTIONSET system variable	475
22.62.1	Rollover selection set	475
22.63	ROLLOVERTIPS system variable	475
22.63.1	Rollover tips	475
22.64	RTDISPLAY system variable	476
22.64.1	Realtime display	476
22.65	RTISOLATESELECTION system variable	476
22.65.1	Realtime selection isolation	476
22.66	RTROTATIONSPEEDFACTOR system variable	476
22.66.1	Realtime Rotation Speed Factor	476
22.67	RUBBERBANDCOLOR system variable	477
22.67.1	Rubber band color	477
22.68	RUBBERBANDSTYLE system variable	477
22.68.1	Rubber band dashed style	477
22.69	RUBBERSHEET (for OS X) system variable	477
22.69.1	Rubbersheet Touchpad	477
22.70	RUBBERSHEETSENSIBILITY (FOR OS X) system variable	478
22.70.1	Rubbersheet gesture activation sensibility	478
22.71	RULERDISPLAY system variable	478
22.71.1	Ruler display	478
22.72	RULERTEXTCOLOR system variable	479
22.72.1	Ruler Text Color	479
22.73	RUNASLEVEL system variable	479
22.73.1	Run as license level	479
22.74	RVTRFALEVELOFDETAIL system variable	480
22.74.1	Level of detail	480
22.75	RVVALIDATEBREP system variable	480
22.75.1	Validate BREP geometry	480



Contents

23.	S	481
23.1	SAFEMODE system variable	481
23.1.1	Safe mode (Read Only)	481
23.2	SAVECHANGETOLAYOUT system variable	481
23.2.1	Save changes to layout	481
23.3	SAVEFIDELITY system variable	481
23.3.1	Save fidelity	481
23.4	SAVEFILE system variable	482
23.4.1	Save file name (Read Only)	482
23.5	SAVEFILEPATH system variable	482
23.5.1	Save file path	482
23.6	SAVEFORMAT system variable	482
23.6.1	Save format	482
23.7	SAVELAYERSNAPSHOT system variable	483
23.7.1	Save Layer Snapshot with view	483
23.8	SAVENAME system variable	484
23.8.1	Saved drawing name (Read Only)	484
23.9	SAVEONDOCSWITCH system variable	484
23.9.1	Save on document switch	484
23.10	SAVEROUNDTRIP system variable	484
23.10.1	Save roundtrip	484
23.11	SAVETIME system variable	484
23.11.1	Save time interval	484
23.12	SCREENBOXES system variable	485
23.12.1	Screen menu boxes (Read Only)	485
23.13	SCREENMODE system variable	485
23.13.1	Screen mode (Read Only)	485
23.14	SCREENSIZE system variable	486
23.14.1	Screen size (Read Only)	486
23.15	SCRLHIST system variable	486
23.15.1	Scroll history	486
23.16	SDI system variable	486
23.16.1	Single-document interface (Windows)	486
23.17	SECTIONRESULTINTERVAL system variable	487
23.17.1	Section result interval	487
23.18	SECTIONSCALE system variable	487
23.18.1	Section scale	487
23.19	SECTIONSETTINGSSEARCHPATH system variable	488
23.19.1	Section settings search path	488
23.20	SECTIONSHEETSETTEMPLATEIMPERIAL system variable	488
23.20.1	Section sheet set template imperial	488
23.21	SECTIONSHEETSETTEMPLATEMETRIC system variable	488
23.21.1	Section sheet set template metric	488
23.22	SECURELOAD system variable	489
23.22.1	Executable file security policy (Read Only)	489
23.23	SELECTIONANNODISPLAY system variable	489
23.23.1	Show all annotation scales on selection	489
23.24	SELECTIONAREA system variable	489



Contents

23.24.1	Selection area	489
23.25	SELECTIONAREAOPACITY system variable	490
23.25.1	Selection area opacity	490
23.26	SELECTIONCYCLING system variable	490
23.26.1	Selection cycling	490
23.27	SELECTIONMODES system variable	491
23.27.1	Selection modes	491
23.28	SELECTIONPREVIEW system variable	491
23.28.1	Selection preview display	491
23.29	SELECTSIMILARMODE system variable	492
23.29.1	Match options for SELECTSIMILAR	492
23.30	SETBYLAYERMODE system variable	493
23.30.1	Set by layer mode	493
23.31	SHADEEDGE system variable	493
23.31.1	Shading edges	493
23.32	SHADEDIF system variable	494
23.32.1	Shading diffusion	494
23.33	SHEETNUMBERLEADINGZEROES system variable	494
23.33.1	Sheet number leading zeroes	494
23.34	SHEETSETAUTOBACKUP system variable	494
23.34.1	Sheet set automatic backup	494
23.35	SHEETSETTEMPLATEPATH system variable	495
23.35.1	Sheet Set template path	495
23.36	SHORTCUTMENU system variable	495
23.36.1	Shortcut menus	495
23.37	SHORTCUTMENUDURATION system variable	496
23.37.1	Shortcut menu duration	496
23.38	SHOWDOCTABS system variable	496
23.38.1	Tabs visibility	496
23.39	SHOWFULLPATHINTITLE system variable	497
23.39.1	Display full path in title	497
23.40	SHOWIDS.getPropertiesONLY system variable	497
23.40.1	Show IDS Properties Only	497
23.41	SHOWLAYERUSAGE system variable	497
23.41.1	Layer Usage	497
23.42	SHOWSCROLLBUTTONS system variable	498
23.42.1	Scroll buttons (Mac & Linux)	498
23.43	SHOWTABCLOSEBUTTON system variable	498
23.43.1	Close button on tabs (Mac & Linux)	498
23.44	SHOWTABCLOSEBUTTONACTIVE system variable	499
23.44.1	Close button on active tab (Mac & Linux)	499
23.45	SHOWTABCLOSEBUTTONALL system variable	499
23.45.1	Close button on all tabs (Mac & Linux)	499
23.46	SHOWWINDOWLISTBUTTON system variable	499
23.46.1	Window list button (Mac & Linux)	499
23.47	SHPNAME system variable	500
23.47.1	Shape name	500
23.48	SIGWARN system variable	500



Contents

23.48.1	Signature warning	500
23.49	SINGLETONMODE system variable	500
23.49.1	Singleton mode	500
23.50	SITELOCATIONVISIBILITY system variable	501
23.50.1	Site location marker visibility	501
23.51	SKETCHFEATURECOPYMODE system variable	501
23.51.1	Sketch feature copy mode	501
23.52	SKETCHINC system variable	502
23.52.1	Sketch increment	502
23.53	SKPOLY system variable	502
23.53.1	Sketch poly	502
23.54	SKYSTATUS system variable	503
23.54.1	Sky status	503
23.55	SMASSEMBLYEXPORTMODE system variable	503
23.55.1	SmAssemblyExport mode	503
23.56	SMASSEMBLYEXPORTREPORTPATHTYPE system variable	503
23.56.1	Report file path type	503
23.57	SMASSEMBLYEXPORTSOLIDTYPESINREPORTS system variable	504
23.57.1	Solid types in reports	504
23.58	SMATTRIBUTESLAYERCOLOR system variable	504
23.58.1	Color of the attributes layer	504
23.59	SMATTRIBUTESLAYERTEXTHEIGHT system variable	505
23.59.1	Height of the text	505
23.60	SMATTRIBUTESLAYERTEXTHEIGHTTYPE system variable	505
23.60.1	Type of the text height	505
23.61	SMBENDANNOTATIONSLAYERCOLOR system variable	505
23.61.1	Color of the bend annotations text layer	505
23.62	SMBENDANNOTATIONSLAYERTEXTHEIGHT system variable	506
23.62.1	Height of the text	506
23.63	SMBENDANNOTATIONSLAYERTEXTHEIGHTTYPE system variable	506
23.63.1	Type of the text height	506
23.64	SMBENDLINESDOWNLAYERCOLOR system variable	507
23.64.1	Color of the bend down lines layer	507
23.65	SMBENDLINESDOWNLAYERLINETYPE system variable	507
23.65.1	Linetype of the bend down lines layer	507
23.66	SMBENDLINESDOWNLAYERLINEWEIGHT system variable	507
23.66.1	Lineweight of the bend down layer	507
23.67	SMBENDLINESUPLAYERCOLOR system variable	508
23.67.1	Color of the bend up lines layer	508
23.68	SMBENDLINESUPLAYERLINETYPE system variable	508
23.68.1	Linetype of the bend up lines layer	508
23.69	SMBENDLINESUPLAYERLINEWEIGHT system variable	508
23.69.1	Lineweight of the bend up layer	508
23.70	SMBEVELFEATURECOLOR system variable	509
23.70.1	Color of the bevel features layer	509
23.71	SMCOLORBEND system variable	509
23.71.1	Bend feature color	509
23.72	SMCOLORBENDRELIEF system variable	509



Contents

23.72.1	Bend relief feature color	509
23.73	SMCOLORBEVEL system variable	510
23.73.1	Bevel feature color	510
23.74	SMCOLORCORNERRELIEF system variable	510
23.74.1	Corner relief feature color	510
23.75	SMCOLORFLANGE system variable	510
23.75.1	Flange feature color	510
23.76	SMCOLORFLANGEREFERENCESIDE system variable	511
23.76.1	Flange feature reference side color	511
23.77	SMCOLORFORM system variable	511
23.77.1	Form feature color	511
23.78	SMCOLORHEM system variable	511
23.78.1	Hem feature color	511
23.79	SMCOLORJOG system variable	512
23.79.1	Jog feature color	512
23.80	SMCOLORJUNCTION system variable	512
23.80.1	Junction feature color	512
23.81	SMCOLORLOFTEDBEND system variable	512
23.81.1	Lofted bend feature color	512
23.82	SMCOLORMITER system variable	512
23.82.1	Miter feature color	512
23.83	SMCOLORROLLEDEDGE system variable	513
23.83.1	Rolled edge feature color	513
23.84	SMCOLORTAB system variable	513
23.84.1	Tab feature color	513
23.85	SMCOLORWRONGBEND system variable	513
23.85.1	Wrong bend feature color	513
23.86	SMCOLORWRONGFLANGE system variable	514
23.86.1	Wrong flange feature color	514
23.87	SMCONTOURSLAYERCOLOR system variable	514
23.87.1	Color of the contour layer	514
23.88	SMCONTOURSLAYERLINETYPE system variable	514
23.88.1	Linetype of the contour layer	514
23.89	SMCONTOURSLAYERLINEWEIGHT system variable	515
23.89.1	Lineweight of the contour layer	515
23.90	SMCONVERTMAXIMALBEVELANGLE system variable	515
23.90.1	Maximal angle of bevel	515
23.91	SMCONVERTMINIMALBEVELANGLE system variable	516
23.91.1	Minimal angle of bevel	516
23.92	SMCONVERTPREFERFORMFEATURES system variable	516
23.92.1	Prefer form features to flanges and bends	516
23.93	SMCONVERTPREFERHEMFEATURES system variable	516
23.93.1	Prefer hem features to flanges and bends	516
23.94	SMCONVERTPREFERJOGFEATURES system variable	517
23.94.1	Prefer jog features to flanges and bends	517
23.95	SMCONVERTPREFERZEROBENDFEATURES system variable	517
23.95.1	Prefer zero bend features to wrong bends	517
23.96	SMCONVERTRECOGNIZEBEVELS system variable	517



Contents

23.96.1	Recognize bevel features	517
23.97	SMCONVERTRECOGNIZEHOLES system variable	518
23.97.1	Recognize holes	518
23.98	SMCONVERTRECOGNIZERIBCONTROLCURVES system variable	518
23.98.1	Recognize bead control curves	518
23.99	SMCONVERTWRONGFEATURETHICKNESSDEVIATIONTYPE system variable	519
23.99.1	Type of deviation of wrong feature thickness	519
23.100	SMCONVERTWRONGFEATURETHICKNESSDEVIATIONVALUE system variable	519
23.100.1	Deviation value of wrong feature thickness	519
23.101	SMDEFAULTBENDLINEEXTENTTYPE system variable	519
23.101.1	Bend line extent type	519
23.102	SMDEFAULTBENDLINEEXTENTVALUE system variable	520
23.102.1	Bend line extent value	520
23.103	SMDEFAULTBENDRADIUSTYPE system variable	520
23.103.1	Bend radius type	520
23.104	SMDEFAULTBENDRADIUSVALUE system variable	521
23.104.1	Bend radius value	521
23.105	SMDEFAULTBENDRELIEFWIDHTTYPE system variable	521
23.105.1	Bend relief type	521
23.106	SMDEFAULTBENDRELIEFWIDTHVALUE system variable	521
23.106.1	Bend relief width value	521
23.107	SMDEFAULTBEVELFEATUREUNFOLDMODE system variable	522
23.107.1	Bevel unfolding mode	522
23.108	SMDEFAULTCORNERRELIEFDIAMETERVALUE system variable	522
23.108.1	Corner relief diameter value	522
23.109	SMDEFAULTFLANGESPLITEXTENSIONTYPE system variable	523
23.109.1	Miter extension type	523
23.110	SMDEFAULTFLANGESPLITEXTENSIONVALUE system variable	523
23.110.1	Miter extension value	523
23.111	SMDEFAULTFLANGESPLITGAPTYPE system variable	523
23.111.1	Miter gap type	523
23.112	SMDEFAULTFLANGESPLITGAPVALUE system variable	524
23.112.1	Miter gap value	524
23.113	SMDEFAULTFORMFEATUREUNFOLDMODE system variable	524
23.113.1	Form feature unfolding mode	524
23.114	SMDEFAULTGUSSETDEPTHTYPE system variable	525
23.114.1	Gusset depth type	525
23.115	SMDEFAULTGUSSETDEPTHVALUE system variable	525
23.115.1	Gusset height value	525
23.116	SMDEFAULTGUSSETFILLETTRADIUSTYPE system variable	525
23.116.1	Gusset fillet radius type	525
23.117	SMDEFAULTGUSSETFILLETTRADIUSVALUE system variable	526
23.117.1	Gusset fillet radius value	526
23.118	SMDEFAULTGUSSETTYPE system variable	526
23.118.1	Gusset type	526
23.119	SMDEFAULTGUSSETWIDTHTYPE system variable	527
23.119.1	Gusset width type	527
23.120	SMDEFAULTGUSSETWIDTHVALUE system variable	527



Contents

23.120.1	Gusset width value	527
23.121	SMDEFAULTHEMGAPTYPE system variable	527
23.121.1	Open Hem gap type	527
23.122	SMDEFAULTHEMGAPVALUE system variable	528
23.122.1	Open Hem gap value (in addition to the thickness)	528
23.123	SMDEFAULTHEMRELATIVEBENDDEDUCTION system variable	528
23.123.1	Hem relative bend deduction value	528
23.124	SMDEFAULTJOGANGLEVALUE system variable	529
23.124.1	Jog angle value	529
23.125	SMDEFAULTJOGHEIGHTTYPE system variable	529
23.125.1	Jog height type	529
23.126	SMDEFAULTJOGHEIGHTVALUE system variable	529
23.126.1	Jog height value	529
23.127	SMDEFAULTJOGRADIUSTYPE system variable	530
23.127.1	Jog radius type	530
23.128	SMDEFAULTJOGRADIUSVALUE system variable	530
23.128.1	Jog radius value	530
23.129	SMDEFAULTJUNCTIONALIGNMENTTORELIEF system variable	531
23.129.1	Junction alignment to relief	531
23.130	SMDEFAULTJUNCTIONGAPTYPE system variable	531
23.130.1	Junction gap type	531
23.131	SMDEFAULTJUNCTIONGAPVALUE system variable	531
23.131.1	Junction gap value	531
23.132	SMDEFAULTKFACTOR system variable	532
23.132.1	K-Factor value	532
23.133	SMDEFAULTLOFTEDBENDNUMBERSAMPLES system variable	532
23.133.1	Lofted bend subdivisions	532
23.134	SMDEFAULTRELIEFEXTENSIONTYPE system variable	533
23.134.1	Relief extension type	533
23.135	SMDEFAULTRELIEFEXTENSIONVALUE system variable	533
23.135.1	Relief extension value	533
23.136	SMDEFAULTTRIBFILLETRADIUSTYPE system variable	533
23.136.1	Bead fillet radius type	533
23.137	SMDEFAULTTRIBFILLETRADIUSVALUE system variable	534
23.137.1	Bead fillet radius value	534
23.138	SMDEFAULTTRIBPROFILERADIUSTYPE system variable	534
23.138.1	Bead profile radius type	534
23.139	SMDEFAULTTRIBPROFILERADIUSVALUE system variable	534
23.139.1	Bead profile radius value	534
23.140	SMDEFAULTTRIBROUNDRADIUSTYPE system variable	535
23.140.1	Bead round radius type	535
23.141	SMDEFAULTTRIBROUNDRADIUSVALUE system variable	535
23.141.1	Bead round radius value	535
23.142	SMDEFAULTSHARPBENDRADIUSLIMITRATIO system variable	535
23.142.1	Sharp bend radius limit ratio	535
23.143	SMDEFAULTTABCHAMFERDISTANCETYPE system variable	536
23.143.1	Tab chamfer distance type	536
23.144	SMDEFAULTTABCHAMFERDISTANCEVALUE system variable	536



Contents

23.144.1	Tab chamfer distance value	536
23.145	SMDEFAULTTABCLEARANCETYPE system variable	537
23.145.1	Tab clearance type	537
23.146	SMDEFAULTTABCLEARANCEVALUE system variable	537
23.146.1	Tab clearance value	537
23.147	SMDEFAULTTABDISTANCETYPE system variable	537
23.147.1	Tab distance type	537
23.148	SMDEFAULTTABDISTANCEVALUE system variable	538
23.148.1	Tab distance value	538
23.149	SMDEFAULTTABEDGE TYPE system variable	538
23.149.1	Tab edge type	538
23.150	SMDEFAULTTABFILLETRADIUSTYPE system variable	539
23.150.1	Tab fillet radius type	539
23.151	SMDEFAULTTABFILLETRADIUSVALUE system variable	539
23.151.1	Tab fillet radius value	539
23.152	SMDEFAULTTABHEIGHTTYPE system variable	539
23.152.1	Tab height type	539
23.153	SMDEFAULTTABHEIGHTVALUE system variable	540
23.153.1	Tab height value	540
23.154	SMDEFAULTTABLENGTHTYPE system variable	540
23.154.1	Tab length type	540
23.155	SMDEFAULTTABLENGTHVALUE system variable	540
23.155.1	Tab length value	540
23.156	SMDEFAULTTABSLOTNUMBER system variable	541
23.156.1	Tab slot number	541
23.157	SMDEFAULTTHICKNESS system variable	541
23.157.1	Thickness value	541
23.158	SMEXPORTOSMAPPROXIMATIONACCURACY system variable	541
23.158.1	Accuracy of the approximation	541
23.159	SMEXPORTOSMMINIMALEDGELENGTH system variable	542
23.159.1	Minimal edge length	542
23.160	SMFORMFEATURESDOWNCOLOR system variable	542
23.160.1	Color of the form features down layer	542
23.161	SMFORMFEATURESDOWNLAYERLINETYPE system variable	542
23.161.1	Linetype of the form features down layer	542
23.162	SMFORMFEATURESDOWNLAYERLINEWEIGHT system variable	543
23.162.1	Lineweight of the form features down layer	543
23.163	SMFORMFEATURESUPCOLOR system variable	543
23.163.1	Color of the form features up layer	543
23.164	SMFORMFEATURESUPPLAYERLINETYPE system variable	544
23.164.1	Linetype of the form features up layer	544
23.165	SMFORMFEATURESUPPLAYERLINEWEIGHT system variable	544
23.165.1	Lineweight of the form features up layer	544
23.166	SMHEMCREATECLOSEDHEMGAP system variable	544
23.166.1	Closed Hem, Teardrop, and Round gap value	544
23.167	SMJUNCTIONCREATEHEALCOINCIDENT system variable	545
23.167.1	Heal coincident junction faces	545
23.168	SMOOTHMESHCONVERT system variable	545



Contents

23.168.1	Mesh conversion mode	545
23.169	SMOVERALLANNOTATIONSLAYERCOLOR system variable	546
23.169.1	Color of the overall dimensions annotations layer	546
23.170	SMOVERALLANNOTATIONSLAYERLINETYPE system variable	546
23.170.1	Linetype of the overall annotation layer	546
23.171	SMOVERALLANNOTATIONSLAYERLINEWEIGHT system variable	546
23.171.1	Lineweight of the overall annotation layer	546
23.172	SMPARAMETRIZEHOLESPARAMETRIZATION system variable	547
23.172.1	Hole parametrization	547
23.173	SMREPAIRLOFTEDBENDMERGE system variable	547
23.173.1	Merge lofted bends	547
23.174	SMROLLEDEDGEANNOTATIONSLAYERCOLOR system variable	548
23.174.1	Color of the rolled edge annotations text layer	548
23.175	SMROLLEDEDGEANNOTATIONSLAYERTEXTHEIGHT system variable	548
23.175.1	Height of the text	548
23.176	SMROLLEDEDGEANNOTATIONSLAYERTEXTHEIGHTTYPE system variable	548
23.176.1	Type of the text height	548
23.177	SMROLLEDEDGE_LINESDOWNLAYERCOLOR system variable	549
23.177.1	Color of the rolled edge down lines layer	549
23.178	SMROLLEDEDGE_LINESDOWNLAYERLINETYPE system variable	549
23.178.1	Linetype of the rolled edge down lines layer	549
23.179	SMROLLEDEDGE_LINESDOWNLAYERLINEWEIGHT system variable	549
23.179.1	Lineweight of the rolled edge down layer	549
23.180	SMROLLEDEDGE_LINESUPLAYERCOLOR system variable	550
23.180.1	Color of the rolled edge up lines layer	550
23.181	SMROLLEDEDGE_LINESUPLAYERLINETYPE system variable	550
23.181.1	Linetype of the rolled edge up lines layer	550
23.182	SMROLLEDEDGE_LINESUPLAYERLINEWEIGHT system variable	550
23.182.1	Lineweight of the rolled edge up layer	550
23.183	SMSMARTFEATURES system variable	551
23.183.1	Automatic update features after sheet metal commands	551
23.184	SMSPLITAMBIGUOUSINPUT system variable	551
23.184.1	Ambiguous input behavior	551
23.185	SMSPLITCONVERTBENDTOJUNCTION system variable	552
23.185.1	Convert bend to junction	552
23.186	SMSPLITHEALCOINCIDENT system variable	552
23.186.1	Heal coincident miter faces	552
23.187	SMSPLITORTHOGONALBENDSPLIT system variable	552
23.187.1	Orthogonal bend split	552
23.188	SMTARGETCAM system variable	553
23.188.1	Target CAM	553
23.189	SMUNFOLDAPPEARANCE system variable	553
23.189.1	Unfold appearance	553
23.190	SNAPANG system variable	553
23.190.1	Snap angle	553
23.191	SNAPBASE system variable	554
23.191.1	Snap base	554
23.192	SNAPISOPAIR system variable	554



Contents

23.192.1	Snap isometric pair	554
23.193	SNAPMARKERCOLOR system variable	555
23.193.1	Snap marker color	555
23.194	SNAPMARKERSIZE system variable	555
23.194.1	Snap marker size	555
23.195	SNAPMARKERTHICKNESS system variable	556
23.195.1	Snap marker thickness	556
23.196	SNAPMODE system variable	556
23.196.1	Snap mode	556
23.197	SNAPSTYL system variable	556
23.197.1	Snap style	556
23.198	SNAPTYPE system variable	557
23.198.1	Snap type	557
23.199	SNAPUNIT system variable	557
23.199.1	Snap unit	557
23.200	SOLIDCHECK system variable	557
23.200.1	Solid check	557
23.201	SORTENTS system variable	558
23.201.1	Sort entities	558
23.202	SPAADJUSTMODE system variable	558
23.202.1	Adjust mode	558
23.203	SPACHECKLEVEL system variable	559
23.203.1	Check level	559
23.204	SPAGRIDASPECTRATIO system variable	560
23.204.1	Grid aspect ratio	560
23.205	SPAGRIDMODE system variable	560
23.205.1	Grid mode	560
23.206	SPAMAXFACETEDGELENGTH system variable	561
23.206.1	Maximum facet edge length	561
23.207	SPAMAXNUMGRIDLINES system variable	561
23.207.1	Maximum number of grid lines	561
23.208	SPAMINUGRIDLINES system variable	562
23.208.1	Minimum number of U grid lines	562
23.209	SPAMINVGRIDLINES system variable	562
23.209.1	Minimum number of V grid lines	562
23.210	SPANORMALTOL system variable	562
23.210.1	Normal tolerance	562
23.211	SPASURFACETOL system variable	563
23.211.1	Surface tolerance	563
23.212	SPATRIANGMODE system variable	563
23.212.1	Triangulation mode	563
23.213	SPAUSEFACETRES system variable	564
23.213.1	Use FACETRES system variable	564
23.214	SPLFRAME system variable	564
23.214.1	Spline frame	564
23.215	SPLINESEGS system variable	564
23.215.1	Spline segments	564
23.216	SPLINETYPE system variable	565



Contents

23.216.1	Spline type	565
23.217	SRCHPATH system variable	565
23.217.1	Support file search path	565
23.218	SSFOUND system variable	566
23.218.1	Sheet Set found (Read Only)	566
23.219	SSLOCATE system variable	566
23.219.1	Sheet Set locate	566
23.220	SSMAUTOOPEN system variable	566
23.220.1	Sheet Set manager auto open	566
23.221	SSMPOLTIME system variable	567
23.221.1	Sheet Set manager poll time	567
23.222	SSMSHEETSTATUS system variable	567
23.222.1	Sheet Set manager status	567
23.223	SSMSTATE system variable	567
23.223.1	Sheet Set manager state (Read Only)	567
23.224	STACKPANELTYPE system variable	568
23.224.1	Stack panel type	568
23.225	STAMPFONTSIZE system variable	568
23.225.1	Font Size	568
23.226	STAMPFONTSTYLE system variable	569
23.226.1	Font Style	569
23.227	STAMPFOOTER system variable	569
23.227.1	Footer	569
23.228	STAMPFOOTEROFFSETX system variable	569
23.228.1	Stamp footer X offset	569
23.229	STAMPFOOTEROFFSETY system variable	569
23.229.1	Stamp footer Y offset	569
23.230	STAMPHEADER system variable	570
23.230.1	Header	570
23.231	STAMPHEADEROFFSETX system variable	570
23.231.1	Stamp header X offset	570
23.232	STAMPHEADEROFFSETY system variable	570
23.232.1	Stamp header Y offset	570
23.233	STAMPUNITS system variable	571
23.233.1	Units	571
23.234	STANDARDSOPTIONS system variable	571
23.234.1	Standards validation options	571
23.235	STANDARDSVIOLATION system variable	572
23.235.1	Standards Violation Notification	572
23.236	STARTUP system variable	572
23.236.1	Startup	572
23.237	STATUSBAR system variable	572
23.237.1	Window Status bar	572
23.238	STEP SIZE system variable	573
23.238.1	Step size	573
23.239	STEPSPERSEC system variable	573
23.239.1	Steps per second	573
23.240	STLPOSITIVEQUADRANT system variable	574



Contents

23.240.1	STL export coordinates adjustment	574
23.241	STORYBAR system variable	574
23.241.1	Display Story Bar	574
23.242	STRUCTURETREECONFIG system variable	574
23.242.1	Structure Tree Configuration	574
23.243	SURFTAB1 system variable	575
23.243.1	Surface tabulation 1	575
23.244	SURFTAB2 system variable	575
23.244.1	Surface tabulation 2	575
23.245	SURFTYPE system variable	575
23.245.1	Surface-fitting type	575
23.246	SURFU system variable	576
23.246.1	Surface U	576
23.247	SURFV system variable	576
23.247.1	Surface V	576
23.248	SVGBLENDEDGRADIENTS system variable	576
23.248.1	SVG Blended Gradients	576
23.249	SVGCOLORPOLICY system variable	577
23.249.1	SVG Color Policy	577
23.250	SVGDEFAULTIMAGEEXTENSION system variable	577
23.250.1	SVG Default Image Extension	577
23.251	SVGGENERICFONTFAMILY system variable	578
23.251.1	SVG Generic Font Family	578
23.252	SVGIMAGEBASE system variable	578
23.252.1	SVG Image base path	578
23.253	SVGIMAGEURL system variable	578
23.253.1	SVG Image Url	578
23.254	SVGLINEWEIGHTSCALE system variable	579
23.254.1	SVG Line Weight Scale	579
23.255	SVGOUTPUTHEIGHT system variable	579
23.255.1	SVG Output Height	579
23.256	SVGOUTPUTWIDTH system variable	579
23.256.1	SVG Output Width	579
23.257	SVGPRECISION system variable	580
23.257.1	SVG Floating Point Precision	580
23.258	SVGSCALEFACTOR system variable	580
23.258.1	SVG Scale Factor	580
23.259	SYSCODEPAGE system variable	580
23.259.1	System code page (Read Only)	580
24.	T	582
24.1	TABCONTROLHEIGHT system variable	582
24.1.1	Tab control height in pixels (Mac & Linux)	582
24.2	TABMODE system variable	582
24.2.1	Tablet mode	582
24.3	TABSFIXEDWIDTH system variable	582
24.3.1	Tabs fixed width (Mac & Linux)	582
24.4	TANGENTLENGTHTYPE system variable	583
24.4.1	Tangent Length Type	583



Contents

24.5	TANGENTLENGTHVALUE system variable	583
24.5.1	Tangent Length Value	583
24.6	TARGET system variable	583
24.6.1	Target (Read Only)	583
24.7	TDCREATE system variable	584
24.7.1	Time/Date create (Read only)	584
24.8	TDINDWG system variable	584
24.8.1	Time/Date in drawing (Read Only)	584
24.9	TDUCREATE system variable	584
24.9.1	Time/Date universal create (Read Only)	584
24.10	TDUPDATE system variable	584
24.10.1	Time/Date update (Read Only)	584
24.11	TDUSRTIMER system variable	585
24.11.1	Time/Date user timer (Read Only)	585
24.12	TDUUPDATE system variable	585
24.12.1	Time/Date universal update (Read Only)	585
24.13	TEETANGENTLENGTHTYPE system variable	585
24.13.1	Tee Length Type	585
24.14	TEETANGENTLENGTHVALUE system variable	585
24.14.1	Tee Length Value	585
24.15	TEMPLATEPATH system variable	586
24.15.1	Template path	586
24.16	TEMPPREFIX system variable	586
24.16.1	Temporary prefix	586
24.17	TEXTANGLE system variable	586
24.17.1	Text angle	586
24.18	TEXTED system variable	586
24.18.1	Text editor for single line text entities	586
24.19	TEXTEDITMODE system variable	587
24.19.1	Text edit mode	587
24.20	TEXTEVAL system variable	587
24.20.1	Text evaluation	587
24.21	TEXTFILL system variable	588
24.21.1	Text fill	588
24.22	TEXTQLTY system variable	588
24.22.1	Text quality (Mac & Linux)	588
24.23	TEXTSIZE system variable	589
24.23.1	Text size	589
24.24	TEXTSTYLE system variable	589
24.24.1	Text style	589
24.25	TEXTUREMAPPATH system variable	589
24.25.1	Texture map path	589
24.26	THICKNESS system variable	590
24.26.1	Thickness	590
24.27	THREADDISPLAY system variable	590
24.27.1	Thread representation	590
24.28	THUMBSIZE system variable	590
24.28.1	Thumbnail preview image size	590



Contents

24.29	TILEMODE system variable	591
24.29.1	Tile mode	591
24.30	TILEMODELIGHTSYNCH system variable	591
24.30.1	Tile mode light synch	591
24.31	TIMEZONE system variable	592
24.31.1	Timezone	592
24.32	TOOLBARMARGIN system variable	594
24.32.1	Toolbar margin	594
24.33	TOOLBUTTONSIZE system variable	594
24.33.1	Tool button size	594
24.34	TOOLICONPADDING system variable	595
24.34.1	Tool icon padding	595
24.35	TOOLPALETTEPATH system variable	595
24.35.1	Tool palettes path	595
24.36	TOOLTIPDELAY system variable	595
24.36.1	Tooltip delay	595
24.37	TOOLTIPS system variable	596
24.37.1	Tooltips	596
24.38	TPSTATE system variable	596
24.38.1	Tool Palettes Panel state (Read Only)	596
24.39	TRACEWID system variable	596
24.39.1	Trace width	596
24.40	TRACKPATH system variable	597
24.40.1	Track path	597
24.41	TRANSPARENCYDISPLAY system variable	597
24.41.1	Transparency display	597
24.42	TRAYICONS system variable	597
24.42.1	Tray icons	597
24.43	TRAYNOTIFY system variable	598
24.43.1	Tray notify	598
24.44	TRAYTIMEOUT system variable	598
24.44.1	Tray timeout	598
24.45	TREEDEPTH system variable	598
24.45.1	Tree depth	598
24.46	TREEMAX system variable	599
24.46.1	Tree maximum	599
24.47	TRIMEDGES system variable	599
24.47.1	TRIM and EXTEND to hatches	599
24.48	TRIMEXTENDMODE system variable	600
24.48.1	TRIM and EXTEND mode	600
24.49	TRIMMODE system variable	600
24.49.1	Trim mode	600
24.50	TRUSTEDPATHS system variable	601
24.50.1	Trusted executable file locations (Read Only)	601
24.51	TSPACEFAC system variable	601
24.51.1	Text space factor	601
24.52	TSPACETYPE system variable	601
24.52.1	Text space type	601



Contents

24.53	TSTACKALIGN system variable	602
24.53.1	Text stack align	602
24.54	TSTACKSIZE system variable	602
24.54.1	Text stack size	602
24.55	TTFASTEXT system variable	603
24.55.1	TrueType Text displaying mode	603
24.56	TUTORIALSONSTARTPAGE system variable	603
24.56.1	Tutorials on start page	603
25.	U	604
25.1	UCSAXISANG system variable	604
25.1.1	UCS axis angle	604
25.2	UCSBASE system variable	604
25.2.1	UCS base	604
25.3	UCSDETECT system variable	604
25.3.1	UCS detect	604
25.4	UCSFOLLOW system variable	605
25.4.1	UCS follow	605
25.5	UCSICON system variable	605
25.5.1	UCS icon	605
25.6	UCSICONPOS system variable	605
25.6.1	UCS icon position	605
25.7	UCSNAME system variable	606
25.7.1	UCS name (Read Only)	606
25.8	UCSORG system variable	606
25.8.1	UCS origin (Read Only)	606
25.9	UCSORTHO system variable	606
25.9.1	UCS orthographic	606
25.10	UCSVIEW system variable	607
25.10.1	UCS view	607
25.11	UCSVP system variable	607
25.11.1	UCS viewports	607
25.12	UCSXDIR system variable	608
25.12.1	UCS X direction (Read Only)	608
25.13	UCSYDIR system variable	608
25.13.1	UCS Y direction (Read Only)	608
25.14	UNDOCTL system variable	608
25.14.1	Undo control (Read Only)	608
25.15	UNDOMARKS system variable	609
25.15.1	Undo marks (Read Only)	609
25.16	UNITESURFACES system variable	609
25.16.1	Unite adjacent surfaces	609
25.17	UNITMODE system variable	609
25.17.1	Unit mode	609
25.18	USECOMMUNICATOR system variable	610
25.18.1	Use Communicator	610
25.19	USENEWSTATUSBAR system variable	610
25.19.1	Status Bar Preview	610
25.20	USERI1 system variable	611



Contents

25.20.1	User integer 1	611
25.21	USERI2 system variable	611
25.21.1	User integer 2	611
25.22	USERI3 system variable	611
25.22.1	User integer 3	611
25.23	USERI4 system variable	611
25.23.1	User integer 4	611
25.24	USERI5 system variable	612
25.24.1	User integer 5	612
25.25	USERR1 system variable	612
25.25.1	User real 1	612
25.26	USERR2 system variable	612
25.26.1	User real 2	612
25.27	USERR3 system variable	613
25.27.1	User real 3	613
25.28	USERR4 system variable	613
25.28.1	User real 4	613
25.29	USERR5 system variable	613
25.29.1	User real 5	613
25.30	USERS1 system variable	613
25.30.1	User string 1	613
25.31	USERS2 system variable	614
25.31.1	User string 2	614
25.32	USERS3 system variable	614
25.32.1	User string 3	614
25.33	USERS4 system variable	614
25.33.1	User string 4	614
25.34	USERS5 system variable	614
25.34.1	User string 5	614
25.35	USESTANDARDOPENFILEDIALOG system variable	615
25.35.1	Use standard open file dialog (Windows)	615
26.	V	616
26.1	VBAMACROS system variable	616
26.1.1	Enable macros	616
26.2	VENDORNAME system variable	616
26.2.1	Vendor name (obsolete)	616
26.3	VERBOSEBIMSECTIONUPDATE system variable	616
26.3.1	Additional diagnostics while section update	616
26.4	VERSIONCONTROLCONFIGPATH system variable	617
26.4.1	Version Control config path	617
26.5	VERSIONCONTROLDOWNLOADPATH system variable	617
26.5.1	Version Control download path	617
26.6	VERSIONCUSTOMIZABLEFILES system variable	617
26.6.1	Version customizable files (Read Only)	617
26.7	VIEWCTR system variable	617
26.7.1	View center (Read Only)	617
26.8	VIEWDIR system variable	618
26.8.1	View direction (Read Only)	618



Contents

26.9	VIEWMODE system variable	618
26.9.1	View mode (Read Only)	618
26.10	VIEWSIZE system variable	618
26.10.1	View size (Read Only)	618
26.11	VIEWTWIST system variable	619
26.11.1	View twist (Read Only)	619
26.12	VIEWUPDATEAUTO system variable	619
26.12.1	Automatically update drawing views	619
26.13	VISRETAIN system variable	619
26.13.1	Visibility retain	619
26.14	VOLUMEPREC system variable	620
26.14.1	Volume precision	620
26.15	VOLUMEUNITS system variable	621
26.15.1	Volume units	621
26.16	VPMAXIMIZEDSTATE system variable	621
26.16.1	Viewport maximized (Read Only)	621
26.17	VPROTATEASSOC system variable	621
26.17.1	Rotate view	621
26.18	VSMAX system variable	622
26.18.1	Virtual screen maximum (Read Only)	622
26.19	VSMIN system variable	622
26.19.1	Virtual screen minimum (Read Only)	622
26.20	VTDURATION system variable	622
26.20.1	View transition duration	622
26.21	VTENABLE system variable	623
26.21.1	Enable view transitions	623
26.22	VTFPS system variable	623
26.22.1	View transition minimum FPS	623
27.	W	624
27.1	WARNINGMESSAGES system variable	624
27.1.1	Warning messages	624
27.2	WHIPARC system variable	624
27.2.1	Whip arcs	624
27.3	WHIPTHREAD system variable	625
27.3.1	Whip thread	625
27.4	WINDOWAREACOLOR system variable	625
27.4.1	Window area color	625
27.5	WIPEOUTFRAME system variable	626
27.5.1	Wipeout frame	626
27.6	WMFBKGND system variable	626
27.6.1	Windows Meta File background	626
27.7	WMFFOREGND system variable	626
27.7.1	Windows Meta File foreground	626
27.8	WMFTTFASTEXT system variable	627
27.8.1	TrueType Text mode for Windows Meta File	627
27.9	WNDLMAIN system variable	627
27.9.1	Main window state	627
27.10	WNDLSCRL system variable	628



Contents

27.10.1	Window scrollbars (Windows)	628
27.11	WNDLTEXT system variable	628
27.11.1	Text window state	628
27.12	WNDPMAIN system variable	628
27.12.1	Main window top-left	628
27.13	WNDPTEXT system variable	629
27.13.1	Text window top left	629
27.14	WNDSMAIN system variable	629
27.14.1	Main window size	629
27.15	WNDSTEXT system variable	629
27.15.1	Text window size	629
27.16	WORLDUCS system variable	629
27.16.1	World UCS (Read Only)	629
27.17	WORLDVIEW system variable	630
27.17.1	World view	630
27.18	WRITESTAT system variable	630
27.18.1	Write status (Read Only)	630
27.19	WSAUTOSAVE system variable	631
27.19.1	Workspace autosave	631
27.20	WSCURRENT system variable	631
27.20.1	Current workspace	631
28.	X	632
28.1	XCLIPFRAME system variable	632
28.1.1	Xref clipping frame	632
28.2	XDWGFADECTL system variable	632
28.2.1	XRef database fade control	632
28.3	XEDIT system variable	632
28.3.1	XRef editable	632
28.4	XFADECTL system variable	633
28.4.1	Reference editing fade control	633
28.5	XLOADCTL system variable	633
28.5.1	XRef load control	633
28.6	XLOADPATH system variable	634
28.6.1	XRef load path	634
28.7	XNOTIFYTIME system variable	634
28.7.1	Xnotify time	634
28.8	XREFCTL system variable	634
28.8.1	XRef control	634
28.9	XREFNOTIFY system variable	635
28.9.1	XRef notify	635
28.10	XREFOVERRIDE system variable	635
28.10.1	XRef override	635
29.	Y	636
30.	Z	637
30.1	ZOOMFACTOR system variable	637
30.1.1	Zoom factor	637
30.2	ZOOMWHEEL system variable	637
30.2.1	Mouse wheel zoom direction	637



Contents



1. System variable reference

The System variable reference gives an overview of all the system variables in BricsCAD.

System variables and preferences variables are used to save BricsCAD settings and user preferences. They can be accessed through the Settings dialog box. Many system variables correspond to other CAD software. When a variable is BricsCAD specific, this is indicated as well.

Note: The AUTOCOMPLETEMODE system variable value defines whether system and/or preference variables are recognized when typing in the Command line.

1.1 System variable data types

- **Boolean:** the value is either 1 or 0 (True or False, Yes or No).
- **Short:** integer value in the range of -32,768 to +32,767.
- **Long:** integer value in the range of -2,147,483,648 to +2,147,483,647.
- **Real:** floating point numbers with a period for a decimal point and no thousands separator.
- **String:** text.
- **String Standard:** text according to a specific format, for example a folder path.
Note: String Standard system variables support multiple folder paths. Use semicolons (;) to separate the file paths.
- **3D point:** specifies a point in a 3D space.
- **2D point:** specifies a point in the XY-plane.
- **Bit flag variables:** integer variable controlled by bit codes. The value of this variable changes by adding or removing options.

Entity snap mode	0x0007 (7)
1	<input checked="" type="checkbox"/> Endpoint
2	<input checked="" type="checkbox"/> Midpoint
4	<input checked="" type="checkbox"/> Center
8	<input type="checkbox"/> Node
16	<input type="checkbox"/> Quadrant
32	<input type="checkbox"/> Intersection
64	<input type="checkbox"/> Insertion
128	<input type="checkbox"/> Perpendicular
256	<input type="checkbox"/> Tangent
512	<input type="checkbox"/> Nearest
1024	<input type="checkbox"/> Geometric center
2048	<input type="checkbox"/> Apparent intersection
4096	<input type="checkbox"/> Extension
8192	<input type="checkbox"/> Parallel
16384	<input type="checkbox"/> Turn off all snaps

1.2 System variables save location

- **Windows registry** (or **config** file for macOS and Linux): the value is saved in a user profile. When you start BricsCAD, the values of the current user profile are loaded. The values apply to all drawings in the current BricsCAD session. The current user profile is set in the **User Profile Manager** dialog box. Launch the PROFILEMANAGER command to open this dialog box.
- **Drawing:** the value is saved in the drawing and applies to that drawing only.



- **Preference:** the value is saved in a user profile. When you start BricsCAD the values of the current user profile are loaded. The values apply to all drawings in the current BricsCAD session.
- **NOT saved:** the default value is hard-coded, and the new value is not saved when BricsCAD is restarted.
- **Workspace:** the value is saved in the current workspace.

Note: The distinction between system and preference variable is strictly about whether the setting is marked as a system variable (`save="reg"`) or user preference (`save="prf"`) in `settings.xml`.

1.3 Editing system variables

The system variables have a default value which can be edited:

- Through the **Settings** dialog box.
- By typing it in the Command line.

In the **Settings** dialog box, you can also filter variables that are no longer set to their default value.

1.4 Searching for variables

You can use the `SETVAR` command to search for a variable.



2. —

2.1 _QUADTABFLAGS system variable

2.1.1 Quad tab flags

Temporary setting used while new Quad tab layout is implemented.

The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 31
Default value:	12
Possible options:	<ul style="list-style-type: none">1: Fixed width tabs2: Center tab labels4: Tab borders8: Double tab height16: Show 3D Solid mass properties

2.2 _VERNUM system variable

2.2.1 Version number (Read Only)

Shows the program version number.

Type:	String
Saved in:	Not saved



3. 2

3.1 2DCONSTRAINTFLAGS system variable

3.1.1 2D Constraint Flags

Controls behavior during solving 2D constraints.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Keeps directions of segments and arcs. 1: Disables segments.



4. 3

4.1 3DCOMPAREMODE system variable

4.1.1 Compare mode

Controls the visualization for the 3DCOMPARE command.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	3
Possible values:	0: First model on the left, second model on the right. 1: First model with differences on the left, second model on the right. 2: First model on the left, second model with differences on the right. 3: First model with differences on the left, second model with differences on the right. 4: Both models with all differences in one viewport. 5: Both models with all differences in one viewport. 6: Both models with all differences in one viewport. 7: Both models with all differences in one viewport.

4.2 3DOSMODE system variable

4.2.1 3D entity snap mode

Controls the 3D entity snap types.

Type:	Long
Saved in:	Registry
Range:	0 to 33023
Default value:	11



Possible values:	1: Turn off all 3D snaps 2: 3D Entity Vertices and Control Vertices of Splines 4: Midpoint of edge 8: Center of face 16: Spline Knot 32: Perpendicular to face 64: Nearest to face 128: Pointcloud nearest Point 32768: Intersection with face
------------------	--

4.3 3DSNAPMARKERCOLOR system variable

4.3.1 3d snap marker color

Controls the color of 3D snap markers. Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	5



5. A

5.1 ACADLSPASDOC system variable

5.1.1 on_start.lsp for each doc

Loads the on_start_default.lsp, on_start.lsp, on_doc_load.lsp and on_doc_load_default.lsp files, for every new drawing.

If off, only loads these files for the first drawing.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Do not load on_start.lsp with every drawing On (1): Load on_start.lsp with every drawing

5.2 ACADPREFIX system variable

5.2.1 Program folder path (Read only)

List of support paths, with path separators if necessary.

Type:	String
Saved in:	Not saved

5.3 ACADVER system variable

5.3.1 AutoCAD version (Read Only)

Shows the AutoCAD® compatible program version number.

Type:	String
Saved in:	Not saved

5.4 ACISHLRRESOLUTION system variable

5.4.1 Hidden line removal resolution

Controls the smallest distance used for Hidden Line Removal calculation.



Negative value is Auto-calibration based on the size of the model (recommended). For very small entities the value can be set to 0.001 or smaller.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	-1.0

5.5 ACISSAVEASMODE system variable

5.5.1 Acis save as mode

Controls the explode mode of ACIS entities (3DSolids, Bodies, Regions) when saved to R12.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible options:	0: Save meshes 1: Save edges only

5.6 ACISOUTVER system variable

5.6.1 Acisout version

Controls the ACIS version of the SAT files for the ACISOUT command.

Type:	Short
Saved in:	Not saved
Default value:	70

5.7 ADAPTIVEGRIDSTEPSIZE system variable

5.7.1 Adaptive grid step size

Controls the snap spacing for 'Adaptive Grid Snap' mode of SNAPTYPE system variable, in pixels. Also Controls the step size of the Manipulator ruler.



BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	4.0

5.8 AFLAGS system variable

5.8.1 Attribute options

Sets the default options for attribute creation.

Type:	Short
Saved in:	Not saved
Default value:	0
Possible options:	0: No mode selected 1: Invisible 2: Constant 4: Verify 8: Preset 16: Lock position 32: Multiline

5.9 ALIGNDIMENSIONONISOMETRIC system variable

5.9.1 Dimension alignment

Enables isometric dimensions. Dimensions are aligned to the geometry.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): Disable isometric dimensions On (1): Enable isometric dimensions



5.10 ALLOWBENDANGLES system variable

5.10.1 Allowed bend angles

Sets allowed bend angles for MEP elements.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	1
Possible values:	1: Any 2: 90 4: 60 8: 45 16: 30

5.11 ALLOWTABEXTERNALMOVE system variable

5.11.1 Move tabs externally (Mac & Linux)

Allows a tab to be moved to another tab control, in the documents tab.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't allow a tab to be moved externally On (1): Allow a tab to be moved externally

5.12 ALLOWTABMOVE system variable

5.12.1 Move tabs (Mac & Linux)

Allows a tab to be dragged horizontally, in the documents tab.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't allow tabs to be moved On (1): Allow tabs to be moved

5.13 ALLOWTABSSPLIT system variable

5.13.1 Split tabs (Mac & Linux)

Allows drag to split the tab control, in the documents tab.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't allow tabs to be split On (1): Allow tabs to be split

5.14 AMPOWERDIMDISPLAY system variable

5.14.1 Mechanical 2D Editor

Controls the opening the **Edit Dimensioning** dialog box after placing a power dimension.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	0: On demand only 1: For the first dimension only 2: Always



5.15 AMSYMSCALE system variable

5.15.1 Mechanical2D annotation scaling

Controls the display of Mechanical2D symbols and text in Model Space.

Type:	Real
Saved in:	Drawing
Default value:	1.0

Note: The minimum value is 1.0E-100.

5.16 ANGBASE system variable

5.16.1 Angle base

Controls the start location of angle 0.

Type:	Real
Saved in:	Drawing
Default value:	0.0

5.17 ANGDIR system variable

5.17.1 Angle direction

Toggles the angle direction clockwise/Counterclockwise.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Counter-clockwise On (1): Clockwise



5.18 ANNOALLVISIBLE system variable

5.18.1 Annotation visibility

Hides or displays annotative entities that do not support the current annotation scale. The setting is saved individually for model space and each layout.

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	0: Only annotative entities that support the current scale representation are displayed 1: All annotative entities are displayed

5.19 ANNOAUTOSCALE system variable

5.19.1 Annotation scaling

Synchronizes new annotative entities with the current annotation scale.

Type:	Short
Saved in:	Registry
Default value:	-4
Possible values:	0: Do not add to annotative entities. 1: Add to annotative entities that support it, except entities on locked, turned off, frozen or viewport-frozen layers. 2: Add to annotative entities that support it, except entities on turned off, frozen or viewport-frozen layers. 3: Add to annotative entities that support it, except entities on locked layers. 4: Add all annotative entities supporting it. -1: Do not add to annotative entities (toggled value 1). -2: Do not add to annotative entities (toggled value 2). -3: Do not add to annotative entities (toggled value 3). -4: Do not add to annotative entities (toggled value 4).



5.20 ANNOMONITOR system variable

5.20.1 Annotation monitor

Turns the annotation monitor on or off. When ON, a warning sign is displayed near the disassociated dimension.

Type:	Short
Saved in:	Drawing
Default value:	-2
Possible values:	<p>-2: Annotation monitor is Off, any Model Documentation edit and update events automatically changes the value to 2. The status bar control toggles between 2 and -2.</p> <p>-1: Annotation monitor is Off. The status bar control toggles between 1 and -1.</p> <p>0: Annotation monitor is Off.</p> <p>1: Annotation monitor is On. The status bar control toggles between 1 and -1.</p> <p>2: Annotation monitor is On. The status bar control toggles between 2 and -2.</p>

5.21 ANNOTATEDWG system variable

5.21.1 Annotative drawing

Creates an annotative block when this drawing is inserted into another drawing.

Note: The ANNOTATEDWG system variable becomes read-only if the drawing contains annotative entities

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Not annotative On (1): Annotative



5.22 ANTIALIASRENDER system variable

5.22.1 Anti-alias amount for render

Controls the smoothness of the output of the RENDER command.

For values higher than 1, an anti-aliased output is calculated, at a cost, this increases with bigger values.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 5
Default value:	2
Possible values:	1: 1x1 (no anti-aliasing) 2: 2x2 3: 3x3 4: 4x4 5: 5x5 (maximum anti-aliasing)

5.23 ANTALIASSCREEN system variable

5.23.1 Anti-alias amount for screen

Controls the smoothness of on-screen curve display.

CAUTION: When the visual style is set to 2DWireframe and the value is higher than 1, calculation of an anti-aliased display comes at a high performance cost. For the other display modes the calculation time is increased, but with lesser impact.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 5
Default value:	1



Possible values:	1: 1x1 (no anti-aliasing) 2: 2x2 3: 3x3 4: 4x4 5: 5x5 (maximum anti-aliasing)
------------------	---

5.24 APBOX system variable

5.24.1 Entity snap aperture box

Displays the Entity Snap aperture box, at the cursor, during a pick action. Entity snaps are activated when the aperture box passes over an entity. See also the APERTURE system variable.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Does not display the aperture box. On (1): Displays the aperture box.


5.25 APERTURE system variable

5.25.1 Entity snap sensitivity

Controls the Aperture Box size, in pixels. Entity snaps are activated when the aperture box passes over an entity. To display the aperture box switch on the APBOX system variable.

Values between 1 and 50 are accepted.

Type:	Short
Saved in:	Registry
Range:	1 to 50
Default value:	10



5.26 AREA system variable

5.26.1 Area (Read Only)

The last calculated area by the AREA, LIST or DBLIST commands.

Type:	Real
Saved in:	Not saved

5.27 AREAPREC system variable

5.27.1 Area precision

Controls the number of decimal places displayed for areas, if area properties are formatted with the PROPUNITS system variable.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	-1
Possible values:	<ul style="list-style-type: none">-1: Use the LUPREC system variable0: 01: 0.02: 0.003: 0.0004: 0.00005: 0.000006: 0.0000007: 0.00000008: 0.00000000



5.28 AREAUNITS system variable

5.28.1 Area units

Controls a list of units used to display areas, if area properties are formatted with the PROPUNITS system variable. If empty, all areas match the drawing.

Note: The string contains a space-separated list of unit abbreviations.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	in ft mi µm mm cm m km

5.29 ARRAYASSOCIATIVITY system variable

5.29.1 Associative arrays

Creates new arrays as associative arrays.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Not associative On (1): Associative

5.30 ARRAIEDITSTATE system variable

5.30.1 Array edit state (Read Only)

Displays if an associative array's source entity is currently being edited.

Type:	Boolean
Saved in:	Not saved
Default value:	Off



5.31 ARRAYTYPE system variable

5.31.1 Array type

Controls the default associative array type. See also the ARRAYASSOCIATIVITY system variable.

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Rectangular array 1: Path array 2: Polar array

5.32 ATTDIA system variable

5.32.1 Attribute dialog

Shows a dialog box for attribute values for the INSERT command.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't use dialog box On (1): Use dialog box

5.33 ATTFULLUPDATE system variable

5.33.1 Reset attributes when editing a block parameter

Adjusts the behavior of parametric blocks' attributes.

If on, when changing a parameter of a block reference causes the underlying block to be cloned, the values of all attributes of the block reference will be reset to the values in the original block.

If off, only the missing attributes will be copied from the original block.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Only the missing attributes will be copied from the original block. On (1): The values of all attributes of the block reference will be reset to the values in the original block.

5.34 ATTMODE system variable

5.34.1 Attribute display mode

Controls the display of attributes.

Note: If the ATTMODE variable is set to 2, all attributes display, including Hidden attributes.

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	0: Don't show 1: As defined in block 2: Show all

5.35 ATTRACTONDISTANCE system variable

5.35.1 Grips attraction distance

Sets the grip attraction distance. See also the ENABLEATTRACTION system variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	4

5.36 ATTREQ system variable

5.36.1 Insertion default settings

Controls attribute settings for a block inserted with the INSERT command.

If off, uses default values. If on, uses a prompt.



Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): Use default values On (1): Prompt user

5.37 AUDITCTL system variable

5.37.1 Audit control

Creates an audit report (ADT) file when the AUDIT command is used.

When you turn on the AUDITCTL settings variable, AUDIT creates an ASCII file describing problems and the action taken. This report, with the file extension ADT, is placed in the same directory as the current drawing.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't write ADT files On (1): Write ADT files

5.38 AUDITERRORCOUNT system variable

5.38.1 Audit Error Count (Read Only)

The number of errors found in the last audit (AUDIT command).

Type:	Short
Saved in:	Not saved

5.39 AUNITS system variable

5.39.1 Angular unit type

Controls the unit type for angles.



Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Decimal degrees 1: Degrees/minutes/seconds 2: Gradians 3: Radians 4: Surveyor's units

5.40 AUPREC system variable

5.40.1 Angular unit precision

Controls the number of decimal places for angular units.

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: 0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000 8: 0.00000000

5.41 AUTOCOMPLETEDELAY system variable

5.41.1 Auto complete delay

Controls the delay before features display at the Command line. See also the AUTOCOMPLETEMODE system variable.

Values between 0.0 and 10.0 are accepted.

Type:	Real
-------	------



Saved in:	Registry
Default value:	0.3

5.42 AUTOCOMPLETEMODE system variable

5.42.1 Auto complete mode

Controls the types features shown at the Command line.

Type:	Short
Saved in:	Registry
Range:	0 to 63
Default value:	47
Possible options:	<ul style="list-style-type: none">1: Enable2: Auto-Append4: Suggestion List8: Display Icons (unsupported)16: Exclude the display of System Variables32: Display preference variables

5.43 AUTOMATICCONNECTION system variable

5.43.1 Automatic connection

Controls automatic creation of connections for the BIMLINEARSOLID and BIMAPPLYPROFILE commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): Disable On (1): Enable



5.44 AUTOMATICSTAIRSECTIONBEHAVIOR system variable

5.44.1 Automatic stair section behavior

Controls the generation of 2D representations of BIM stair entities during a section generation.

Affects only the automatic stair sectioning behavior. See the BIMGENERATE2DSTAIR command.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Symbolic 1: Geometric

If set to **Symbolic**, a symbolic representation of entities classified as **Stairs** will be generated during section generation. This will affect only the automatic stair sectioning behavior. To customize, launch the BIMGENERATE2DSTAIR command before sectioning.

5.45 AUTOMATICTEES system variable

5.45.1 Automatic tees

Controls the automatic creation of T type connections during the BIMFLOWCONNECT command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Disable On (1): Enable

5.46 AUTORESETSCALES system variable

5.46.1 Purge unused scales

Controls how unused annotation scales are managed, when a drawing containing a large number of scales is loaded. A large number of annotation scales decreases performance.

BricsCAD only



Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Show a dialog box before purging unused annotation scales 1: Automatically purge unneeded scales 2: Don't purge scales and don't show dialog box when drawing contains a large number of scales

5.47 AUTOSAVECHECKSONLYFIRSTBITDBMOD system variable

5.47.1 Ignore all but first bit of DBMOD for autosave

Does not create autosave files for drawings, when they have been viewed but not edited (includes zoom and pan actions).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Autosave file for files that are viewed only On (1): No autosave file for files that are viewed only

5.48 AUTOSNAP system variable

5.48.1 AutoSnap

Toggles polar and entity snap tracking and controls the display of a snap marker, tooltips and magnet.

Type:	Short
Saved in:	Registry
Range:	0 to 127
Default value:	127



Possible options:	0: All off 1: AutoSnap marker 2: AutoSnap tooltips 4: AutoSnap magnet 8: Polar tracking 16: Entity snap tracking 32: Tooltips for polar tracking and entity snap tracking 64: Tracking line from LASTPOINT
-------------------	---

5.49 AUTOTRACKINGVECCOLOR system variable

5.49.1 Auto tracking vector color

Controls the color of polar/snap tracking markers.

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	171

5.50 AUTOVPFITTING system variable

5.50.1 Automatically resize viewports

Controls if viewport borders automatically adjust to fit, when a viewport is updated.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't fit viewport borders automatically On (1): Fit viewport borders automatically



6. B

6.1 BACKGROUNDPLOT system variable

6.1.1 Background plotting

Controls if background plotting is enabled for plot and/or publish actions.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	2
Possible options:	0: None 1: When plotting (Not yet supported) 2: When publishing

6.2 BACKZ system variable

6.2.1 Back clipping plane offset

The value of the **Clipping** option of the DVIEW command.

Type:	Real
Saved in:	Drawing
Default value:	0.0

6.3 BASEFILE system variable

6.3.1 Template

The file path and default template file name for new drawings. If empty, uses built-in defaults.

BricsCAD only

Type:	String
Saved in:	Registry



6.4 BCFSOURCEURL system variable

6.4.1 BCF source url

The address (URL) of the BCF source.

BricsCAD only

Type:	String
Saved in:	Registry

6.5 BEDITASSOCMODE system variable

6.5.1 Associative identifiers in BEDIT

Controls if additional service data is generated during the BEDIT command.

This enables the automatic re-association of constraints and dimensions attached to the references of the block, including references in other documents.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible options:	0: Do not initialize identifiers in BEDIT 1: Initialize identifiers in BEDIT

6.6 BILLOFMATERIALSSETTINGS system variable

6.6.1 Bill of materials defaults

Sets the default options for BOMs (Bill Of Materials).

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	10



Possible values:	1: Add thumbnails to new bill of materials 2: Automatically update thumbnails 4: Display warning messages 8: Allow multiple inserts of the same table
------------------	--

6.7 BIMDEFAULTPROPERTIESPATH system variable

6.7.1 Default properties path

The file paths for properties, loaded when a new document is opened.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	bimproj_user.xml;bimproj_IFC.xml;bimproj_quantity.xml

6.8 BIMMATCHPROP system variable

6.8.1 Match BIM Properties

Matches BIM properties during the MATCHPROP command.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Match standard properties 1: Match standard and BIM properties

6.9 BIMOSMODE system variable

6.9.1 BIM snap mode

Overrules the OSMODE and 3DOSMODE system variables for BIM entities.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	0: Entity snap modes are not overruled for BIM entities 1: Axis of linear solid 2: Axis of BIM grid

6.10 BIMPROFILESTANDARDS system variable

6.10.1 Profile's standards

Controls the profiles standards used in the **Profiles** dialog box and panel.

Separate entries with semicolons (;).

BricsCAD only

Type:	String
Saved in:	Registry

6.11 BINDTYPE system variable

6.11.1 Xref bind type

Controls how XRefs names are handled when XRefs are bound or edited in place.

If on, uses insert-like behavior. If off, uses traditional bind behavior.

Type:	Boolean
Saved in:	Not saved
Default value:	0
Possible values:	Off (0): Traditional binding behavior On (1): Insert-like behavior

- If the BINDTYPE system variable = 1 (Insert-like behavior): Xrefs will be converted into blocks.



- If BINDTYPE system variable = 0 (Traditional binding behavior): it binds the xref and makes the xref part of the drawing (the objects/layers from the external drawing will be added to the current drawing with the prefix equal to the file name).

6.12 BKGCOLOR system variable

6.12.1 Background color

Controls the background color of the drawing window in model space.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	RGB:24,25,28

6.13 BKGCOLORPS system variable

6.13.1 Paper space background color

Controls the background color of the drawing window in paper space.

BricsCAD only


Type:	String
Saved in:	Registry
Default value:	RGB:250,250,250

6.14 BLIPMODE system variable

6.14.1 Blip mode

Determines whether or not marker blips are displayed.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't display marker blips On (1): Display marker blips



6.15 BLOCKEDITLOCK system variable

6.15.1 Block editor lock

Disables the **Block Editor** (BEdit mode). Blocks cannot be edited.

Type:	Boolean
Saved in:	Registry
Default value:	Off

6.16 BLOCKEDITOR system variable

6.16.1 Block editor (Read Only)

Shows if the **Block Editor** (BEdit mode) is open or not.

Type:	Boolean
Saved in:	Not saved

6.17 BLOCKIFYMODE system variable

6.17.1 Blockify settings

Controls the behavior of the BLOCKIFY and PARAMETRICBLOCKIFY commands.

BricsCAD only

Type:	Short
Saved in:	Registry



Range:	16 to 503
Default value:	215
Possible options:	<ul style="list-style-type: none">1: Use entire drawing as search space2: Use default block insertion point4: Use default block name32: Compare geometry only64: Convert unique solids to blocks128: Show preview256: Use parametrization

6.18 BLOCKIFYTOLERANCE system variable

6.18.1 Blockify tolerance

Controls the relative tolerance used in the BLOCKIFY and PARAMETRICBLOCKIFY commands to determine if two entities are equal.

A negative value means the program will determine the optimal tolerance (recommended).

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	-1.0

6.19 BLOCKLEVELOFDETAIL system variable

6.19.1 Block Level of detail

Controls the block level of detail (LOD).

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	<ul style="list-style-type: none">0: Low1: High



Note: The low level of detail representation is a bounding box.

6.20 BLOCKSPATH system variable

6.20.1 Blocks path

Specifies the file path used for the fifth folder on the left side of the **Select Drawing File** dialog box, opened with the INSERT command when the **Browse** option is selected.

BricsCAD only

Type:	String Standard
Saved in:	Preference

6.21 BMAUTOUPDATE system variable

6.21.1 Update external components

Controls when external assembly components are reloaded to reflect the changes in their definition files.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	1
Possible values:	0: Only when BMUPDATE command is issued 1: Automatically when the file is opened

6.22 BMEXTERNALIZEILLEGALSYMBOLS system variable

6.22.1 Illegal symbols treatment

Defines treatment of symbols that are not allowed in file names.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	3



Possible values:	1: Remove 2: Replace with underscore (_) 3: Replace with escape sequences
------------------	---

6.23 BMFORMTEMPLATEPATH system variable

6.23.1 BMFORM template path

The file path and name of the default BMFORM command Template file.

BricsCAD only

Type:	String
Saved in:	Preference

6.24 BMTOOLPATH system variable

6.24.1 Assembly Inspect tool search paths

The file paths used for searching tool files in Assembly Inspect.

Separate file paths with semicolons (;). If left empty, it defaults to the installed Design library Tools folder.

BricsCAD only

Type:	String Standard
Saved in:	Registry
Default value:	C:\Program Files\Bricsys\BricsCAD V25 en_US\UserDataCache\Support\en_US\DesignLibrary\Tools\

6.25 BMUPDATEMODE system variable

6.25.1 Assembly components update mode

Controls if external assembly components are reloaded if they are modified, or unconditionally.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0



Possible values:	0: Update only modified components (faster) 1: Update all components (slower, but repairs assembly structure)
------------------	--

6.26 BOLTINGASMDEFAULTLENGTHINCREMENT system variable

6.26.1 Default length increment

Controls the default length increment for the default stud, see the BOLTINGASMDEFAULTSTUD system variable.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	25.4

Note:

- If INSUNITS=inches (1), the default value of BOLTINGASMDEFAULTLENGTHINCREMENT is 1.0.
- If INSUNITS=millimeters (4), the default value of BOLTINGASMDEFAULTLENGTHINCREMENT is 25.4.

6.27 BOLTINGASMDEFAULTNUT system variable

6.27.1 Default nut

Controls the default nut used to generate bolt assemblies.

BricsCAD only

Type:	String
Saved in:	Drawing
Default value:	ASME B18.2.2 Heavy Hex Nut

6.28 BOLTINGASMDEFAULTNUTSNUMBER system variable

6.28.1 Default nuts number

Controls the default nuts number used to generate bolt assemblies.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Drawing
Range:	2 to 4
Default value:	4
Possible values:	2: 2 3: 3 4: 4

6.29 BOLTINGASMDEFAULTSTUD system variable

6.29.1 Default stud

Controls the default stud used to generate bolt assemblies.

BricsCAD only

Type:	String
Saved in:	Drawing
Default value:	ASME B18.31.2 Continuous Thread Flange Bolting Stud

6.30 BOMFILTERSETTINGS system variable

6.30.1 Default BOM filter settings

Sets the default filter settings, defines which objects to include.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 127
Default value:	1



Possible values:	1: Include mechanical components, blocks and solids 2: Include non-mechanical local blocks and solids 4: Include non-mechanical external references 8: Include solid plies 16: Ignore BOM status 32: Treat external references as transparent 64: Treat leaf parts as transparent
------------------	---

Note: If the file does not contain any mechanical components and the mode does not require to include any non-mechanical entities, then it will be extended to include all non-mechanical entities.

6.31 BOMPROPERTYSET system variable

6.31.1 Default BOM property set

Sets the default set of properties for BOM tables.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	1: Mechanical-only properties 2: All properties except coordinates 3: All properties

Note: If the BOM filter mode requires to include non-mechanical objects (BOMFILTERSETTINGS = 2 / 4 / 6), then the property set will be automatically extended to include all properties except coordinates (BOMPROPERTYSET=2).

6.32 BOMTEMPLATE system variable

6.32.1 Default template

Controls the file path for the default BOM template.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
Default value:	" "

6.33 BOMTHUMBNAILHEIGHT system variable

6.33.1 Default thumbnail height, px

Sets the default thumbnail height for BOM (Bill Of Material) tables, in pixels.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	200

6.34 BOMTHUMBNAILWIDTH system variable

6.34.1 Default thumbnail width, px

Sets the default thumbnail width for BOM tables, in pixels.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	200

6.35 BOUNDARYCOLOR system variable

6.35.1 Detected Boundary Color

Controls the color used to detect boundaries.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255



Default value:	95
----------------	----

6.36 BSYSLIBCOPYOVERWRITE system variable

6.36.1 Bsystlib copy overwrite

Controls how materials or compositions with a name that already exists in the target drawing are copied.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	0
Possible values:	0: Prompt 1: Skip 2: Overwrite 3: Rename

6.37 BVMODE system variable

6.37.1 Block Visibility Mode (Read Only)

Controls how hidden entities are displayed in **Block Editor**.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Hidden entities are invisible 1: Hidden entities are visible but dimmed



7. C

7.1 CACHELAYOUT system variable

7.1.1 Cache layout

Caches layouts - reduces the time needed to switch between layouts.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't cache layout On (1): Cache layout

7.2 CAMERADISPLAY system variable

7.2.1 Camera display

Displays a visual representation of a camera for all camera locations.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display camera glyphs On (1): Display camera glyphs

7.3 CAMERAHEIGHT system variable

7.3.1 Camera height

Controls the default height, in drawing units, for new cameras.

Type:	Real
Saved in:	Drawing
Default value:	0.0



7.4 CANNOSCALE system variable

7.4.1 Annotation scale name

Controls the name of the current annotation scale for the current space.

Type:	String
Saved in:	Drawing
Default value:	1:1

7.5 CANNOSCALEVALUE system variable

7.5.1 Annotation scale value (Read Only)

Displays the value of the current annotation scale.

Type:	Real
Saved in:	Drawing
Default value:	1.0

7.6 CDATE system variable

7.6.1 Calendar date (Read Only)

Shows the current date and time, in decimal format.

Type:	Real
Saved in:	Not saved

7.7 CECOLOR system variable

7.7.1 Entity color

Sets the color for new entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer



7.8 CELTSCALE system variable

7.8.1 Entity linetype scale

Sets the current entity linetype scale multiplier.

Type:	Real
Saved in:	Drawing
Range:	Greater than 0
Default value:	1.0

7.9 CELTYPE system variable

7.9.1 Entity linetype

Sets the linetype for new entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer

7.10 CELWEIGHT system variable

7.10.1 Entity linewidth

Sets the linewidth of new entities.

Type:	Short
Saved in:	Drawing
Range:	-3 to 211
Default value:	-1
Possible values:	-3: Lineweight Default (defined by LWDEFAULT) -2: Lineweight ByBlock -1: Lineweight ByLayer 0 - 211: Lineweight value in hundredths of millimeters




7.11 CENTERCROSSGAP system variable

7.11.1 Center mark cross gap

Controls the gap between the center mark and its centerlines.

Type:	String
Saved in:	Drawing
Default value:	0.05x




7.12 CENTERCROSSSIZE system variable

7.12.1 Center mark cross size

Controls the size of an associative center mark.

Type:	String
Saved in:	Drawing
Default value:	0.1x




7.13 CENTEREXE system variable

7.13.1 Centerline extension length

Controls the extension length of a centerline.

Type:	Real
Saved in:	Drawing
Default value:	0.12: If MEASUREMENT=0 and INSUNITS=inches 3.5: If MEASUREMENT=1 and INSUNITS=millimeters

Note: The value is expressed in drawing units.



7.14 CENTERLAYER system variable

7.14.1 Default layer for center mark or centerline

Controls a default layer for new centermarks or centerlines.



Type:	String
Saved in:	Drawing
Default value:	.

7.15 CENTERLTSIZE system variable

7.15.1 Linetype scale for center mark or centerline

Controls the linetype scale used to create center marks and centerlines.

Type:	Real
Saved in:	Drawing
Default value:	1.0

7.16 CENTERLTYPE system variable

7.16.1 Center mark/centerline linetype

Controls the linetype used by center marks and centerlines.

Type:	String
Saved in:	Drawing
Default value:	CENTER2

7.17 CENTERLTYPEFILE system variable

7.17.1 Linetype file for center mark or centerline

Controls the linetype file used to create center marks and centerlines.



Type:	String
Saved in:	Drawing
Default value:	<ul style="list-style-type: none">• Default in imperial unit drawings: default.lin.• Default in metric unit drawings: iso.lin.



7.18 CENTERMARKEXE system variable

7.18.1 Automatic extension for center mark or centerline

Automatically extends centerlines for new center marks and centerlines.



Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): No automatic extension On (1): Automatic extension

7.19 CETRANSPARENCY system variable

7.19.1 Transparency

Sets the transparency for new entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer
Possible values:	ByLayer: Apply the layer's transparency ByBlock: Apply the block's transparency 0: Apply no transparency (fully opaque) 1-90: Apply transparency percentage from least (1) to most (90) transparent



7.20 CHAMFERA system variable

7.20.1 Chamfer first distance

Controls the first chamfer distance when the CHAMMODE system variable is Distance-Distance.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.21 CHAMFERB system variable

7.21.1 Chamfer second distance

Controls the second chamfer distance when the CHAMMODE system variable is Distance-Distance.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.22 CHAMFERC system variable

7.22.1 Chamfer length

Controls the chamfer length when the CHAMMODE system variable is Length-Angle.

Type:	Real
Saved in:	Drawing
Default value:	0.0

7.23 CHAMFERD system variable

7.23.1 Chamfer angle

Controls the chamfer angle when the CHAMMODE system variable is Length-Angle.

Type:	Real
-------	------




Saved in:	Drawing
Default value:	0.0

7.24 CHAMMODE system variable

7.24.1 Chamfer mode

Controls the default chamfer creation method.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Distance-Distance 1: Length-Angle



7.25 CHECKDWLPRESENCE system variable

7.25.1 Check DWL file existence before open

Warn if there is a DWL lock file when a drawing is opened, indicates that another user has the drawing open.

The content of the lock files allows to inform other users trying to open that drawing, that it is in use, since when, and by whom. This is typically useful for drawings on a shared folder that can be accessed by multiple users from different operating systems.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	Off (Windows) On (Mac & Linux)
Possible values:	Off (0): Don't check DWL file existence before opening a drawing On (1): Check DWL file existence before opening a drawing

7.26 CIRCLERAD system variable

7.26.1 Circle radius

Controls the default circle radius.

A value of zero means no default.

Type:	Real
Saved in:	Not saved
Default value:	0.0

7.27 CIRCULARARROWHEADLENGTH system variable

7.27.1 Default head length

Sets the default head length of circular arrows.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1 - if INSUNITS=1 (inches) 25 - if INSUNITS=4 (millimeters) 2.5 - if INSUNITS=5 (centimeters) 0.025 - if INSUNITS=6 (meters)

7.28 CIRCULARARROWHEADWIDTH system variable

7.28.1 Default head width

Sets the default head width of circular arrows.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	1.5 - if INSUNITS=1 (inches) 37.5 - if INSUNITS=4 (millimeters) 3.75 - if INSUNITS=5 (centimeters) 0.0375 - if INSUNITS=6 (meters)

7.29 CIRCULARARROWLEADERRADIUS system variable

7.29.1 Default leader radius

Sets the default leader radius of circular arrows.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	2 - if INSUNITS=1 (inches) 50 - if INSUNITS=4 (millimeters) 5 - if INSUNITS=5 (centimeters) 0.05 - if INSUNITS=6 (meters)

7.30 CIRCULARARROWLEADERROTATION system variable

7.30.1 Default leader rotation

Sets the default leader rotation of circular arrows.

Values between 20.0 and 320.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	90



7.31 CIRCULARARROWTHICKNESS system variable

7.31.1 Default thickness

Sets the default thickness of circular arrows.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.5 - if INSUNITS=1 (inches) 12.5 - if INSUNITS=4 (millimeters) 1.25 - if INSUNITS=5 (centimeters) 0.0125 - if INSUNITS=6 (meters)

7.32 CLAYER system variable

7.32.1 Current layer

Sets the layer for new entities.

Type:	String
Saved in:	Drawing
Default value:	0

7.33 CLEANSCREENOPTIONS system variable

7.33.1 Clean screen options

Controls which UI elements are hidden by the CLEANSCREENON command.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 127
Default value:	15



Possible options:	1: Hide document tabs 2: Hide dockable panels 4: Hide toolbars 8: Hide Ribbon 16: Hide Command line 32: Hide Status bar 64: Hide menu bar
-------------------	---

7.34 CLEANSCREENSTATE system variable

7.34.1 Clean screen state (Read Only)

Indicates if clean screen state is active. Use the CLEANSCREENON and CLEANSCREENOFF commands.

Activating the clean screen state makes the drawing area larger by hiding elements of the user interface.

Type:	Boolean
Saved in:	Not saved
Default value:	Off

7.35 CLIPBOARDFORMAT system variable

7.35.1 Clipboard DWG format

Controls the drawing format version used to copy to the clipboard.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	4
Possible values:	1: DWG 2018 4: DWG 2013 7: DWG 2010 10: DWG 2007 13: DWG 2004 16: DWG 2000 19: DWG R14 22: DWG R13 25: DWG R11/R12



7.36 CLIPBOARDFORMATS system variable

7.36.1 Clipboard Formats

Controls the types of data that can be copied to the clipboard.

Reduce the number of data types to improve performance.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 127
Default value:	127
Possible options:	<p>1: Bitmap 2: Metafile Picture Format 4: Enhanced Metafile 8: AutoCAD 16: Native 32: OLE Embed Source and Object Descriptor 64: CVS and XMLSS table data</p>

7.37 CLIPROMPTLINES system variable

7.37.1 Prompt Lines

Controls the maximum number of floating lines of text momentarily displayed above the Command line.

Applies only if the Command line is hidden, or floating with the CMDLINEUSEMINIFRAME system variable set to on (1).

Values between 0 and 64 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 64
Default value:	4



7.38 CLISTATE system variable

7.38.1 Command line state (Read Only)

Command line status.

Type:	Boolean
Saved in:	Not saved
Default value:	1
Possible values:	Off (0): Command line is invisible On (1): Command line is visible

7.39 CLOSECHECKSONLYFIRSTBITDBMOD system variable

7.39.1 Ignore all but first bit of DBMOD for close

If on, does not ask to save drawings, when they have been viewed but not edited (includes zoom and pan actions).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't close drawing without getting a request to save the file. On (1): Close drawing without getting a request to save the file.

7.40 CLOUDDOWNLOADPATH system variable

7.40.1 Cloud download path

The folder path for files downloaded through the **Bricsys 24/7 Panel**.

BricsCAD only

Type:	String Standard
Saved in:	Registry
Default value:	{User}Documents/Bricsys247



7.41 CLOUDLOG system variable

7.41.1 Cloud log

Controls if data exchanged with Bricsys 24/7 is logged or not. If set to "Log file" a log file will be written in the folder set in the LOGFILEPATH system variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: No log 1: Log messages 2: Log file

7.42 CLOUDLOGVERBOSE system variable

7.42.1 Cloud log verbose

Creates a verbose log for Bricsys 24/7.

If switched on, more information is logged and Bricsys 24/7 actions will be slower.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Verbose log off On (1): Verbose log on

7.43 CLOUDONMODIFIED system variable

7.43.1 Cloud on modified

Specifies what to do when a file opened from Bricsys 24/7 is modified and saved locally.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	1
Possible values:	0: Do nothing 1: Prompt 2: Always upload to new revision 3: Always save locally under new name

7.44 CLOUDSERVER system variable

7.44.1 Cloud server

The address of the Bricsys 24/7 server.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	https://my.bricsys247.com/

7.45 CLOUDSSOCLIENTID system variable

7.45.1 Cloud SSO Client ID

The client_id used to connect to the SSO service.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	bricscad



7.46 CLOUDSSOSCOPE system variable

7.46.1 Cloud SSO Scope

Controls scopes or permissions used to connect to the SSO service.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	openid profile email

7.47 CLOUDTEMPFOLDER system variable

7.47.1 Cloud temporary folder

The file path for temporary Bricsys 24/7 files.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	{User}AppData/Local/Temp/Bricsys_24_7

7.48 CLOUDUPLOADDEPENDENCIES system variable

7.48.1 Cloud upload dependencies

Controls what to do with dependencies, such as XRefs, when a drawing is uploaded to Bricsys 24/7.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Upload drawing only (ignore dependencies) 1: Use eTransmit dialog if the drawing contains external references 2: Always use eTransmit dialog



7.49 CMATERIAL system variable

7.49.1 Current material

Controls the default render material for new entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer

7.50 CMDACTIVE system variable

7.50.1 Active command (Read Only)

Indicates the type of the current command.

Type:	Short
Saved in:	Not saved
Default value:	1
Possible options:	1: Ordinary command is active 2: Ordinary command and a transparent command are active 4: Script is active 8: Dialog box is active 16: DDE is active 32: lisp is active (only visible to an ObjectARX-defined command) 64: ObjectARX command is active

7.51 CMDDIA system variable

7.51.1 Command dialogs

Controls if dialog boxes are shown for commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't use dialog box for commands On (1): Use dialog box for commands
------------------	---

7.52 CMDECHO system variable

7.52.1 Command echo

Displays prompts and input during a LISP 'command' function.

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Echoing off On (1): Echoing on

7.53 CMDLINEEDITBGCOLOR system variable

7.53.1 Command line edit background color

The Command line edit field background color.

Color may be represented as a name (for standard colors) or as RGB values. At the Command line, color may be entered as a name (for standard colors), RGB values, or HTML color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB: 50 54 56 (Settings dialog) #323638 (Command line)

7.54 CMDLINEEDITFGCOLOR system variable

7.54.1 Command line edit foreground color

The Command line edit field foreground color.

Color may be represented as a name (for standard colors) or as RGB values. At the Command line, color may be entered as a name (for standard colors), RGB values, or HTML color.

BricsCAD only



Type:	String
Saved in:	Preference
Default value:	White (Settings dialog) #FFFFFF (Command line)

7.55 CMDFADINGLOGBGCOLOR system variable

7.55.1 Command line fade log background color

The Command line fade log background color.

Color may be represented as a name (for standard colors) or as RGB values. At the Command line, color may be entered as a name (for standard colors), RGB values, or HTML color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB: 50 54 56 (Settings dialog) #323638 (Command line)

7.56 CMDFADINGLOGFADEDELAY system variable

7.56.1 Command line fading log fade delay

The delay before Command line's log starts to fade.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 10.0
Default value:	2.0

7.57 CMDFADINGLOGFGCOLOR system variable

7.57.1 Command line fade log foreground color

The Command line fade log foreground color.



BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White

7.58 CMDLINEFADINGLOGTRANSPARENCY system variable

7.58.1 Command line fade log transparency

Controls the Command line fade log transparency.

Values between 0 and 100 are accepted. A value of zero means fully opaque, 100 is fully transparent.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	30

7.59 CMDLINEFONTNAME system variable

7.59.1 Command line font name

The Command line font.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	Consolas

7.60 CMDLINEFONTSIZE system variable

7.60.1 Command line font size

The Command line font size.

Values between 1 and 10 are accepted.



BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	10

7.61 CMDLINEFRAMEACTIVETRANSPARENCY system variable

7.61.1 Command line frame transparency when active

Controls Command line frame transparency when active. Values between 0 and 100 are accepted.

A value of zero means fully opaque, 100 if fully transparent.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	10

7.62 CMDLINEFRAMEINACTIVETRANSAPRENCY system variable

7.62.1 Command line frame transparency when inactive

Controls the Command line frame transparency when inactive.

Values between 0 and 100 are accepted. A value of zero means fully opaque, 100 is fully transparent.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	30



7.63 CMDLINEFRAMEUSETEXTSCR system variable

7.63.1 Command line frame TEXTSCR

When the Command line is floating, controls the effect of TEXTSCR command, also impacts log prompt delay. If on, displays a separate window, the same as in the docked state. If off, displays as a mini-frame.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't display (TEXTSCR) history window in a separate floating frame On (1): Display (TEXTSCR) history window in a separate floating frame

7.64 CMDLINELISTBGCOLOR system variable

7.64.1 Command line list background color

The Command line history list background color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:130,130,130

7.65 CMDLINELISTFGCOLOR system variable

7.65.1 Command line list foreground color

The Command line history list foreground color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White



7.66 CMDLINEOPTIONBGCOLOR system variable

7.66.1 Command line option background color

The Command line options background color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:121,132,142

7.67 CMDLINEOPTIONSHORTCUTCOLOR system variable

7.67.1 Command line option shortcut color

The Command line option shortcut color.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:255,187,0

7.68 CMDLINEUSEMINIFRAME system variable

7.68.1 Command line mini floating frame

Controls if the mini-frame is used when the Command line floats.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't use new mini-frame On (1): Use new mini-frame

Note: The CMDLINEUSEMINIFRAME system variable replaces the CMDLINEUSENEWFRAME system variable.



7.69 CMDLNTEXT system variable

7.69.1 Prompt prefix

Controls the prefix text shown in the Command line when no command is active.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	:

7.70 CMDNAMES system variable

7.70.1 Active Command Name (Read Only)

The names of any active or transparent commands.

Type:	String
Saved in:	Not saved

7.71 CMLEADERSTYLE system variable

7.71.1 Multileader style

Controls the multileader style for entities created with the MLEADER command.

Type:	String
Saved in:	Drawing
Default value:	Standard

7.72 CMLJUST system variable

7.72.1 Multiline justification

Controls the justification of multilines relative to the cursor, for the MLINE command.

Type:	Short
Saved in:	Drawing



Range:	0 to 2
Default value:	0
Possible values:	0: Top (second line created below the cursor) 1: Zero (lines created either side of the cursor) 2: Bottom (second line created above the cursor)

7.73 CMLSCALE system variable

7.73.1 Multiline scale

Controls the overall distance between lines created with the MLINE command.

A negative value mirrors the offset lines.

Type:	Real
Saved in:	Drawing
Default value:	1.0: If MEASUREMENT=0 and INSUNITS=inches 20.0: If MEASUREMENT=1 and INSUNITS=millimeters

7.74 CMLSTYLE system variable

7.74.1 Multiline style

Controls the multiline style for entities created with the MLINE command.

Type:	String
Saved in:	Drawing
Default value:	Standard

7.75 CMPCLRMISST system variable

7.75.1 Color of missing entities - DWGCOMPARE

Controls the color of missing entities during the DWGCOMPARE command.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Registry
Range:	1 to 255
Default value:	1

7.76 CMPCLRMOD1 system variable

7.76.1 Color of modified entities- DWGCOMPARE

Controls the color of modified entities during the DWGCOMPARE command.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	253

7.77 CMPCLRMOD2 system variable

7.77.1 Color of modified entities in the second drawing- DWGCOMPARE

Controls the color of modified entities in the second drawing during the DWGCOMPARE command.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	2

7.78 CMPCLRNEW system variable

7.78.1 Color of new entities in - DWGCOMPARE

Controls the color of new entities during the DWGCOMPARE command.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	3

7.79 CMPDIFFLIMIT system variable

7.79.1 Maximum number of entities - DWGCOMPARE

Controls the limit for entities to compare during the DWGCOMPARE command.

Values between 1 and 10,000,000 are accepted.

BricsCAD only

Type:	Long
Saved in:	Registry
Range:	1 to 10000000
Default value:	10000000

7.80 CMPFADECTL system variable

7.80.1 Fade - DWGCOMPARE

Controls the fade level for unmodified entities during the DWGCOMPARE command.

Values between 0 and 90 are accepted. A value of zero means Maximum opacity, 90 means maximum transparency.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 90
Default value:	80



7.81 CMPLOG system variable

7.81.1 Log control - DWGCOMPARE

Toggles the creation of a log report (cmplog) for the DWGCOMPARE command.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't write cmplog files On (1): Write cmplog files

7.82 COLORBOOKPATH system variable

7.82.1 Color book file search path

The file path(s) for color books.

Separate file paths with semicolons (:).

BricsCAD only

Type:	String
Saved in:	Registry

7.83 COLORPICKBOX system variable

7.83.1 Pickbox color

Sets the color for the pickbox. Values between 0 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 255
Default value:	7



7.84 COLORTHEME system variable

7.84.1 UI color theme

Applies a dark or light color theme to the user interface.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Dark color theme 1: Light color theme

7.85 COLORX system variable

7.85.1 X axis color

Controls the color of the X-axis.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	11

7.86 COLORY system variable

7.86.1 Y axis color

Controls the color of the Y-axis.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255



Default value:	112
----------------	-----

7.87 COLORZ system variable

7.87.1 Z axis color

Controls the color of the Z-axis.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	150

7.88 COMACADCOMPATIBILITY system variable

7.88.1 COM Acad compatibility

Use registry settings to improve support for existing VB applications.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't use registry settings On (1): Use registry settings

Note: When the COMACADCOMPATIBILITY system variable is set to **On**, AutoCAD® drawing files that are embedded as OLE objects in other applications will open in BricsCAD.

7.89 COMBINETEXTMODE system variable

7.89.1 Combined text mode

Controls the order of the text selection word-wrap method and linespacing style, for the TXT2MTXT command.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	11
Possible options:	1: Combine into a single mtext 2: Sort top-down 4: Word-wrap text 8: Uniform linespacing

7.90 COMMANDASSIST system variable

7.90.1 AI Assist command line

Controls the use of personalized, AI command suggestions.

Only possible if **Application Data** collection is enabled in the DATACOLLECTIONOPTIONS system variable.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	Off
Possible values:	Off (0): Do not enable AI Assist command line On (1): Enable AI Assist command line

7.91 COMMUNICATORBACKGROUNDMODE system variable

7.91.1 Perform import and export in background

Enables user interaction while import or export is performed.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off



Possible values:	Off (0): Disables user interaction while import or export is performed. On (1): Enables user interaction while import or export is performed.
------------------	--

7.92 COMMUNICATORPATH system variable

7.92.1 Communicator path (Mac & Linux)

The file path used to install the Communicator for BricsCAD®.

BricsCAD only

Type:	String Standard
Saved in:	Preference

7.93 COMPASS system variable

7.93.1 Compass

Toggles the display of the 3D compass on/off in the current viewport.

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): 3D Compass off On (1): 3D Compass on

7.94 COMPONENTS CONFIG system variable

7.94.1 Library Panel Configuration

The name of the active **Library** panel configuration file. Controls what is shown in the **Library** panel.

Use the SRCHPATH command to find the file.

BricsCAD only

Type:	String
Saved in:	Workspace



7.95 COMPONENTSPATH system variable

7.95.1 Library directory path

The file path(s) for user created components.

Separate file paths with semicolons (:).

BricsCAD only

Type:	String
Saved in:	Registry

7.96 CONSTRAINTBARDISPLAY system variable

7.96.1 Constraint Display

Controls when constraints are shown.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	1: Show constraint markers when geometrical constraints are added 2: Show hidden constraint markers when constrained entities are selected

7.97 CONTINUOUSMOTION system variable

7.97.1 Continuous motion

Controls if rotation continues after the mouse is released during the ROTATE commands

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Disable continuous inertial motion in realtime On (1): Enable continuous inertial motion in realtime



7.98 CONVERTODMAX system variable

7.98.1 Maximal multiplier for an outer diameter

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	1.1

7.99 CONVERTODMIN system variable

7.99.1 Minimal multiplier for an outer diameter

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.95

7.100 CONVERTTHMAX system variable

7.100.1 Maximal multiplier for a thickness

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	2

7.101 CONVERTTHMIN system variable

7.101.1 Minimal multiplier for a thickness

BricsCAD only

Type:	Real
-------	------



Saved in:	Registry
Default value:	0.5

7.102 COORDS system variable

7.102.1 Coordinates

Controls the format and update frequency of the coordinate field in the Status bar.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	0: Update coordinates only when points are selected 1: Coordinates show pointer location 2: Coordinates in polar form for point, distance and angle selection 3: Coordinates in geographic form as latitude and longitude

7.103 COPYGUIDED3DDISPLAYSOURCEFACES system variable

7.103.1 COPYGUIDED3D source faces

Displays source faces during the COPYGUIDED3D command. Source faces are used to position the copied entity/entities.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable display of source faces On (1): Enable display of source faces



7.104 COPYMODE system variable

7.104.1 Copy mode

Controls if the COPY command creates a single copy or multiple copies, by default.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Repeat automatically 1: Create single copy

7.105 CPLOTSTYLE system variable

7.105.1 Current plot style

Controls the plot style for new entities. In color-dependent mode drawings this is "BYCOLOR" and is read-only. In named-plot-style mode drawings, the options: "BYLAYER" (default), "BYBLOCK", "NORMAL" and "USER DEFINED", this can be changed. See also the PSTYLEMODE system variable. Use the CONVERTPSTYLES command to convert the current drawing to use named or color-dependent plot styles.

Note: To convert the current drawing to use named or color-dependent plot styles, use CONVERTPSTYLES.

Type:	String
Saved in:	Drawing

7.106 CPROFILE system variable

7.106.1 Current profile (Read Only)

The name of the current user profile.

Type:	String
Saved in:	Registry
Default value:	Default



7.107 CRASHREPORTSENDING system variable

7.107.1 Crash report sending (Windows)

Controls the preferences of sharing the crash report and showing the **Crash report** dialog box.

Sending a crash report helps identify and fix any issues and improve BricsCAD for all users.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Ask before sending 1: Send always and don't ask 2: Don't send and don't ask

7.108 CREATESKETCHFEATURE system variable

7.108.1 Sketch based feature (experimental)

Links 3D entities created with the EXTRUDE, LOFT, SWEEP, and REVOLVE commands and their options

Subtract and **Unite** to the 2D entities used to create them and converts the 2D entities into a sketch. Any modifications to the sketch are reflected in the 3D entity.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Do not create sketch based feature 1: Create sketch based feature

Note: This system variable can also be set by pressing the **CreateSketchFeature** toggle button



in the ribbon.



The location of the toggle button depends on the loaded CUI file and the workspace:

Classic interface

Modeling workspace: **Solid & Surface** tabs > **Direct Modeling** ribbon panel.

Mechanical workspace: **Solid & Surface** tabs > **Create** ribbon panel.

Modern interface

Modeling & Mechanical workspaces: **Home** tab > **Controls** ribbon panel.

7.109 CREATETHUMBNAILONTHEFLY system variable

7.109.1 Create preview thumbnail on the fly

Generates a preview thumbnail in the **Open** dialog box, if a drawing doesn't have a thumbnail. Does not apply if the drawing was saved with RASTERPREVIEW system variable switched on (1).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't create preview thumbnail on the fly On (1): Create preview thumbnail on the fly

7.110 CREATEVIEWPORTS system variable

7.110.1 Automatic viewport creation

Controls if a viewport is automatically included when a new layout is created.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't create viewport for new layouts On (1): Create viewport for new layouts



7.111 CROSSHAIRDRAWMODE system variable

7.111.1 Crosshair rendering mode

Controls the way the mouse cursor is rendered while inside the drawing window (crosshair, pickbox, etc.) for 3D visualization. Rendering by RedSDK will be faster, but some old systems might not support rendering by RedSDK.

- In 2dwireframe, render the crosshair in OpenGL. Attempts to eliminate cursor duplicates or flickering, which may happen using the window toolkit.
- In RedSDK visual styles, render the crosshair by RedSDK. Rendering the cursor by RedSDK tends to be faster, but some old systems might not support it.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3 (macOS & Linux) 2 (Windows)
Possible values:	0: Always render crosshair at window toolkit level 1: Render crosshair in OpenGL, for 2d drawings 2: Render crosshair by RedSDK, for 3d drawings

7.112 CROSSINGAREACOLOR system variable

7.112.1 Crossing area color

Controls the color for the crossing selection areas (right-left).

Note: In effect only when SELECTIONAREA setting is on.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	91



7.113 CTAB system variable

7.113.1 Current tab

The name of the current tab, model or layout.

Type:	String
Saved in:	Drawing
Default value:	Model

7.114 CTABLESTYLE system variable

7.114.1 Current table style

Sets the table style for new table entities.

Type:	String
Saved in:	Drawing
Default value:	Standard

7.115 CTRL3Dmouse system variable

7.115.1 3D mouse mode

Enables a 3Dconnexion 3D mouse.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Disable 3D mouse 1: Enable 3D mouse



7.116 CTRLMBUTTON system variable

7.116.1 Middle Button Click

Enables/disables temporary tracking points on middle click (mouse wheel click).

Note: This system variable is only available on the command line.

If CTRLMBUTTON is ON, then during a command a mouse middle click can be used to start entering temporary tracking points.

Default value:	1
Possible values:	0: Disables temporary tracking points on middle button click. 1: Enables temporary tracking points on middle button click.

7.117 CTRLMOUSE system variable

7.117.1 Mouse shortcuts

Toggles mouse shortcuts on/off.

For Windows and Linux short cuts include:

- **Ctrl+Shift + Left button** for realtime zoom.
- **Ctrl+Shift + Right button** for realtime pan.
- **Ctrl + middle button** for view rotation.
- **Ctrl + right button** for view rotation with fixed Z-axis.

For macOS short cuts include:

- **Cmd+Shift + Left button** for realtime zoom.
- **Cmd+Shift + Right button** for realtime pan.
- **Cmd + middle button** for view rotation.
- **Cmd + right button** for view rotation with fixed Z-axis.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Disable mouse shortcuts 1: Enable mouse shortcuts



7.118 CURSORMODE system variable

7.118.1 Crosshair displaying mode

Controls how the crosshair is displayed.

Values 0 and 1 are accepted.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Displays the crosshair in XOR mode. On (1): Displays the crosshair in Non-XOR mode.

7.119 CURORSIZE system variable

7.119.1 Crosshair size

Controls the crosshair size, as a percentage of the screen size.

Type:	Short
Saved in:	Registry
Range:	1 to 100
Default value:	5

7.120 CVALLOWBREAKLINECROSSINGS system variable

7.120.1 Allow breakline crossings

If on, intersections between breakline segments are calculated and added as points to the TIN surface.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	1



7.121 CVANGLESAMPLINGINTERVAL system variable

7.121.1 Angle sampling interval

Controls the angle sampling interval in decimal degrees, used to round gradings at convex vertices.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 90
Default value:	5

7.122 CVARCTESSELLATIONGRADING system variable

7.122.1 Arc approximation mid-ordinate distance

Controls the grading mid-ordinate distance, the maximum distance between the arc and the chord (straight) segment, used for arc approximation.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.01

7.123 CVARCTESSELLATIONSURFACE system variable

7.123.1 Arc approximation mid-ordinate distance

Controls the surface mid-ordinate distance, the maximum distance between the arc and the chord (straight) segment, used for arc approximation.

BricsCAD only


Type:	Real
Saved in:	Drawing
Default value:	0.01



7.124 CVARCTESSELLATIONTEMPLATEELEMENT system variable

7.124.1 Template Element arc approximation mid-ordinate distance

Controls the corridor mid-ordinate distance (1), the maximum distance between the arc and the chord (straight) segment, used for arc approximation.



BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.01

7.125 CVASSOCIATIVITY system variable

7.125.1 Associativity

Controls if Civil entities are associative.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	15
Possible options:	1: TIN Surfaces are associative 2: Gradings are associative 4: TIN Volume Surfaces are associative 8: Corridors are associative

7.126 CVDEFAULTCURVETYPEHA system variable

7.126.1 Default curve type for horizontal alignment

Controls the curve type, used to create new horizontal alignment or to add a new PI.

BricsCAD only



Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	-1: None 0: Auto Arc 1: Free Arc 2: Auto Spiral-Curve-Spiral 3: Free Spiral-Curve-Spiral

7.127 CVDEFAULTCURVETYPEVA system variable

7.127.1 Default curve type for vertical alignments

Controls the curve type, used to create new vertical alignment or to add a new PVI.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	2
Possible values:	-1: None 0: Auto Arc 1: Free Arc 2: Auto Parabola 3: Free Parabola

7.128 CVELEVATIONATBREAKLINECROSSINGS system variable

7.128.1 Elevation at breakline crossings

Controls the elevation at breakline crossings.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 2



Default value:	0
Possible values:	0: Minimum 1: Maximum 2: Average

7.129 CVVERSIONCONTROLPATH system variable

7.129.1 Current version control path

The file path used to store the current version control project.

BricsCAD only

Type:	String
Saved in:	Registry

7.130 CVGRADEUNIT system variable

7.130.1 Format

Controls the unit format for grade units

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: percent 1: per mille 2: decimal

7.131 CVGRADEUNITPREC system variable

7.131.1 Precision

Controls the number of decimal places displayed for grade units

BricsCAD only



Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	2
Possible values:	0: 0 1: 0.0 2: 0:00 3: 0:000 4: 0:0000 5: 0:00000 6: 0:000000 7: 0:0000000 8: 0:00000000

7.132 CVLENGTHSAMPLINGINTERVAL system variable

7.132.1 Sampling interval for straight segments

Controls the length of sampling intervals, used to sample straight segments.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1.00

7.133 CVPORT system variable

7.133.1 Current viewport

Changes the identification number of the current viewport on three conditions:

- 1 The identification number is an active viewport.
- 2 Cursor movement in that viewport is not locked by a command in progress.
- 3 Tablet mode is off.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	1 or greater
Default value:	2

7.134 CVSLOPEUNIT system variable

7.134.1 Format

Controls the unit format for slope units

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: run:rise 1: rise:run

7.135 CVSLOPEUNITPREC system variable

7.135.1 Precision

Controls the number of decimal places displayed for slope units

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	1



Possible values:	0: 0 1: 0.0 2: 0:00 3: 0:000 4: 0:0000 5: 0:00000 6: 0:000000 7: 0:0000000 8: 0:00000000
------------------	--

7.136 CVSTATIONUNIT system variable

7.136.1 Station delimiter position

Controls the delimiter position for station units

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 5
Default value:	3
Possible values:	0: 0 1: 1+0 2: 1+00 3: 1+000 4: 1+0000 5: 1+00000

7.137 CVSTATIONUNITPREC system variable

7.137.1 Precision

Controls the number of decimal places displayed for station units

BricsCAD only

Type:	Short
Saved in:	Drawing



Range:	0 to 8
Default value:	2
Possible values:	0: 0 1: 0.0 2: 0:00 3: 0:000 4: 0:0000 5: 0:00000 6: 0:000000 7: 0:0000000 8: 0:00000000



8. D

8.1 DATAcollection system variable

8.1.1 Diagnostics and usage data collection

Controls the sharing of anonymous usage data.

This helps personalize the program and significantly enhances the user experience for everyone.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-2 to 1
Default value:	-2
Possible values:	-2: Not asked -1: Not set 0: Off 1: On

8.2 DATAcollectionenabled system variable

8.2.1 Current state of data collection (Read Only)

Controls diagnostic and usage data collection.

BricsCAD only

Type:	Boolean
Saved in:	Not saved
Range:	Off
Possible values:	Off (0): Data collection is disabled On (1): Data collection is enabled

Note: The value of this system variable is by default based on the value of the DATAcollection preference variable, however it is possible to override the default by applying an administrative override. The administrative override is applied by manually adding the registry value in *HKLM\Software\Bricsys\BricsCAD\V25x64\AdminPolicy*.



To add this override follow the next steps:

- Go to: Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Bricsys\BricsCAD\V25x64.
- Right-click the V25x64 key and choose **New > Key** and rename it to **AdminPolicy**.
- Right-click on the new created key and choose **New > DWORD (32-bit)** and name the value **DATACOLLECTIONENABLED**.
- Change its value to 0 or 1 to override the value of DATACOLLECTION user preference.

8.3 DATACOLLECTIONLOGINTYPE system variable

8.3.1 Latest type of login for data collection (Read Only)

The login type for data collection.

See the DATACOLLECTIONOPTIONS system variable.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	Off
Possible values:	-1: Off 0: Anonymous 1: User/Password

8.4 DATACOLLECTIONOPTIONS system variable

8.4.1 Data Collection Options

Controls what anonymous data is shared.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 7
Default value:	0



Possible values:	0: Nothing 1: System and Settings Data 2: Application Data 4: Anonymized Geometry
------------------	--

8.5 DATALINKNOTIFY system variable

8.5.1 Data link Notifications

Controls data link notifications.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Disables data link update notifications. 1: Enables data link notifications. 2: Enables data link notification and balloon message notifications.

8.6 DATE system variable

8.6.1 Current date (Read Only)

Shows the current date and time in Julian Day format.

Type:	Real
Saved in:	Not saved

8.7 DBCSTATE system variable

8.7.1 DbConnect state (Read Only)

Shows if the dbConnect Manager is active or not.

Type:	Boolean
Saved in:	Drawing



Default value:	Off
Possible values:	Off (0): Don't display dbConnect Manager On (1): Display dbConnect Manager

8.8 DBCLKEDIT system variable

8.8.1 Double click editing

Enables **Block Editor** (BEdit mode) and **Reference Editor** (RefEdit mode) on double click of Blocks and XRefs.

Type:	Boolean
Saved in:	Registry
Range:	On
Possible values:	Off (0): Disable double click editing On (1): Enable edit on double click

8.9 DBMOD system variable

8.9.1 Modification status (Read Only)

The status of drawing modifications.

Type:	Short
Saved in:	Not saved
Possible values:	1: Entity database modified 4: Database variable modified 8: Window modified 16: View modified 32: Field modified

8.10 DCTCUST system variable

8.10.1 Custom spelling dictionary

The file path and file name of the current, custom spelling dictionary.



During a spelling check, the SPELL command matches the words in the drawing or the current selection set to the words in the current main dictionary and the current custom dictionary. Custom dictionaries are used for discipline-specific words, such as medical or mechanical.

Type:	String
Saved in:	Registry

8.11 DCTMAIN system variable

8.11.1 Main spelling dictionary

The file name of the current, main spelling dictionary. Stored in the support folder.

Note: Keywords can be used to set this variable.

Type:	String
Saved in:	Registry

8.12 DEFAULTBSYSLIBIMPERIAL system variable

8.12.1 Default Bsylslib imperial

Default location of the Bsylslib central database when MEASUREMENT is 0 (imperial).

BricsCAD only

Type:	String
Saved in:	Preference

8.13 DEFAULTBSYSLIBMETRIC system variable

8.13.1 Default Bsylslib metric

Default location of the Bsylslib library database when MEASUREMENT is 1 (metric).

BricsCAD only

Type:	String
Saved in:	Preference



8.14 DEFAULTLIGHTING system variable

8.14.1 Default lighting

Controls if default lighting overrides other lights in the drawing. Default lighting is a distant light that follows the view direction, can be set per viewport.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Default lighting is used only when no other lights are switched on On (1): Default lighting overrides other lights.

8.15 DEFAULTLIGHTSHADOWBLUR system variable

8.15.1 Default light shadow blur

Controls the default shadow blur for lights.

Values between 1 and 40 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 40
Default value:	8

8.16 DEFAULTNEWSHEETTEMPLATE system variable

8.16.1 Default new sheet template

The default drawing template file (DWG or DWT) for new sheets.

BricsCAD only

Type:	String
Saved in:	Preference



8.17 DEFAULTPLOTSTYLETABLE system variable

8.17.1 Default plot style table

Controls the default plot style table for new page setups and new layouts.

Note: Changing this preference will not apply to the layouts that already exist.

BricsCAD only

Type:	String
Saved in:	Preference

8.18 DEFAULTSPACEHEIGHT system variable

8.18.1 Default Space Height

Default height of a space. Used if there are no ceilings to connect to or walls to get the height from.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	120 for MEASUREMENT=0 (inches) 3000 for MEASUREMENT=1 (millimeters)

8.19 DEFAULTSTORYNAMINGSCHEME system variable

8.19.1 Default Story Naming Scheme

Defines the story naming scheme for new buildings. Use \$0 or \$1 to control the numbering.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	Floor \$1

Note: When you add new stories to an existing building, you can override their naming and numbering by changing the value of the building's **Story Naming Scheme** property in the **Spatial Locations Manager** dialog box.



8.20 DEFAULTSTYLEPIPECROSS system variable

8.20.1 Default style for pipe cross

Controls the default style in use while BIM FlowFittings cross is converts to a Std part.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Cross

8.21 DEFAULTSTYLEPIPEECCENTRICREDUCER system variable

8.21.1 Default style for pipe eccentric reducer

Controls the default style in use while BIM FlowFittings eccentric converts to an Std part.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Eccentric Reducer

8.22 DEFAULTSTYLEPIPEELBOW45 system variable

8.22.1 Default style for pipe elbow (45 deg)

Controls the default style in use while BIM FlowBends with 45 degrees angle converts to an Std part.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Elbow LR 45 Deg

8.23 DEFAULTSTYLEPIPEELBOW90 system variable

8.23.1 Default style for pipe elbow (90 deg)

Controls the default style in use while BIM FlowBends with 90 degrees angle converts to an Std part.



BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Elbow LR 90 Deg

8.24 DEFAULTSTYLEPIPERREDUCER system variable

8.24.1 Default style for pipe reducer

Controls the default style in use while BIM FlowFittings reducer converts to an Std part.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B16.9 Reducer

8.25 DEFAULTSTYLEPIPESEGMENT system variable

8.25.1 Default style for pipe segment

Controls the default style in use while BIM FlowSegments converts to an Std part.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	ASME B36.10M Pipe

8.26 DEFAULTSTYLEPIPETEE system variable

8.26.1 Default style for pipe tee

Controls the default style in use while BIM FlowFittings tee is converts to an Std part.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
Default value:	ASME B16.9 Tee

8.27 DEFPLSTYLE system variable

8.27.1 Default layer plot style

Controls the default plot style for layer 0. "BYCOLOR" in color-dependent mode drawings, read-only. "NORMAL" in named-plot-style mode drawings, can be changed. See also the PSTYLEMODE system variable.

Note: To convert the current drawing to use named or color-dependent plot styles, use CONVERTPSTYLES

Type:	String
Saved in:	Registry

8.28 DEFPLSTYLE system variable

8.28.1 Default entity plot style

Controls the default plot style for new entities. "BYCOLOR" in color-dependent mode drawings, read-only. "NORMAL" in named-plot-style mode drawings, can be changed. See also the PSTYLEMODE system variable. Use the CONVERTPSTYLES command to convert the current drawing to use named or color-dependent plot styles.

Type:	String
Saved in:	Registry

8.29 DELETETOOL system variable

8.29.1 Delete tool


Controls the behavior of the SUBTRACT command. If on, entities used to subtract are deleted.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Default value:	0



Possible values:	Off (0): Don't delete tool entities in command SUBTRACT On (1): Delete tool entities in command SUBTRACT
------------------	---



8.30 DELOBJ system variable

8.30.1 Delete source entity

Controls if source entities, used to create 3D entities (with commands such as EXTRUDE, REVOLVE and LOFT) are retained or deleted.

Type:	Short
Saved in:	Registry
Default value:	1
Possible values:	0: Retain defining entities 1: Delete profile entities 2: Delete all defining entities -1: Prompt to delete profile entities -2: Prompt to delete all defining entities (including paths and reference curves)

8.31 DEMANDLOAD system variable

8.31.1 Demand load

Controls how the program handles custom entities created by third-party applications.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	1: Demand-load source application when opening a drawing that contains custom entities 2: Demand-load source application when invoking one of the application's commands

Note: If you set this system variable to 0, third-party applications and some internal commands may not function.

8.32 DETAILSPATH system variable

8.32.1 Details directory path

The file path(s) for user created detail files.

Separate file paths with semicolons (;).

BricsCAD only

Type:	String
Saved in:	Registry

8.33 DGNEXPXREFMODE system variable

8.33.1 Export Conversion of XRefs

Controls the conversion of XRefs for DGN export.

The dependent files themselves are not converted when exporting the parent. They must be converted separately.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0



Possible values:	0: Convert reference to DGN 1: Keep reference to DWG 2: Bind reference file to the parent DGN 3: Detach Xrefs
------------------	--

8.34 DGNFRAME system variable

8.34.1 DGN frame

Controls the visibility of DGN frames, if the FRAME system variable is set to 'Use individual system variables' (3).

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Hide DGN frames 1: Display and plot DGN frames 2: Display but do not plot DGN frames

8.35 DGNIMP2DCLOSEDBSPLINECURVEIMPORTMODE system variable

8.35.1 2D closed B-spline curve import mode

Controls how to convert DGN closed 2D B-Spline curve elements.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Convert to spline 1: Convert to region



8.36 DGNIMP2DELLIPSEIMPORTMODE system variable

8.36.1 2D ellipse import mode

Controls how to convert DGN 2D Ellipse elements.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Convert to ellipse 1: Convert to region

8.37 DGNIMP2DSHAPEIMPORTMODE system variable

8.37.1 2D shape import mode

Controls how to convert DGN 2D Shape and 2D Complex Shape elements.

If an element is filled, then a hatch is created as well.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: Convert to polyline 1: Convert to region 2: Convert to polyface mesh

8.38 DGNIMP3DCLOSEDBSPLINECURVEIMPORTMODE system variable

8.38.1 3D closed B-spline curve import mode

Controls how to convert DGN closed 3D B-Spline curve elements.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: Convert to spline 1: Convert to region

8.39 DGNIMP3DELLIPSEIMPORTMODE system variable

8.39.1 3D ellipse import mode

Controls how to convert DGN 3D Ellipse elements.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Convert to ellipse 1: Convert to region

8.40 DGNIMP3DOBJECTIMPORTMODE system variable

8.40.1 3D entity import mode

Controls how 3D entities are converted during DGN import.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1



Default value:	1
Possible values:	0: Convert to polyface mesh 1: Convert to 3D Solid, Body or Surface

8.41 DGNIMP3DSHAPEIMPORTMODE system variable

8.41.1 3D shape import mode

Controls how to convert DGN 3D Shape and 3D Complex Shape elements.

If an element is filled, a hatch is created as well.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Convert to polyline 1: Convert to region 2: Convert to polyface mesh

8.42 DGNIMPBREAKDIMENSIONASSOCIATION system variable

8.42.1 Break dimension association

Breaks DGN dimension associations during DGN import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't break dimension associations On (1): Break dimension associations



8.43 DGNIMP CONVERTDGN COLOR INDICES TO TRUE COLORS system variable

8.43.1 Convert DGN color indices to true colors

Converts DGN color indexes to RGB true colors. If off, DGN color indexes are converted to DWG color indexes.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Convert DGN color indices to DWG color indices On (1): Convert DGN color indices to RGB true colors

Specifies how Microstation colors are mapped to BricsCAD colors. Microstation assigns color numbers to colors that are different from BricsCAD. If on, then BricsCAD converts DGN color indexes to RGB true colors. Otherwise it tries to convert DGN color indices to DWG color indices. BricsCAD gets the color from the DGN color table and tries to find the same color in DWG color table. If it is not possible, then the color will be saved as an RGB true color to the DWG file.

8.44 DGNIMP CONVERTEMPTYDATAFIELDSTOSPACES system variable

8.44.1 Convert empty data fields to spaces

Replaces empty field values from a DGN file with space symbols. If off, empty field values from a DGN file are replaced with underscore symbols ("_").

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Replace by underscore symbols ("_") On (1): Replace by space symbols



8.45 DGNIMPERASEUNUSEDRESOURCES system variable

8.45.1 Erase unused resources

Erases unreferenced items (text styles, linetypes, etc.) during DGN import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Import unreferenced elements. On (1): Erase unreferenced imported items

8.46 DGNIMPEXPLODETEXTNODES system variable

8.46.1 Explode text nodes

Imports DGN text nodes as a set of simple entities (text, line, etc.). If off, DGN text nodes are converted to multiline text.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Convert text nodes to multiline text On (1): Convert text nodes to simple entities, such as text and lines

8.47 DGNIMPIMPORTACTIVEMODELTOMODELSPACE system variable

8.47.1 Import active model to Model Space

Imports the active DGN model to Model Space, during DGN import. If off, imports only the first DGN design model from the model table.

Note: Microstation uses the phrase “design model” for model space, and “active model” for the current view of a model.

BricsCAD only



Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Import the first design model from the model table to the model space On (1): Import the active model to model space

8.48 DGNIMPIMPORTDGTEXTSASDBMTEXTS system variable

8.48.1 Import Texts as MTexts

Imports simple DGN text entities as multiline texts.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Does not import simple text objects as multiline texts. On (1): Imports simple text objects as multiline texts.

8.49 DGNIMPIMPORTINVISIBLEELEMENTS system variable

8.49.1 Import invisible elements

Imports invisible DGN elements as invisible entities. If off invisible DGN elements are not imported.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Skip invisible elements On (1): Import invisible elements



8.50 DGNIMPIMPORTPAPERSPACEMODELS system variable

8.50.1 Import Paper Space models

Imports all DGN sheet models to paper space layouts. If off, sheet models are not imported.

Note: Microstation uses the phrase "sheet model" for paper space.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import sheet models On (1): Import sheet models to paper space layouts

8.51 DGNIMPIMPORTVIEWINDEX system variable

8.51.1 Import view index

Controls the number of DGN views, level masks and view settings to use.

Values between -1 and 7 are accepted. -1 means that the view is not defined and view settings and level masks are not used.

Note: Microstation uses the word "level" for layers; a "mask" hides content in areas or levels/layers.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	-1 to 7
Default value:	-1
Possible values:	-1: View is not defined 1 to 7: Specifies level mask

8.52 DGNIMPRECOMPUTEDIMENSIONS AFTERR IMPORT system variable

8.52.1 Recompute dimensions after import

Converts DGN dimensions to DWG-based dimensions.



If off creates DGN-based dimensions.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): create DGN-style dimension geometry blocks On (1): re-compute all dimensions to create DWG dimension geometry blocks

8.53 DGNIMPSYMBOLRESOURCEFILES system variable

8.53.1 Symbol resource files

The file path for DGN resource RSC files - fonts, line styles, etc. Analog of the MS_SYMBRSRC MicroStation system variable.

BricsCAD only

Type:	String
Saved in:	Preference

8.54 DGNIMPXREFIMPORTMODE system variable

8.54.1 External references import mode

Controls DGN attachment import.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	2



Possible values:	0: Omit - does not import DGN attachments 1: Retain - converts attached DGN files to DWG XRefs 2: Merge to cell - converts attached DGN files to DWG blocks 3: Create DGN Underlay - converts attached DGN files to Underlay entities
------------------	--

8.55 DGNOSNAP system variable

8.55.1 DGN entity snap

Enables entity snap for DGN underlay files.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable DGN entity snap On (1): Enable DGN entity snap

8.56 DIASTAT system variable

8.56.1 Dialog state (Read Only)

Shows how the most recent dialog box was exited.

Type:	Boolean
Saved in:	Not saved
Possible values:	Off (0): Cancel On (1): OK

8.57 DIMADEC system variable

8.57.1 Dim Angle Precision

Controls the number of decimal places for angular dimensions.

A value of -1 uses the DIMDEC system variable.

Type:	Short
Saved in:	Drawing



Range:	-1 to 8
Default value:	0
Possible values:	-1: Use the DIMDEC system variable 0 - 8: Decimal places

8.58 DIMALT system variable

8.58.1 Alt units

Enables alternate units in dimensions.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Disable alternate units On (1): Enable alternate units

8.59 DIMALTD system variable

8.59.1 Alt precision

Controls the number of decimal places for alternate dimension units.

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	2 - If MEASUREMENT=0 and INSUNITS=inches 3 - If MEASUREMENT=1 and INSUNITS=millimeters

8.60 DIMALTF system variable

8.60.1 Alt multiplier

Controls the conversion of alternate units. See also the DIMALT system variable.



Multiples the primary unit to give alternate units. If one drawing unit equals 1 inch and the value is set to 25.4, alternate linear dimensions are expressed in mm.

Type:	Real
Saved in:	Drawing
Default value:	25.4 - If MEASUREMENT=0 and INSUNITS=inches 0.0394 - If MEASUREMENT=1 and INSUNITS=milimeters

8.61 DIMALTRND system variable

8.61.1 Alt roundoff

Controls the roundoff for alternate units.

Type:	Real
Saved in:	Drawing
Default value:	0.0

8.62 DIMALTDD system variable

8.62.1 Alt tolerance precision

Controls the tolerance precision in the alternate dimension units.

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	3 - If MEASUREMENT=1 and INSUNITS= inches 2 - If MEASUREMENT=0 and INSUNITS=millimeters

8.63 DIMALTTZ system variable

8.63.1 Alt tolerance suppress zeros

Controls the suppression of zeros in tolerance values.

Type:	Boolean
-------	---------



Saved in:	Drawing
Default value:	0
Possible values:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions

8.64 DIMALTU system variable

8.64.1 Alt unit type

Controls the alternate unit type for linear dimensions.

Type:	Short
Saved in:	Drawing
Range:	1 to 8
Default value:	2
Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural (stacked) 5: Fractional (stacked) 6: Architectural 7: Fractional 8: Windows Control Panel

8.65 DIMALTZ system variable

8.65.1 Alt suppress zeros

Suppresses leading and/or trailing zeros for alternate unit dimension.

Type:	Short
Saved in:	Drawing



Range:	0 to 12
Default value:	0
Possible values:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions

8.66 DIMANNO system variable

8.66.1 Style is annotative (Read Only)

Indicates if the current dimension style is annotative.

Type:	Boolean
Saved in:	Drawing

8.67 DIMAPOST system variable

8.67.1 Alt units prefix/suffix

Controls the prefix and/or suffix that appears in the alternate dimension text, does not apply to angular dimensions. See also the **Drawing Explorer > Dimension Styles** (DIMSTYLE command).

Set to " to turn off, or use the suffix string 'prefix[]suffix'. Insert a single linefeed with '\X' (often when alternate units are active).

Type:	String
Saved in:	Drawing

8.68 DIMARCSYM system variable

8.68.1 Arc symbol

Controls the display of arc symbols, in arc length dimensions.

Type:	Short
Saved in:	Drawing



Range:	0 to 2
Default value:	0
Possible values:	0: Arc length symbol is placed before the dimension text 1: Arc length symbol is placed above the dimension text 2: The display of the arc length symbol is suppressed

8.69 DIMASO system variable

8.69.1 Associativity (obsolete)

Replaced by DIMASSOC. Has no effect except to preserve the integrity of scripts.

Type:	Boolean
Saved in:	Drawing
Default value:	On

8.70 DIMASSOC system variable

8.70.1 Associativity

Controls the associativity of dimension entities or if exploded dimensions are created.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Exploded dimensions 1: Non-associative dimension entities 2: Associative dimension entities

8.71 DIMASZ system variable

8.71.1 Arrow size

Controls the size of dimension and leader line arrowheads.



Type:	Real
Saved in:	Drawing
Default value:	0.18 - If MEASUREMENT=0 and INSUNITS=inches 2.5 - If MEASUREMENT=1 and INSUNITS=millimeters

8.72 DIMATFIT system variable

8.72.1 Arrow and text fit

Controls how dimension text and arrows are arranged when there is insufficient space between the extension lines.

When the DIMMOVE system variable is set to 1, a leader is added if the dimension text is placed outside.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible values:	0: Place both text and arrows outside extension lines 1: Move arrows first, then text 2: Move text first, then arrows 3: Move either text or arrows, whichever fits best

8.73 DIMAUNIT system variable

8.73.1 Dim angle units

Controls the angular dimension unit type.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	0



Possible values:	0: Decimal degrees 1: Degrees/minutes/seconds 2: Gradians 3: Radians
------------------	---

8.74 DIMAZIN system variable

8.74.1 Suppress angle zeros

Suppresses leading and/or trailing zeros for angular dimensions.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	0
Possible options:	1: Suppress leading zeros 2: Suppress trailing zeros

8.75 DIMBLK system variable

8.75.1 Arrow

The name of the block displayed at the ends of dimension and leader lines, when the DIMSAH system variable is set to **Set by DIMBLK**.

The block name can be either a standard name or refer to a user-defined arrowhead block.

Type:	String
Saved in:	Drawing

8.76 DIMBLK1 system variable

8.76.1 Arrow 1

The name of the block displayed at the first end of a dimension line, when the DIMSAH system variable is set to **Set by DIMBLK1 and DIMBLK2**.

Type:	String
-------	--------



Saved in:	Drawing
-----------	---------

8.77 DIMBLK2 system variable

8.77.1 Arrow 2

The name of the block displayed at the second end of a dimension line, when the DIMSAH system variable is set to **Set by DIMBLK1 and DIMBLK2**.

Type:	String
Saved in:	Drawing

8.78 DIMCEN system variable

8.78.1 Center mark

Controls if and how center marks and centerlines of circles and arcs are drawn with the DIMCENTER, DIMDIAMETER and DIMRADIUS commands.

- A value of zero means no center mark.
- Negative numbers mean a line.
- Positive numbers mean a mark.

Type:	Real
Saved in:	Drawing
Default value:	0.09 - If MEASUREMENT=0 and INSUNITS=inches 2.5 - If MEASUREMENT=1 and INSUNITS=millimeters
Possible values:	0: None <0: Line >0: Mark

8.79 DIMCLRD system variable

8.79.1 Dim line color

The color of dimension lines, arrowheads and dimension leader lines.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 256
Default value:	0
Possible values:	0: ByBlock 1 - 255: index 256: ByLayer

8.80 DIMCLRE system variable

8.80.1 Ext line color

Controls the color for dimension extension lines.

Type:	Short
Saved in:	Drawing
Range:	0 to 256
Default value:	0
Possible values:	0: ByBlock 1 - 255: index 256: ByLayer

8.81 DIMCLRT system variable

8.81.1 Text color

Controls the default dimension text color.

Type:	Short
Saved in:	Drawing
Range:	0 to 256
Default value:	0



Possible values:	0: ByBlock 1 - 255: index 256: ByLayer
------------------	--

8.82 DIMCONTINUEMODE system variable

8.82.1 Dim continue mode

Controls if dimension styles and layers are inherited from the starting dimension, for continued or baseline dimension.

Type:	Short
Saved in:	Registry
Default value:	1
Possible values:	0: Use the current dimension style and layer 1: Use the dimension style and layer of the starting dimension

8.83 DIMDEC system variable

8.83.1 Dim precision

Controls the number of decimal places for primary dimension units.

Values between 0 and 8 are accepted.

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	4

8.84 DIMDLE system variable

8.84.1 Dim line ext

Controls the length of dimension lines beyond the extension lines, when obliques or architectural ticks are drawn instead of arrowheads.

Type:	Real
-------	------



Saved in:	Drawing
Default value:	0.0

8.85 DIMDLI system variable

8.85.1 Dim baseline spacing

Controls the spacing between baselines dimension lines.

Type:	Real
Saved in:	Drawing
Default value:	0.38 - If MEASUREMENT=0 and INSUNITS=inches 3.75 - If MEASUREMENT=1 and INSUNITS=millimeters

8.86 DIMDSEP system variable

8.86.1 Decimal separator

Sets the decimal separator character.

Type:	String
Saved in:	Drawing

8.87 DIMEXE system variable

8.87.1 Ext line ext

Controls the extension of dimension extension lines beyond the dimension line.

Type:	Real
Saved in:	Drawing
Default value:	0.18 - If MEASUREMENT=0 and INSUNITS=inches 1.25 - If MEASUREMENT=1 and INSUNITS=millimeters



8.88 DIMEXO system variable

8.88.1 Ext line offset

Controls the offset of dimension extension lines from their origin points.

Type:	Real
Saved in:	Drawing
Default value:	0.0625 - If MEASUREMENT=0 and INSUNITS=inches 0.625 - If MEASUREMENT=1 and INSUNITS=millimeters

8.89 DIMFIT system variable

8.89.1 Dim fit (obsolete)

Replaced by DIMATFIT and DIMTMOVE.

Type:	Short
Saved in:	Drawing
Default value:	3

8.90 DIMFRAC system variable

8.90.1 Fractional type

Controls the fraction format for Architectural or Fractional linear dimensions. See also the DIMLUNIT system variable.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Horizontal 1: Diagonal 2: Not stacked



8.91 DIMFXL system variable

8.91.1 Ext line fixed length

Controls the length of extension lines, if the DIMFXLON system variable is on (1).

Type:	Real
Saved in:	Drawing
Default value:	1.0

8.92 DIMFXLON system variable

8.92.1 Ext line fixed

Fixes the length of extension lines on dimensions.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't use fixed length extension lines On (1): Use fixed length extension lines

8.93 DIMGAP system variable

8.93.1 Text offset

Controls the offset distance around dimension text, and the distance between annotations and hook lines created with the LEADER command.

See the DIMTAD system variable. Negative numbers mean draws a box around the dimension or annotation text.

Type:	Real
Saved in:	Drawing
Default value:	0.09 - If MEASUREMENT=0 and INSUNITS=inches 0.625 - If MEASUREMENT=1 and INSUNITS=millimeters




8.94 DIMJOGANG system variable

8.94.1 Jogged angle

Controls the angle of oblique dimension line segments, in jogged radius dimensions.

Note: Jogged radius dimensions are often created when the center point is located off the page.

Type:	Real
Saved in:	Drawing
Default value:	45.0



8.95 DIMJUST system variable

8.95.1 Text Position Horizontal

Controls the horizontal position of dimension text.

Type:	Short
Saved in:	Drawing
Range:	0 to 4
Default value:	0
Possible values:	<ul style="list-style-type: none">0: Text above the dimension line and center-justified between extension lines1: Text next to the first extension line2: Text next to the second extension line3: Text above and aligned with the first extension line4: Text above and aligned with the second extension line



8.96 DIMLAYER system variable

8.96.1 Default layer for new dimensions

The default layer for new dimensions.

Type:	String
Saved in:	Drawing
Default value:	.

8.97 DIMLDRBLK system variable

8.97.1 Leader arrow

Controls the arrowhead block for leaders.

Type:	String
Saved in:	Drawing

8.98 DIMLFAC system variable

8.98.1 Dim Scale Linear

Controls the scale multiplier for linear dimensions, including radius, diameter and ordinate dimensions.

Linear dimensions are multiplied by DIMLFAC.

- Positive values mean that it is used for model space and paper space.
- Negative values mean paper space only.

Type:	Real
Saved in:	Drawing
Default value:	1.0

8.99 DIMLIM system variable

8.99.1 Tolerance method

Generates dimension limits as the default text for dimensions.

If On, switches DIMTOL Off.



Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't generate dimension limits as default text On (1): Generate dimension limits as default text

8.100 DIMTEX1 system variable

8.100.1 Ext line 1 linetype

Controls the linetype for the first extension line of a dimension.

Type:	String
Saved in:	Drawing

8.101 DIMTEX2 system variable

8.101.1 Ext line 2 linetype

Controls the linetype for the second extension line of a dimension.

Type:	String
Saved in:	Drawing

8.102 DIMTYPE system variable

8.102.1 Dim line linetype

Controls the linetype for dimension lines.

Type:	String
Saved in:	Drawing

8.103 DIMLUNIT system variable

8.103.1 Dim units

Controls the primary unit type for linear dimensions.



Type:	Short
Saved in:	Drawing
Range:	1 to 6
Default value:	2
Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural 5: Fractional 6: Windows Control Panel

8.104 DIMLWD system variable

8.104.1 Dim line LW

Controls the linewidth of dimension lines.

Type:	Short
Saved in:	Drawing
Range:	-3 to 211
Default value:	Bylayer
Possible values:	-3: Default (defined by LWDEFAULT) -2: ByBlock -1: ByLayer 0 - 211: Lineweight value in hundredths of millimeters

8.105 DIMLWE system variable

8.105.1 Ext line LW

Controls the linewidth of dimension extension lines.

Type:	Short
Saved in:	Drawing



Range:	-3 to 211
Default value:	Bylayer
Possible values:	<ul style="list-style-type: none">-3: Default (defined by LWDEFAULT)-2: ByBlock-1: ByLayer0 - 211: Lineweight value in hundredths of millimeters

8.106 DIMMARKTYPE system variable

8.106.1 Dimension override marking

Automatically displays overridden associative dimensions with a special marking, when they do not include the default dimension text.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	<ul style="list-style-type: none">0: Not enabled1: Display overridden dimensions with an underline2: Display overridden dimensions with an overline

8.107 DIMPOST system variable

8.107.1 Dim prefix/suffix

Controls the prefix and/or suffix added to dimension text. See also the **Drawing Explorer > Dimension Styles** (DIMSTYLE command).

Set to " to turn off, or use the suffix string 'prefix[]suffix'. Insert a single linefeed with '\X' when alternate units are active.

Type:	String
Saved in:	Drawing



8.108 DIMRND system variable

8.108.1 Dim round

Controls the roundoff rules for linear dimensions.

Note: It does not effect angular dimensions.

A value of 0.1 rounds to the nearest 0.1 unit, a value of 1 rounds to the nearest whole number. The number of decimal places is limited by the DIMDEC system variable.

Type:	Real
Saved in:	Drawing
Default value:	0.0

8.109 DIMSAH system variable

8.109.1 Arrowheads

Controls how dimension line arrowhead blocks are set.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Set by DIMBLK - uses the same block for the first and the second arrowhead On (1): Set by DIMBLK1 and DIMBLK2 - uses different blocks for the first and the second arrowhead

8.110 DIMSCALE system variable

8.110.1 Dim scale overall

Applies a scale multiplier to dimension variables that specify the size of the components of dimension entities, such as text height, distance or offsets.

Note: It does not affect measured lengths, coordinates, or angles.

Type:	Real
Saved in:	Drawing



Range:	0 or greater
Default value:	1.0

8.111 DIMSD1 system variable

8.111.1 Dim line 1

Suppresses the first part of dimension lines - from the first extension line to the text origin.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't suppress first dimension line On (1): Suppress first dimension line

8.112 DIMSD2 system variable

8.112.1 Dim line 2

Suppresses the second part of dimension lines - from the text origin to the second extension line.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't suppress second dimension line On (1): Suppress second dimension line

8.113 DIMSE1 system variable

8.113.1 Ext line 1

Suppresses the first extension line of a dimension.

Type:	Boolean
Saved in:	Drawing



Default value:	Off
Possible values:	Off (0): Don't suppress first extension line On (1): Suppress first extension line

8.114 DIMSE2 system variable

8.114.1 Ext line 2

Suppresses the second extension line of a dimension.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't suppress second extension line On (1): Suppress second extension line

8.115 DIMSHO system variable

8.115.1 Dimension show (Obsolete)

Has no effect except to preserve the integrity of scripts. Controls the redefinition of dimension entities while dragging.

Type:	Boolean
Saved in:	Drawing
Default value:	On

8.116 DIMSOXD system variable

8.116.1 Dim line inside

Suppresses arrowheads outside extension lines if there is insufficient room inside the extension lines and if the DIMTIX system variable is on (1).

Type:	Boolean
Saved in:	Drawing



Default value:	Off
Possible values:	Off (0): Don't suppress outside arrowheads On (1): Suppress outside arrowheads

8.117 DIMSTYLE system variable

8.117.1 Dimension style (Read Only)

The current dimension style.

Type:	String
Saved in:	Drawing
Default value:	Standard

8.118 DIMTAD system variable

8.118.1 Text Position Vert

Controls the vertical position of text in relation to dimension lines. The position above dimension line is set by the DIMGAP system variable.

The **Above dimension line** option does not apply if the DIMTIH system variable is set to **Horizontal** and the dimension line is not horizontal.

Type:	Short
Saved in:	Drawing
Range:	0 to 4
Default value:	0
Possible values:	0: Centered between extension lines 1: Above dimension line 2: Farthest from defining points 3: Japanese Industrial Standards 4: Below dimension line



8.119 DIMTDEC system variable

8.119.1 Tolerance precision

Controls the number of decimal places for tolerance values in the primary dimension units.

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	4

8.120 DIMTFAC system variable

8.120.1 Tolerance text height

Controls the scale multiplier used to calculate the text height for dimension fractions and tolerances, relative to the dimension text height, set with the DIMTXT system variable. Only applies if the DIMLUNIT system variable is set to **Fractional** (5).

Type:	Real
Saved in:	Drawing
Default value:	1.0

8.121 DIMTFILL system variable

8.121.1 Text fill

Controls the dimension text background.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0



Possible values:	0: No background or fill 1: Background or fill color matches the background of the drawing window 2: Background or fill color matches the value specified by DIMTFILLCLR system variable
------------------	--

8.122 DIMTFILLCLR system variable

8.122.1 Text fill color

Controls dimension text background color, when the DIMTFILL system variable is set to 2.

Type:	Short
Saved in:	Drawing
Range:	0 to 256
Default value:	0
Possible values:	0: ByBlock 1-255: index 256: ByLayer

8.123 DIMTIH system variable

8.123.1 Text inside align

Controls the dimension text position on dimensions.

Note: It does not apply to ordinate dimensions.

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	Off (0): Aligned with dimension line On (1): Horizontal

8.124 DIMTIX system variable

8.124.1 Text inside

Draws dimension text between extension lines, even if there is insufficient room.



Note: It does not apply to radius and diameter dimensions.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't force text between extension lines On (1): Force text between extension lines

8.125 DIMTM system variable

8.125.1 Tolerance limit lower

Controls the minimum (lower) tolerance limit for dimension text when the DIMTOL or DIMLIM system variable is on.

Type:	Real
Saved in:	Drawing
Default value:	0.0

8.126 DIMTMOVE system variable

8.126.1 Text movement

Controls how dimension text moves.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Move dimension line with dimension text 1: Add leader when dimension text is moved 2: Allow text to be moved freely without a leader



8.127 DIMTOFL system variable

8.127.1 Dim line forced

Forces a dimension line to be drawn between dimension extension lines, even when text is placed outside.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't force dimension lines even when text is outside On (1): Force dimension lines even when text is outside

8.128 DIMTOH system variable

8.128.1 Text outside align

Places dimension text outside extension lines horizontally.

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	Off (0): Aligned with dimension line On (1): Horizontal

8.129 DIMTOL system variable

8.129.1 Tolerance display

Adds tolerances to dimension text.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display tolerance On (1): Display tolerance



8.130 DIMTOLJ system variable

8.130.1 Tolerance pos vert

Controls the vertical position for tolerance values relative to the primary dimension text.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Bottom 1: Middle 2: Top

8.131 DIMTP system variable

8.131.1 Tolerance limit upper

Controls the maximum (upper) tolerance limit for dimension text when the DIMTOL or DIMLIM system variable is on.

Type:	Real
Saved in:	Drawing
Default value:	0.0

8.132 DIMTSZ system variable

8.132.1 Dim tick size

Controls the size of tick marks drawn instead of arrowheads for linear, radius and diameter dimensions.

If the value is zero, arrowheads are drawn.

Type:	Real
Saved in:	Drawing
Default value:	0.0



Possible values:	0: Draw arrowheads >0: Draw oblique strokes instead of arrowheads
------------------	--

8.133 DIMTVP system variable

8.133.1 Text offset vertical

Controls the vertical position of dimension above or below the dimension line. Acts as a multiplier of the DIMTXT system variable, when the DIMTAD system variable is set to **Centered between extension lines**. A value of 1.0 is equivalent to setting the DIMTAD system variable to on (1).

Type:	Real
Saved in:	Drawing
Default value:	0.0

8.134 DIMTXSTY system variable

8.134.1 Text style

Controls the default dimension text style.

Type:	String
Saved in:	Drawing
Default value:	Standard

8.135 DIMTXT system variable

8.135.1 Text height

Controls the default dimension text height, if the text style set in the DIMTXSTY system variable has no fixed height.

Type:	Real
Saved in:	Drawing
Default value:	0.18 - If MEASUREMENT=0 and INSUNITS=inches 2.5 - If MEASUREMENT=1 and INSUNITS=millimeters



8.136 DIMXTDIRECTION system variable

8.136.1 Text direction

Controls the dimension text direction.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Left to right On (1): Right to left

8.137 DIMTZIN system variable

8.137.1 Tolerance suppress zeros

Controls the suppression of zeros in tolerance values.

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	0
Possible options:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions

8.138 DIMUNIT system variable

8.138.1 Dim unit type (obsolete)

Replaced by DIMLUNIT and DIMFRAC system variables.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	1 to 8
Default value:	2
Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural (stacked) 5: Fractional (stacked) 6: Architectural 7: Fractional 8: Windows Control Panel

8.139 DIMUPT system variable

8.139.1 Place text manually

Toggles the placement of dimension text during dimension creation.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Cursor controls only the dimension line location On (1): Cursor controls both the text position and the dimension line location

8.140 DIMZIN system variable

8.140.1 Suppress dim zeros

Suppresses leading and/or trailing zeros for primary units.

Type:	Short
Saved in:	Drawing
Range:	0 to 15



Default value:	0
Possible options:	0: Suppress zero feet and precisely zero inches 1: Include zero feet and precisely zero inches 2: Include zero feet and suppress zero inches 3: Suppress zero feet and include zero inches 4: Suppress leading zeros in decimal dimensions 8: Suppress trailing zeros in decimal dimensions

8.141 DISPLAYAXES system variable

8.141.1 Display Axes

Displays the axes of structural elements.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible options:	Off (0): Do not display axes On (1): Display axes

8.142 DISPLAYAXESFORMEP system variable

8.142.1 Display axes

Controls the display of MEP element axes.

Type:	Boolean
Saved in:	Registry
Default value:	0

8.143 DISPLAYSCALING system variable

8.143.1 Automatic display scaling (Read Only)

Current display scaling - the same as the system display settings.

BricsCAD only



Type:	Short
Saved in:	Not saved
Range:	50 to 1000
Default value:	100

8.144 DISPLAYSIDESANDENDS system variable

8.144.1 Display Sides and Ends

Displays the sides and ends of structural entities on selection. If on, these are selectable.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display sides and ends On (1): Display side and ends

8.145 DISPLAYSNAPMARKERINALLVIEWS system variable

8.145.1 Snap marker in all views

Controls if snap markers display in all viewports.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't display snap marker in all views On (1): Display snap marker in all views



8.146 DISPLAYTOOLTIPS system variable

8.146.1 Snap tooltips

Toggles the display of snap tooltips on/off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable snap tooltips On (1): Enable snap tooltips

8.147 DISPLAYTRUEDIMENSION system variable

8.147.1 Default dimension type

Sets the default dimension type placed on an isometric view.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Projected - not aligned with geometry. 1: True - aligned with geometry

8.148 DISPPAPERBKG system variable

8.148.1 Paper background

Displays a paper sheet in paper space.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Don't display paper background On (1): Display paper background

8.149 DISPPAPERMARGINS system variable

8.149.1 Printable area

Displays the printable area of a layout in paper space.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display printable area On (1): Display printable area


8.150 DISPSILH system variable

8.150.1 Display silhouette curves

Displays silhouette curves on solid entities in Wireframe modes (2D and 3D).

Note: To view changes on existing entities, perform a REGEN.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display silhouette curves On (1): Display silhouette curves



8.151 DISTANCE system variable

8.151.1 Distance (Read Only)

The last calculated distance of the DIST command.

Type:	Real
Saved in:	Not saved

8.152 DMAUDITLEVEL system variable

8.152.1 DMAUDIT command, level of detail

Controls the message types displayed for the DMAUDIT command.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 3
Default value:	1
Possible options:	1: Ignore dynamic range errors 2: Ignore sliver faces

Dynamic range

The dynamic range is the range of lengths required to create valid geometry. The range is limited because a modeler expresses the coordinates of points in 3D-space in terms of double precision floating point numbers. To represent a number, floating point numbers use a finite number of significant digits, which in the case of double precision numbers is roughly fourteen to sixteen significant digits. The modeler's use of digits is limited to nine significant digits to avoid susceptibility to round-off error. This means that a model's dynamic range can only be nine orders of magnitude wide. Thus, the ratio of the longest to shortest length that can be modeled is 10^9 .

The numbers could be interpreted as inches, millimeters, or any other unit. The modeler has a resolution of 10^{-6} , which means that if the distance between two points is less than that, they are considered to be the same. A guard band of at least one order of magnitude around the resolution value is also required.



For practical reasons, there can be ambiguity about distances that are close to the resolution value, so this guard band is a safety margin to improve reliability.

As a result, the valid dynamic range of models in BricsCAD is 10^{-5} to 10^4 and is not unit dependent. The dynamic range of parts modeled in millimeters is 0.00001 mm to 10000 mm. The dynamic range of parts modeled in meters is 0.00001 m to 10000 m.

If the dynamic range is exceeded, the behavior of modeling algorithms is unpredictable. This may cause modeler algorithms to produce incorrect results or failures.

Sliver face

Some models may contain long narrow faces that were not intended to be present in the design of the model. Typically, these occur in imported models due to the tolerance differences between geometric modeling systems.

Because the size of a feature cannot be smaller than the resolution of a modeler, genuine faces are at least an order of magnitude larger than the maximum gap in the model. Any face smaller than that is a candidate for being spurious.

The entity's tolerance is calculated as the highest tolerance value among the entity's tolerant edges and vertices.

The maximum distance between the long edges of such a face is smaller than the specified tolerance. It has at least one short and no more than three long edges. A short edge is an edge that is shorter than the specified tolerance. A long edge is longer than the specified tolerance. The tolerance can be calculated automatically based on the entity's bounding box.

Because the dimensions of sliver geometry are close to the modeler resolution, performing operations on it is difficult. Because such geometry isn't usually intended, it is attempted to be replaced with tolerant geometry. In bodies, tolerant edges replace sliver faces, and tolerant vertices replace short edges. When fixing manually, slivers can be removed and adjacent faces extended if needed.

Note: When performing entity check and heal in various contexts, tolerance is taken from the entity as the biggest value of tolerance among entity's tolerant edges and vertices, or some other values on discretion of the caller.

8.153 DMAUTOUPDATE system variable

8.153.1 3D constraints recalculation mode

Updates the model automatically, when constraints are applied or modified.

If off, use the DMUPDATE command to update the model.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't update 3D constraints automatically On (1): Update 3D constraints automatically



8.154 DMCONNECTIONCUTTYPE system variable

8.154.1 Connection type

Controls the type of connection created by the BIMSTRUCTURALCONNECT command.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Smooth 1: Planar

8.155 DMPUSHPULLSUBTRACT system variable

8.155.1 DMPUSHPULL subtract

Controls what happens when an entity, modified with the DMPUSHPULL command, touches an existing entity.

When OFF, a solid that intersects with another solid, no longer subtracts the intersecting areas from the other solid.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Range:	0 to 1
Default value:	Off
Possible values:	Off (0): Disable DMPUSHPULL subtract On (1): Enable DMPUSHPULL subtract



8.156 DMRECOGNIZE system variable

8.156.1 Automatic 3D geometry constraints recognition

Automatically constrains geometrical relations between surfaces, when 3D entities are edited or 3D constraints are recalculated.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	-1 to 1023
Default value:	0
Possible options:	Negative: Switch off automatic 3D geometry constraints recognition 1: Tangent surfaces 2: Coincident planes 4: Parallel planes 8: Perpendicular planes 16: Cylinders perpendicular to planes 32: Coaxial surfaces 64: Cylinders and spheres of equal radius 128: Vertices between 4 or more faces 256: Edges between coincident faces 512: Fix a constrained plane lying in XY/YZ/ZX (compatibility)

8.157 DOCKPRIORITY system variable

8.157.1 Docking Priority

Controls the dock priority of top, left, right and bottom docking bars.

Note: A restart is required.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 14
Default value:	1



Possible values:	1: Top, Left, Right, Bottom 2: Top, Bottom, Left, Right 3: Top, Left, Bottom, Right 4: Top, Right, Bottom, Left 5: Left, Right, Top, Bottom 6: Left, Top, Bottom, Right 7: Left, Top, Right, Bottom 8: Left, Bottom, Right, Top 9: Right, Top, Left, Bottom 10: Right, Bottom, Left, Top 11: Right, Top, Bottom, Left 12: Bottom, Left, Right, Top 13: Bottom, Left, Top, Right 14: Bottom, Right, Top, Left
------------------	---

8.158 DOCTABPOSITION system variable

8.158.1 Tabs position

Controls where the document control tab is displayed.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	0
Possible values:	0: Top 1: Bottom 2: Left 3: Right

8.159 DONUTID system variable

8.159.1 Donut inside diameter

The default inside diameter for the DONUT command.

Type:	Real
-------	------



Saved in:	Not saved
Default value:	0.5

8.160 DONUTOD system variable

8.160.1 Donut outside diameter

The default outside diameter for the DONUT command.

Type:	Real
Saved in:	Not saved
Default value:	1.0

8.161 DRAGMODE system variable

8.161.1 Entity drag mode

Controls if a preview displays during the MOVE and COPY commands.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: No dragging 1: When requested 2: Whenever possible

8.162 DRAGMODECONSTRAINTS system variable

8.162.1 Solve 3D constraints dynamically

Solves 3D constraints live when entities are moved.

Turn off to optimize performance.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable dynamic solution of 3D constraints On (1): Enable dynamic solution of 3D constraints

8.163 DRAGMODEFACES system variable

8.163.1 MOVE face

Controls the behavior of the MOVE and DMMOVE commands, if these commands are used to move a face.
BricsCAD only

Type:	Short
Saved in:	Workspace
Default value:	1
Possible values:	0: Move the whole solid 1: Move the face's surface 2: Move the face's edges

8.164 DRAGMODEHIDE system variable

8.164.1 Hide during drag

Hides the original entity during move and stretch actions.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	1: During 3D Modeling commands 2: During 2D Drafting commands



8.165 DRAGMODEINTERRUPT system variable

8.165.1 Drag interruption mode

Controls the recalculation/redrawing of the model is interrupted when the cursor is in motion.

If on, display a live preview. If off, every drag action must first be completed.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	0: Disabled 1: Enabled

8.166 DRAGOPEN system variable

8.166.1 Drag open

Controls what to do when a drawing is dragged from the explorer to the program.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Insert file to current drawing 1: Open file in new tab

8.167 DRAGP1 system variable

8.167.1 Regen-drag rate

Controls the regen-drag input sampling rate.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 32767
Default value:	10

8.168 DRAGP2 system variable

8.168.1 Fast-drag rate

Controls the fast-drag input sampling rate.

Type:	Short
Saved in:	Registry
Range:	0 to 32767
Default value:	25

8.169 DRAGSNAP system variable

8.169.1 Snap dragged entities

Enables rubber band dynamics during modify commands: COPY, PASTECLIP, PASTEBLOCK, MOVE, ROTATE, MIRROR, SCALE, STRETCH and more.

The DRAGSNAP system variable controls the snap behavior while dragging. DRAGSNAP controls whether rubberband dynamics are displayed at the current cursor location or at the current entity snap location.

Note: Rubber band dynamics means that the cursor and the entity being modified will jump to the active snap point, this will make the target location more obvious.

- If on, the cursor and any selected entities will jump to the active snap point, this will make the target location more obvious.
- If off, snap is only in effect during drawing and editing commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't snap dragged entities On (1): Snap dragged entities
------------------	---

8.170 DRAWINGPATH system variable

8.170.1 Drawings path

The file path used for the fifth folder on the left of the OPEN, SAVEAS and INSERT command dialogs (Windows only).

BricsCAD only

Type:	String Standard
Saved in:	Preference

8.171 DRAWINGVIEWASM system variable

8.171.1 Assemblies optimization

Enables the use of assembly data structures, optimizes the generation of views created with the VIEWBASE command.

Toggles between normal analytical hidden line removal (HLR) and ASM_HLR procedure.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Disable assemblies optimization On (1): Enable assemblies optimization

8.172 DRAWINGVIEWENTS system variable

8.172.1 Additional entities

Controls entities that will be processed in drawing views created by VIEWBASE command.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Disable displaying of the Points On (1): Point (appearance is controlled by PDSIZE and PDMODE)

8.173 DRAWINGVIEWFLAGS system variable

8.173.1 Drawing View Flags

Enables the settings for drawing view related commands (for example, VIEWBASE, VIEWUPDATE).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible options:	0: Disable the settings for the drawing views 1: Enable parallel generation and update of views 2: Enable background generation of views

8.174 DRAWINGVIEWPRESET system variable

8.174.1 Drawing view preset

Controls the view preset for the VIEWBASE command.

Presets specify the types of generated drawings and their placement in the layout.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	None



8.175 DRAWINGVIEWPRESETHIDDEN system variable

8.175.1 Drawing view hidden lines preset

Controls the hidden lines preset for the VIEWBASE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't store the current hidden line preset On (1): Store the current hidden line preset

8.176 DRAWINGVIEWPRESETSCALE system variable

8.176.1 Scale for drawing view preset

Controls the annotation scale for the current drawing view preset.

BricsCAD only

Type:	String
Saved in:	Registry

8.177 DRAWINGVIEWPRESETTANGENT system variable

8.177.1 Drawing view tangent lines preset

Controls the tangent lines preset for the VIEWBASE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't store the current tangent lines preset On (1): Store the current tangent lines preset



8.178 DRAWINGVIEWPRESETTRAILING system variable

8.178.1 Drawing view trailing lines preset

Controls the trailing lines preset for the VIEWBASE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't store the current trailing lines preset On (1): Store the current trailing lines preset

8.179 DRAWINGVIEWQUALITY system variable

8.179.1 Quality of drawing views

Controls the quality of views created with the VIEWBASE command.

Turn off to significantly reduce the time needed to generate drawing views. Views with draft-quality geometry are created, it is not possible to put annotations on the edges of entities in these views.

However, they look very similar to a precise (high-quality) drawing view and you can use them to quickly create layouts.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Draft quality 1: High quality

8.180 DRAWORDERCTL system variable

8.180.1 Draworder control

Controls draw order functionality. Limits the draw order, use if some editing operations take slightly longer.



Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible options:	1: Default display of entities with draw order 2: Draw order inheritance

8.181 DWFFORMAT system variable

8.181.1 Default DWF format

Controls the default export format for the 3DDWF command.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: DWF 1: DWFX

8.182 DWFFRAME system variable

8.182.1 DWF frame

Controls the visibility of DWF or DWFX underlay frames, if the FRAME system variable is set to **Use individual system variables (3)**.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2



Possible values:	0: Hide DWF frames 1: Display and plot DWF frames 2: Display but do not plot DWF frames
------------------	---

8.183 DWFOSNAP system variable

8.183.1 DWF entity snap

Enables entity snap for DWF underlay files.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable DWF entity snap On (1): Enable DWF entity snap

8.184 DWFVERSION system variable

8.184.1 DWF version

Controls the DWF export version.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 10
Default value:	2



Possible values:	1: 3D DWF v6.01 2: Binary DWF v6.0 3: Zipped Ascii Encoded 2D Stream DWF v6.0 4: Compressed DWF v5.5 5: Binary DWF v5.5 6: Ascii DWF v5.5 7: Compressed DWF v4.2 8: Binary DWF v4.2 9: Ascii DWF v4.2 10: XPS DWFx
------------------	---

8.185 DWGCHECK system variable

8.185.1 Drawing check

Executes an automatic data integrity check when a drawing is opened.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: Warn on potential problem 1: Warn on potential problem and on other application 2: Notify on potential problem 3: Notify on potential problem, warn on other application

8.186 DWGCODEPAGE system variable

8.186.1 Drawing codepage (Read Only)

Displays the drawing code page, same as the SYSCODEPAGE system variable.

Type:	String
Saved in:	Drawing



8.187 DWGGUIDCLOUDAI system variable

8.187.1 Drawing Guid

Unique GUID (Globally Unique Identifier) for this drawing.

BricsCAD only

Type:	String
Saved in:	Drawing
Default value:	" "

8.188 DWGNAME system variable

8.188.1 Drawing name (Read Only)

The name of the current drawing.

Type:	String
Saved in:	Not saved

8.189 DWGPREFIX system variable

8.189.1 Drawing prefix (Read Only)

The folder path of the current drawing.

Type:	String Standard
Saved in:	Not saved

8.190 DWGTITLED system variable

8.190.1 Drawing titled (Read Only)

Shows if the current drawing has been named.

Type:	Boolean
Saved in:	Not saved



Possible values:	Off (0): Drawing has not been named On (1): Drawing has been named
------------------	---

8.191 DXEVAL system variable

8.191.1 Data extraction update mode

Controls the notification for data extraction tables.

Type:	Short
Saved in:	Drawing
Range:	0 to 511
Default value:	12
Possible options:	0: No notification 1: Notification on open 2: Notification on save 4: Notification on plot 8: Notification on publish 16: Notification on ETRANSMIT or ARCHIVE 32: Notification on save + automatic update 64: Notification on plot + automatic update 128: Notification on publish + automatic update 256: Notification on ETRANSMIT or ARCHIVE + automatic update

8.192 DXFTEXTADJUSTALIGNMENT system variable

8.192.1 DXF text adjust alignment

Controls if alignment is adjusted when text is loaded from a DXF.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't adjust alignment On (1): Adjust alignment



8.193 DYNCONSTRAINTMODE system variable

8.193.1 Dynamic Constraint Mode

Displays hidden dimensional constraints when constrained entities are selected.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display hidden dimensional constraints when constrained entities are selected. On (1): Display hidden dimensional constraints when constrained entities are selected.

8.194 DYNDIGRIP system variable

8.194.1 Show dynamic dimensions

Controls which dynamic dimensions are shown.

Type:	Short
Saved in:	Registry
Range:	0 to 31
Default value:	31
Possible options:	0: None 1: Resulting length 2: Extended length 4: Absolute angle 8: Relative angle 16: Arc radius

8.195 DYNDIMAPERTURE system variable

8.195.1 Dynamic dimension aperture

Controls the radius around the cursor, used to detect the nearest entity during a command, in pixels.

Applies only when the DYNMODE system variable is set to **Nearest entity dynamic dimensions**.

Values between 1 and 500 are accepted.



BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 500
Default value:	20
Unit	pixels

8.196 DYNDIMCOLORHOT system variable

8.196.1 Dynamic dimension hot color

The color of dynamic dimensions, during a grip move action.

Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	142

8.197 DYNDIMCOLORHOVER system variable

8.197.1 Dynamic dimension hover color

The color of dynamic dimensions, when the cursor hovers over a grip point.

Values between 1 and 255 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255



Default value:	142
----------------	-----


8.198 DYNDIMDISTANCE system variable

8.198.1 Dynamic dimension distance

Controls the position of the dynamic dimension box - the offset distance from the entity.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 10.0
Default value:	1.0



8.199 DYNDIMLINETYPE system variable

8.199.1 Dynamic dimension linetype

Controls the linetype visualization of dynamic dimensions during a grip move action.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	-1 to 2
Default value:	0



Possible values:	-1: Current 0: Continuous 1: Dotted 2: Dashed
------------------	--

8.200 DYNDIVIS system variable

8.200.1 Dynamic dimension visibility

Controls which dynamic dimensions are displayed when grips are moved.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Only the first dynamic dimension 1: Only the first two dynamic dimensions 2: All dynamic dimensions, as specified by DYNDIGRIP

8.201 DYNINPUTTRANSPARENCY system variable

8.201.1 Transparency of dynamic input fields

Controls the transparency of dynamic input fields, as a percentage.

- A value of zero means fully transparent.
- A value of 100 means fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	90



8.202 DYNMODE system variable

8.202.1 Dynamic input mode

Toggles dynamic input features on/off.

Type:	Short
Saved in:	Registry
Range:	-31 to 31
Default value:	3
Possible options:	Negative: Switch all off temporarily 0: No dynamic input 1: Dynamic input at pointer (not yet supported) 2: Editable dynamic dimensions 4: Tracking dynamic dimensions 8: Nearest entity by UCS X/Y axes dynamic dimensions 16: Nearest entity dynamic dimensions

8.203 DYNPICOORDS system variable

8.203.1 Default mode for dynamic coordinates input

The default mode for coordinate entry, during dynamic input.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Relative 1: Absolute



9. E

9.1 EDGEMODE system variable

9.1.1 Edge mode

Controls how cutting and boundary edges are checked with the TRIM and EXTEND commands, with or without extension.


Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Use the selected edge without an extension On (1): Extend or trim the selected entity to an imaginary extension of the cutting or boundary edge

9.2 ELEVATION system variable

9.2.1 Elevation

The elevation (Z-axis) for new entities, relative to the current UCS.

Type:	Real
Saved in:	Drawing
Default value:	0.0





9.3 ENABLEATTRACTION system variable

9.3.1 Grips attraction

Enables grip to grip attraction during move or modify actions on a grip point.

Note: The OSMODE system variable may override this behavior.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable grip attraction On (1): Enable grip attraction

9.4 ENABLEBIMBKUPDATE system variable

9.4.1 Enable section update in background

Enables section update in the background, see the BIMBKUPDATE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

9.5 ENABLEHYPERLINKMENU system variable

9.5.1 Hyperlink menu

Toggles the hyperlink menu on/off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



Possible values:	Off (0): Disable hyperlink menu On (1): Enable hyperlink menu
------------------	--

9.6 ENABLEHYPERLINKTOOLTIP system variable

9.6.1 Hyperlink tooltip

Toggles the display of the hyperlink tooltip on/off.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Disable hyperlink tooltip On (1): Enable hyperlink tooltip

9.7 ERRNO system variable

9.7.1 Error number (Read Only)

Reports the error type of a LISP program.

Type:	Short
Saved in:	Not saved
Default value:	0

9.8 EXPERIMENTALMODE system variable

9.8.1 Enable experimental features

You may experience bugs or performance issues in BricsCAD when the experimental mode is enabled. We encourage you to report them. Experimental features can change or be removed from future versions.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	0
Possible options:	0: Disable the Experimental mode 1: Enable the Experimental mode

9.9 EXPERIMENTALONSTARTPAGE system variable

9.9.1 Experimental features on start page

Switch to control whether experimental features can be managed from the start page.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible options:	0: Experimental features cannot be managed from the start page 1: Experimental features can be managed from the start page

9.10 EXPERT system variable

9.10.1 Expert

Controls the display of certain prompts. If prompts are suppressed, continues as though y(es) was entered. Can affect scripts, menu macros, LISP and command functions.

Type:	Short
Saved in:	Not saved
Range:	0 to 5
Default value:	0
Possible values:	0: Issue all prompts normally 1: Suppress regen and layer off prompts 2: Also suppress block already defined (BLOCK) and file already exists (SAVE and WBLOCK) prompts 3: Also suppress linetype already loaded prompt 4: Also suppress file already exists (UCS and VPORTS Save) prompts 5: Also suppress dimstyle already exists prompt



9.11 EXPINSALIGN system variable

9.11.1 Explorer Insert Aligned

Align blocks inserted from the Drawing Explorer with selected entities.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't insert blocks aligned On (1): Insert blocks aligned

9.12 EXPINSANGLE system variable

9.12.1 Explorer Insert Angle

The rotation angle used for blocks inserted from the Drawing Explorer.

Applies if the EXPINSFIXANGLE system variable is switched on.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0
Unit	degrees

9.13 EXPINSFIXANGLE system variable

9.13.1 Explorer Insert Fix Angle

Uses a rotation angle for blocks inserted from the Drawing Explorer. See also the EXPINSANGLE system variable.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	On
Possible values:	Off (0): Don't insert blocks at fixed angle On (1): Insert blocks at fixed angle

9.14 EXPINSFIXSCALE system variable

9.14.1 Explorer Insert Fix Scale

Inserts blocks from Drawing Explorer at a fixed scale.

See the EXPINSSCALE system variable.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't insert blocks at fixed scale On (1): Insert blocks at fixed scale

9.15 EXPINSSCALE system variable

9.15.1 Explorer Insert Scale

The scale multiplier used for blocks inserted from the Drawing Explorer.

Applies if the EXPINSFIXSCALE system variable is switched on (1).

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	1.0

9.16 EXPLMODE system variable

9.16.1 Explode mode

Enables the EXPLODE command on nonuniformly scaled (NUS) blocks.



Type:	Boolean
Saved in:	Registry
Range:	On
Possible values:	Off (0): Don't explode nonuniformly scaled blocks On (1): Explode nonuniformly scaled blocks

9.17 EXPORT3DPDFWRITER system variable

9.17.1 3D PDF writer

Controls the writer used to save 3D PDF files.

Type:	Short
Saved in:	Registry
Default value:	1
Possible values:	0: Communicator 3D PDF writer 1: Internal 3D PDF writer

9.18 EXPORTACISASSEMBLYWRITER system variable

9.18.1 ASAT/ASAB writer

Controls the writer used to save ASAT/ASAB files. The internal ASAT/ASAB writer used if the Communicator for BricsCAD® is not installed.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Communicator ASAT/ASAB writer 1: Internal ASAT/ASAB writer



9.19 EXPORTACISFORMATVERSION system variable

9.19.1 ACIS export format version

Controls the ACIS file version to export to.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0
Possible options:	0: Latest available 1: R18 2: R19 3: R20 4: R21 5: R22 6: R23 7: R24 8: R25 9: 2016 10: 2017 11: 2018 12: 2019 13: 2020 14: 2021 15: 2022 16: 2023 17: 2024

9.20 EXPORTCATIAV4FORMATVERSION system variable

9.20.1 CATIA V4 export format version

Controls CATIA V4 file version to export to.

Type:	Short
Saved in:	Registry
Range:	0 to 6
Default value:	0



Possible values:	0: Latest available 1: 4.1.9 2: 4.2.0 3: 4.2.1 4: 4.2.2 5: 4.2.3 6: 4.2.4
------------------	---

9.21 EXPORTCATIAV5FORMATVERSION system variable

9.21.1 CATIA V5 export format version

Controls CATIA V5 file version to export to.

Type:	Short
Saved in:	Registry
Range:	0 to 17
Default value:	0
Possible values:	0: Latest available 1: CATIA V5 R16 2: CATIA V5 R17 3: CATIA V5 R18 4: CATIA V5 R19 5: CATIA V5 R20 6: CATIA V5 R21 7: CATIA V5 R22 8: CATIA V5 R23 9: CATIA V5 R24 10: CATIA V5 R25 11: CATIA V5-6 R2016 12: CATIA V5-6 R2017 13: CATIA V5-6 R2018 14: CATIA V5-6 R2019 15: CATIA V5-6 R2020 16: CATIA V5-6 R2021 17: CATIA V5-6 R2022 18: CATIA V5-6 R2023 19: CATIA V5-6 R2024



9.22 EXPORTGEOMETRYFLAGS system variable

9.22.1 Export Geometry Flags

Controls how geometry representations in IGES and STEP formats are exported.

Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	0
Possible values:	01: Convert Analytical Curves to Splines 02: Convert Analytical Surfaces to Splines 04: Split Pcurves at G1 Discontinuities (Mac only) 08: Split Periodic Faces

9.23 EXPORTHIDDENPARTS system variable

9.23.1 Hidden parts

Controls how hidden parts are exported.

Entities can be invisible because of:

- The result of the HIDEOBJECTS command.
- Sitting on a hidden layer.
- Owned by an invisible component.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Export and hide if possible: Exports hidden entities. If the target format supports hidden entities, hidden entities in the source document will be hidden also in target document. 1: Do not export: Invisible entities are skipped.



9.24 EXPORTMODELSPACE system variable

9.24.1 Export model space

Controls what part of model space to export to DWF, DWFx or PDF.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Display 1: Extents 2: Window

Note: The EXPORTMODELSPACE, EXPORTPAPERSPACE and EXPORTPAGESETUP system variables currently are dummies for DWF exports.

9.25 EXPORTPAGESETUP system variable

9.25.1 Export page setup

Toggles the page setup for DWF, DWFx or PDF export.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Default 1: Override

Note: The EXPORTMODELSPACE, EXPORTPAPERSPACE and EXPORTPAGESETUP system variables currently are dummies for DWF exports.



9.26 EXPORTPAPERSPACE system variable

9.26.1 Export paper space

Controls which layout(s) to export to DWF, DWFx or PDF, from paper space.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Current layout 1: All layouts

Note: The EXPORTMODELSPACE, EXPORTPAPERSPACE and EXPORTPAGESETUP system variables currently are dummies for DWF exports.

9.27 EXPORTPARASOLIDFORMATVERSION system variable

9.27.1 Parasolid export format version

Controls the Parasolid file version to export to.

Type:	Short
Saved in:	Registry
Range:	0 to 23
Default value:	0



Possible values:	0: Latest available 1: Parasolid 12 2: Parasolid 13 3: Parasolid 14 4: Parasolid 15 5: Parasolid 16 6: Parasolid 17 7: Parasolid 18 8: Parasolid 19 9: Parasolid 20 10: Parasolid 21 11: Parasolid 22 12: Parasolid 23 13: Parasolid 24 14: Parasolid 25 15: Parasolid 26 16: Parasolid 27 17: Parasolid 28 18: Parasolid 29 19: Parasolid 30 20: Parasolid 31 21: Parasolid 32 22: Parasolid 33 23: Parasolid 34 24: Parasolid 35 25: Parasolid 36
------------------	--

9.28 EXPORTPRODUCTSTRUCTURE system variable

9.28.1 Product structure

Controls if a product structure is exported.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1



Possible values:	0: No product structure: Exports a flat structure without components in the target document, whether the BricsCAD document has a product structure or not. 1: Export product structure: Exports the BricsCAD product structure data (if existing) to the target document.
------------------	--

Note: The option [1] is valid for Pro (or higher) license level. It works as [0] otherwise.

9.29 EXPORTSTEPFORMATVERSION system variable

9.29.1 STEP export format version

Controls the STEP file version to export to.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: AP203 1: AP214 2: AP242

9.30 EXPORTXCGMFORMATVERSION system variable

9.30.1 XCGM export format version

Controls the XCGM file version to export to.

Type:	Short
Saved in:	Registry
Range:	0 to 16
Default value:	0



Possible values:	0: Latest available 1: CGM R2013x 2: CGM R2014 3: CGM R2014x 4: CGM R2015x B1 5: CGM R2015x B5 6: CGM R2015x B5 SP1 7: CGM R2016 1.0 8: CGM R2016 1.1 9: CGM R2017 1.0 10: CGM R2017 1.1 11: CGM R2018 1.0 12: CGM R2018 1.1 13: CGM R2019 1.0 14: CGM R2020 1.0 15: CGM R2021 1.0 16: CGM R2022 1.0 17: CGM R2023 1.0 18: CGM R2024 1.0
------------------	--

9.31 EXTMAX system variable

9.31.1 Extents maximum (Read Only)

The drawing extents' upper-right coordinate.

It increases as new entities are created outside the existing extents.

Type:	3D point
Saved in:	Drawing

9.32 EXTMIN system variable

9.32.1 Extents minimum (Read Only)

The drawing extents' lower-left coordinates.

Type:	3D point
Saved in:	Drawing



9.33 EXTNAMES system variable

9.33.1 Extend names

Controls the maximum characters for the names of named entities (for example: linetypes and layers) saved in symbol tables.

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	Off (0): Names up to 31 characters On (1): Names up to 255 characters

9.34 EXTRUDEINSIDE system variable

9.34.1 Extrude behavior inside

Controls how new entities, modify a parent entity when they intersect. Applies to entities as they are created with the EXTRUDE and REVOLVE commands, when the **Auto** option is selected.

A parent entity is any entity that touches the contour from which the extruded/revolved entity was created.

The EXTRUDEINSIDE system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0 - for Workspaces Drafting and Modeling 1 - for Workspaces Mechanical and BIM
Possible options:	0: Do not modify 1: Subtract created entity from parent 2: Unite created entity with parent



9.35 EXTRUDEOUTSIDE system variable

9.35.1 Extrude behavior outside

Controls how new entities, modify a parent entity when they touch. Applies to entities as they are created with the EXTRUDE and REVOLVE commands, when the **Auto** option is selected.

A parent entity is any entity that touches the contour from which extruded/revolved entity was created.

The EXTRUDEOUTSIDE system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0 - for Workspaces Drafting and Modeling 1 - for Workspaces Mechanical and BIM
Possible options:	0: Do not modify 1: Subtract the new entity from the existing entity 2: Unite the entities



10. F

10.1 FACETRATIO system variable

10.1.1 Faceting aspect ratio

Controls the aspect ratio of faceting for cylindrical and conic ACIS solids.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Creates an N by 1 mesh for cylindrical and conic ACIS solids 1: Creates an N by M mesh for cylindrical and conic ACIS solids

10.2 FACETRES system variable

10.2.1 Facet resolution

Controls the smoothness of shaded, rendered and hidden line views.

Values between 0.01 and 10.0 are accepted. Large values can have a significant impact on memory usage and performance.

Type:	Real
Saved in:	Drawing
Range:	0.01 to 10.0
Default value:	0.5

10.3 FBXEXPORTCAMERAS system variable

10.3.1 FBX Export Cameras

Enables the export of cameras to FBX.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable export of cameras On (1): Enable export of cameras

10.4 FBXEXPORTENTITIES system variable

10.4.1 FBX Export Entities

Enables the export of entities to FBX.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable export of entities On (1): Enable export of entities

10.5 FBXEXPORTENTITIESSELTYPE system variable

10.5.1 FBX entities to export

Controls which entities are exported to FBX.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Visible Entities 1: Selected Entities



10.6 FBXEXPORTLIGHTS system variable

10.6.1 FBX Export Lights

Enables the export of lights to FBX.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable export of lights On (1): Enable export of lights

10.7 FBXEXPORTMATERIALS system variable

10.7.1 FBX Export Materials

Enables the export of materials to FBX.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable export of materials On (1): Enable export of materials

10.8 FBXEXPORTTEXTURES system variable

10.8.1 FBX Export Textures

Sets the material type used for an FBX file export.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2



Default value:	0
Possible values:	0: Embed 1: Reference 2: Copy textures to location

10.9 FBXEXPORTTEXTURESPATH system variable

10.9.1 Fbx Export Textures path

The file path for FBX Export Textures.

This setting is only used when the FBXEXPORTTEXTURES system variable is set to 2.

BricsCAD only

Type:	String Standard
Saved in:	Preference

10.10 FEATURECOLORS system variable

10.10.1 Feature colors

Colors sheet metal parts based on feature type.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible options:	On (1): Solid faces are colored by specified color of related feature Off (0): All feature faces are colored with the default 3d solid color

10.11 FIELDDISPLAY system variable

10.11.1 Field display

Applies a gray fill behind field text.

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): No gray background On (1): Gray background

10.12 FIELDEVAL system variable

10.12.1 Field update mode

Controls the way fields are updated.

Type:	Short
Saved in:	Drawing
Range:	0 to 31
Default value:	31
Possible options:	0: Not updated 1: Updated on open 2: Updated on save 4: Updated on plot 8: Updated on use of ETRANSMIT 16: Updated on regeneration

Note: Date fields are only updated by the UPDATEFIELD command; they are not automatically updated based on the FIELDEVAL system variable value.

10.13 FILEDIA system variable

10.13.1 File dialog

Toggles the display of file dialog boxes. If off, enter a tilde (~) to bring up the file dialog. This also works for LISP functions and command fields in tool definitions.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display dialog boxes On (1): Display dialog boxes



10.14 FILLETRAD system variable

10.14.1 Fillet radius

The last radius used with the FILLET command.

Type:	Real
Saved in:	Drawing
Default value:	0.5 - If MEASUREMENT=0 and INSUNITS=inches 10.0 - If MEASUREMENT=1 and INSUNITS=millimeters

10.15 FILLETWELDINGCOMBINEADJACENT system variable

10.15.1 Combine adjacent fillet welds

Makes it possible to combine adjacent fillet weld segments into one fillet welding feature.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't combine adjacent fillet weld segments. On (1): Combine adjacent fillet weld segments.

10.16 FILLETWELDINGMAXGAPRATIO system variable

10.16.1 Maximal ratio of a gap to a weld size

Sets the default maximal ratio of a gap between a welding part and the fillet weld size, see the FILLETWELDINGZSIZE system variable.

Values between 0.0 and 0.8 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 0.8



Default value:	0.4
----------------	-----

10.17 FILLETWELDINGZSIZE system variable

10.17.1 Default fillet weld Z size

Sets default Z-size of symmetric fillet welds.

Values between 0 and 50 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 50
Default value:	5

10.18 FILLMODE system variable

10.18.1 Fill mode

Shows fills for multilines, traces, solids, hatches (includes solid-fill), and wide polylines.

A REGEN is required.

If off, all filled entities display and print as outlines, this will also reduce the time it takes to display or print a drawing.

Type:	Boolean
Saved in:	Drawing
Range:	On
Possible values:	Off (0): Entities are not filled On (1): Entities are filled

10.19 FITLINEFITARCMODE system variable

10.19.1 FitLine FitArc mode

The FITLINEFITARCMODE system variable sets the values for the options **Use entire drawing**, **Fit in 3d**, and **Delete original entities after fitting**, that are used by the FITLINE and FITARC commands. The value is stored as a bit code using the sum of the values of all selected options.



Note: This system variable is only available at the Command line.

Type:	Byte
Saved in:	Registry
Range:	0 to 255
Default value:	0
Possible values:	0: None 1: Use entire drawing 2: Fit in 3D 4: Delete original entities after fitting

10.20 FITTINGRADIUSTYPE system variable

10.20.1 Fitting Radius Type

Sets the default flow fitting radius type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

10.21 FITTINGRADIUSVALUE system variable

10.21.1 Fitting Radius Value

Sets default flow fitting radius value.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1.5



10.22 FLANGEASMDEFAULTGASKET system variable

10.22.1 Default gasket

Controls the default gasket for flange assemblies.

BricsCAD only

Type:	String
Saved in:	Drawing
Default value:	ASME B16.21 Gasket FullFace for ASME B16.5

10.23 FONTALT system variable

10.23.1 Alternate font

The substitute font used when a text font cannot be found.

Type:	String
Saved in:	Registry
Default value:	simplex.shx

10.24 FONTMAP system variable

10.24.1 Font mapping file

The font mapping file.

Type:	String
Saved in:	Registry
Default value:	default.fmp

10.25 FRAME system variable

10.25.1 Frame

Controls the visibility of frames for XRefs, images and underlays.

Overrides the IMAGEFRAME, DWFFRAME, PDFFRAME, DGNFRAME, and XCLIPFRAME system variables.



Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible values:	0: Hide frames 1: Display and plot frames 2: Display but do not plot frames 3: Use individual system variables

10.26 FRAMESELECTION system variable

10.26.1 Frame selection

Controls if the hidden frame of an image, underlay, clipped XRefs, or wipeout can be selected.

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): Hidden frames cannot be selected On (1): Hidden frames can be selected

10.27 FRONTZ system variable

10.27.1 Front clipping plane offset

Displays the CLIPPING option of the DVIEW command.

Type:	Real
Saved in:	Drawing
Default value:	0.0



10.28 FULLOPEN system variable

10.28.1 Full open (Read Only)

Indicates the state of the current drawing.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Possible values:	0: Drawing is partially open 1: Drawing is fully open



11. G

11.1 GEARTEETHNUMBER system variable

11.1.1 Maximum number of sprocket teeth

Controls the number of teeth for sprockets, during the -BMHARDWARE command. Use this option to insert sprockets with simplified or full geometry.

Values between 0 and 1000 are accepted.

Note: This number must be greater or equal to the number of teeth of the inserted sprocket to create a sprocket with full geometry. 1000 is enough to insert any sprocket from the library with a full set of teeth.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	1

11.2 GENERATEASSOCATTRS system variable

11.2.1 Generate associative attributes

Enables the generation of associative attributes on 3D entities.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Possible values:	Off (0): Do not generate associative attributes for 3D entities On (1): Generate associative attributes for 3D entities

11.3 GENERATEASSOCVIEWS system variable

11.3.1 Generate associative drawings

Enables associative dimensions for drawings generated with the BIMSECTIONUPDATE, VIEWBASE and VIEWSECTION commands.

As a result, dimensions are updated in the associated paperspace viewports and BIM section drawings.

BricsCAD only



Type:	Boolean
Saved in:	Workspace
Default value:	Off
Possible values:	Off (0): Disable associative dimensions On (1): Enable associative dimensions

11.4 GEOCSMAPPRIORITY system variable

11.4.1 CSMAP priority

Controls priority of CSMAP engine over internal engine.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Internal engine is preferred, with CSMAP as fallback On (1): CSMAP engine is preferred, with internal as fallback

11.5 GEOLATLONGFORMAT system variable

11.5.1 Geographic latitude/longitude format

Controls the format of geographical latitude and longitude values.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	Off
Possible values:	0: Decimal degrees 1: Degrees/minutes/seconds



11.6 GEOMARKERVISIBILITY system variable

11.6.1 Geographic marker visibility

Controls the visibility of the geographic marker.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Geographic marker is not visible On (1): Geographic marker is visible

11.7 GEOMRELATIONS system variable

11.7.1 Geometric relationship indication

Controls if geometric relationships are recognized and maintained when a 2D entity is dragged.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	0
Possible options:	1: Recognize tangent relationships 2: Recognize perpendicular relationships

11.8 GETSTARTED system variable

11.8.1 Get Started

Controls if the Launcher is displayed on startup.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Don't show Launcher dialog On (1): Show Launcher dialog

11.9 GFANG system variable

11.9.1 Gradient fill angle

Controls the default gradient fill angle.

Type:	Real
Saved in:	Not saved
Default value:	0.0

11.10 GFCLR1 system variable

11.10.1 Gradient fill primary color

Controls the default first color of a gradient fill.

Type:	String
Saved in:	Not saved
Default value:	5

11.11 GFCLR2 system variable

11.11.1 Gradient fill secondary color

Controls the default second color of a gradient fill.

Type:	String
Saved in:	Not saved
Default value:	7



11.12 GFCLRLUM system variable

11.12.1 Gradient fill tint level

Controls the default tint intensity in a one-color gradient fill.

Type:	Real
Saved in:	Not saved
Default value:	1.0

11.13 GFCLRSTATE system variable

11.13.1 Number of colors for a gradient fill

Controls the default number of colors for a gradient fill.

Type:	Boolean
Saved in:	Not saved
Default value:	0
Possible values:	Off (0): Two colors On (1): One color

11.14 GFNAME system variable

11.14.1 Gradient fill name

Controls the pattern of a gradient fill.

Type:	Short
Saved in:	Not saved
Range:	1 to 9
Default value:	1



Possible values:	1: LINEAR 2: CYLINDER 3: INVCYLINDER 4: SPHERICAL 5: HEMISPHERICAL 6: CURVED 7: INVSPHERICAL 8: INVHEMISPHERICAL 9: INVCURVED
------------------	---

11.15 GFSHIFT system variable

11.15.1 Gradient fill shift

Controls if a gradient fill pattern is centered or is shifted up and to the left.

Type:	Boolean
Saved in:	Not saved
Default value:	0
Possible values:	Off (0): Centered On (1): Shifted

11.16 GLSWAPMODE system variable

11.16.1 GL Swap Mode

Controls the swap method used when drawing with the GL engine. Depending on the hardware driver used, the visual effect may differ between these options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 4
Default value:	2



Possible values:	0: Call glCopyPixels to copy back to front, don't call glXSwapBuffers. 1: Call glCopyPixels to copy back to front, then call glXSwapBuffers. 2: Call glXSwapBuffers, don't call glCopyPixels. 3: Call glXSwapBuffers, then call glCopyPixels to copy front to back. 4: Do nothing - for testing purposes only.
------------------	--

11.17 GRADIENTCOLORBOTTOM system variable

11.17.1 Background gradient color bottom

Controls the default bottom color for gradient backgrounds and the default for solid view backgrounds.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:210,210,210

11.18 GRADIENTCOLORMIDDLE system variable

11.18.1 Background gradient color middle

Controls the default middle color for gradient backgrounds.

Applies only if the GRADIENTMODE system variable is set to **Three-color gradient**.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	RGB:250,250,250

11.19 GRADIENTCOLORTOP system variable

11.19.1 Background gradient color top

Controls the default top color for gradient backgrounds.

BricsCAD only

Type:	String
-------	--------



Saved in:	Preference
Default value:	White

11.20 GRADIENTMODE system variable

11.20.1 Background gradient mode

Controls if and how a gradient is applied in the default background. Can be adjusted in the **Background** dialog box.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: No gradient background 1: Two-color gradient (top/bottom) 2: Three-color gradient (top/middle/bottom)

11.21 GRIDAXISCOLOR system variable

11.21.1 Grid axis color

Controls the color of the grid axis lines.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	254



11.22 GRIDDISPLAY system variable

11.22.1 Grid display

Controls how the grid is displayed.

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	2
Possible options:	0: Restrict to LIMITS area 1: Display beyond LIMITS area 2: Adaptive grid display 4: Allow subdivision below grid spacing 8: Follow Dynamic UCS

11.23 GRIDMAJOR system variable

11.23.1 Grid major

Controls the frequency of major versus minor grid lines.

Values between 1 and 100 are accepted.

Type:	Short
Saved in:	Drawing
Range:	1 to 100
Default value:	5

11.24 GRIDMAJORCOLOR system variable

11.24.1 Grid major color

Controls the color of the major grid lines.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Registry
Range:	1 to 255
Possible values:	251

11.25 GRIDMINORCOLOR system variable

11.25.1 Grid minor color

Controls the color of the minor grid lines.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	250

11.26 GRIDMODE system variable

11.26.1 Grid mode

Turns the grid on.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Grid off On (1): Grid on

11.27 GRIDSTYLE system variable

11.27.1 Grid style

Controls if the grid is displayed as dots or lines.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 7
Default value:	0
Possible options:	0: Lined grid 1: Dotted grid in 2D model space 2: Dotted grid in Block Editor 4: Dotted grid in Sheet/Layout

11.28 GRIDUNIT system variable

11.28.1 Grid unit

Controls the X and Y grid spacing for the current viewport.

Type:	2D point
Saved in:	Drawing
Default value:	0.5,0.5 - If MEASUREMENT=0 and INSUNITS=inches 10.0,10.0 - If MEASUREMENT=1 and INSUNITS=millimeters

11.29 GRIDXYZTINT system variable

11.29.1 Grid XYZ tint

Applies the UCS axis colors for grid lines. See also the COLORX, COLORY and COLORZ system variables.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	1
Possible options:	1: Apply XYZ tint to grid axis lines 2: Apply XYZ tint to major grid lines 4: Apply XYZ tint to minor grid lines



11.30 GRIPBLOCK system variable

11.30.1 Grips in blocks

Displays grips on entities inside a block, when a block is selected.

The insertion point of the block is displayed regardless of this setting.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Doesn't display grips on entities within the block On (1): Display grips on entities within the block

11.31 GRIPCOLOR system variable

11.31.1 Grip color

Controls the color of unselected grips.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	72

11.32 GRIPDYNCOLOR system variable

11.32.1 Dynamic grip color

Controls the color of custom grips for dynamic blocks.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	140



11.33 GRIPHOT system variable

11.33.1 Selected grip color

Controls the color of selected grips.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	240

11.34 GRIPHOVER system variable

11.34.1 Hover grip color

Controls the color of an unselected grip, when the cursor hovers over it.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	150

11.35 GRIPOBJLIMIT system variable

11.35.1 Grip entity limit

Sets the maximum number of grips to display for a selection.

Values between 0 and 32767 are accepted.

- The display of grips is suppressed if the number of selected entities exceeds the value of this system variable.
- If set to 0, grips are always displayed.

Type:	Short
Saved in:	Registry
Range:	0 to 32767



Default value:	100
----------------	-----

11.36 GRIPS system variable

11.36.1 Grips

Controls how grips display when entities are selected.

Type:	Short
Saved in:	Registry
Default value:	2
Possible values:	0: Turn off grips 1: Turn on endpoint grips 2: Turn on endpoint and midpoint grips

11.37 GRIPSIZE system variable

11.37.1 Grip size

Controls the grip display size, in pixels.

Values between 1 and 255 are accepted.

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	4

11.38 GRIPTIPS system variable

11.38.1 Grip tips

Controls if grip tips display when the cursor hovers over grips on custom entities or dynamic blocks that support grip tips (Not yet supported).

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Don't display grip tips On (1): Display grip tips

11.39 GSDEVICETYPE2D system variable

11.39.1 2D graphic system device

Sets current graphic system device used for wireframe.

GDI+ option is strongly recommended, extra options are available only for testing purposes.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	0
Possible values:	0: GDI+ 1: OpenGL (not recommended, available only for testing) 2: RedOpenGL (not recommended, available only for testing) 3: GDI (not recommended, available only for testing)

11.40 GSDEVICETYPE3D system variable

11.40.1 3D graphic system device

Set current graphic system device for rendered output for Hidden, Gouraud (with edges) and Flat (with edges) visual styles.

Other rendered visual styles, such as Modeling and Realistic, will always use RedOpenGL.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1



Possible values:	0: OpenGL 1: RedOpenGL
------------------	---------------------------



12. H

12.1 HALOGAP system variable

12.1.1 Halo gap

Controls the value of the gap displayed if an entity is hidden by another entity. Applies to 2D views only.

Specified as a percent of one drawing unit, independent of the zoom level.

Type:	Short
Saved in:	Drawing
Range:	0 to 100
Default value:	0

12.2 HANDLES system variable

12.2.1 Publish Handles (Read Only)

Shows if entity handles can be accessed by applications or not.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Handles cannot be accessed by applications On (1): Handles can be accessed by applications

12.3 HANDSEED system variable

12.3.1 Handle seed (Read Only)

Indicates the handle used to create new entities.

BricsCAD only

Type:	String
Saved in:	Not saved
Default value:	25



12.4 HEALTHADVISOR system variable

12.4.1 Health Advisor

Controls whether the health advisor is activated. When activated it does analyses of your drawing in the background.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Do not run background advisor process On (1): Run background advisor process

12.5 HIDEPRECISION system variable

12.5.1 Hide and shade precision

Controls the accuracy of hides and shades. If on, uses double precision, more memory is needed, which might affect performance.

Type:	Short
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Disable double precision On (1): Enable double precision

12.6 HIDESYSTEMPRINTERS system variable

12.6.1 Hide system printers

Hides system printers.

Type:	Boolean
Saved in:	Preference
Default value:	Off



12.7 HIDETEXT system variable

12.7.1 Hide text on HIDE

Controls if text can be hidden with the HIDE command.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Text is not hidden and does not hide other entities 1: Text is hidden but does hide other entities

12.8 HIDEXREFSCALES system variable

12.8.1 Hide xref scales

Hides XRefs scales.

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Don't hide XRefs scales On (1): Hide XRefs scales

12.9 HIGHLIGHT system variable

12.9.1 Highlight

Highlights entities when they are selected.

Note: Does not affect entities selected with grips.

Type:	Boolean
Saved in:	Not saved
Default value:	On



Possible values:	Off (0): Do not highlight entity selection On (1): Highlight entity selection
------------------	--

12.10 HIGHLIGHT_ALPHA system variable

12.10.1 Highlighted area transparency

Controls the transparency of a filled area when selected.

Values between 0 and 100 are accepted. A value of zero means fully transparent. A value of 100 means fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	85

12.11 HIGHLIGHTCOLOR system variable

12.11.1 Selection Highlight Color

Controls the highlight color used when GLSelectionHighlightStyle is set to **Use a different color for highlight**.

Note: The HIGHLIGHTCOLOR system variable is effective only in the **2dWireframe** visual style.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	150

12.12 HIGHLIGHTEFFECT system variable

12.12.1 Selection Highlight Style

Controls how entities are highlighted.



Note: The HIGHLIGHTEFFECT system variable is effective only in the **2dWireframe** visual style.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	0: Use line stipple for highlight 1: Use a different color for highlight 2: Use a thickened line for highlight 3: Use a different color and thickened line for highlight

12.13 HORIZONBKG_ENABLE system variable

12.13.1 Horizon background

Controls if horizon background is shown in perspective views.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable horizon background On (1): Enable horizon background

12.14 HORIZONBKG_GROUNDHORIZON system variable

12.14.1 Ground horizon

Controls the color of the ground horizon.

Type:	String
Saved in:	Preference
Default value:	RGB:67,74,80



12.15 HORIZONBKG_GROUNDORIGIN system variable

12.15.1 Ground origin

Controls the color of the ground.

Type:	String
Saved in:	Preference
Default value:	RGB:95,103,112

12.16 HORIZONBKG_SKYHIGH system variable

12.16.1 Sky high

Controls the color of the higher regions of the sky.

Type:	String
Saved in:	Preference
Default value:	RGB:204,229,234

12.17 HORIZONBKG_SKYHORIZON system variable

12.17.1 Sky horizon

Controls the color at the lowest part of the sky at the horizon. This effect can be very subtle. This color is also used as the color of the "sky" when the camera is below the "earth".

Type:	String
Saved in:	Preference
Default value:	RGB:238,248,250

12.18 HORIZONBKG_SKYLOW system variable

12.18.1 Sky low

Controls the color of the lower regions of the sky.

Type:	String
-------	--------



Saved in:	Preference
Default value:	RGB:238,248,250

12.19 HOTKEYASSISTANT system variable

12.19.1 Hotkey Assistant

Displays the Hotkey Assistant.

The Hotkey Assistant appears in the bottom-middle of the screen and displays keyboard shortcut tips, during some commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show Hotkey Assistant On (1): Show Hotkey Assistant

12.20 HPANG system variable

12.20.1 Hatch pattern angle

The hatch pattern angle.

Type:	Real
Saved in:	Not saved
Default value:	0.0

12.21 HPANNOTATIVE system variable

12.21.1 Hatch pattern annotative

Controls if new hatch patterns are created as annotative hatch patterns.

Type:	Boolean
Saved in:	Not saved



Default value:	Off
Possible values:	Off (0): Do not create annotative patterns On (1): Create annotative patterns

12.22 HPASSOC system variable

12.22.1 Hatch pattern associativity

Controls if new hatch patterns and gradient fills are associative. Associative hatches and gradient fills are updated automatically when their boundaries change.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't associate hatch patterns and gradient fills with their boundaries On (1): Associates hatch patterns and gradient fills with their boundaries

12.23 HPBACKGROUNDCOLOR system variable

12.23.1 Hatch background default color

The default hatch background color.

Enter '' for none.

Type:	String
Saved in:	Drawing
Default value:	.

12.24 HPOUND system variable

12.24.1 Hatch pattern boundary

Controls the entity type created by the BHATCH and BOUNDARY commands.

Type:	Short
-------	-------



Saved in:	Not saved
Range:	0 to 1
Default value:	1
Possible values:	0: Region 1: Polyline

12.25 HBOUNDRETAIN system variable

12.25.1 Hatch pattern boundary retain

Creates boundary entities for hatches and gradient fills.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Do not create boundary entities 1: Create boundary entities

12.26 HCOLOR system variable

12.26.1 Hatch default color

Controls the default hatch foreground color.

Enter '' to use the current color, defined by the CECOLOR system variables.

Type:	String
Saved in:	Drawing
Default value:	.



12.27 HPDOUBLE system variable

12.27.1 Hatch pattern doubling

Controls user-defined hatch pattern crosshatching.

- If on, creates a cross hatch.
- If off, creates a single hatch.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Hatch pattern doubling off On (1): Hatch pattern doubling on

12.28 HPDRAWORDER system variable

12.28.1 Hatch pattern draw order

Controls the draw order of hatches and gradient fills, defined by the **Draw order** setting in the **Hatch and Gradient** dialog box.

Type:	Short
Saved in:	Not saved
Range:	0 to 4
Default value:	3
Possible values:	0: None 1: Send to back 2: Bring to front 3: Send behind boundary 4: Bring in front of boundary



12.29 HPGAPTOL system variable

12.29.1 Hatch pattern gap tolerance

Controls the tolerance for a boundary created with the BHATCH or BOUNDARY commands. When zoomed in closely, boundary detection will fail. When zoomed so the contour 'looks' closed, the boundary is detectable.

Values between 0.0 and 500.0 are accepted.

Type:	Real
Saved in:	Registry
Range:	0 or greater
Default value:	0.0

12.30 HPISLANDDETECTION system variable

12.30.1 Hatch pattern island detection

Controls hatch creation when islands are within a hatch boundary.

Type:	Short
Saved in:	Not saved
Range:	0 to 2
Default value:	0
Possible values:	0: Nested - Hatches areas within islands. 1: Outer - Hatches areas outside of islands. 2: Ignore - Hatches whole the boundary.

12.31 HPLAYER system variable

12.31.1 Default layer for new hatches

The default layer for new hatches.

Type:	String
Saved in:	Drawing



Default value:	<Use Current>
----------------	---------------

12.32 HPLINETYPE system variable

12.32.1 Hatch pattern linetype

Applies non-continuous linetypes to hatch entities (decreases performance).

When turned off, lines in the hatch pattern display as continuous, even if a non-continuous linetype is applied to the hatch entity. When turned on, lines in the hatch pattern display with the linetype that's applied to the hatch entity. This is not recommended because it can impact performance. Instead, you can choose a hatch pattern that is predefined with a non-continuous linetype.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): Don't apply non-continuous linetypes to hatch entities On (1): Apply non-continuous linetypes to hatch entities

12.33 HPMAXAREAS system variable

12.33.1 Fill mode for sparse hatches

Converts sparse hatches to fills.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Sparse hatches are left blank 1: Sparse hatches are changed to solid fills



12.34 HPMAXCONTOURPOINTS system variable

12.34.1 Maximum number of points on a hatch contour

Controls the maximum number of points on a contour (outline) that a hatch entity can contain and still render.

Values between 0 and 10,000,000 are accepted.

Hatches do not render if the number of points exceeds the specified value.

Setting to 0 disables the check, meaning the variable is not used.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 10000000
Default value:	100000

12.35 HPNAME system variable

12.35.1 Hatch pattern name

The default hatch pattern name.

Type:	String
Saved in:	Not saved

12.36 HPOBJWARNING system variable

12.36.1 Hatch pattern entity warning

Controls how many hatch boundary entities can be selected before a warning message appears.

Values between 1 and 100,000,000 are accepted.

Type:	Long
Saved in:	Registry
Range:	1 to 100000000
Default value:	10000



12.37 HPORIGIN system variable

12.37.1 Hatch pattern origin

Stores the origin point for new hatches, relative to the current UCS.

Type:	2D point
Saved in:	Drawing
Default value:	0,0

12.38 HPSCALE system variable

12.38.1 Hatch pattern scale

The default hatch pattern scale.

Type:	Real
Saved in:	Not saved
Default value:	1.0

12.39 HPSEPARATE system variable

12.39.1 Hatch pattern separate

Controls if separate hatches or a single hatch is created when several hatch boundaries are selected, during the HATCH command.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): Don't create separate hatches On (1): Create separate hatches

12.40 HPSPACE system variable

12.40.1 Hatch pattern spacing

Controls the hatch pattern line spacing for user-defined hatch patterns.



Type:	Real
Saved in:	Not saved
Default value:	1.0

12.41 HPTRANSPARENCY system variable

12.41.1 Default transparency for new hatches

The default transparency for new hatches, as a percentage.

Values accepted: ByLayer, ByBlock, '' (use current), 0 (fully opaque), and 90 (maximum transparency).

Type:	String
Saved in:	Drawing
Default value:	.
Possible values:	.: Use current ByLayer: Apply the layer's transparency ByBlock: Apply the block's transparency 0: Apply no transparency (fully opaque) 1-90: Apply transparency percentage from least (1) to most (90) transparent

12.42 HYPERLINKBASE system variable

12.42.1 Hyperlink base

The file path for relative hyperlinks in the drawing.

Type:	String Standard
Saved in:	Drawing



13. I

13.1 IFCCREATEUNIQUEGUID system variable

13.1.1 Export with unique guids

Controls if unique GUIDs (Globally Unique Identifiers) for nested elements are generated during IFC export.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible values:	1: Inside classified blocks 2: Inside classified XRefs

13.2 IFCEXplodeExternalReferences system variable

13.2.1 Explode external references in IFC spatial structure

Explodes external references in IFC spatial structures during IFC export.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

13.3 IFCEXPORTAUTHOR system variable

13.3.1 Export Author Name

Author name defined in the IFC file header.

BricsCAD only

Type:	String
Saved in:	Registry



Default value:	" "
----------------	-----

13.4 IFCEXPORTAUTHORIZATION system variable

13.4.1 Export Authorization

Authorization defined in the IFC file header.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	" "

13.5 IFCEXPORTBASEQUANTITIES system variable

13.5.1 Export base quantities

Export derived base quantities (quantities calculated from two or more measurements) from BIM entities during IFC export.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

Note: Ply quantities are exported when both IFCEXPORTMULTIPLYELEMENTSASAGGREGATED and IFCEXPORTBASEQUANTITIES system variables are set to ON. For **IFC4 Reference View file**, next to the quantities for the wall as a whole, the ply quantities are exported as a sub set for each ply (as IfcPhysicalComplexQuantity).

13.6 IFCEXPORTELEMENTSONOFFANDFROZENLAYER system variable

13.6.1 Export elements on Off and Frozen layers

Exports elements on Off and Froze layers during IFC export.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	1

13.7 IFCEXPORTIDS.getPropertiesOnly system variable

13.7.1 Export IDS Properties Only

When an IDS-XML file has been imported, this setting controls whether only the properties required by the IDS file should be exported to the IFC file or all properties should be exported.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Export all properties On (1): Export only the properties required by the IDS

13.8 IFCEXPORTMAPPINGPATH system variable

13.8.1 Export mapping file path

Exports file paths during IFC export.

Type:	String
Saved in:	Registry
Default value:	" "

13.9 IFCEXPORTMULTIPLYELEMENTSASAGGREGATED system variable

13.9.1 Export multi-ply elements as aggregated elements

Export multi-ply elements as aggregated elements.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	0
----------------	---

Note: Ply quantities are exported when both IFCEXPORTMULTIPLYELEMENTSASAGGREGATED and IFCEXPORTBASEQUANTITIES system variables are set to ON. For **IFC4 Reference View file**, next to the quantities for the wall as a whole, the ply quantities are exported as a sub set for each ply (as IfcPhysicalComplexQuantity).

13.10 IFCEXPORTORGANIZATION system variable

13.10.1 Export Organization Name

Organization defined in the IFC file header.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	" "

13.11 IFCEXPORTPROFILECENTEROFGRAVITY system variable

13.11.1 Export profile center of gravity

Export profile center of gravity during IFC export, applies only to IFC2x3.

Warning: May cause linear solids to appear in the wrong position.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

13.12 IFCEXPORTSUBTRACTOPENINGS system variable

13.12.1 Subtracts the openings from the host geometry before export

Use this to increase the reliability of the geometry when opening in another software (it avoids relying on the boolean operations of the target software).

It will make editing the model in the target software more difficult.

Note: This behavior is the default for **IFC4 Reference View file** export.



BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

13.13 IFCEXPORTSWEPTSOLIDSBREP system variable

13.13.1 Always export swept solids as BRep

Exports extrusions, revolutions, swept 3D solids with clippings and subtractions with a boundary representation during IFC export.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

13.14 IFCEXPORTTESSELATION system variable

13.14.1 Level of tessellation

Controls the exported geometry tessellation level during IFC export. When the **Current** faceting option is chosen, no regeneration is required, the faceting as set by FACETRES system variables or the Modeler Properties.

The **Low**, **Medium**, or **High** options cause regeneration of facets, which takes longer.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0



Possible values:	0: Current 1: Low 2: Medium 3: High
------------------	--

13.15 IFCEXPORTVALIDATEMODEL system variable

13.15.1 Apply IFC model validation

Checks that an IFC model complies with schema rules during IFC export. Problems are reported in an export log next to IFC file.

Warning: Validation takes extra time and can slow down the export of big IFC files.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

13.16 IFCIMPORTSETTINGSCONFIG system variable

13.16.1 IFC import settings configuration

Specifies the name of the IFC import settings configuration file.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	"bim_ifc_settings.xml"

13.17 IFCTESSELATEBSPLINECURVESANDSURFACES system variable

13.17.1 Tessellate complex curves and surfaces

Tessellates BSpline curves and surfaces in IFC4 and IFC4.1 during IFC export.

Note: BSpline curves are not supported by some software products in IFC import.

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	0

13.18 IMAGECACHEFOLDER system variable

13.18.1 Image disk cache folder

The file path used to store temporary image cache file.

See the IMAGEDISKCACHE system variable.

BricsCAD only

Type:	String Standard
Saved in:	Preference
Default value:	{User}AppData/Local/Temp/ImageCache

13.19 IMAGECACHEMAXMEMORY system variable

13.19.1 Maximum used memory

Maximum size of the in-memory image cache, in MiB.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	160

13.20 IMAGEDISKCACHE system variable

13.20.1 Image disk cache

Stores temporary image cache files.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Default value:	On
Possible values:	Off (0): Disable image disk cache On (1): Enable image disk cache

13.21 IMAGEFRAME system variable

13.21.1 Image frame

Controls the visibility of image frames, if the FRAME system variable is set to **Use individual system variables** (3).

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Hide image frames 1: Display and plot image frames 2: Display but do not plot image frames

13.22 IMAGEHLT system variable

13.22.1 Image highlight

Controls how an image is highlighted when selected.

- If on, highlights the whole image.
- If off, highlights the border only.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Don't highlight entire raster image On (1): Highlight entire raster image



13.23 IMAGENOTIFY system variable

13.23.1 Image notify

Displays a warning, when a drawing is opened, if there are missing raster images.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Disable image notification On (1): Enable image notification

13.24 IMPORTCATIAV5EDGEATTRIBUTES system variable

13.24.1 Import edge attributes mode

Controls the import of edge attributes, by edge type, during a Catia V5 import.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible options:	0: None 1: Edges that are parts of wire entities 2: Edges that are owners of part PMI 3: All edges

13.25 IMPORTCATIAV5REPRESENTATION system variable

13.25.1 Import representation

Controls the data that the Communicator for BricsCAD® imports during a Catia V5 import.

Preview graphics are only imported and shown if the COMMUNICATORBACKGROUNDMODE system variable is on.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible options:	0: Graphics 1: Geometry 2: Geometry with preview graphics

13.26 IMPORTCATIAV5SEARCHPATHSPREFERENCE system variable

13.26.1 Search path preference

Controls the priority of file paths during a Catia V5 import.

Note: This option is taken into account only when import in background is enabled (COMMUNICATORBACKGROUNDMODE system variable is ON).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

13.27 IMPORTCOLORS system variable

13.27.1 Translate colors

Controls how colors are converted during import.

Type:	Short
Saved in:	Registry



Range:	0 to 2
Default value:	1
Possible values:	0: To RGB 1: To RGB, if there is no matching palette index 2: To nearest palette index

- If 0: all entity colors will be converted to RGB, regardless of the current palette.
- If 1: if the entity color is found in the palette, the entity gets an index color. Otherwise, it is given a true color.
- If 2: for any true color of the imported entity, the nearest match is searched in the palette and this index color is assigned to the entity.

13.28 IMPORTCREOALTERNATESEARCHPATHS system variable

13.28.1 Alternate search paths

The alternate file used during a Creo import.

Separate values with semicolons (:).

Note: Paths must be absolute (fully qualified) and separated with a semicolon.

BricsCAD only

Type:	String
Saved in:	Registry

13.29 IMPORTCREOCONFIGURATION system variable

13.29.1 Import configuration

Sets the name of the configuration to import. If no configuration name is specified, then the part's default configuration is imported.

Note: A named configuration sets a collection of body entities in a part that can be imported as a group while suppressing the import of other body entities.

BricsCAD only

Type:	String
Saved in:	Registry



13.30 IMPORTCUIFILEEXISTS system variable

13.30.1 Import cui file exists

Controls what to do when a CUI file already exists, when a MNU or CUIX file is imported.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0 to 2
Possible values:	0: Prompt 1: Overwrite 2: Rename

13.31 IMPORTHIDDENPARTS system variable

13.31.1 Hidden parts

Controls how hidden parts are imported.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Import and hide 1: Import and set visible 2: Do not import

- If 0: all entities are imported; invisible entities are hidden. Note that currently there are no user tools to make these hidden entities visible again.
- If 1: all entities are imported and visible, regardless of the visibility in the source file.
- If 2: hidden entities in the source file are not imported.

13.32 IMPORTIGESSIMPLIFY system variable

13.32.1 Perform simplification

Automatically runs the DMSIMPLIFY command during an IGES import.



If on, overrides the IMPORTSIMPLIFY system variable on IGES models.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1

13.33 IMPORTIGESTITCH system variable

13.33.1 Perform stitching

Automatically runs the DMSTITCH command during an IGES import.

If on, overrides the IMPORTSTITCH system variable on IGES models.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1

13.34 IMPORTINVENTORALTERNATESEARCHPATHS system variable

13.34.1 Alternate search paths

Controls the list of alternate file system paths used during an Inventor file import.

Separate values with semicolons (:).

Note: Paths must be absolute (fully qualified) and separated with semicolon.

BricsCAD only

Type:	String
Saved in:	Registry

13.35 IMPORTINVENTORSEARCHPATHSPREFERENCE system variable

13.35.1 Search paths preference

Controls the priority order of search paths during an Inventor file import.

Note: This option is taken into account only when import in background is enabled (COMMUNICATORBACKGROUNDMODE system variable is ON).



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

13.36 IMPORTJTREPRESENTATION system variable

13.36.1 Import representation

Controls the data to import during a JT import.

Note: This option is only taken into account when import in background is enabled.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Graphics 1: Geometry 2: Geometry with graphics

13.37 IMPORTNXALTERNATESEARCHPATHS system variable

13.37.1 Alternate search paths

Controls the list of alternate file paths used during an NX import.

Separate values with semicolons (;).

Note: Paths must be absolute (fully qualified) and separated with semicolon.

BricsCAD only



Type:	String
Saved in:	Registry

13.38 IMPORTNXCONFIGURATION system variable

13.38.1 Import configuration

Sets the name of the configuration that should be imported. If no configuration name is specified, then the part's default configuration will be imported.

Note: A named configuration sets a collection of body entities in a part that can be imported as a group while suppressing the import of other body entities.

BricsCAD only

Type:	String
Saved in:	Registry

13.39 IMPORTNXSEARCHPATHSPREFERENCE system variable

13.39.1 Search paths preference

Controls the priority of file paths during an NX import.

Note: This option is taken into account only when import in background is enabled (COMMUNICATORBACKGROUNDMODE system variable is ON).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first



13.40 IMPORTPMI system variable

13.40.1 Product and manufacturing information

Enables the import of product and manufacture information.

Note: Currently, such information is imported as exploded data (lines, text, etc.) instead of compound entities (for example: annotations).

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1

13.41 IMPORTPRODUCTSTRUCTURE system variable

13.41.1 Product structure

Controls the way a product structure is represented for an imported model.

As mechanical components automatically runs the BMMECH command after import.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: None 1: As blocks 2: As mechanical components

- If 0: creates a flat structure without blocks in the model space of the target database, regardless of whether the imported data have an assembly structure or not.
- If 1: the imported data have an assembly structure, which will be converted into a hierarchy of plain blocks; so the structure will be preserved, while the assembly metadata are lost. If the imported data is composed of entities only, they are placed in the modelspace of the target database.
- If 2: in this mode, data will be translated to BricsCAD assembly data, the structure and its properties (physical materials – BLMATERIALS command). If the imported file has no assembly data, a mechanical component will nevertheless be created in the BricsCAD target document root.



13.42 IMPORTREPAIR system variable

13.42.1 Repair model on import

Automatically runs the DMAUDITALL command on imported models.

3D geometry is analyzed and problems are fixed automatically, in order to improve the quality of the imported geometry. Geometry modeled in CAD systems which use a kernel different from ACIS, often needs to be healed because of possible flaws.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Do not repair model on import On (1): Repair model on import

13.43 IMPORTSIMPLIFY system variable

13.43.1 Perform simplification

Automatically runs the DMSIMPLIFY command on imported models. See also the IMPORTIGESSIMPLIFY system variable.

Note: The IMPORTIGESSIMPLIFY system variable can set an override for the IGES file format.

- Convert imported splines into canonical surfaces.
- Simplify topology (remove imprinted edges) if possible.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

13.44 IMPORTSOLIDEDGEALTERNATESEARCHPATHS system variable

13.44.1 Alternate search paths

Controls the list of alternate file paths used during a Solid Edge file import.

Separate values with semicolons (:).

Note: Paths must be absolute (fully qualified) and separated with semicolon.



BricsCAD only

Type:	String
Saved in:	Registry

13.45 IMPORTSOLIDEDGESEARCHPATHSPREFERENCE system variable

13.45.1 Search paths preference

Controls the priority order of files paths during a Solid Edge file import.

Note: This option is taken into account only when import in background is enabled (COMMUNICATORBACKGROUNDMODE system variable is ON).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

13.46 IMPORTSOLIDWORKSALTERNATESEARCHPATHS system variable

13.46.1 Alternate search paths

Controls the list of alternate file system paths to search during a Solid Works import.

Separate values with semicolons (:).

Note: Paths must be absolute (fully qualified) and separated with a semicolon.

BricsCAD only

Type:	String
Saved in:	Registry



13.47 IMPORTSOLIDWORKSCONFIGURATION system variable

13.47.1 Import configuration

Sets the name of the configuration that should be imported. If no configuration name is specified, then the part's default configuration will be imported.

Note: A named configuration sets a collection of body entities in a part that can be imported as a group while suppressing the import of other body entities.

BricsCAD only

Type:	String
Saved in:	Registry

13.48 IMPORTSOLIDWORKSREPRESENTATION system variable

13.48.1 Import representation

Controls the data imported during a Solid Works import. Preview graphics are only imported and shown if the COMMUNICATORBACKGROUNDMODE system variable is on.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Graphics 1: Geometry 2: Geometry with preview graphics

13.49 IMPORTSOLIDWORKSROTATEYZ system variable

13.49.1 Map SolidWorks Y to current Z axis

Enables the conversion of a SolidWorks coordinate system to the current coordinate system.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0) On (1)

13.50 IMPORTSOLIDWORKSSEARCHPATHSPREFERENCE system variable

13.50.1 Search paths preference

Controls the priority order for search paths during a Solid Works import.

Note: This option is taken into account only when import in background is enabled (COMMUNICATORBACKGROUNDMODE system variable is ON).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 3
Default value:	1
Possible options:	1: Sub-folders first 2: Root folder only 3: Root folder first

13.51 IMPORTSTEPROTATEYZ system variable

13.51.1 Map Y to current Z axis

Enables conversion of a SolidWorks coordinate system to the current coordinate system, during a STEP import.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0) On (1)



13.52 IMPORTSTITCH system variable

13.52.1 Perform stitching

Automatically runs the DMSTITCH command on imported models. See the IMPORTIGESSTITCH system variable.

In some cases, imported geometry represents solid geometry as a set of separate surfaces. Use the DMSTITCH command to work with solid operations on the imported geometry. If IMPORTSTITCH is set to ON, the DMSTITCH command is executed automatically when the geometry is imported.

Note:

- Stitch operations are time-consuming when importing large files.
- Check the IMPORTIGESSTITCH setting, which can set an override for the IGES file format.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0

13.53 INCLUDEPLOTPRINT system variable

13.53.1 Include Plot Stamp

Includes a plot stamp when printing.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't include Plot Stamp On (1): Include Plot Stamp

13.54 INDEXCTL system variable

13.54.1 Index control

Controls if layer and/or spatial indexes are created and saved.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 3
Default value:	0
Possible options:	0: No indexes 1: Layer index 2: Spatial index

13.55 INETLOCATION system variable

13.55.1 Internet location

The default website for the BROWSER command.

Type:	String
Saved in:	Registry
Default value:	"http://www.bricsys.com"

13.56 INSBASE system variable

13.56.1 Insertion base point

The drawing's insertion point, used when the drawing is inserted into other drawings as a block. Set by the BASE command, and expressed as a UCS coordinate for the current space.

Type:	3D point
Saved in:	Drawing
Default value:	0,0,0

13.57 INSNAME system variable

13.57.1 Insertion name

Stores the default block name for the INSERT command.

Type:	String
-------	--------



Saved in:	Drawing
Default value:	

13.58 INSUNITS system variable

13.58.1 Insertion units

Controls the unit used to scale blocks, images or XRefs, when they are inserted into a drawing. When both the INSUNITS and PROPUNITS system variables are on, length, area, volume and/or inertia properties are formatted with their respective unit(s).

Note: It does not convert current drawing units.

See also the *LUNITS* and *MEASUREMENT* system variables

Type:	Short
Saved in:	Drawing
Range:	0 to 24
Default value:	1



Possible values:	0: Unspecified (No units) 1: Inches 2: Feet 3: Miles 4: Millimeters 5: Centimeters 6: Meters 7: Kilometers 8: Microinches 9: Mils 10: Yards 11: Ångströms 12: Nanometers 13: Microns 14: Decimeters 15: Decameters 16: Hectometers 17: Gigameters 18: Astronomical Units 19: Light-years 20: Parsecs 21: US Survey Feet 22: US Survey Inch 23: US Survey Yard 24: US Survey Mile
------------------	--

13.59 INSUNITSDEFSOURCE system variable

13.59.1 Insertion units default source

Controls the source content units value.

Note: If INSUNITS in the source drawing is **Unspecified**, INSUNITSDEFSOURCE is used instead.

Type:	Short
Saved in:	Registry
Range:	0 to 24
Default value:	0



Possible values:	0: Unspecified (No units) 1: Inches 2: Feet 3: Miles 4: Millimeters 5: Centimeters 6: Meters 7: Kilometers 8: Microinches 9: Mils 10: Yards 11: Ångströms 12: Nanometers 13: Microns 14: Decimeters 15: Decameters 16: Hectometers 17: Gigameters 18: Astronomical Units 19: Light-years 20: Parsecs 21: US Survey Feet 22: US Survey Inch 23: US Survey Yard 24: US Survey Mile
------------------	--

13.60 INSUNITSDEFTARGET system variable

13.60.1 Insertion units default target

Controls the target drawing units value, if the INSUNITS system variable is zero.

Values between 0 and 20 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 24
Default value:	0



Possible values:	0: Unspecified (No units) 1: Inches 2: Feet 3: Miles 4: Millimeters 5: Centimeters 6: Meters 7: Kilometers 8: Microinches 9: Mils 10: Yards 11: Ångströms 12: Nanometers 13: Microns 14: Decimeters 15: Decameters 16: Hectometers 17: Gigameters 18: Astronomical Units 19: Light-years 20: Parsecs 21: US Survey Feet 22: US Survey Inch 23: US Survey Yard 24: US Survey Mile
------------------	--

13.61 INSUNITSSCALING system variable

13.61.1 Insertion units scaling

Controls how the INSUNITS system variable is applied when entities are inserted, imported or pasted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	1: Scale with the INSUNITS system variable, if inactive, uses the INSUNITSDEFSOURCE system variable 2: Use paper size unit instead of INSUNITS in paper space.



When inserting or attaching Xrefs, Blocks or images the inserted content is scaled with respect to the value of INSUNITS in the target and source drawing.

- If INSUNITS in the source drawing is **Unspecified**, INSUNITSDEFSOURCE is used instead.
- If INSUNITS in the target drawing is **Unspecified**, INSUNITSDEFTARGET is used instead.

13.62 INTERFERECOLOR system variable

13.62.1 Interference color

Controls the color of interference entities.

Type:	String
Saved in:	Drawing
Default value:	ByLayer

13.63 INTERFERELAYER system variable

13.63.1 Interference layer

Controls the layer used for interference entities.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	"Interferences"

13.64 INTERERENCELEVEL system variable

13.64.1 Interference Check Level

Controls the interference check between details, copied details and/or the rest of the model.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0



Possible values:	0: No interference checking 1: Check overlap of detail volumes 2: Full interference check, ignore background spatial elements 3: Full interference checking
------------------	--

13.65 INTERFEREOBJVS system variable

13.65.1 Interference entity visual style

Controls the interference entity visual style.

Type:	String
Saved in:	Drawing
Default value:	

13.66 INTERFREVVPVS system variable

13.66.1 Interference viewport visual style

Controls the interference checking visual style for the viewport.

Type:	String
Saved in:	Drawing
Default value:	

13.67 INTERIORELEVATIONMINLENGTH system variable

13.67.1 Interior Elevation Minimum Length

Minimum length of a wall for an Interior Elevation to generate.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	20 - for MEASUREMENT=0 (inches) 500 - for MEASUREMENT=1 (millimeters)



13.68 INTERIORELEVATIONOFFSET system variable

13.68.1 Interior Elevation Offset Distance

Offset distance, for an Interior Elevation volume, from wall surfaces.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	2 - for MEASUREMENT=0 (inches) 50 - for MEASUREMENT=1 (millimeters)

13.69 INTERSECTEDENTITIES system variable

13.69.1 Resolve intersection

Controls how new entities, modify existing entities when they intersect. Applies to entities as they are created with the EXTRUDE and REVOLVE commands, when the **Auto** option is selected.

The INTERSECTEDENTITIES system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0 - for Workspaces Drafting and Modeling 1 - for Workspaces Mechanical and BIM
Possible options:	0: Do not modify 1: Subtract from intersection 2: Unite at intersection

13.70 INTERSECTIONCOLOR system variable

13.70.1 Intersection color

Controls the polyline color at the intersection of 3D surfaces in 2D Wireframe views, if INTERSECTIONDISPLAY is on (Not yet supported).



Type:	Short
Saved in:	Drawing
Range:	0 to 257
Default value:	257
Possible values:	0: ByBlock 1 - 255: index 256: ByLayer 257: ByEntity

13.71 INTERSECTIONDISPLAY system variable

13.71.1 Intersection display

Toggles the display of polylines at the intersection of 3D surfaces in 2D Wireframe views (Not yet supported).

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display intersection polylines On (1): Display intersection polylines

13.72 ISAVEBAK system variable

13.72.1 Incremental save backup

Creates backup files (BAK) for active drawings. If off, improves the speed of incremental saves, especially for large drawings.

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't create BAK file On (1): Create BAK file
------------------	---

13.73 ISAVEPERCENT system variable

13.73.1 Save percent

Controls the "wasted space" allowed for QUICKSAVE actions, before a full save is executed, as a percentage.

Values between 0 and 100 are accepted. A value of zero means Each save is a full save.

Type:	Short
Saved in:	Registry
Range:	0 to 100
Default value:	50

13.74 ISOLINES system variable


13.74.1 Isolines

Controls the number of isolines (contour lines) per curved surface.

Values between 0 and 2047 are accepted.

Note: To view changes on existing entities, perform a REGEN.

Type:	Short
Saved in:	Drawing
Range:	0 to 2047
Default value:	4





14. J



15. K

15.1 KEEPCONNECTIONS system variable

15.1.1 Solve interferences and gaps

Controls whether interferences or gaps should be solved.

If on: When a modification of a solid through TCONNECT, BIMUPDATETHICKNESS, BIMATTACHCOMPOSITION or BIMAUTOMATCH, causes interferences, these will be subtracted from the other solids; when it causes gaps, these will be filled.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't solve interferences after commands On (1): Solve interferences and gaps after commands



16. L

16.1 LASTANGLE system variable

16.1.1 Last angle (Read Only)

The end angle of the last arc drawn.

Type:	Real
Saved in:	Not saved

16.2 LASTPOINT system variable

16.2.1 Last point

The coordinates of the last point entered - the value used by the '@' symbol in the Command line.

Note: Expressed as a UCS coordinate for the current space; referenced by the at symbol (@) during keyboard entry.

Type:	3D point
Saved in:	Not saved

16.3 LASTPROMPT system variable

16.3.1 Last prompt (Read Only)

The last string in Command line.

Type:	String
Saved in:	Not saved

16.4 LATITUDE system variable

16.4.1 Latitude

Controls the latitude of the current drawing, in decimal format.

Values between -90.0 and 90.0 are accepted. Positive values represent north latitudes.

Type:	Real
Saved in:	Drawing



Range:	-90.0 to 90.0
Default value:	37.795

16.5 LAYERFILTEREXCESS system variable

16.5.1 Layer Filter Excess

Specifies the maximum number of layer filters allowed in a drawing before suggesting some be removed. You can create any number of layer filters. However, if the number of layer filters exceeds this value and exceeds the number of layers, a message dialog displays the next time you open the drawing. It recommends deleting all layer filters to improve performance.

If LAYERFILTEREXCESS is 0, dialog is suppressed.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	250

16.6 LAYERPMODE system variable

16.6.1 Layer previous mode

Tracks layer settings modification and enables the LAYERP command.

Type:	Boolean
Saved in:	Registry
Range:	On
Possible values:	Off (0): Doesn't allow tracking of layer settings modification and enables LAYERP command On (1): Allows tracking of layer settings modification and enables LAYERP command



16.7 LAYLOCKFADECTL system variable

16.7.1 Locked layer fade control

Controls the fade level for entities on locked layers to contrast them with entities on unlocked layers and reduces the visual complexity of a drawing. Entities on locked layers are still visible for reference and for object snapping.

Values between -90 and 90 are accepted. Negative values disable fading.

Type:	Short
Saved in:	Registry
Range:	-90 to 90
Default value:	50

16.8 LAYOUTREGENCTL system variable

16.8.1 Layout regeneration control

Controls how the display of the Model and layout tabs is updated. If performance is poor in general or when switching between tabs.

Setting LAYOUTREGENCTL to 1 or 0 might improve performance.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Always regenerate between when a tab is activated 1: Suppress the regeneration of the Model tab and last layout made current regenerate all other tabs when activated 2: Regenerate only the first time the tab is active

16.9 LAYOUTTAB system variable

16.9.1 Layout and model tabs

Controls the display of layout and model tabs.



Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show layout and model tabs On (1): Show layout and model tabs

16.10 LEGACYCODESEARCH system variable

16.10.1 Legacy code search mode (Read Only)

Enables unsafe search for executable code in drawing folders.

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Disable unsafe searching for executable code On (1): Enable unsafe searching for executable code

16.11 LENGTHUNITS system variable

16.11.1 Length units

Controls a list of units used to display lengths, if length properties are formatted with the PROPUNITS system variable. The string contains a space-separated list of unit abbreviations.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	"in ft mi µm mm cm m km"

16.12 LENSLENGTH system variable

16.12.1 Lens length (Read Only)

Displays the current viewport's lens length, in millimeters, used for perspective mode.



Type:	Real
Saved in:	Drawing
Default value:	50.0
Unit	mm

16.13 LEVELOFTDETAIL system variable

16.13.1 Composition Level of detail

Controls the composition level of detail (LOD).

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Low 2: High

- If 0: Composition plies do not display.
- If 2: Composition plies display.

16.14 LICFLAGS system variable

16.14.1 Licensed components (Read Only)

Controls if certain components are licensed or not. The value is stored as a bitcode using the sum of the values of all selected options.

BricsCAD only

Type:	Short
Saved in:	Not saved
Range:	0 to 7
Default value:	0



Possible options:	0: No components licensed 1: VBA is licensed 2: Acis editing is licensed 4: Pro
-------------------	--

16.15 LIGHTGLYPHCOLOR system variable

16.15.1 Color for light glyph

Controls the color of light glyphs (icons used to indicate the placement of lights in model space).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	30

16.16 LIGHTGLYPHDISPLAY system variable

16.16.1 Light display

Displays a visual representation of lights for all light locations.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't display light On (1): Display light

16.17 LIGHTINGUNITS system variable

16.17.1 Lighting units

Controls the light units type.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Obsolete. Generic lighting 1: Photometric, American units (foot-candles) 2: Photometric, International units (lux)

16.18 LIGHTWEBGLYPHCOLOR system variable

16.18.1 Color for web light glyph

Controls the color for web light glyphs (icons used to indicate the placement of web lights in model space).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	1

16.19 LIMCHECK system variable

16.19.1 Limits check

Prevent the creation of entities outside the drawing limits.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Can create entities outside limits On (1): Cannot create entities outside limits



16.20 LIMMAX system variable

16.20.1 Limits maximum

The upper-right corner of the drawing limits, expressed in world coordinates.

Type:	2D point
Saved in:	Drawing
Default value:	12,9

16.21 LIMMIN system variable

16.21.1 Limits minimum

The lower-left corner of the drawing limits, expressed in world coordinates.

Type:	2D point
Saved in:	Drawing
Default value:	0,0

16.22 LINEARARROWHEADLENGTH system variable

16.22.1 Default head length

Sets the default head length of linear arrows.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1 - if INSUNITS=1 (inches) 25 - if INSUNITS=4 (millimeters) 2.5 - if INSUNITS=5 (centimeters) 0.025 - if INSUNITS=6 (meters)

16.23 LINEARARROWHEADWIDTH system variable

16.23.1 Default head width

Sets the default head width of linear arrows.



BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1.5 - if INSUNITS=1 (inches) 37.5 - if INSUNITS=4 (millimeters) 3.75 - if INSUNITS=5 (centimeters) 0.0375 - if INSUNITS=6 (meters)

16.24 LINEARARROWTHICKNESS system variable

16.24.1 Default thickness

Sets the default thickness of linear arrows.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.5 - if INSUNITS=1 (inches) 12.5 - if INSUNITS=4 (millimeters) 1.25 - if INSUNITS=5 (centimeters) 0.0125 - if INSUNITS=6 (meters)

16.25 LINEARBRIGHTNESS system variable

16.25.1 Linear brightness

Controls the intensity of lights, can be specified per viewport.

Values between -10 and 10 are accepted. A value of zero means no scaling.

Smaller values decrease light intensity and bigger values increase light intensity. This setting can be specified per viewport.

Type:	Short
Saved in:	Drawing
Range:	-10 to 10
Default value:	0



16.26 LINEARCONTRAST system variable

16.26.1 Linear contrast

Controls ambient light intensity. Only effects materials with a non-black ambient color, can be set per viewport.

Values between -10 and 10 are accepted.

- A value of -10 means maximum ambient light.
- A value of 10 means no ambient light.

This setting only has effect on materials that have a non-black ambient color. This setting can be specified per viewport.

Type:	Short
Saved in:	Drawing
Range:	-10 to 10
Default value:	0

16.27 LINETYPE3DPLINE system variable

16.27.1 3D Polyline linetype

Controls applying line type to 3D Polyline.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	0: Continuous Linetype is always applied to 3D Polyline 1: Complex Linetype is applied to 3D Polyline

16.28 LISPINIT system variable

16.28.1 LISP init

Controls if LISP variables and functions are preserved between drawings.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Preserved from drawing to drawing 1: Valid in current drawing only

16.29 LOADMECHANICAL2D system variable

16.29.1 Mechanical 2D Editor

Controls if Mechanical 2D enablers can load.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Loading of Mechanical 2D enablers is not permitted On (1): Loading of Mechanical 2D enablers is permitted

Note: Changing the value of this variable will take effect after restarting the application.

16.30 LOCALE system variable

16.30.1 Locale (Read Only)

The ISO language code of this version of the program.

Type:	String
Saved in:	Not saved
Default value:	"en_US"

16.31 LOCALROOTPREFIX system variable

16.31.1 Local root prefix (Read Only)

The path of the folder, where local files for the current user, such as templates, were installed.



The Template and Textures folders are in this location, and you can add any customizable files that you do not want to roam on the network. See ROAMABLEROOTPREFIX for the location of the roamable files.

Type:	String Standard
Saved in:	Registry

16.32 LOCKUI system variable

16.32.1 Lock user interface elements

Locks interface elements and prevents repositioning.

- Windows and Linux: hold the Ctrl key to override.
- macOS: hold the Cmd key to override.

Type:	Short
Saved in:	Registry
Range:	-7 to 7
Default value:	0
Possible options:	negative: Locking temporarily disabled 1: Lock docked toolbars 2: Lock docked panels 4: Lock floating panels and toolbars


16.33 LOFTANG1 system variable

16.33.1 Loft angle 1

Sets the angle at the first cross-section, for the LOFT command, modifies the loft shape. Works only if the LOFTNORMALS system variable is set to **Surface uses draft angle and magnitude**.

Values between 0.0 and 360.0 are accepted.

Type:	Real
Saved in:	Drawing
Range:	0.0 to 360.0
Default value:	90.0




16.34 LOFTTANG2 system variable

16.34.1 Loft angle 2

Sets the angle at the last cross-section, for the LOFT command, modifies the loft shape. Works only if the LOFTNORMALS system variable is set to **Surface uses draft angle and magnitude**.

Values between 0.0 and 360.0 are accepted.

Type:	Real
Saved in:	Drawing
Range:	0.0 to 360.0
Default value:	90.0




16.35 LOFTMAG1 system variable

16.35.1 Loft magnitude 1

Sets the relative distance of the surface from the cross section in the direction of the LOFTTANG1 system variable, before the surface starts to bend towards the next section. Works only if the LOFTNORMALS system variable is set to **Surface uses draft angle and magnitude**.

Type:	Real
Saved in:	Drawing
Default value:	0.0






16.36 LOFTMAG2 system variable

16.36.1 Loft magnitude 2

Sets the relative distance of the surface from the cross section in the direction of the LOFTANG2 system variable, before the surface starts to bend towards the next section. Works only if the LOFTNORMALS system variable is set to **Surface uses draft angle and magnitude**.

Type:	Real
Saved in:	Drawing
Default value:	0.0



16.37 LOFTNORMALS system variable

16.37.1 Loft normals

Controls the behavior of surfaces and solids created with the LOFT command as they pass through a cross section.

Type:	Short
Saved in:	Drawing
Range:	0 to 6
Default value:	1



Possible values:	0: Ruled surface 1: Smooth surface 2: Surface is perpendicular to the first cross section 3: Surface is perpendicular to the last cross section 4: Surface is perpendicular to the first and last cross sections 5: Surface is perpendicular to all cross sections 6: Surface uses draft angle and magnitude
------------------	--

16.38 LOFTPARAM system variable

16.38.1 Loft param

Controls the shape of surfaces and solids created with the LOFT command.

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	7
Possible options:	0: No parameters 1: No twist between cross sections 2: Align directions of cross sections 4: Create simple surfaces and solids 8: Close between the first and last cross sections

16.39 LOGFILEMODE system variable

16.39.1 Log file mode

Maintains a logfile.

A logfile contains each executed command. These logfiles are saved in the folder specified by the LOGFILEPATH system variable.

Type:	Boolean
Saved in:	Registry
Default value:	Off



Possible values:	Off (0): Don't maintain log file On (1): Maintain log file
------------------	---

16.40 LOGFILENAME system variable

16.40.1 Log file name (Read Only)

The name of the log file. See also the LOGFILEMODE system variable.

Type:	String
Saved in:	Not saved

16.41 LOGFILEPATH system variable

16.41.1 Log file path

The file path used for the log file.

Type:	String Standard
Saved in:	Registry

16.42 LOGGEDINSTATUS system variable

16.42.1 Logged in (Read Only)

Shows if a Bricsys account is currently logged in to this version of the program.

BricsCAD only

Type:	Boolean
Saved in:	Registry

16.43 LOGINNAME system variable

16.43.1 Login name (Read Only)

Shows the Windows login name, saved to the file properties statistics of the drawing.

Type:	String
Saved in:	Not saved



16.44 LONGITUDE system variable

16.44.1 Longitude

Controls the longitude of the drawing, in decimal format.

Values between -180.0 and 180.0 are accepted. Positive values represent east longitudes.

Type:	Real
Saved in:	Drawing
Range:	-180.0 to 180.0
Default value:	-122.394

16.45 LOOKFROMDIRECTIONMODE system variable


16.45.1 LookFrom direction mode




Controls how many view directions can be selected in isometric mode.

- Windows and Linux: hold the Ctrl key to switch from top to down directions.
- macOS: hold the Cmd key to switch from top to down directions.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 3
Default value:	1
Possible values:	0: Orthogonal only (6 directions) 1: No flat view at corners (14 directions) 2: 4 top/down corners(18 directions) 3: 8 top/down corners(26 directions)





16.46 LOOKFROMFEEDBACK system variable

16.46.1 LookFrom feedback

Controls if the LookFrom control displays messages in tooltips or on the Status bar.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: None 1: Tooltips 2: Status bar

16.47 LOOKFROMZOOMEXTENTS system variable

16.47.1 LookFrom zoom extents

Zooms to extents whenever a view direction is selected from the LookFrom control.

BricsCAD only

Type:	Boolean
Saved in:	Preference



Range:	On
Possible values:	Off (0): Zoom extents off On (1): Zoom extents on

16.48 LTGAPSELECTION system variable

16.48.1 Linetype gap selection

Makes it possible to snap to gaps on non-continuous linetypes.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): No selection or snapping within gaps (legacy behavior) On (1): Selection or snapping within gaps

16.49 LTSCALE system variable

16.49.1 Linetype scale

Sets the default linetype scale multiplier.

Type:	Real
Saved in:	Drawing
Default value:	1.0

16.50 LUNITS system variable

16.50.1 Linear unit type

Controls the unit type for lengths.

Type:	Short
Saved in:	Drawing
Range:	1 to 5



Default value:	2
Possible values:	1: Scientific 2: Decimal 3: Engineering 4: Architectural 5: Fractional

16.51 LUPREC system variable

16.51.1 Linear unit precision

Controls the number of decimal places displayed for linear units. See also the MEASUREMENT and INSUINTS system variables.

Type:	Short
Saved in:	Drawing
Range:	0 to 8
Default value:	4
Possible values:	0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000

16.52 LWDEFAULT system variable

16.52.1 Default linewidth

Controls the default linewidth, in hundredths of millimeters.

Type:	Short
Saved in:	Registry
Range:	0 to 211



Default value:	25
Possible values:	-3: Default (defined by LWDEFAULT) -2: ByBlock -1: ByLayer 0 - 211: Lineweight value in hundredths of millimeters

16.53 LWDISPLAY system variable

16.53.1 Lineweight display

Displays lineweights.

Type:	Boolean
Saved in:	Drawing
Range:	Off
Possible values:	Off (0): Don't display linewidth On (1): Display linewidth

16.54 LWDISPSCALE system variable

16.54.1 Lineweight display scale

Controls the linewidth display scale in Model space.

Values between 0.0 and 1.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Registry
Range:	0.0 to 1.0
Default value:	0.55

16.55 LWUNITS system variable

16.55.1 Lineweight units

Controls the linewidth display unit.



Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Inches 1: Millimeters



17. M

17.1 MACROREC system variable

17.1.1 Macro recording

Controls if a macro is currently being recorded.

BricsCAD only

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Macro is not being recorded On (1): Macro is being recorded

17.2 MANIPULATOR system variable

17.2.1 Manipulator

Controls when the Manipulator is displayed.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Manipulator is not displayed 1: Display Manipulator whenever entities are selected 2: Display Manipulator if left mouse button was pressed longer than MANIPULATORDURATION

Note: The manipulator can be displayed manually through the Quad.

17.3 MANIPULATORCOLORTHEME system variable


17.3.1 Color theme of Manipulator

Controls the color theme of the Manipulator.



BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: Monochrome color theme 1: Classic color theme



17.4 MANIPULATORDURATION system variable

17.4.1 Manipulator duration

Controls the delay before the Manipulator is displayed, on a long left-click, when an entity is selected, in milliseconds.

Values between 100 and 10,000 are accepted.

BricsCAD only

Type:	Long
Saved in:	Registry



Range:	100 to 10000
Default value:	250

17.5 MANIPULATORHANDLE system variable

17.5.1 Manipulator handle

Controls the behavior of the Manipulator anchor handles (the bars of the Manipulator).

The handle can be used for unconstrained move and copy operations. Unconstrained meaning: not along an axis or constrained to a plane.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Handles move the Manipulator 1: Handles move the selected entities unrestricted

17.6 MANIPULATORSIZE system variable

17.6.1 Size of Manipulator

Controls the size of the Manipulator.

Values between 0.5 and 2.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.5 to 2
Default value:	1



17.7 MASSPREC system variable

17.7.1 Mass precision

Controls the number of decimal places displayed for masses, if mass properties are formatted with the PROPUNITS system variable.

Note: If negative, LUPREC (Linear Unit Precision) is used.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-1 to 8
Default value:	-1
Possible values:	<p>-1: Use LUPREC 0: 0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000 8: 0.00000000</p>

17.8 MASSPROPACCURACY system variable

17.8.1 Mass properties calculation relative accuracy

Controls the accuracy used for mass properties calculations. This accuracy is relative. For a value of 3 the calculated values may deviate up to 0.1% from the actual value, for 12 it is 1.e-10%. For value of 2 the deviation may exceptionally exceed 1% and we assume a margin of 2%.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	2 to 12



Default value:	2
Possible values:	2: 2% accuracy 3: 0.1% accuracy 4: 0.01% accuracy 5: 0.001% accuracy 6: 1.e-4% accuracy 7: 1.e-5% accuracy 8: 1.e-6% accuracy 9: 1.e-7% accuracy 10: 1.e-8% accuracy 11: 1.e-9% accuracy 12: 1.e-10% accuracy

17.9 MASSUNITS system variable

17.9.1 Mass units

Controls the units used to display mass, if mass properties are formatted with the PROPUNITS system variable. If empty, all masses are displayed without units.

The MASSUNITS setting affects the mass values only. Other mass properties such as density or moments of inertia are formatted in SI units for the metric system and in imperial units for the imperial system, regardless of the MASSUNITS setting.

The string contains a space-separated list of unit abbreviations.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	oz lb st mg g kg t

17.10 MAXACTVP system variable

17.10.1 Maximum active viewports

Controls the maximum number of viewports that can be active simultaneously in a layout. Has no effect on the number of viewports that are plotted.

Type:	Short
Saved in:	Drawing



Default value:	64
----------------	----

17.11 MAXHATCH system variable

17.11.1 Maximum hatch dashes

Controls the maximum number of dashes in a hatch pattern.

Hatches of which the number of dashes exceeds the maximum number of dashes cannot be created.

Values between 100 and 10,000,000 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	100 to 10000000
Default value:	100000

17.12 MAXSORT system variable

17.12.1 Maximum sort

Controls the maximum number of symbol, file and/or block names sorted by commands that list.

If the number of items exceeds this value, the items are not sorted into alphabetical order.

Values between 0 and 200 are accepted.

Type:	Short
Saved in:	Registry
Default value:	200

17.13 MAXTHREADS system variable

17.13.1 Maximum number of threads

Controls the maximum number of threads used to display and load drawings and point cloud operations.

See also the MTFLAGS system variable.

Values between 0 and 16 are accepted. A value of zero means automatically use the optimal number of threads.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	0 to 16
Default value:	0

17.14 MBSTATE system variable

17.14.1 Mechanical browser state (Read Only)

Mechanical browser status.

BricsCAD only

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	1
Possible values:	0: Mechanical browser is invisible 1: Mechanical browser is visible

17.15 MBUTTONPAN system variable

17.15.1 Middle button pan

Controls how the middle mouse button/wheel responds.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Action defined in menu file 1: Pan



17.16 MEASUREINIT system variable

17.16.1 Measurement initial

Controls drawing units as Imperial or Metric for new drawings

Also controls the hatch pattern and linetype files used: ANSI for Imperial and ISO for Metric units.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Imperial (use ANSI Hatch and ANSI Linetype) 1: Metric (use ISO Hatch and ISO Linetype)

17.17 MEASUREMENT system variable

17.17.1 Measurement

Controls the current drawing units as Imperial or Metric, also controls if ANSI or ISO hatch pattern and linetype files are used. See also the LUNITS and INSUINTS system variables.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Imperial (use ANSI Hatch and ANSI Linetype) 1: Metric (use ISO Hatch and ISO Linetype)

17.18 MECH2DSAVEFORMAT system variable

17.18.1 Mechanical 2D save format

Controls the save format of Mechanical 2D entities.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Registry
Range:	2013 to 2018
Default value:	2021
Possible values:	2013: 2013 Mechanical 2D 2014: 2014 Mechanical 2D 2015: 2015 Mechanical 2D 2016: 2016 Mechanical 2D 2018: 2018 Mechanical 2D 2021: 2021 Mechanical 2D

17.19 MECHANICALBLOCKS system variable

17.19.1 Mechanical blocks

Enables or disables mechanical blocks as an alternative to mechanical components.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
	Off (0): Disables mechanical blocks On (1): Enables mechanical blocks

17.20 MECHANICALBLOCKOPTIONS system variable

17.20.1 Mechanical blocks options

Controls how blocks and mechanical blocks are used in the drawing.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0



Possible options:	0: Do not convert new blocks to mechanical blocks 1: Automatically convert new blocks to mechanical blocks
-------------------	---

17.21 MECHANICALBROWSERSETTINGS system variable

17.21.1 Mechanical browser options

Sets the default mechanical browser options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2047
Default value:	819
Possible options:	<ul style="list-style-type: none">1: Expressions of constraints2: Components parameters4: Expressions of components parameters8: Sub-components of standard parts16: Arrays32: Block and External References64: Always synchronize selection128: Keep values list order256: Highlight objects selected in the browser512: Asynchronous properties load1024: Expose all solids

17.22 MENUBAR (EXCEPT OS X) system variable

17.22.1 Menu bar

Displays the Menu bar.

Type:	Boolean
Saved in:	Workspace
Range:	0 to 1
Default value:	On



Possible values:	Off (0): Don't show menubar On (1): Show menubar
------------------	---

17.23 MENUCTL system variable

17.23.1 Menu control

Controls if the screen menu switches pages in response to keyboard command entry.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Screen menu doesn't switch pages in response to keyboard command entry On (1): Screen menu switches pages in response to keyboard command entry

17.24 MENUCHO system variable

17.24.1 Menu echo

Controls menu echo and prompt control.

Type:	Short
Saved in:	Not saved
Range:	0 to 15
Default value:	0
Possible options:	1: Suppress menu item echo 2: Suppress system prompts during menu 4: Disable ^P toggle 8: Display input/output strings (DIESEL macros debugging)

17.25 MENUNAME system variable

17.25.1 Menu name (Read Only)

The file path for the menu file.



Type:	String
Saved in:	Registry

17.26 MESHTYPE system variable

17.26.1 Mesh type

Controls the type of mesh that is created by REVsurf, TABsurf, RULEsurf and EDGESurf commands
(Not yet supported).

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Create legacy polygon or polyface mesh 1: Create full-featured mesh entities (recommended)

17.27 MIDDLECLICKCLOSE system variable

17.27.1 Middle click close (Mac & Linux)

Allows a tab to be closed with a middle button click on the tab bar.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	true

17.28 MILLISECS system variable

17.28.1 Milliseconds (Read Only)

Counts the number of milliseconds that have passed since system startup.

Type:	Long
-------	------



Saved in:	Not saved
-----------	-----------

17.29 MIRRHATCH system variable

17.29.1 Mirror hatch patterns

Controls if hatch patterns are mirrored by the MIRROR command.


Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't mirror hatch patterns On (1): Mirror hatch patterns

17.30 MIRRTEXT system variable

17.30.1 Mirror text

Controls if text is mirrored by the MIRROR command.

Type:	Boolean
Saved in:	Drawing
Range:	On
Possible values:	Off (0): Don't mirror text On (1): Mirror text





17.31 MLEADERSCALE system variable

17.31.1 Multileader scale

Controls the width scale for entities created with the MLEADER command.

Note: The scale must have a positive value.

Type:	Real
Saved in:	Drawing
Default value:	1.0

17.32 MODEMACRO system variable

17.32.1 Mode macro

Displays a text string on the status line, such as the name of the current drawing, time/date stamp or special modes. Used to help debug Diesel programs.

Type:	String
Saved in:	Not saved

17.33 MSLTSCALE system variable

17.33.1 Model space linetype scale

Controls the linetype annotation scale behavior, in model space.

Note: When changing MSLTSCALE, REGEN or REGENALL is needed to update the display.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Linetypes are not scaled by annotation scale 1: Linetypes are scaled by the annotation scale



17.34 MSOLESCALE system variable

17.34.1 Model space OLE scale

Controls the size of an OLE (Object Linking & Embedding) entity, that contains text, when pasted into model space. Entities already placed in the drawing are not affected.

If set to zero, uses the DIMSCALE system variable.

Type:	Real
Saved in:	Drawing
Range:	0.0 or greater
Default value:	1.0

17.35 MTEXTCOLUMN system variable

17.35.1 Multiline text column setting

Controls the default column property for multi-line text.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: No columns 1: Dynamic columns with auto height 2: Dynamic columns with manual height

17.36 MTEXTDETECTSPACE system variable

17.36.1 Space detection for creating lists in mtext editor

Creates formatted list items, when the space bar is pressed after a letter, number or symbol, in mtext editor mode.

Type:	Boolean
Saved in:	Registry



Range:	On
Possible values:	Off (0): Don't allow spaces for mtext editor lists On (1): Allow spaces for mtext editor lists

17.37 MTEXTED system variable

17.37.1 Multiline text editor

Controls the text editors to use for multiline text entities.

Type:	String
Saved in:	Registry

17.38 MTEXTFIXED system variable

17.38.1 Multiline text fixed

Controls whether the application zooms, rotates and/or pans the view to fit the multiline text to be edited.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Do nothing when mtext editor is opened 1: Do nothing when mtext editor is opened 2: Rotate / zoom / pan view to fit multiline text

17.39 MTEXTTOOLBAR system variable

17.39.1 MText Formatting toolbar

Controls if the formatting toolbar is displayed when multiline text is edited.

Type:	Boolean
Saved in:	Registry



Range:	On
Possible values:	Off (0): Don't show formatting toolbar On (1): Show formatting toolbar

17.40 MTFLAGS system variable

17.40.1 Multi-Threading Flags

Bit flags for parallel processing of display and loading.

Type:	Short
Saved in:	Registry
Range:	0 to 4095
Default value:	3015
Possible options:	0: No parallel processing 1: Parallelized regeneration of display. 2: Parallelized redraw of display. 4: Parallelized loading of drawings. 8: Parallelized calculation of hidden line removal. 16: Parallelized generation of BIM sections to separate destination files. 32: Parallelized generation of BIM sections to the same destination file. 64: Parallelized computations in Direct Modeling commands and operations. 128: Parallelized computations in Assembly commands and operations. 256: Parallelized computations in Sheet Metal commands and operations. 512: Parallelized interference checking 1024: Delayed XREF loading 2048: Parallelized point cloud operations

17.41 MULTISELECTANGULARTOLERANCE system variable

17.41.1 BimMultiSelect angular tolerance

Controls the maximum angle between two linear solids axes, for these solids to still be considered parallel.

BricsCAD only

Type:	Real
-------	------



Saved in:	Registry
Range:	0 to 90
Default value:	3

17.42 MYDOCUMENTSPREFIX system variable

17.42.1 MyDocuments root prefix (Read Only)

The path of the user documents folder.

Type:	String Standard
Saved in:	Registry



18. N


18.1 NAVVCUBEDISPLAY system variable

18.1.1 LookFrom display

Toggles the LookFrom control on/off.

The LookFrom is the navigation control, by default this appears in the top-right corner.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	On
Possible values:	Off (0): Don't display the LookFrom control On (1): Display the LookFrom control



18.2 NAVVCUBELOCATION system variable

18.2.1 LookFrom location

Controls the location of the LookFrom control.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0



Possible values:	0: Top-right corner 1: Top-left corner 2: Bottom-left corner 3: Bottom-right corner
------------------	--

18.3 NAVVCUBEOPACITY system variable

18.3.1 LookFrom opacity

Controls the opacity of the LookFrom control while inactive.

Type:	Short
Saved in:	Registry
Range:	0 to 100
Default value:	50

18.4 NAVVCUBEORIENT system variable

18.4.1 LookFrom orientation

Controls if the LookFrom control reflects the current WCS (World Coordinate System) or UCS (User Coordinate System).

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: WCS 1: UCS

18.5 NEARESTDISTANCE system variable


18.5.1 Nearest Distance

Controls nearest distance dimension between a pair of selected entities. The value is stored as a bitcode using the sum of the values of all selected options.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	1
Possible options:	<ul style="list-style-type: none">1: Show nearest distance dimension2: Show OX aligned nearest distance dimension4: Show OY aligned nearest distance dimension8: Show OZ aligned nearest distance dimension



18.6 NOMUTT system variable

18.6.1 No muttering

Suppresses text in the Command line.

When on, the Command line will stop prompting all the options and actions.

Type:	Boolean
Saved in:	Not saved



Default value:	Off
Possible values:	Off (0): Don't suppress Command line prompts On (1): Suppress Command line prompts

18.7 NORTHDIRECTION system variable

18.7.1 North direction

Controls the angle of the sun, from north, in the context of the world coordinate system (WCS).

Type:	Real
Saved in:	Drawing
Default value:	0.0



19. 0

19.1 OBJECTISOLATIONMODE system variable

19.1.1 Object Isolation Mode

Controls if entities hidden with HIDEOBJECTS or ISOLATEOBJECTS remain hidden after a drawing is saved, closed and reopened.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	<p>0: Entities are hidden only for the current session, includes interference solids</p> <p>1: Entities remain hidden between sessions, includes interference solids</p> <p>2: Entities are hidden only for the current session, does not include interference solids</p> <p>3: Entities remain hidden between sessions, does not include interference solids</p>

19.2 OBSCUREDCOLOR system variable

19.2.1 Obscured color

Controls the color of obscured lines.

Visible only if the OBSCUREDLTYPE system variable is in use.

Type:	Short
Saved in:	Drawing
Range:	0 to 257
Default value:	257
Possible values:	<p>0: ByBlock</p> <p>1 - 255: index</p> <p>256: ByLayer</p> <p>257: ByEntity</p>



19.3 OBSCUREDLTYPE system variable

19.3.1 Obscured linetype

Controls the linetype of obscured lines. Unlike regular linetypes, obscured linetypes are zoom level independent.

Type:	Short
Saved in:	Drawing
Range:	0 to 11
Default value:	0
Possible values:	0: Off 1: Solid 2: Dashed 3: Dotted 4: Short Dash 5: Medium Dash 6: Long Dash 7: Double Short Dash 8: Double Medium Dash 9: Double Long Dash 10: Medium Long Dash 11: Sparse Dot

19.4 OFFSETDIST system variable

19.4.1 Offset distance

Stores the last distance used for the OFFSET command.

Type:	Real
Saved in:	Not saved
Range:	-1.0
Possible values:	<0: draws a parallel copy of an entity through a specified point



19.5 OFFSETERASE system variable

19.5.1 Offset erase

Erases the source entity for the OFFSET command.

Type:	Boolean
Saved in:	Registry
Range:	Off
Possible values:	Off (0): Offset erase off On (1): Offset erase on

19.6 OFFSETGAPTYPE system variable

19.6.1 Offset gap type

Controls how possible gaps, in parallel copies of closed polylines, are filled.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Extend polyline segments 1: Filleted arc segments 2: Chamfered line segments



19.7 OLEFRAME system variable

19.7.1 OLE frame

Controls the display of a frame around an OLE object, if the FRAME system variable is set to **Use individual system variables** (3).



Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: No OLE frames 1: Display and plot OLE frames 2: Display but do not plot OLE frames

19.8 OLEHIDE system variable

19.8.1 OLE hide

Controls the visibility of OLE objects for both screen display and plotting.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: All OLE entities are visible and plot 1: OLE entities are visible and plot in paper space only 2: OLE entities are visible and plot in model space only 3: No OLE entities are visible and do not plot

19.9 OLEQUALITY system variable

19.9.1 OLE quality

Controls the default plot quality of OLE entities. When set to **Automatically Select** (3), the quality level is assigned automatically depending on the entity type (for example, photographs are set to **High**).

Type:	Short
Saved in:	Registry
Range:	0 to 3



Default value:	3
Possible values:	0: Monochrome 1: Low graphics 2: High graphics 3: Automatically Select

19.10 OLESTARTUP system variable

19.10.1 OLE startup

Loads the OLE entity source when plotting.

Type:	Boolean
Saved in:	Drawing
Range:	Off
Possible values:	Off (0): Don't load OLE source application when plotting On (1): Load OLE source application when plotting

19.11 OPMSTATE system variable

19.11.1 Properties bar state (Read Only)

Properties bar status.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	1
Possible values:	0: Properties bar is invisible 1: Properties bar is visible

19.12 ORBITAUTOTARGET system variable

19.12.1 Orbit Auto Target

Controls the behavior of the RTROT command.



Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Mouse - The rotation point is located at the mouse click location 1: Center - The target point is located at the center of the selected entities(s), or the entities displayed on screen

19.13 ORTHOMODE system variable

19.13.1 Orthogonal mode

Constrains cursor movement perpendicularly. When on the cursor can only move horizontally or vertically, relative to the current UCS and grid rotation angle. See also the SNAPANG system variable.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Orthogonal mode off On (1): Orthogonal mode on

19.14 OSMODE system variable

19.14.1 Entity snap mode

Controls the 2D entity snap types.

Type:	Short
Saved in:	Registry
Range:	0 to 32767
Possible options:	4135



Possible values:	0: None 1: Endpoint 2: Midpoint 4: Center 8: Node 16: Quadrant 32: Intersection 64: Insertion 128: Perpendicular 256: Tangent 512: Nearest 1024: Geometric center 2048: Apparent intersection 4096: Extension 8192: Parallel 16384: Turn off all snaps
------------------	---

19.15 OSNAPCOORD system variable

19.15.1 Entity snap coordinates

Controls if entity snaps override manually entered coordinates.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Entity snap settings override keyboard coordinate entry 1: Keyboard entry overrides entity snap settings 2: Keyboard entry overrides entity snap settings except in scripts

19.16 OSNAPZ system variable

19.16.1 Ignore entity snap elevation

Overrides the Z coordinate of an entity snap with the current ELEVATION system variable value.

Type:	Boolean
Saved in:	Not saved



Default value:	Off
Possible values:	Off (0): Don't replace Z value with current elevation On (1): Replace Z value with current elevation

19.17 OSOPTIONS system variable

19.17.1 Entity snap options

Suppresses entity snaps on certain entity types.

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	7
Possible options:	1: Entity snap ignores hatches 2: Entity snap ignores negative Z values in Dynamic UCS mode 4: Entity snap ignores end points of dimension extension lines 8: Entity snap ignores invisible geometry in shaded and hidden-line views

19.18 OVERKILLAYER system variable

19.18.1 Duplicate Entities Layer

The layer that entities are moved to during the OVERKILL command - the **Move duplicates to Duplicate Entities layer** option.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	Duplicate Entities



20. P

20.1 PANBUFFER system variable

20.1.1 Pan buffer

Enables faster panning, particularly in complex drawings.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable faster panning On (1): Enable faster panning

20.2 PANELBUTTONSIZE system variable

20.2.1 Panel control button size

Controls the size of the icons used for panels.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	1
Default value:	0 to 2
Possible values:	0: Small buttons 1: Large buttons 2: Extra-large buttons



20.3 PAPERUPDATE system variable

20.3.1 Paper update

Controls paper size adaption when printers are switched in the **Print** dialog box.

- If Off: does not update the paper size, preserving the paper size currently selected. If the printer has no close match, the size will be displayed as **Previous paper size**. On print, your confirmation is required before substitution with default values.
- If On: updates the paper size, using the default paper size of the selected printer.

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	Off (0): Use default paper size of the selected printer On (1): Use configured paper size of the plotter configuration file

20.4 PARAMETERCOPYMODE system variable

20.4.1 Parameter copy mode

Controls how constraints and related parameters are copied with the COPY command.

Type:	Short
Saved in:	Registry
Range:	0 to 4
Default value:	3
Possible values:	0: Do not copy 2D constraints 1: Replace all expressions with constants 2: Use existing parameters, if parameter is missing replace it with constant 3: Use existing parameters, create new parameter if it is missing 4: Use existing parameters, create new parameter if it is missing or has different value



20.5 PARAMETERMATCHMODE system variable

20.5.1 Match Parametric Blocks by parameters

The option is not stored in registry, however for some designated blocks it is known that the individual copy is required for each separate insert.

BricsCAD only

Type:	Short
Saved in:	Not saved
Range:	0 to 2
Default value:	0
Possible values:	0: Re-use existing block if insert has same expressions 1: Use separate copy for each block insert 2: Force default behavior for previously separated blocks

20.6 PARAMETRICBLOCKS2DPATH system variable

20.6.1 Parametric blocks 2D directory path

The file path(s) for user created 2D Parametric Blocks files.

Separate file paths with semicolons (;).

BricsCAD only

Type:	String
Saved in:	Registry

20.7 PARAMETRIZECONNECTIONS system variable

20.7.1 Parametrize Connections

Controls if constraints connect components for the BMCONVERT, BMCONNECT and BMINSERT (SMART insert option) commands.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Range:	0 to 1
Default value:	1
Possible values:	0: Don't use constraints 1: Use constraints

20.8 PBLOCKREFERENCEOPERATIONSVISUALIZATION system variable

20.8.1 Visualize parametric operations on block references

Enables the visualization of the parametric operations' information when hovering the cursor over parametric block references.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Visualization off On (1): Visualization on

20.9 PDFANIMATIONFPS system variable

20.9.1 Frames per second

Controls the number of frames per second for an animation.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	24

20.10 PDFCACHE system variable

20.10.1 PDF cache

Enables/disables the PDF cache.



A multi-resolution persistent image cache is used to display attached Pdf underlays, enabling (very) fast zoom and pan operations. The highest cached resolution is 5000 x 5000 pixels. Still, when zooming in very close, the display of the Pdf underlay will become pixelated. So a hybrid modus can be used which switches to real-time generation of crisp Pdf underlay display when zooming in very close. The initial generation of the image cache may take a few seconds, from then on processing gets (very) fast, and remains like that in subsequent sessions.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2 (Windows) 0 (Mac & Linux)
Possible values:	0: No caching, always real time generation 1: Use pdf cache, only use real time generation when zooming in close 2: Always use pdf cache

20.11 PDFCREATEBOOKMARKS system variable

20.11.1 Create bookmarks

Create bookmarks for PDF exports.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Do not create bookmarks On (1): Creates bookmarks

20.12 PDFEMBEDDEDTTF system variable

20.12.1 Pdf embedded fonts

Embeds True Type fonts for PDF exports.

BricsCAD only



Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable embedded TTF fonts On (1): Enable embedded TTF fonts

20.13 PDFEXPORTHYPERLINKS system variable

20.13.1 Export hyperlinks

Exports entity hyperlinks for PDF exports.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disables export of entity hyperlinks On (1): Enables export of entity hyperlinks

20.14 PDFFRAME system variable

20.14.1 PDF frame

Controls the visibility of PDF underlay frames, if the FRAME system variable is set to **Use individual system variables** (3).

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Hide PDF frames 1: Display and plot PDF frames 2: Display but do not plot PDF frames



20.15 PDFIMAGEANTIALIAS system variable

20.15.1 Image anti-aliasing

Enables anti-aliasing for images that are upscaled during PDF export.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disables anti-aliasing for images On (1): Enables anti-aliasing for images

20.16 PDFIMAGECOMPRESSION system variable

20.16.1 Image compression

Compresses images to JPEG during PDF export.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: None 1: JPEG

20.17 PDFIMAGEDPI system variable

20.17.1 Image DPI

Controls the minimal resolution for an image exported to PDF.

Cannot exceed the value of the PDFVECTORRESOLUTIONDPI system variable.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Preference
Default value:	300

20.18 PDFIMPORTAPPLYLINEWEIGHT system variable

20.18.1 Apply linewidth properties

Retains the linewidth properties of imported entities, during PDF import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Ignore the linewidth properties of the imported entities On (1): Retain the linewidth properties of the imported entities

20.19 PDFIMPORTASBLOCK system variable

20.19.1 Import as block

Imports PDF files as blocks.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't import PDF files as a block On (1): Import PDF files as a block

20.20 PDFIMPORTCHARSPACEFACTOR system variable

20.20.1 Inter-character space factor

The multiplier for the width of the space between characters in a word, used during PDF import.

If the distance between the text objects in the string is less than the width of the space taken from the font metric multiplied by this factor, the text objects are combined into one word.



Note: Applies only if PDFIMPORTCOMBINETEXTOBJECTS is turned on.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.6

20.21 PDFIMPORTCOMBINETEXTOBJECTS system variable

20.21.1 Combine text entities

Controls if text entities, that use the same font and are on the same line, are combined, during PDF import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Text entities are not combined On (1): Text entities are combined

20.22 PDFIMPORTCONVERTSOLIDSTOHATCHES system variable

20.22.1 Convert solid fills to hatches

Converts 2D solid entities into solid-filled hatches, during PDF import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't convert solid fills to hatches from imported PDF files On (1): Convert solid fills to hatches from imported PDF files



20.23 PDFIMPORTIMAGEPATH system variable

20.23.1 Raster Images Folder

The file path used to save images, during PDF import, absolute or relative.

- If relative, the PDF image path is relative to the folder of the current drawing file.
- If empty, the folder of the current drawing is used, if the drawing has not yet been saved the images will be saved in the same folder as the imported PDF.

Type:	String
Saved in:	Registry
Default value:	PDF Images

20.24 PDFIMPORTJOINLINEANDARCSEGMENTS system variable

20.24.1 Join line and arc segments

Joins continuous segments into a polyline, where possible, during PDF import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	On
Possible values:	Off (0): Don't join the line and arc segments from imported PDF files On (1): Join the line and arc segments from imported PDF files

20.25 PDFIMPORTLAYERSUSETYPE system variable

20.25.1 Layers

Controls layers during PDF import.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2



Default value:	0
Possible values:	0: Use PDF Layers 1: Create layers per entity type 2: Use current layer

20.26 PDFIMPORTRASTERIMAGES system variable

20.26.1 Raster Images

Extracts images to PNG files and attaches these to the current drawing, during PDF import. These images are stored in the folder set in the PDFIMPORTIMAGEPATH system variable.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	Off
Possible values:	Off (0): Don't extract raster images On (1): Extract raster images

20.27 PDFIMPORTSOLIDFILLS system variable

20.27.1 Solid fills

Ignore or import solid-filled areas during PDF import, if the information is in the PDF. Solid-filled areas include solid-filled hatches, 2D solids, wipeout entities, wide polylines, and triangular arrowheads.

Note: Solid-filled hatches are assigned a 50% transparency.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Ignore solid-filled areas. On (1): Import solid-filled areas.



20.28 PDFIMPORTSPACEFACTOR system variable

20.28.1 Inter-word space factor

Controls the multiplier for the width of the space between words on a line.

If the distance between the text objects in the string is greater than the width of the space between characters in a word (specified by the PDFIMPORTCHARSPACEFACTOR system variable), but less than the width of the space taken from the font metrics multiplied by this factor, the text objects are combined into one word.

Note: Applies only if PDFIMPORTCOMBINETEXTOBJECTS is turned on.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	1.5

20.29 PDFIMPORTTRUETYPETEXT system variable

20.29.1 TrueType text

Import TrueType text as a TrueType text, the textstyle named is inherited from the font, during PDF import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import the TrueType text On (1): Import the TrueType text

20.30 PDFIMPORTTRUETYPETEXTASGEOMETRY system variable

20.30.1 Import True Type text as geometry

Imports True Type Text as geometry, during PDF import.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't import TrueType text as geometry On (1): Import TrueType text as geometry

20.31 PDFIMPORTUSECLIPPING system variable

20.31.1 Apply clipping

Clips entities, during PDF import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Clipping is not applied to entities on import On (1): Clipping is applied to entities on import

20.32 PDFIMPORTUSEGEOMETRYOPTIMIZATION system variable

20.32.1 Import geometry with optimization

Optimizes geometry, during PDF import.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import geometry with optimization On (1): Import geometry with optimization



20.33 PDFIMPORTUSEIMAGECLIPPING system variable

20.33.1 Clip images

Clips images during a PDF import. The clipped part images becomes transparent.

Note: Applies only if PDFIMPORTUSECLIPPING is on (1).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Images are not clipped on import On (1): Images are clipped on import

20.34 PDFIMPORTUSEPAGEBORDERCLIPPING system variable

20.34.1 Apply clipping at page border

Clips entities at the page border during, PDF import.

Note: Applies only if the PDFIMPORTUSECLIPPING system variable is on (1).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Clipping at page border is not applied on import. On (1): Clipping at page border is applied on import.

20.35 PDFIMPORTVECTORGEOMETRY system variable

20.35.1 Vector geometry

Imports vector geometry during PDF import.

If on, linear paths and Beziér curves are imported as polylines within a tolerance. Curves that resemble arcs, circles, and ellipses are also converted. Solid-filled areas are imported as 2D solids or solid-filled hatches. Patterned hatches are imported as many separate entities.

BricsCAD only



Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't import vector geometry On (1): Import vector geometry

20.36 PDFLAYERSSETTING system variable

20.36.1 PDF layer support

Controls the way layers are exported to PDF.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	1
Possible values:	0: Don't use layers 1: Use all layers with visible entities 2: Use all layers with entities, including OFF and FROZEN layers.

20.37 PDFLAYOUTSTOEXPORT system variable

20.37.1 PDF layouts to export

Controls the layout(s) exported to PDF (paper space).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0



Possible values:	0: Active layout 1: All layout(s) in multi-sheet files 2: All layout(s) in single-sheet files
------------------	---

20.38 PDFMERGECONTROL system variable

20.38.1 PDF Merge Control

Controls the appearance of lines that cross in PDF exports.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: Lines Overwrite - Uses the last plotted line and obscures the line(s) under it 1: Lines Merge - Merges the colors of crossing lines

20.39 PDFNOTIFY system variable

20.39.1 PDF notify

Displays a warning, when a drawing is opened, if there are missing PDFs.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Disable PDF notification On (1): Enable PDF notification

20.40 PDFOPENINVIEWER system variable

20.40.1 Open in viewer

Open result file in system default PDF viewer.

BricsCAD only



Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Do not open in PDF viewer. On (1): Open in PDF viewer.

20.41 PDFOSNAP system variable

20.41.1 PDF entity snap

Enables entity snap for PDF underlay files.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable PDF entity snap On (1): Enable PDF entity snap

20.42 PDFPAPERHEIGHT system variable

20.42.1 PDF override - paper height

Paper height for PDF export, in millimeters, if the PDFPAPERSIZE OVERRIDE system variable is on (1).

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	297

20.43 PDFPAPERSIZE OVERRIDE system variable

20.43.1 PDF papersize override

Enables papersize override for PDF export.



If On, the papersize as defined in the BricsCAD Print settings is overridden. The papersize width and height defined by PDFPAPERWIDTH and PDFPAPERHEIGHT are used instead.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Disable papersize override On (1): Enable papersize override

20.44 PDFPAPERWIDTH system variable

20.44.1 PDF override - paper width

Paper width for PDF export, in millimeters, if the PDFPAPERSIZE OVERRIDE system variable is on (1).

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	210

20.45 PDFPDFA system variable

20.45.1 PDF/A format support

Controls archived PDF support.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible options:	0: Don't use PDF/A 1: Use version PDF/A-1b 2: Use version PDF/A-2b 3: Use version PDF/A-3b



20.46 PDFPRCCOMPRESSION system variable

20.46.1 PRC Compression

Controls the compression of PRC 3D data (3D PDF).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: No compression 1: Medium compression 2: High compression

20.47 PDFPRCEXPORT system variable

20.47.1 PRC Export Mode

PRC mode for the export of PRC 3D data (3D PDFs).

Export as BREP is an experimental mode which may work incorrectly. We recommend using **Export as Mesh** mode.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: No export 1: Export as BREP (Experimental) 2: Export as Mesh



20.48 PDFPRCPROJECTION system variable

20.48.1 PRC Projection

Controls the projection type for PRC 3D data (3D PDF).

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: Orthogonal 1: Perspective

20.49 PDFPRCVIEWMODE system variable

20.49.1 PRC View mode

Controls how 2D entities and 3D entities are exported for PRC PDFs (3D PDFs).

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	0: All entities in single view 1: Only 3D entities in single view 2: Only 3D entities in multiple views

20.50 PDFSHXTEXTASGEOMETRY system variable

20.50.1 PDF SHX text as geometry

Converts SHX font text to geometry for PDF exports. This might be necessary if the receiving party does not have the same SHX fonts on their computer.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't convert SHX text to geometry On (1): Convert SHX text to geometry

20.51 PDFSIMPLEGEOMOPTIMIZATION system variable

20.51.1 Pdf simple geometry optimization

Simplifies geometry for PDF exports (merges separate line segments to one polyline and uses Bezier curve control points).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable simple geometry optimization On (1): Enable simple geometry optimization

20.52 PDFTTFFTEXTASGEOMETRY system variable

20.52.1 PDF TTF text as geometry

Converts True Type font text to geometry for PDF exports.

This is useful for when the TTF files are covered by a license that prohibits sharing, or you want to make it harder to extract text.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't convert TTF text to geometry On (1): Convert TTF text to geometry



20.53 PDFUSEPLOTTYLES system variable

20.53.1 Use PDF plotstyles

Enables plotstyles for PDF exports.

If On, the plotstyle of the layout controls the color and linewidth in the PDF export.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disables usage of plotstyles On (1): Enables usage of plotstyles

20.54 PDFVECTORRESOLUTIONDPI system variable

20.54.1 Vector Resolution DPI

Resolution of vector graphics for PDF export from model space.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	72 to 40000
Default value:	2400

20.55 PDFZOOMTOEXTENTSMODE system variable

20.55.1 PDF zoom to extents mode

Scales the layout geometry of papersize layouts for PDF exports.

If switched off, uses the scale and papersize from the pagesetup data.

BricsCAD only

Type:	Boolean
Saved in:	Preference




Default value:	On
Possible values:	Off (0): Don't zoom to extents On (1): Zoom to extents

20.56 PDMODE system variable

20.56.1 Point display mode

Controls the display style for point entities.

Type:	Short
Saved in:	Drawing
	0 to 100
Default value:	0
Possible options:	1: none 0: . 2: + 3: x 4: ' 32: circle 64: square



20.57 PDSIZE system variable

20.57.1 Point display size

Controls the display size for point entities.

Type:	Real
Saved in:	Drawing
Default value:	0
Possible values:	0: 5% of the drawing area height >0: Absolute size <0: Percentage of the viewport size

20.58 PEDITACCEPT system variable

20.58.1 Polyline edit accept

Displays a warning, when non-polylines are selected during the PEDIT command. When suppressed, the selected entity is automatically converted to a polyline.

Type:	Boolean
Saved in:	Registry




Default value:	0
Possible values:	Off (0): Display prompt On (1): Suppress prompt

20.59 PELLIPSE system variable

20.59.1 Polyline ellipse

Controls the entity type created with the ELLIPSE command.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Create real ellipses On (1): Create polyline representations of an ellipse



20.60 PERIMETER system variable

20.60.1 Last perimeter (Read Only)

The last perimeter calculated by the AREA, LIST, or DBLIST commands.

Type:	Real
Saved in:	Not saved

20.61 PERSPECTIVE system variable

20.61.1 Perspective

Turns on perspective view for the current viewport.

Type:	Boolean
-------	---------



Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Perspective view off On (1): Perspective view on

20.62 PFACEVMAX system variable

20.62.1 Polyface mesh maximum vertices (Read Only)

The maximum number of vertices for each face.

Type:	Short
Saved in:	Not saved
Range:	3 or greater
Default value:	4

20.63 PICKADD system variable

20.63.1 Pick add

Controls how the Shift key selects entities.

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	On
Possible values:	Off (0): Press SHIFT to add entities to the current selection On (1): Press SHIFT to remove entities to the current selection

20.64 PICKAUTO system variable

20.64.1 Selection window behavior

Controls the selection behavior - window and lasso - used to select multiple entities at the same time.



See also the PICKDRAG system variable.

Type:	Short
Saved in:	Registry
Range:	-7 to 7
Default value:	5
Possible options:	Negative: No window selection, saving earlier value 0: No window selection 1: Window selection, pick the first and last point, if the cursor does not start above an entity 2: Window selection, for click and drag, if the cursor starts above an entity 4: Lasso selection, for click and drag, if the cursor does not start above an entity

Note: A negative value is the same as 0, but helps in storing the earlier value.

20.65 PICKBOX system variable

20.65.1 Pick box

Controls the selection area size around the cursor, in pixels.

Values between 0 and 50 are accepted.

Note: If you select an entity by clicking, the Pick Box must touch or overlap the entity.

Type:	Short
Saved in:	Registry
Range:	0 to 50
Default value:	4
Unit	pixels

20.66 PICKDRAG system variable

20.66.1 Pick drag

Controls the window selection behavior used to select multiple entities at the same time.

See also the PICKAUTO system variable.



Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Draw selection window with two points On (1): Draw selection window with click and drag

20.67 PICKFIRST system variable

20.67.1 Pick first

Makes it possible to select entities first, then issue a command.

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): First issue a command, then select entities On (1): First select entities, then issue a command

20.68 PICKSTYLE (EXCEPT OS X) system variable

20.68.1 Pick style

Controls the selection of groups and associative hatches.

Use **Ctrl+H** to toggle this system variable.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1



Possible options:	0: No group selection or associative hatch selection 1: Group selection - if a member of a selectable group is selected, all members of the group are selected 2: Associative hatch selection - the hatch and its boundary are selected, no matter what is picked (the hatch or the boundary)
-------------------	---

20.69 PICTUREEXPORTSCALE system variable

20.69.1 Picture format export scale factor

Controls the output resolution scale for WMF, EMF or BMP exports. Used in commands EXPORT, WMFOUT, COPYCLIP, CUTCLIP and in COM/VBA function AcadDocument. The output view size is the current view size-in pixels, multiplied by this value.

Trouble: Scale values of 10 or more may cause slow system response.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 or greater
Default value:	1.0

20.70 PLACESBARFOLDER1 system variable

20.70.1 First folder

Controls the first folder in the places bar of the nonstandard **Open file** dialog box (Windows only).

This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

See also the USESTANDARDOPENFILEDIALOG system variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	0



Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents
------------------	---

20.71 PLACESBARFOLDER2 system variable

20.71.1 Second folder

Controls the second folder in the places bar of the nonstandard **Open file** dialog box (Windows platform only).

This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

See also the USESTANDARDOPENFILEDIALOG system variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	1
Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents

20.72 PLACESBARFOLDER3 system variable

20.72.1 Third folder

Controls the third folder in the places bar of the nonstandard **Open file** dialog box (Windows platform only).

This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

See also the USESTANDARDOPENFILEDIALOG system variable.



BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	3
Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents

20.73 PLACESBARFOLDER4 system variable

20.73.1 Fourth folder (Windows)

Controls the fourth folder in the places bar of the nonstandard **Open file** dialog box (Windows platform only).

This enables you to place shortcuts to your favorite drawing folders on your desktop or in your Favorites folder.

See also the USESTANDARDOPENFILEDIALOG system variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	5
Possible values:	0: Desktop 1: My Computer 2: My Documents 3: Favorites 4: Network 5: My Recent Documents



20.74 PLATFORM system variable

20.74.1 Platform (Read Only)

Displays the current Operating System version.

Type:	String
Saved in:	Not saved

20.75 PLINECACHE system variable

20.75.1 Polyline cache

Controls the creation of a cache of polyline vertices, when a drawing is opened.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Disable polyline cache On (1): Enable polyline cache

20.76 PLINECONVERTMODE system variable

20.76.1 Polyline convert mode

Controls how splines are converted to polylines.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Create polylines with linear segments 1: Create polylines with arc segments




20.77 PLINEGEN system variable

20.77.1 Polyline generation

Controls how linetype patterns are generated around 2D polyline vertices.

Linetypes are normally generated from vertex to vertex (0). Polylines of which the vertices are very close together might be rendered as a continuous line, if the linetype pattern does not fit between two subsequent vertices. When set to 1, the linetype is drawn from one end of the polyline to the other end, instead of from vertex to vertex.



Polyline starts and ends with a dash at each vertex. The linetype will not display on parts that are too small.

The linetype displays in a continuous pattern around the polyline vertices.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Polylines start and end with a dash at each vertex On (1): Linetype in a continuous pattern around the polyline vertices

20.78 PLINETYPE system variable

20.78.1 Polyline type

Controls how polylines are created with the PLINE command and if old-format polylines are converted.

It saves disk space and memory by using the optimized format.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2



Possible values:	0: Old-format polylines are not converted; PLINE creates old-format polylines 1: Old-format polylines are not converted; PLINE creates optimized polylines 2: Old-format polylines are converted; PLINE creates optimized polylines
------------------	---

20.79 PLINEWID system variable

20.79.1 Polyline width

The default width for new polyline.

Type:	Real
Saved in:	Drawing
Default value:	0.0

20.80 PLOTCFGPATH system variable

20.80.1 Plotter configuration path

The file path used for the Plotter configuration folders. Separate file paths with semicolons (;).

When printing a layout, the available paper size settings are controlled by a Plotter Configuration File. The Printer/Plotter Configuration list is composed of all printer drivers that are installed on your computer. The Printer Configuration are the files in the folder which is specified by the Plotter Configuration Path. If this is set to a large folder with many files and subfolders, then the entire folder and subfolders are searched for appropriate files. This might cause the print dialog to take a long time to open.

BricsCAD only

Type:	String
Saved in:	Preference

20.81 PLOTID system variable

20.81.1 Plot id (Obsolete)

Obsolete, has no effect except to preserve the integrity of old scripts and LISP routines.

Type:	String
Saved in:	Registry



20.82 PLOTOUTPUTPATH system variable

20.82.1 Plot output path

The default file path used for the creation of plot files.

BricsCAD only

Type:	String
Saved in:	Preference

20.83 PLOTSTYLEPATH system variable

20.83.1 Plot styles path

The file path used for the Plot styles folders.

Separate file paths with semicolons (;).

BricsCAD only

Type:	String
Saved in:	Preference

20.84 PLOTTER system variable

20.84.1 Plotter (Obsolete)

Has no effect except to preserve the integrity of older scripts and LISP routines.

Type:	Short
Saved in:	Registry

20.85 PLOTTRANSPARENCY OVERRIDE system variable

20.85.1 Plot transparency override

Controls if transparencies are enabled for print.

Type:	Short
Saved in:	Registry
Range:	0 to 2



Default value:	1
Possible values:	0: Transparencies are disabled 1: Value from page setup dialog is used 2: Transparencies are enabled

20.86 PLQUIET system variable

20.86.1 Plot quiet

Controls if optional dialog boxes and nonfatal errors display during batch plot or when a script is run.

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Display plot dialog boxes and nonfatal errors On (1): Log nonfatal errors and don't display plot-related dialog boxes

20.87 POINTCLOUD2DVSDISPLAY system variable

20.87.1 Toggle show/hide bounding box in 2d wireframe mode

Controls the display of a bounding box and warning message when the 2D Wireframe visual style is active and there are point clouds in the drawing. Point clouds are not displayed when the 2D Wireframe visual style is active.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Display a bounding box and warning message that point clouds are not displayed in 2D wireframe visual style 1: Do not display bounding box and warning message



20.88 POINTCLOUDADAPTIVEDISPLAY system variable

20.88.1 Toggle adaptive vs. fixed point sizes

Uses adaptive point sizes for point cloud display. If off, uses fixed point sizes.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Use fixed point sizes - all points have the same size 1: Use adaptive point sizes - point sizes are adjusted for a better visual appearance

20.89 POINTCLOUDBOUNDARY system variable

20.89.1 Show/hide point cloud extent boundary

Controls how the point cloud boundary is displayed.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Don't show 1: Show only when selected 2: Always show

20.90 POINTCLOUDCACHEFOLDER system variable

20.90.1 Disk cache folder

The file path(s) used to store point cloud cache files.

Multiple paths are supported. The first one will be used for adding new cached/preprocessed data.

Separate file paths with semicolons (;).



BricsCAD only

Type:	String Standard
Saved in:	Preference
Default value:	C:\Users\%username%\AppData\Roaming\Bricsys\BricsCAD\V25x64\en_US\PointCloudCache

20.91 POINTCLOUDEYEDOMELIGHTING system variable

20.91.1 Eye dome lighting strength

Eye dome lighting strength. If 0, eye dome lighting is disabled.

Values between 0 and 10 are accepted (default 1).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 10
Default value:	1

20.92 POINTCLOUDGAPFILLING system variable

20.92.1 Gap filling size

Gap between points to fill in pixels. If 0, gap filling is disabled.

Values between 0 and 10 are accepted (default 0).

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 10
Default value:	0



20.93 POINTCLOUDHSPC system variable

20.93.1 Point Cloud format (hspc/bcad)

Specifies the format used for processing point clouds (HSPC or BCAD).

Note: The HSPC file format (Hexagon Smart Point Cloud) is a proprietary format developed by Hexagon VCH (Visual Computing Hub). Using this format enables storing per point information which will be used to have more point cloud functionalities (in the future).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Use BCAD format. On (1): Use HSPC format.

20.94 POINTCLOUDIGNOREGEOTAGS system variable

20.94.1 Ignore geo tags in source data (deprecated!)

Ignores geo tags in source data. The setting is kept for v25 but has no effect.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't ignore geo tags in source data On (1): Ignore geo tags in source data

20.95 POINTCLOUDDOLLHOUSE system variable

20.95.1 Enable/disable dollhouse render mode

When true, the interior of the point cloud is visible because points with normal vector pointing away from the viewpoint are not shown.

BricsCAD only



Type:	Short
Saved in:	Registry
Default value:	0
Possible options:	0: Normal rendering: all points are shown 1: Dollhouse rendering: points with normal pointing away from the viewpoint are not shown

20.96 POINTCLOUDNORMALS system variable

20.96.1 Normal calculation

Calculates normals during point cloud preprocessing, used to identify planar (flat surfaces) such as walls and floors.

Note: Applies if the POINTCLOUDHSPC system variable is on (1).

When a point cloud is structured (in other words it has bubbles), the normal vectors will be computed automatically during preprocessing.

Structured point clouds already available in the cache in HSPC which have no normal vectors yet can be computed with the POINTCLOUDNORMALS command.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable normal calculation during HSPC preprocessing. On (1): Enable normal calculation during HSPC preprocessing.

20.97 POINTCLOUDPOINTMAX system variable

20.97.1 Maximum number of points displayed on screen

Maximum number of points displayed per point cloud. This is independent of the number of points present in the dataset.

Note: Values between 500,000 and 50,000,000 are accepted.

Type:	Short
-------	-------



Saved in:	Registry
Range:	500000 to 50000000
Default value:	10000000

20.98 POINTCLOUDPOINTSIZE system variable

20.98.1 Point size

Point cloud point display size, in pixels.

Values between 1 and 10 are accepted.

Type:	Short
Saved in:	Drawing
Range:	1 to 10
Default value:	2

20.99 POLARADDANG system variable


20.99.1 Polar add angles

Contains a list of custom polar snap angles, if the POLARMODE system variable is set to **Use additional polar tracking angles**.

Up to 10 angles, up to 25 characters each, separated with semicolons (;).

Requires POLARMODE flag 0x04 to be set (**Use additional polar tracking angles**). The AUNITS system variable sets the format for display of angles. Unlike POLARANG, POLARADDANG angles do not result in multiples of their values.

Type:	String
Saved in:	Registry



20.100 POLARANG system variable

20.100.1 Polar angle

Controls the polar angle increments, in degrees.

Type:	Real
Saved in:	Registry
Default value:	90.0
Unit	degrees

20.101 POLARDIST system variable

20.101.1 Polar distance

Controls the snap increment for polar snap (if the SNAPTYPE system variable is set to **Polar snap**).

Type:	Real
Saved in:	Registry
Default value:	0.0

20.102 POLARMODE system variable

20.102.1 Polar mode

Controls entity snap tracking and polar snap tracking.

Type:	Short
Saved in:	Registry



Range:	0 to 15
Default value:	1
Possible options:	1: Relative 2: Use polar tracking settings in entity snap tracking 4: Use additional polar tracking angles 8: Press SHIFT to acquire entity snap tracking points

20.103 POLYSIDES system variable

20.103.1 Polygon sides

The number of sides last used with the POLYGON command.

Type:	Short
Saved in:	Not saved
Range:	3 to 1024
Default value:	4

20.104 POPERATIONS COLOR system variable

20.104.1 Parametric operations color

Controls the color of the parametric operations' geometry.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	RGB:238,173,60

20.105 POPUPS system variable

20.105.1 Popups (Read Only)

Shows the status of the currently configured display driver.

Type:	Boolean
-------	---------



Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Don't support dialog boxes, the menu bar, and icon menus On (1): Support dialog boxes, the menu bar, and icon menus

20.106 PREVIEWDELAY system variable

20.106.1 Delay to preview selection

Controls the delay, before entities are highlighted on hover, in milliseconds.

Values between 0 and 1000 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1000
Default value:	30

20.107 PREVIEWEFFECT system variable

20.107.1 Selection preview effect

Controls how a selection preview is displayed (Not yet supported).

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Dashed lines 1: Thickened lines 2: Dashed and thickened lines



20.108 PREVIEWFILTER system variable

20.108.1 Selection filter

Controls the entity types that can not be selected.

Type:	Short
Saved in:	Registry
Range:	0 to 63
Default value:	1
Possible options:	1: Exclude entities on locked layers 2: Exclude entities in xrefs 4: Exclude tables 8: Exclude multiline text entities 16: Exclude hatch entities 32: Exclude entities in groups

20.109 PREVIEWTYPE system variable

20.109.1 Preview type

Controls which view is used for drawing preview thumbnails (Not yet supported).

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Last saved view 1: Home view

20.110 PREVIEWWNDINOPENDLG system variable

20.110.1 Preview window in open dialog

Shows a file preview in the Open dialog box. Can be set from the dialog (check box).

BricsCAD only



Type:	Boolean
Saved in:	Preference
Range:	On
Possible values:	Off (0): Don't display preview in the Open dialog box On (1): Display preview in the Open dialog box

20.111 PRINTFILE system variable

20.111.1 Print file

Alternate name for plot files.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	.

20.112 PRINTPDFPREVIEW system variable

20.112.1 Print As PDF Preview

Controls if the Print As PDF preview uses the system default PDF viewer or an internal program window.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	1
Possible values:	0: Use internal window 1: Use external viewer



20.113 PRODUCT system variable

20.113.1 Product (Read Only)

Displays the product name.

Type:	String
Saved in:	Not saved
Default value:	BricsCAD

20.114 PROFILEOFFSETBEHAVIOR system variable

20.114.1 Profile offset behavior

Controls the position of a solid or its axis, when the profile offset is changed.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Keep axis 1: Keep solid

20.115 PROGBAR system variable

20.115.1 Progress bar

Controls the display of the progress bar.

BricsCAD only

Type:	Boolean
Saved in:	Not saved
Default value:	On



Possible values:	Off (0): Don't show progress bar On (1): Show progress bar
------------------	---

20.116 PROGRAM system variable

20.116.1 Program (Read Only)

Displays the program name.

Type:	String
Saved in:	Not saved
Default value:	BRICSCAD

20.117 PROJECTIONTYPE system variable

20.117.1 Drawing view projection type


Switches between first and third angle projection types.

These angle projections are a way to represent 3D entities in 2D drawing views. These projection types will show the same views but the difference between the two types is the position of these views (top, right, left, bottom). See **Generated drawing views** to learn more about it.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: First angle projection type - Europe 1: Third angle projection type - United States, Canada, Australia



Projection	Symbol
First angle	
Third angle	



20.118 PROJECTLOCATIONVISIBILITY system variable

20.118.1 Project location marker visibility

Controls the visibility of the Project location marker.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	OFF (0): Does not display the Project location marker in the drawing ON (1): Displays the Project location marker in the drawing



20.119 PROJECTNAME system variable

20.119.1 Project name

The project name of the current drawing.

Project names help to keep track of Xrefs and images easier by assigning additional support paths specific to the project only.

Type:	String
Saved in:	Drawing

20.120 PROJECTSEARCHPATHS system variable

20.120.1 Project search paths

Stores a list of project names, each with a list of file paths to search.

If external references and images are not found in the saved path, the project search paths are used to find the external references and images.

Separate file paths with semicolons (;).

BricsCAD only

Type:	String
Saved in:	Preference

20.121 PROJMODE system variable

20.121.1 Projection mode

Controls the projection mode for the TRIM and EXTEND commands.

If the cutting entity is not in the same plane as the entity you want to TRIM/EXTEND, this system variable defines how the intersection is to be calculated.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1



Possible values:	0: True 3D mode (no projection) 1: Project to the XY plane of the current UCS 2: Project to the current view plane
------------------	--

20.122 PROMPTMENU system variable

20.122.1 Prompt menu

Controls the command prompt menu dialog.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 5
Default value:	0
Possible values:	0: Don't display prompt menu 1: Display prompt menu 2: Display prompt menu top-left 3: Display prompt menu top-right 4: Display prompt menu bottom-left 5: Display prompt menu bottom-right

20.123 PROMPTMENUFLAGS system variable

20.123.1 Prompt menu flags

Controls the behavior of the prompt menu.

See the PROMPTMENU system variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 7
Default value:	0



Possible options:	1: Show hidden options - hidden options display in italics 2: Hide prompt menu during selection 4: Disable selection options in the prompt menu
-------------------	---

20.124 PROMPTOPTIONFORMAT system variable

20.124.1 Prompt option format

Controls how command options are displayed in the Command line.

A command option has a keyword, a description and a shortcut. The shortcut is the keyword without lower case characters (a-z).

For example, the third option of the CIRCLE command:

Keyword = **TanTanRad**

Description = **Tangent-Tangent-Radius**

Shortcut = **TTR**

Note: The PROMPTOPTIONTRANSLATEKEYWORDS system variable controls whether translations of command option keywords are loaded or not. If disabled, the local keyword will be a copy of the global (English) keyword. As a result global shortcuts can be used without an underscore.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 4
Default value:	0
Possible values:	0: Show description, with shortcut in upper-case 1: Show keyword only 2: Show description and keyword in brackets 3: Show description and shortcut in brackets 4: Show local keyword and global keyword in brackets (non-English versions only)

Example for the CIRCLE command:

Show description only (0)

Select center of circle or [2 Point/3 Point/Tangent-Tangent-Radius/turn Arc into circle/Multiple circles]:

Note: This is the default prompt option format in the English version. In other versions the default prompt option format depends on local standards.



Show keyword only (1)

Select center of circle or [2Point/3Point/TanTanRad/Arc/Multiple]:

Show description and keyword in brackets (2)

Select center of circle or [2 Point(2Point)/3 Point(3Point)/Tangent-Tangent-Radius(TanTanRad)/Turn arc into circle(Arc)/Multiple circles(Multiple)]:

Show description and shortcut in brackets (3)

Select center of circle or [2 Point(2P)/3 Point(3P)/Tangent-Tangent-Radius(TTR)/Turn arc into circle(A)/Multiple circles(M)]:

Show local keyword and global keyword in brackets (relevant in localized versions only) (4)

Select center of circle or [2Point/3Point/TanTanRad/Arc/Multiple]:

20.125 PROMPTOPTIONTRANSLATEKEYWORDS system variable

20.125.1 Prompt option translate keywords

Loads translated command option keywords.

If disabled, English keywords are used and global shortcuts can be used without an underscore.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't load translations of keywords On (1): Load translations of keywords

20.126 PROPAGATESEARCHSPACE system variable

20.126.1 Search space

Asks for a search space during the BIMPROPAGATE command. Limits the locations and entity can be propagated to.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off



20.127 PROPAGATETOLERANCE system variable

20.127.1 Position tolerance

The position tolerance used for the BIMPROPAGATE command, in drawing units.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.00001

20.128 PROPERTYPREVIEW system variable

20.128.1 Property Preview

Shows property changes, on hover of combo box list values, in **Properties** panel, for selected entities.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Do not show property changes, on hover of combo box list values, in Properties panel, for selected entities On (1): Show property changes, on hover of combo box list values, in Properties panel, for selected entities

20.129 PROPERTYPREVIEWDELAY system variable

20.129.1 Property Preview Delay

Controls the delay before property changes show, on hover of combo box list values in **Properties** panel, in milliseconds. Applies if the PROPERTYPREVIEW system variable is on (1).

Values between 100 and 10000 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	100 to 10000



Default value:	500
----------------	-----

20.130 PROPERTYPREVIEWOBJLIMIT system variable

20.130.1 Property Preview Object Limit

Controls the maximum number of entities that can support hover properties. Values between 1 and 30,000 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 30000
Default value:	500

20.131 PROPOBJLIMIT system variable

20.131.1 Properties objects limit

Controls the limit of entities displayed in the **Properties** panel to improve performance.

Values between 0 and 100000 are accepted. A value of 0 turns off the limitation.

Type:	Long
Saved in:	Registry
Default value:	1000
Possible values:	0 to 100000

20.132 PROPPREVTIMEOUT system variable

20.132.1 Property Preview Timeout

Controls the delay before hover properties display, in seconds.

Values between 1 and 5 are accepted.

Type:	Short
-------	-------



Saved in:	Preference
Range:	1 to 5
Default value:	1

20.133 PROPUNITS system variable

20.133.1 Property units

Automatically formats length, area, volume, dimension and mass units, in panels and input boxes. For example, 2000mm will be displayed as 2m.

Applies if the INSUNITS system variable is active.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 255
Default value:	47
Possible values:	<ul style="list-style-type: none">1: Format length properties2: Format area properties4: Format volume properties8: (Reserved)16: Format dynamic dimensions32: Format mass properties

20.134 PROXYGRAPHICS system variable

20.134.1 Proxy graphics

Saves images of proxy entities to the drawing. If switched off, a bounding box displays instead.

Type:	Boolean
Saved in:	Drawing
Default value:	On



Possible values:	Off (0): Don't save images with the drawing On (1): Save images with the drawing
------------------	---

20.135 PROXYNOTICE system variable

20.135.1 Proxy notice

Displays a notice when you open a drawing containing custom entities created by an application that is not present.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display proxy warning On (1): Display proxy warning

20.136 PROXYSERVERENABLED system variable

20.136.1 Proxy server

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Don't use proxy server On (1): Use proxy server

20.137 PROXYSERVERHTTP system variable

20.137.1 HTTP server

The address of proxy server for HTTP protocol.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
-----------	----------

20.138 PROXYSERVERHTTPPORT system variable

20.138.1 HTTP server port

The port number of proxy server for HTTP protocol.

BricsCAD only

Type:	String
Saved in:	Registry

20.139 PROXYSERVERHTTPS system variable

20.139.1 HTTPS server

The address of proxy server for HTTPS protocol.

BricsCAD only

Type:	String
Saved in:	Registry

20.140 PROXYSERVERHTTPSPORT system variable

20.140.1 HTTPS server port

The port number of proxy server for HTTPS protocol.

BricsCAD only

Type:	String
Saved in:	Registry

20.141 PROXYSERVERPASSWORD system variable

20.141.1 User password

The user password to log in to proxy server.

BricsCAD only

Type:	String
-------	--------



Saved in:	User setting
-----------	--------------

20.142 PROXYSERVERUSER system variable

20.142.1 User name

The user name to log in to proxy server.

BricsCAD only

Type:	String
Saved in:	User setting

20.143 PROXYSHOW system variable

20.143.1 Proxy show

Controls how proxy entities display in a drawing.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Proxy entities are not displayed 1: Graphic images are displayed for all proxy entities 2: Only the bounding box is displayed for all proxy entities

20.144 PROXYWEBSEARCH system variable

20.144.1 Proxy web search

Toggles the check for entity enablers.

Type:	Short
Saved in:	Registry
Range:	0 to 1



Default value:	1
Possible values:	0: Does not check for entity enablers 1: Check for entity enablers if connected to the internet

20.145 PSLTSCALE system variable

20.145.1 Paper space linetype scale

Controls the linetype scaling in paper space. If **Viewport scaling governs linetype scaling** is active, the length of the dashes is based on paper space drawing units - linetypes display identically, in all viewports, even if scaled differently.

A REGEN is required.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: No special linetype scaling 1: Viewport scaling governs linetype scaling

20.146 PSOLHEIGHT system variable

20.146.1 Polysolid height

Controls the default height, in drawing units, for the POLYSOLID command.

Type:	Real
Saved in:	Drawing
Default value:	80.0

20.147 PSOLWIDTH system variable

20.147.1 Polysolid width

Controls the default width, in drawing units, for the POLYSOLID command.



Type:	Real
Saved in:	Drawing
Default value:	5.0

20.148 PSTYLEMODE system variable

20.148.1 Plot style mode (Read Only)

The plot style mode of the current drawing.

To convert the current drawing to use named or color-dependent plot styles, use CONVERTPSTYLES.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Named plot style tables 1: Color-dependent plot style tables

20.149 PSTYLEPOLICY system variable

20.149.1 Plot style policy

Controls if the color of an entity is associated with its plot style.

Note: If PSTYLEPOLICY is 0, the plot style for new entities is set to the default defined in DEFPLSTYLE and the plot style for new layers is set to the default defined in DEFLPLSTYLE.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: No association between color and plot style 1: Associate an entity's plot style with its color



20.150 PSVPSCALE system variable

20.150.1 Paper space viewport scale

Controls the scale multiplier for new viewports created with the VPORTS command.

Note: The view scale multiplier is defined by comparing the ratio of units in paper space to the units in newly created model space viewports.

The view scale multiplier you set is used with the VPORTS command. A value of 0 means the scale multiplier is Scaled to Fit.

Type:	Real
Saved in:	Drawing
Default value:	0.0

20.151 PUBLISHALLSHEETS system variable

20.151.1 Publish all sheets

Controls how layouts are loaded to the **Publish** dialog box.

If on, loads all layouts from all active drawings. If off, loads only the layouts from the current drawing.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Only the contents of the current document automatically load On (1): The contents of all open documents automatically load

20.152 PUBLISHCOLLATE system variable

20.152.1 Collate published sheets

Combines published sheets with equal output configurations into single multi-page plot job.

Type:	Boolean
Saved in:	Registry
Default value:	Off



Possible values:	Off (0): Process the sheet set in multiple steps (one sheet at a time) to generate a PLT file for each sheet. When plotting, the sheet plotting sequence can be interrupted by other plot jobs. On (1): Process the sheet set in one step to generate one multi-sheet PLT file. When plotting, the sheet plotting sequence cannot be interrupted by other plot jobs.
------------------	---

Note: A plot driver that supports the multi-sheet plotting or printing option is needed for publishing sheets in a single step.

20.153 PUCSBASE system variable

20.153.1 Paper space UCS base (Read Only)

The name of the UCS that controls the orthographic UCS in paper space.

Type:	String
Saved in:	Drawing



21. Q

21.1 QAFLAGS system variable

21.1.1 Quality Assurance flags

Internal system variable with flags for Quality Assurance and testing.

Note: This is subject to change, and not intended for regular use. Some of these options could have unpredictable or unwanted side-effects.

Type:	Short
Saved in:	Registry
Range:	0 to 32767
Default value:	0
Possible options:	<p>0: Red device: no low quality draw 2: No pause during text screen listings 4: No 'alert' dialogs (text display instead) 8: Have Warnings act as Errors and stop scripts 16: Minimal audit report 32: Disable window recreation on switch between 2d and rendered visual styles. 64: Enable various performance measurements printed as info prompts 128: Parallel vectorization: EnableSchedulerLogOutput 256: Cmd message enable 512: Dcl take screenshot 1024: Print time on statusbar 2048: No crash dump file 4096: Create assert log file 8192: Create RED files during rendering 16384: Parallel vectorization performance measurement</p>

Note: When bit 4096 is checked, it enables assertion logging in the BricsCAD Command line.

21.2 QTXTMODE system variable

21.2.1 Quick text mode

Controls how text entities are displayed.



- When On: this turns on quick text mode, rendering all text – text, mtext, attributes, dimension text, and so on—as rectangles.
- When Off (0): this turns off quick text mode, returning text to its normal display.



- This is useful when drawings contain much text, thereby slowing down the display of the drawing, but you still need to see the location of the text. The rectangles display the color of the text as well.

Note: To view changes on existing entities, perform a REGEN.

Type:	Boolean
Saved in:	Drawing
Range:	Off
Possible values:	Off (0): Don't display box in place of text On (1): Display box in place of text



21.3 QUADCOMMANDLAUNCH system variable

21.3.1 Quad default command launch

Controls how the first Quad command is activated.

The default quad command depends on which command from the quad is used last.

- When 0: hover over an entity to see the quad and click on the command button to launch the command.
- When 1: hover over an entity to see the quad and right-click on the entity to launch the command, instead of clicking on the command button first.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Do not launch the first Quad command on right-click 1: Launch the first Quad command on right-click when the Quad is displayed

21.4 QUADDISPLAY system variable

21.4.1 Quad display

Determines when to display the Quad.

BricsCAD only

Note: When the SELECTIONPREVIEW system variable is Off, the **Display the Quad when the cursor hovers over an entity** option of the QUADDISPLAY system variable is ignored, and the Quad is not displayed.

Type:	Short
Saved in:	Registry
Range:	-15 to 15
Default value:	5
Possible options:	negative: Switch off Quad 0: Do not display the Quad 1: Display the Quad when the cursor hovers over an entity 2: Display the Quad when entities are selected 4: Display the Quad on right click 8: Suppress the Quad on hover, when entities are selected

21.5 QUAEXPANDDELAY system variable

21.5.1 Quad expand delay

Controls the delay for the Quad to expand, after the cursor moves over the Quad, in milliseconds.



BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	160

21.6 QUADEXPANDTABDELAY system variable

21.6.1 Quad expand tab delay

Controls the delay for a Quad tab to expand, after the cursor moves over the Quad, in milliseconds.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	50

21.7 QUADGOTRANSPARENT system variable

21.7.1 Quad go transparent

Controls if the Quad goes transparent when the mouse moves away from it.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't go transparent On (1): Go transparent

21.8 QUADHIDEDELAY system variable

21.8.1 Quad hide delay

Controls the delay before the Quad hides, when the mouse is inactive, in milliseconds.

Applies to the zone set in the QUADHIDEMARGIN system variable.



BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	350

21.9 QUADHIDEMARGIN system variable

21.9.1 Quad hide margin

Controls the width of the active margin area around the Quad.

As long as the mouse keeps moving inside this margin, the Quad will stay visible. The Quad will still gradually go transparent if QUADGOTRSPARENT system variable is on.

As soon as the mouse movement stops, or when the mouse is moved beyond the margin, the quad will disappear.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	50

21.10 QUADICONSIZE system variable

21.10.1 Quad icon size

Controls the Quad icon size.

BricsCAD only

Type:	Short
Saved in:	Workspace
Default value:	1
Possible values:	0: Small icons 1: Large icons 2: Extra-large icons



System variable reference


Small Icons:



Large Icons:



Extra Large Icons:



21.11 QUADICONSPACE system variable

21.11.1 Quad icon space

Controls the spacing between icons.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Narrow 1: Normal 2: Wide

Narrow:



Normal:



Wide:



21.12 QUADMOSTRECENTITEMS system variable

21.12.1 Quad most recent items

Controls how many most recent items are displayed in the top bar of the Quad, remaining slots are filled by AI.

Values between 0 and 16 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 16
Default value:	4

21.13 QUADPOPUPCORNER system variable

21.13.1 Quad popup corner

Controls where the Quad will popup relative to the current cursor position.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1



Possible values:	0: Upper right 1: Middle right 2: Lower right
------------------	---

21.14 QUADSHOWDELAY system variable

21.14.1 Quad show delay

Controls the delay before the Quad shows, on hover, in milliseconds.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	150

21.15 QUADWIDTH system variable

21.15.1 Quad width

Controls the number of columns in the Quad.

Values between 4 and 16 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	4 to 16
Default value:	6



22. R

22.1 R12SAVEACCURACY system variable

22.1.1 R12 Save accuracy

Controls the number of segments between spline control segments or on 90 degrees elliptical arcs when saved to R12.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	8

22.2 R12SAVEDEVIATION system variable

22.2.1 R12 Save deviation

Controls the deviation for ellipses and splines when saved to R12.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.0

22.3 RASTERPREVIEW system variable

22.3.1 Raster preview

Controls if preview image is saved with the drawing.

This image is displayed by file managers and other programs.

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't create preview image On (1): Create preview image
------------------	---

22.4 RE_INIT system variable

22.4.1 Reinitialize Aliases (Read Only)

Reinitializes the digitizer, digitizer port and/or reloads PGP file (command aliases).

Type:	Short
Saved in:	Not saved
Range:	0 to 21
Default value:	0
Possible options:	1: Digitizer input/output port reinitialization 4: Digitizer reinitialization 16: PGP file reinitialization (reload)

22.5 REALTIMESPEEDUP system variable

22.5.1 Realtime speedup

Controls the number of mouse messages that are skipped during Pan operations.

Values between 0 and 10 are accepted.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 10
Default value:	5

22.6 REALWORLDSCALE system variable

22.6.1 Real world scale

Renders materials with units set to real-world scale.



Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't render real-world scale materials On (1): Render real-world scale materials

22.7 RECENTFILES system variable

22.7.1 Recent file list max count

Controls the maximum number of files shown in the **Recent Files** section in the File menu (MRU's) and the Start page.

Values between 0 and 60 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 60
Default value:	30

22.8 RECENTPATH system variable

22.8.1 Recent path

Most recently used file path.

BricsCAD only

Type:	String Standard
Saved in:	Preference

22.9 REDHILITE_DUCSLOCKED_FACE_ALPHA system variable

22.9.1 Face opacity

Controls the transparency of a selected face.



Values between 0 and 100 are accepted.

- A value of zero means fully transparent.
- A value of 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	25 to 100
Default value:	25

22.10 REDHILITE_DUCSLOCKED_FACE_COLOR system variable

22.10.1 Face color

Controls the highlight color of a Dynamic UCS locked face.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	#007AFF

22.11 REDHILITE_HIDDENEDGE_ALPHA system variable

22.11.1 Edge opacity

Controls the transparency hidden edges, when a whole entity is selected, if the REDHILITEFULL_EDGE_SHOWHIDDEN system variable is on (1).

Values between 0 and 100 are accepted.

- A value of zero means fully transparent.
- A value of 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference



Range:	0 to 100
Default value:	50

22.12 REDHILITE_HIDDENEDGE_COLOR system variable

22.12.1 Hidden edge color

Controls the color of hidden edges, when a whole entity is selected, if the REDHILITEFULL_EDGE_SHOWHIDDEN system variable is on (1).

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White (Settings dialog) #FFFFFF (Command line)

22.13 REDHILITEFULL_EDGE_ALPHA system variable

22.13.1 Edge opacity

Controls the transparency of an edge, when a whole entity is selected.

Values between 0 and 100 are accepted.

- A value of zero means fully transparent.
- A value of 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	100

22.14 REDHILITEFULL_EDGE_COLOR system variable

22.14.1 Edge color

Controls the color of an edge, when a whole entity is selected.



BricsCAD only

Type:	String
Saved in:	Preference
Default value:	0, 122, 255 (Settings dialog) #007AFF (Command line)

22.15 REDHILITEFULL_EDGE_SHOWHIDDEN system variable

22.15.1 Hidden edges

Displays hidden edges, when a whole entity is selected.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't show hidden edges On (1): Show hidden edges

22.16 REDHILITEFULL_EDGE_SMOOTHING system variable

22.16.1 Edge smoothing

Controls if smooth (anti-aliased) lines are shown, when a whole entity is selected.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Smooth edges off On (1): Smooth edges on



22.17 REDHILITEFULL_EDGE_THICKNESS system variable

22.17.1 Edge thickness

Controls the thickness of an edge, when a whole entity is selected.

Values between 0.0 and 20.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 20.0
Default value:	2.0

22.18 REDHILITEFULL_FACE_ALPHA system variable

22.18.1 Face transparency

Controls the transparency of a face when selected.

Values between 0 and 100 are accepted.

- A value of zero means fully transparent.
- A value of 100 means fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	10

22.19 REDHILITEFULL_FACE_COLOR system variable

22.19.1 Face color

Controls the color of a face, when a whole entity is selected.

BricsCAD only

Type:	String
-------	--------



Saved in:	Preference
Possible values:	0, 122, 255 (Settings dialog) #007AFF (Command line)

22.20 REDHILITEPARTIAL_SELECTEDEDGE_ALPHA system variable

22.20.1 Edge opacity

Controls the transparency of an edge, when selected.

Values between 0 and 100 are accepted.

- 0 is fully transparent.
- 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	100

22.21 REDHILITEPARTIAL_SELECTEDEDGE_COLOR system variable

22.21.1 Edge color

Controls the color of an edge, when selected.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	255, 128, 0 (Settings dialog) #FF8000 (Command line)

22.22 REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable

22.22.1 Glow

Toggles a glow effect on an edge, when selected.



BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show glow On (1): Show glow

22.23 REDHILITEPARTIAL_SELECTEDEDGE_SMOOTHING system variable

22.23.1 Edge smoothing

Displays smooth (anti-aliased) lines when, when selected.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Smooth edges off On (1): Smooth edges on

22.24 REDHILITEPARTIAL_SELECTEDEDGE_THICKNESS system variable

22.24.1 Edge thickness

Controls the thickness of an edge, when selected, in pixels.

Values between 0.0 and 20.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 20.0
Default value:	2.0



22.25 REDHILITEPARTIAL_SELECTEDEDGEGLOW_ALPHA system variable

22.25.1 Glow transparency

Controls the transparency of the glow. See also the REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable.

Values between 0 and 100 are accepted.

- A value of zero means fully transparent.
- A value of 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	75



22.26 REDHILITEPARTIAL_SELECTEDEDGEGLOW_COLOR system variable

22.26.1 Glow color

Controls the color of the glow effect on an edge, when selected. See also the REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	White (Settings dialog) #FFFFFF (Command line)



22.27 REDHILITEPARTIAL_SELECTEDEDGEGLOW_SMOOTHING system variable

22.27.1 Glow smoothing

Displays smooth (anti-aliased) lines for the glow effect on an edge, when selected. See also the REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Smooth glow lines off On (1): Smooth glow lines on



22.28 REDHILITEPARTIAL_SELECTEDEDGEGLOW_THICKNESS system variable



22.28.1 Glow thickness

Controls the thickness of the glow effect on an edge, when selected, in pixels. See also the REDHILITEPARTIAL_SELECTEDEDGE_SHOWGLOW system variable.

Values between 0.0 and 20.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Preference
Range:	0.0 to 20.0
Default value:	3.0





22.29 REDHILITEPARTIAL_SELECTEDFACE_ALPHA system variable

22.29.1 Face opacity

Controls the transparency of a face, when selected.

Values between 0 and 100 are accepted.

- A value of zero means fully transparent.
- A value of 100 is fully opaque.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 100
Default value:	10

22.30 REDHILITEPARTIAL_SELECTEDFACE_COLOR system variable

22.30.1 Face color

Controls the color of a face, when selected.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	#007AFF

22.31 REDHILITEPARTIAL_UNSELECTEDEDGE_SHOWHIDDEN system variable

22.31.1 Hidden edges

Controls if hidden edges are be displayed on selection.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



Possible values:	Off (0): Don't show hidden edges On (1): Show hidden edges
------------------	---

22.32 REDSDKLINESMOOTHING system variable

22.32.1 Line smoothing

Enables line smoothing for 3D rendering modes.

Note: It has no effect if anti-aliasing is on.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Line smoothing off On (1): Line smoothing on

22.33 REDUCELENGTHTYPE system variable

22.33.1 Reduce Length Type

Sets default flow fitting reduce length type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

22.34 REDUCELENGTHVALUE system variable

22.34.1 Reduce Length Value

Sets default flow fitting reduce length value.

BricsCAD only



Type:	Real
Saved in:	Drawing
Range:	0.0 to 1e6
Default value:	0.5

22.35 REFEDITLOCKNOTINWORKSET system variable

22.35.1 Refedit lock

Locks entities that are not in the XRef, when in Reference Edit mode (REFEDIT).

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Do not lock entities not in the chosen XRef On (1): Lock entities not in the chosen XRef

22.36 REFEDITNAME system variable

22.36.1 Refedit name (Read Only)

The name of the XRef currently being edited.

Type:	String
Saved in:	Not saved

22.37 REFPATHTYPE system variable

22.37.1 Default path type of reference files

Controls if reference files are attached using full, relative or no paths, when they are attached for the first time.

Type:	Short
-------	-------



Saved in:	Registry
Default value:	1
	0: No path 1: Relative path 2: Full path

Note: Reference files that are already attached are not affected.

22.38 REGENMODE system variable

22.38.1 Regeneration mode

Toggles automatic regeneration on/off. See also the REGENAUTO command.

BricsCAD will regenerate the display automatically when REGENMODE is On, but in a few cases a forced regeneration of the drawing might be necessary. This is done by the REGEN command.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Turn off REGENAUTO command On (1): Turn on REGENAUTO command

22.39 REGEXPAND system variable

22.39.1 Registry paths expanding type

Controls the types of paths stored to a registry (absolute or expandable).

Note: A re-start is required.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't store paths in a portable format using environment variables On (1): Store paths in a portable format using environment variables
------------------	---

22.40 REMEMBERFOLDERS system variable

22.40.1 Remember folders

The file path used for the standard file selection dialog boxes.

- When 0: When you start the program by double-clicking a shortcut icon, if a Start In path is specified for the icon, that path is used as the default for all standard file selection dialog boxes.
- When 1: The default path in each standard file selection dialog box is the last path used in that dialog box. The Start In folder specified for the shortcut icon is not used.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Start in path - see the DRAWINGPATH and BLOCKSPATH system variables 1: Use most recent path

22.41 RENDERCOMPOSITIONMATERIAL system variable

22.41.1 Render Composition Material

Renders the materials of compositions and their plies.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0-1 (On-Off)
Default value:	0
Possible values:	0: Do not render the materials of compositions and their plies 1: Render the materials of compositions and their plies



Note: The RENDERCOMPOSITIONMATERIAL system variable is only available for **BIM** and **Ultimate** license levels.

22.42 RENDERMATERIALDOWNLOAD system variable

22.42.1 Download missing resources for render materials

Automatically downloads missing render materials resources.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't download missing resources for render materials On (1): Download missing resources for render materials

22.43 RENDERMATERIALSPATH system variable

22.43.1 Render materials directory path

The file path(s) for user created render material files.

Separate file paths with semicolons (;).

BricsCAD only

Type:	String
Saved in:	Registry

22.44 RENDERUSINGHARDWARE system variable

22.44.1 Render using hardware

Controls if hardware is used to render. Switch this off if there are problems caused by the graphics card or driver.

A restart may be required.

BricsCAD only

Type:	Short
Saved in:	Preference



Range:	0 to 3
Default value:	1
Possible values:	0: Use software only (slower) 1: Prefer hardware (faster) 2: Prefer software (only for testing purposes) 3: Use hardware only (only for testing purposes)

22.45 REPORTPANELMODE system variable

22.45.1 Report panel mode

Controls the look of the **Report** panel.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	2
Possible values:	0: Classic - Report Panel has a classic appearance as a dockable window 1: Modern - Report Panel is a transparent window 2: Hidden - Report panel is a transparent window hidden in the Status bar

22.46 RESTORECONNECTIONS system variable

22.46.1 Restore Connections

Restores structural connections after commands.

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	Off (0): Don't Restore Connections On (1): Restore Connections



22.47 RESTORELOSTFOCUS system variable

22.47.1 Restore lost focus (Linux)

Controls lost focus recovery. Dependent on the window manager, focus may be lost by when short-lived windows like Quad and rollover tips are used.

Type:	Boolean
Saved in:	Registry
Possible values:	Off (0): Do not try to recover from focus loss On (1): Attempt automatic recovery from focus loss

22.48 RETAINEDGRAPHICS system variable

22.48.1 Retained Graphics

Toggles the use of retained graphics.

Retained graphics can improve the performance of certain operations, for example, rotating and panning the camera.

Type:	Boolean
Saved in:	Preference
Default value:	1
Possible values:	Off (0): Don't use retained graphics On (1): Use retained graphics

22.49 REVCLoudArcStyle system variable


22.49.1 Revision cloud default arc style

Controls the default arc style for revision clouds.


Type:	Short
Saved in:	Registry
Default value:	0



Possible values:	0: Normal 1: Calligraphy
------------------	-----------------------------



Normal




Calligraphy

22.50 REVCLoudCreateMode system variable


22.50.1 Revision cloud creation mode

Controls the default revision cloud creation mode.


Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1
Possible values:	0: Freehand 1: Rectangular 2: Polygonal



Freehand



Rectangular



Polygonal



22.51 REVCLOUDGRIPS system variable

22.51.1 Revision cloud grips

Uses custom grips for revision clouds.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Displays grips on every arc segment On (1): Displays only the most relevant grips

22.52 REVCLODMAXARCLENGTH system variable

22.52.1 Revision cloud default maximum arc length

Controls the default maximum arc length for revision clouds. The maximum arc length is multiplied by the value of the DIMSCALE system variable.

Type:	Real
Saved in:	Registry
Default value:	0.375

22.53 REVCLODMINARCLENGTH system variable

22.53.1 Revision cloud default minimum arc length

Controls the default minimum arc length for revision clouds. The minimum arc length is multiplied by the value of the DIMSCALE system variable.

Type:	Real
Saved in:	Registry
Default value:	0.375



22.54 RHINOVERSION system variable

22.54.1 Rhino Export version

The 3DM version used to export to Rhino.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 60
Default value:	0
Possible values:	0: Last available 2: Rhino 2 3: Rhino 3 4: Rhino 4 50: Rhino 5 60: Rhino 6

22.55 RIBBONDOCKEDHEIGHT system variable

22.55.1 Ribbon docked height

Controls the height of the Ribbon.

Values between 0 and 500 are accepted. Values lower than the current Ribbon content will be disregarded.

A value of 0 means Automatic height.

Note: Values below 124 are effective only in certain circumstances.

Type:	Short
Saved in:	Registry
Range:	0 to 500
Default value:	0

22.56 RIBBONPANELMARGIN system variable

22.56.1 Panel margin

The size, in pixels, of the blank space at the Ribbon panel edges.



BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 50
Default value:	8

22.57 RIBBONSETTINGSENABLED system variable

22.57.1 Ribbon interface settings control on/off

Toggles the display of the Interface Settings control in the ribbon on/off.

Note: A restart may be required.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	0: Do not display the Interface Settings control in the ribbon 1: Display the Interface Settings control in the ribbon

22.58 RIBBONSTATE system variable

22.58.1 Ribbon state (Read Only)

Indicates if the Ribbon is on.

The ribbon can be closed with the RIBBONCLOSE command and can be displayed with the RIBBON command.

Type:	Boolean
Saved in:	Registry
Default value:	Off



Possible values:	Off (0): Don't show ribbon bar On (1): Show ribbon bar
------------------	---

22.59 ROAMABLEROOTPREFIX system variable

22.59.1 Roamable root prefix (Read Only)

The path of the root folder where roamable files for the current user such as menus and plotstyles, were installed.

Type:	String Standard
Saved in:	Registry

22.60 ROLLOVEROPACITY system variable

22.60.1 Rollover opacity

Controls the opacity of the Quad.

Values between 10 and 100 are accepted.

- A value of 10 means maximum transparency.
- A value of 100 means full opacity.

Type:	Short
Saved in:	Registry
Range:	10 to 100
Default value:	100

22.61 ROLLOVERPARAMS system variable

22.61.1 Rollover parameters

Show block parameters in the rollover tips.

Type:	Boolean
Saved in:	Registry
Default value:	On



Possible values:	Off (0): Don't show block parameters On (1): Show block parameters
------------------	---

22.62 ROLLOVERSELECTIONSET system variable

22.62.1 Rollover selection set

Controls the behavior of properties in the rollover tips, when mixed entities are selected. Setting the value to **Properties shared by all selected entities** decreases performance on large selections.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	2
Possible values:	0: No properties 1: General properties 2: Properties shared by all selected entities

22.63 ROLLOVERTIPS system variable

22.63.1 Rollover tips

Toggles the display of entity properties in the Quad, on hover.

Note: When the SELECTIONPREVIEW system variable is Off, the ROLLOVERTIPS system variable is ignored, and entity properties are not displayed when you hover the cursor over entities.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show properties on hover On (1): Show properties on hover



22.64 RTDISPLAY system variable

22.64.1 Realtime display

Controls how raster images and OLE entities display during ZOOM or PAN action.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Display raster images and OLE content 1: Display outlines only

22.65 RTISOLATESELECTION system variable

22.65.1 Realtime selection isolation

Controls if the active selection is automatically isolated during realtime rotation.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Disable automatic isolation of active selection during realtime rotation On (1): Enable automatic isolation of active selection during realtime rotation

22.66 RTROTATIONSPEEDFACTOR system variable

22.66.1 Realtime Rotation Speed Factor

Controls the rotation speed for the Look and Walk tools (RTLOOK and RTWALK commands).

Values between 0.01 and 100.00 are accepted.

BricsCAD only

Type:	Real
-------	------



Saved in:	Preference
Range:	0.01 to 100.
Default value:	1

22.67 RUBBERBANDCOLOR system variable

22.67.1 Rubber band color

Controls the color of the rubber band line, used for temporary snap tracking.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	40

22.68 RUBBERBANDSTYLE system variable

22.68.1 Rubber band dashed style

Enables a dashed linestyle for the rubber band line, used for temporary snap tracking.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Dashed style off On (1): Dashed style on

22.69 RUBBERSHEET (for OS X) system variable

22.69.1 Rubbersheet Touchpad

Enable simultaneous zoom/rotate/pan with dual finger movements on the touchpad.



Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Dual finger touch simultaneously zooms/rotates/pans off On (1): Dual finger touch simultaneously zooms/rotates/pans on

22.70 RUBBERSHEETSENSIBILITY (FOR OS X) system variable

22.70.1 Rubbersheet gesture activation sensibility

Controls the sensitivity of gestures.

Values of 0 to 10 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 10
Default value:	5

22.71 RULERDISPLAY system variable

22.71.1 Ruler display

Shows a ruler during Manipulator operations.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Do not display ruler On (1): Display ruler



22.72 RULERTEXTCOLOR system variable

22.72.1 Ruler Text Color

Controls the text color of the Manipulator ruler.

Applies only if the RULERDISPLAY system variable is on (1).

Type:	String
Saved in:	Preference
Default value:	#c8c8c8
Possible values:	RGB color code Hex color code Index color code

A new value for the variable can be entered in the Command line.

22.73 RUNASLEVEL system variable

22.73.1 Run as license level

Runs the program in a different (lower) level than the licensed level. If the licensed level is lower than RUNASLEVEL, RUNASLEVEL is ignored.

Note: A restart is required.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 5
Default value:	5
Possible values:	0: Lite 1: Pro 2: (Obsolete) 3: BIM 4: Mechanical 5: Ultimate



22.74 RVTRFALEVELOFDETAIL system variable

22.74.1 Level of detail

Controls the level of detail (LOD) for RVT and RFA import.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	1 to 3
Default value:	3
Possible values:	1: Coarse 2: Medium 3: Fine

22.75 RVTVALIDATEBREP system variable

22.75.1 Validate BREP geometry

Validate BREP geometry during an RVT import.

Warning: Disabling this may import more geometry without no check on integrity.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	0: Off (Disable) 1: ON (Enable)



23. S

23.1 SAFEMODE system variable

23.1.1 Safe mode (Read Only)

Indicates if executable code can be loaded and executed in the current session. Starting in a clean environment can help to eliminate potential causes of a crash.

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Allows executable code run On (1): Does not allow executable code to run

23.2 SAVECHANGETOLAYOUT system variable

23.2.1 Save changes to layout

Saves changes to a layout from the **Print** dialog box.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Range:	0 to 1
Default value:	On
Possible values:	Off (0): Don't save changes to layout On (1): Save changes to layout

23.3 SAVEFIDELITY system variable

23.3.1 Save fidelity

Controls if this drawing is saved with visual fidelity.

Type:	Boolean
-------	---------



Saved in:	Registry
Range:	0 to 1
Default value:	On
Possible values:	Off (0): Don't save with visual fidelity On (1): Save with visual fidelity

23.4 SAVEFILE system variable

23.4.1 Save file name (Read Only)

The current automatic save file name.

Type:	String
Saved in:	Not saved

23.5 SAVEFILEPATH system variable

23.5.1 Save file path

The file path where automatic saves and temporary files are stored.

Type:	String Standard
Saved in:	Registry

23.6 SAVEFORMAT system variable

23.6.1 Save format

Controls the default save format.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 39
Default value:	1



Possible values:	1: DWG 2018 2: DXF 2018 3: Binary DXF 2018 4: DWG 2013 5: DXF 2013 6: Binary DXF 2013 7: DWG 2010 8: DXF 2010 9: Binary DXF 2010 10: DWG 2007 11: DXF 2007 12: Binary DXF 2007 13: DWG 2004 14: DXF 2004 15: Binary DXF 2004 16: DWG 2000 17: DXF 2000 18: Binary DXF 2000 19: DWG R14 20: DXF R14 21: Binary DXF R14 22: DWG R13 23: DXF R13 24: Binary DXF R13 25: DWG R11/R12 26: DXF R11/R12 27: Binary DXF R11/R12 28: DXF R10 29: Binary DXF R10 30: DXF R9
------------------	--

23.7 SAVELAYERSAPSHOT system variable

23.7.1 Save Layer Snapshot with view

Saves the current layer settings and uses them for new views.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



23.8 SAVENAME system variable

23.8.1 Saved drawing name (Read Only)

The file name and folder path of the current drawing.

Type:	String
Saved in:	Not saved

23.9 SAVEONDOCSWITCH system variable

23.9.1 Save on document switch

Saves the drawing automatically when another drawing tab is activated.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't save on doc switch On (1): Save on doc switch

23.10 SAVEROUNDTRIP system variable

23.10.1 Save roundtrip

Allows information, in a database file, not supported in the drawing to be saved.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On

23.11 SAVETIME system variable

23.11.1 Save time interval

Controls the interval for automatic saves, in minutes.



Values between 0 and 240 are accepted. If set to zero, automatic saves are turned off.

Type:	Short
Saved in:	Registry
Range:	0 to 240
Default value:	60
Possible values:	0: Turn off automatic saving 1 - 240: Saves the drawing at intervals specified (in minutes)

23.12 SCREENBOXES system variable

23.12.1 Screen menu boxes (Read Only)

Contains the number of boxes displayed in the screen menu. If the screen menu is turned off, the value is zero.

Type:	Short
Saved in:	Not saved

23.13 SCREENMODE system variable

23.13.1 Screen mode (Read Only)

Stores the graphic/text state of the program display.

Type:	Short
Saved in:	Not saved
Range:	0 to 3
Possible values:	0: Text screen is displayed 1: Drawing area is displayed 2: Dual-screen display is configured



23.14 SCREENSIZE system variable

23.14.1 Screen size (Read Only)

The size of the current viewport, in pixels (width x height).

Type:	2D point
Saved in:	Not saved

23.15 SCRLHIST system variable

23.15.1 Scroll history

Controls the number of lines stored in the history of the Command line.

Values between 0 and 256 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 or greater
Default value:	256

23.16 SDI system variable

23.16.1 Single-document interface (Windows)

Controls if a drawing is opened in a new application instance or an existing instance. Partially implemented: SDI variable controls double-click behavior for drawings, but it is still possible to open multiple documents in each application instance.

Note: SDI setting 2 and 3 are not saved. If SDI is set to 3, the program switches it back to 1 when the application that doesn't support multiple drawings is unloaded.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0



Possible values:	0: Multiple-drawing interface 1: Single-drawing interface 2: (Read-only) Multiple-drawing interface is disabled because an application has been loaded that does not support multiple drawings 3: (Read-only) Multiple-drawing interface is disabled because the user has set SDI to 1 and the program has loaded an application that does not support multiple drawings. (SDI was set to 1 before the application was loaded)
------------------	---

23.17 SECTIONRESULTINTERVAL system variable

23.17.1 Section result interval

The distance between generated section blocks in model space.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	400.0

Note:

- If INSUNITS=inches (1), the default value of SECTIONRESULTINTERVAL is 400.0.
- If INSUNITS=millimeters (4), the default value of SECTIONRESULTINTERVAL is 10000.0.
- If INSUNITS=centimeters (5), the default value of SECTIONRESULTINTERVAL is 1000.0.
- If INSUNITS=meters (6), the default value of SECTIONRESULTINTERVAL is 10.0.

23.18 SECTIONSCALE system variable

23.18.1 Section scale

The default scale used to generate sections.

Values between 0.000001 and 1000000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.02



23.19 SECTIONSETTINGSSEARCHPATH system variable

23.19.1 Section settings search path

The file path for BIM section styles, BIM tag styles and drawing customizations.

Separate paths with semicolons (:).

BricsCAD only

Type:	String Standard
Saved in:	Registry

23.20 SECTIONSHEETSETTEMPLATEIMPERIAL system variable

23.20.1 Section sheet set template imperial

The file path for the Sheet Set file (DST) used as template for a new section. Applies only when MEASUREMENT system variable is 0 (imperial).

The default file is BIM-section-imperial.dst, which can be found in the {SheetSetTemplatePath} folder.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	BIM-section-imperial.dst

Note: The SECTIONSHEETSETTEMPLATEIMPERIAL system variable is only available for **BIM** and **Ultimate** license levels.

23.21 SECTIONSHEETSETTEMPLATEMETRIC system variable

23.21.1 Section sheet set template metric

The file path for Sheet Set file (dst), used as template for a new section. Applies only when the MEASUREMENT system variable is 1 (metric).

The default file is BIM-section-metric.dst, which can be found in the {SheetSetTemplatePath} folder.

BricsCAD only

Type:	String
Saved in:	Registry



Default value:	BIM-section-metric.dst
----------------	------------------------

Note: The SECTIONSHEETSETTEMPLATEMETRIC system variable is only available for **BIM** and **Ultimate** license levels.

23.22 SECURELOAD system variable

23.22.1 Executable file security policy (Read Only)

The security policy used to load executable files.

Type:	Short
Saved in:	Not saved
Range:	0 to 2
Default value:	0
Possible values:	0: No security policy 1: Warn if loading from untrusted location 2: Load only from trusted locations

23.23 SELECTIONANNODISPLAY system variable

23.23.1 Show all annotation scales on selection

Displays an annotated entity, in all scales, on selection.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable annotation scales display On (1): Enable annotation scales display

23.24 SELECTIONAREA system variable

23.24.1 Selection area

Controls the display of selection area effects.



Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show selection area effects On (1): Show selection area effects

23.25 SELECTIONAREAOPACITY system variable

23.25.1 Selection area opacity

Controls the transparency of the selection area. Applies only when SELECTIONAREA setting is on.

Values between 0 and 100 are accepted.

- A value of zero means Fully Transparent.
- A value of 100 means fully opaque.

Type:	Short
Saved in:	Registry
Range:	0 to 100
Default value:	25

23.26 SELECTIONCYCLING system variable

23.26.1 Selection cycling

Controls the display options associated with overlapping objects and selection cycling.

Note: When the SELECTIONPREVIEW system variable is Off, the SELECTIONCYCLING system variable is ignored, and no badge or selection dialog box is displayed when you hover over entities.

Type:	Short
Saved in:	Registry
Range:	-2 to 2
Default value:	2



Possible options:	-2: Selection cycling is turned off, but the setting is stored (toggled value 2) -1: Selection cycling is turned off, but the setting is stored (toggled value 1) 0: The display options are turned off 1: A badge displays when you hover over objects that overlap 2: Both a badge and the Selection dialog box displays
-------------------	--

Note: Use the keyboard shortcut **Ctrl + W** to toggle on/off the current setting of the SELECTIONCYCLING system variable.

23.27 SELECTIONMODES system variable

23.27.1 Selection modes

Controls what is selected by default: whole entities, subentities or boundaries.

Use the TAB key, on hover, to cycle through the options.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 15
Default value:	0
Possible options:	1: Select edges 2: Select faces 4: Select detected boundaries 8: Select vertices

23.28 SELECTIONPREVIEW system variable

23.28.1 Selection preview display

Controls the rules used to highlight entities when the pickbox cursor hovers over an entity.

Note: When the SELECTIONPREVIEW system variable is Off:

- the **Display the Quad when the cursor hovers over an entity** option of the QUADDISPLAY system variable is ignored and the Quad is not displayed,
- the ROLLOVERTIPS system variable is ignored and entity properties are not displayed (the Quad is not displayed),



- the SELECTIONCYCLING system variable is ignored and no badge or selection dialog box is displayed (the Quad is not displayed).

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	3
Possible options:	0: Do not display selection preview. 1: When no commands are active 2: When a command prompts for entity selection

23.29 SELECTSIMILARMODE system variable

23.29.1 Match options for SELECTSIMILAR

Controls which properties must match for the SELECTSIMILAR command. For this command to operate as intended, at least one property must be turned on. When all properties are turned off, this command selects only the entity(ies) you pick at the **Select entities** prompt.

Type:	Short
Saved in:	Registry
Range:	0 to 255
Default value:	130
Possible options:	0: Entity type 1: Color 2: Layer 4: Linetype 8: Linetype scale 16: Lineweight 32: Plot style 64: Entity style 128: Name



23.30 SETBYLAYERMODE system variable

23.30.1 Set by layer mode

Controls which layer properties are applied with the SETBYLAYER command.

Type:	Short
Saved in:	Registry
Range:	0 to 255
Default value:	255
Possible values:	0: None 1: Color 2: Linetype 4: Lineweight 8: Material 16: Plot style 32: ByBlock 64: Blocks 128: Transparency

23.31 SHADEDGE system variable

23.31.1 Shading edges

Controls how faces and edges display in rendered views.

Type:	Short
Saved in:	Drawing
Range:	0 to 3
Default value:	3
Possible values:	0: Faces shaded, edges not highlighted 1: Faces shaded, edges drawn in background color 2: Faces not filled, edges in entity color 3: Faces in entity color, edges in background color



23.32 SHADEDIF system variable

23.32.1 Shading diffusion

Controls the ratio of diffuse reflective light to ambient light as a percentage of diffuse reflective light when the SHADEDGE system variable is set to 0 or 1.

Type:	Short
Saved in:	Drawing
Range:	0 to 100
Default value:	70

23.33 SHEETNUMBERLEADINGZEROES system variable

23.33.1 Sheet number leading zeroes

Controls the number of zeros that prefix new sheet 'Number' values.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 8
Default value:	1
Possible values:	1: 1 (1, 2, 3, ...) 2: 2 (01, 02, 03, ...) 3: 3 (001, 002, 003, ...) 4: 4 (0001, 0002, 0003, ...) 5: 5 (00001, 00002, 00003, ...) 6: 6 (000001, 000002, 000003, ...) 7: 7 (0000001, 0000002, 0000003, ...) 8: 8 (00000001, 00000002, 00000003, ...)

23.34 SHEETSETAUTOBACKUP system variable

23.34.1 Sheet set automatic backup

Creates a backup file when a Sheet Set file is opened.

The backup files must have the same name as the Sheet Set file but with a 'ds\$' extension.



BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't create backup files On (1): Create backup files

23.35 SHEETSETTEMPLATEPATH system variable

23.35.1 Sheet Set template path

The file path for the Sheet Set Templates folder.

The default path is: `\Users\%username%\AppData\Local\Bricsys\BricsCAD\V25x64\en_US\Templates`.

Type:	String
Saved in:	Preference

23.36 SHORTCUTMENU system variable

23.36.1 Shortcut menus

Controls the status of the DEFAULT, EDIT and COMMAND (right-click) context menus.

Type:	Short
Saved in:	Registry
Range:	0 to 63
Default value:	19



Possible options:	0: Disable all Default, Edit, and Command mode shortcut menus 1: Enable Default mode shortcut menus 2: Enable Edit mode shortcut menus 4: Enable Command mode shortcut menus (available whenever a command is active) 8: Enable Command mode shortcut menus only when command options are currently available from the Command line 16: Enable a shortcut menu when the right mouse is held down 32: Repeat command with short right click when entities are selected and Quad is not shown
-------------------	---

23.37 SHORTCUTMENUDURATION system variable

23.37.1 Shortcut menu duration

Controls the delay between right-click and the appearance of the (right-click) context menu, in milliseconds.

Values between 100 and 10,000 are accepted.

Type:	Long
Saved in:	Registry
Range:	100 to 10000
Default value:	250

23.38 SHOWDOCTABS system variable

23.38.1 Tabs visibility

Toggles tabs on/off, in the documents tab.

You can make the drawing area larger by hiding the document tabs from the user interface.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't make tabs visible On (1): Make tabs visible



23.39 SHOWFULLPATHINTITLE system variable

23.39.1 Display full path in title

Displays the full path of a drawing in the title bar. If off, displays only the file name.

Type:	Boolean
Saved in:	Preference
Default value:	Off

23.40 SHOWIDS.getPropertiesOnly system variable

23.40.1 Show IDS Properties Only

When an IDS-XML file has been imported, this setting controls whether only the properties required by the IDS should be shown in the **Properties** panel, or all properties should be shown.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Show all properties On (1): Show only the properties required by the IDS

23.41 SHOWLAYERUSAGE system variable

23.41.1 Layer Usage

Shows information about layer usage in the **Layers** panel.

In the column **Current**, the **Layer Usage** icons indicate when viewport settings for the current layout and paper space viewport are different from model space settings:



: Current layer with viewport overrides.



: Layer with viewport overrides.



: Empty layer with viewport overrides.



Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Do not display Layer Usage On (1): Display Layer Usage

23.42 SHOWSCROLLBUTTONS system variable

23.42.1 Scroll buttons (Mac & Linux)

Displays left and right scroll buttons.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show scroll buttons On (1): Show scroll buttons

23.43 SHOWTABCLOSEBUTTON system variable

23.43.1 Close button on tabs (Mac & Linux)

Toggles the close button on the tab bars on/off, in the documents tab.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't show close button on tabs On (1): Show close button on tabs



23.44 SHOWTABCLOSEBUTTONACTIVE system variable

23.44.1 Close button on active tab (Mac & Linux)

Toggles the close button on the active tab only on/off, in the documents tab.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Don't show close button on the active tab only On (1): Show close button on the active tab only

23.45 SHOWTABCLOSEBUTTONALL system variable

23.45.1 Close button on all tabs (Mac & Linux)

Toggles the close button on all tabs on/off, in the documents tab.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Don't show close button on all tabs On (1): Show close button on all tabs

23.46 SHOWWINDOWLISTBUTTON system variable

23.46.1 Window list button (Mac & Linux)

Shows a drop-down list of windows.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On



Possible values:	Off (0): Don't show window list button On (1): Show window list button
------------------	---

23.47 SHPNAME system variable

23.47.1 Shape name

The default shape name according to naming conventions.

! means no default.

Note: Shapes are an early version of blocks that were efficient, but difficult to code. Shapes are rarely used anymore.

Type:	String
Saved in:	Not saved

23.48 SIGWARN system variable

23.48.1 Signature warning

Controls the Signature dialog behavior, when a drawing with a signature is opened.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Displayed only if the drawing has an invalid signature On (1): Displayed if a drawing has a signature

23.49 SINGLETONMODE system variable

23.49.1 Singleton mode

Switch to control whether one or more instances of BricsCAD can run simultaneously.

- When set to Off, you can launch two or more copies of BricsCAD at the same time.
- When set to On, only a single instance of BricsCAD can run.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Preference
Default value:	Off
Possible values:	Off (0): Singleton mode off On (1): Singleton mode on

23.50 SITELOCATIONVISIBILITY system variable

23.50.1 Site location marker visibility

Controls the visibility of the Site location marker.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	1
Possible values:	OFF (0): Does not display the Site location marker in the drawing ON (1): Displays the Site location marker in the drawing

23.51 SKETCHFEATURECOPYMODE system variable

23.51.1 Sketch feature copy mode

Controls how sketch features will be copied.

If ON, copies of sketch features will be independent of their source (new blocks of the sketches/paths/guide curves/etc. will be created).

BricsCAD only

Type:	Boolean
Saved in:	Registry
Range:	0 to 1
Default value:	1



Possible values:	0: Copies of sketch features share their sketches (paths, guide curves, etc.) with their source. 1: Copies of sketch features have new sketches (paths, guide curves, etc.). The copies do not have a link to their source.
------------------	--

23.52 SKETCHINC system variable

23.52.1 Sketch increment

The length of segments created with the SKETCH command, in drawings units.


Type:	Real
Saved in:	Drawing
Default value:	1.0

23.53 SKPOLY system variable

23.53.1 Sketch poly

Controls the entity type created with the SKETCH command.

Type:	Boolean
Saved in:	Drawing
Default value:	0
Possible values:	Off (0): Generate lines On (1): Generate polylines





23.54 SKYSTATUS system variable

23.54.1 Sky status

Controls if sky illumination is computed at render time (Not yet supported).

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: No sky 1: Sky background 2: Sky background and illumination

23.55 SMASSEMBLYEXPORTMODE system variable

23.55.1 SmAssemblyExport mode

Controls how data is exported by the SMASSEMBLYEXPORT command.

BricsCAD only

Type:	Short
Saved in:	Registry
Possible values:	0: Do not change external components 1: Keep recognized features on sheet metal/poor sheet metal parts

23.56 SMASSEMBLYEXPORTREPORTPATHTYPE system variable

23.56.1 Report file path type

Controls whether absolute or relative file paths are used in the reports generated by the SMASSEMBLYEXPORT command.

BricsCAD only

Type:	Short
Saved in:	Drawing



Range:	0 to 1
Default value:	0
Possible values:	0: Relative paths 1: Absolute paths

23.57 SMASSEMBLYEXPORTSOLIDTYPESINREPORTS system variable

23.57.1 Solid types in reports

Controls the types of solids present in command reports for the SMASSEMBLYEXPORT command. Sheet metal and poor sheet metal solids are always present in reports.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 15
Default value:	1
Possible values:	1: Non sheet metal solids 2: Standard part component solids 4: Recognize hollow linear extruded solids and treat them as non-sheet metal 8: Recognize circular tube linear extruded solids and treat them as non-sheet metal

23.58 SMATTRIBUTESLAYERCOLOR system variable

23.58.1 Color of the attributes layer

Controls the color of the 'Attributes' layer, created by the SMUNFOLD and SMEEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255



Default value:	7
----------------	---

23.59 SMATTRIBUTESLAYERTEXTHEIGHT system variable

23.59.1 Height of the text

Controls the text height of the 'Attributes' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.01

23.60 SMATTRIBUTESLAYERTEXTHEIGHTTYPE system variable

23.60.1 Type of the text height

Controls the text height type for the 'Attributes' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Bounding box ratio 1: Absolute value

23.61 SMBENDANNOTATIONSLAYERCOLOR system variable

23.61.1 Color of the bend annotations text layer

Controls the color of the 'Bend Annotations' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	5

23.62 SMBENDANNOTATIONSLAYERTEXTHEIGHT system variable

23.62.1 Height of the text

Controls the text height of the 'Bend Annotations' layer, created by the SMUNFOLD and SMEEXPORT2D commands.

BricsCAD only

Type:	Real
Saved in:	Registry
Default value:	0.01

23.63 SMBENDANNOTATIONSLAYERTEXTHEIGHTTYPE system variable

23.63.1 Type of the text height

Controls the text height type for the 'Bend Annotations' layer, created by the SMUNFOLD and SMEEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	0
Possible values:	0: Bounding box ratio 1: Absolute value



23.64 SMBENDLINESDOWNLAYERCOLOR system variable

23.64.1 Color of the bend down lines layer

Controls the color of the 'Bends Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	1

23.65 SMBENDLINESDOWNLAYERLINETYPE system variable

23.65.1 Linetype of the bend down lines layer

Controls the linetype of the 'Bends Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

23.66 SMBENDLINESDOWNLAYERLINEWEIGHT system variable

23.66.1 Lineweight of the bend down layer

Controls the linewidth of the 'Bends Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.

Values between -3 and 211 are accepted.

- 1=ByLayer
- 2=ByBlock
- 3=Default

BricsCAD only

Type:	Short
Saved in:	Registry



Range:	-3 to 211
Default value:	-3

23.67 SMBENDLINESUPPLAYERCOLOR system variable

23.67.1 Color of the bend up lines layer

Controls the line color of the 'Bends Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	1

23.68 SMBENDLINESUPPLAYERLINETYPE system variable

23.68.1 Linetype of the bend up lines layer

Controls the linetype of the 'Bends Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

23.69 SMBENDLINESUPPLAYERLINEWEIGHT system variable

23.69.1 Lineweight of the bend up layer

Controls the linewidth of the 'Bends Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.

Values between -3 and 211 are accepted.

- -1=ByLayer
- -2=ByBlock
- -3=Default

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

23.70 SMBEVELFEATURECOLOR system variable

23.70.1 Color of the bevel features layer

Controls the color of the 'Bevel Features' layer, created by the SMUNFOLD and SMEEXPORT2D commands.
BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	6

23.71 SMCOLORBEND system variable

23.71.1 Bend feature color

Controls the display color of sheet metal bends.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#FFDC50

23.72 SMCOLORBENDRELIEF system variable

23.72.1 Bend relief feature color

Controls the display color of sheet metal reliefs.

BricsCAD only



Type:	String
Saved in:	Registry
Default value:	#64D296

23.73 SMCOLORBEVEL system variable

23.73.1 Bevel feature color

Controls the display color of sheet metal bevels.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#C0CE93

23.74 SMCOLORCORNERRELIEF system variable

23.74.1 Corner relief feature color

Controls the display color of sheet metal corner reliefs.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#64D296

23.75 SMCOLORFLANGE system variable

23.75.1 Flange feature color

Controls the display color of sheet metal flanges.

BricsCAD only

Type:	String
Saved in:	Registry



Default value:	#90A4AE
----------------	---------

23.76 SMCOLORFLANGEREFERENCESIDE system variable

23.76.1 Flange feature reference side color

Controls the display color of sheet metal faces on the reference side of a flange.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#68A4AE

23.77 SMCOLORFORM system variable

23.77.1 Form feature color

Controls the display color of sheet metal forms.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#8791E1

23.78 SMCOLORHEM system variable

23.78.1 Hem feature color

Controls the display color of sheet metal hems.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#FCAED6



23.79 SMCOLORJOG system variable

23.79.1 Jog feature color

Controls the display color of sheet metal jogs.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#CC7722

23.80 SMCOLORJUNCTION system variable

23.80.1 Junction feature color

Controls the display color of sheet metal junctions.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#FF6E40

23.81 SMCOLORLOFTEDBEND system variable

23.81.1 Lofted bend feature color

Controls the display color of sheet metal lofted bends.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#A0DCFA

23.82 SMCOLORMITER system variable

23.82.1 Miter feature color

Controls the display color of sheet metal miters.



BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#AF46D8

23.83 SMCOLORROLLEDEDGE system variable

23.83.1 Rolled edge feature color

Controls the display color of sheet metal rolled edges.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#8791E1

23.84 SMCOLORTAB system variable

23.84.1 Tab feature color

Controls the display color of sheet metal tabs.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#FDA542

23.85 SMCOLORWRONGBEND system variable

23.85.1 Wrong bend feature color

Controls the display color of sheet metal wrong bends.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
Default value:	#FF3300

23.86 SMCOLORWRONGFLANGE system variable

23.86.1 Wrong flange feature color

Controls the display color of sheet metal wrong flanges.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	#A82000

23.87 SMCONTOURSLAYERCOLOR system variable

23.87.1 Color of the contour layer

Controls the color of the '2D dxf layer', contains unfolded geometry created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	7

23.88 SMCONTOURSLAYERLINETYPE system variable

23.88.1 Linetype of the contour layer

Controls the linetype of the 'Contour' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	String
-------	--------



Saved in:	Registry
Default value:	CONTINUOUS

23.89 SMCONTOURSLAYERLINEWEIGHT system variable

23.89.1 Lineweight of the contour layer

Controls the line weight of the 'Contour' layer, created by the SMUNFOLD and SMEXPORT2D commands.

Values between -3 and 211 are accepted.

- 1=ByLayer
- 2=ByBlock
- 3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	30

23.90 SMCONVERTMAXIMALBEVELANGLE system variable

23.90.1 Maximal angle of bevel

Controls the maximal angle of bevel during the SMCONVERT command.

Values between 0.0 and 90.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 90
Default value:	80



23.91 SMCONVERTMINIMALBEVELANGLE system variable

23.91.1 Minimal angle of bevel

Controls the minimal angle of a bevel during the SMCONVERT command.

Values between 0.0 and 90.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 90
Default value:	10

23.92 SMCONVERTPREFERFORMFEATURES system variable

23.92.1 Prefer form features to flanges and bends

Controls how features are recognized on solid faces, for the SMCONVERT command, single form features or bends and flanges.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	0: Off 1: On

23.93 SMCONVERTPREFERHEMFEATURES system variable

23.93.1 Prefer hem features to flanges and bends

Controls how features are recognized on solid faces, for the SMCONVERT command, single hem features or bends and flanges.

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Drawing
Default value:	On
Possible values:	0: Off 1: On

23.94 SMCONVERTPREFERJOGFEATURES system variable

23.94.1 Prefer jog features to flanges and bends

Controls how features are recognized on solid faces, during the SMCONVERT command, single jog features or bends and flanges.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off

23.95 SMCONVERTPREFERZEROBENDFEATURES system variable

23.95.1 Prefer zero bend features to wrong bends

Controls how features are recognized on solid faces, during the SMCONVERT command, zero bend features or wrong bend features.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	0: Off 1: On

23.96 SMCONVERTRECOGNIZEBEVELS system variable

23.96.1 Recognize bevel features

Recognizes bevel features during the SMCONVERT command.



BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On

23.97 SMCONVERTRECOGNIZEHOLES system variable

23.97.1 Recognize holes

Recognizes holes on flanges as features during the SMCONVERT command.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	0: Off 1: On

23.98 SMCONVERTRECOGNIZERIBCONTROLCURVES system variable

23.98.1 Recognize bead control curves

Recognizes 2D control curves for bead features, during the SMCONVERT command.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	0: Off 1: On



23.99 SMCONVERTWRONGFEATURETHICKNESSDEVIATIONTYPE system variable

23.99.1 Type of deviation of wrong feature thickness

Controls if the deviation value is treated as ratio to model thickness or an absolute value. See the SMCONVERTWRONGFEATURETHICKNESSDEVIATIONVALUE command.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.100 SMCONVERTWRONGFEATURETHICKNESSDEVIATIONVALUE system variable

23.100.1 Deviation value of wrong feature thickness

Sets the allowed deviation between model thickness and the thickness of a given wrong feature.

Values between 0 and 1,000,000 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 1e6
Default value:	0.2

23.101 SMDEFAULTBENDLINEEXTENTTYPE system variable

23.101.1 Bend line extent type

Controls if the SMDEFAULTBENDLINEEXTENTVALUE system variable is a ratio to the thickness or an absolute value.

The value will be used to initialize sheet metal settings in the document.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Drawing
Default value:	0
Possible values:	1: Thickness ratio 2: Absolute value

23.102 SMDEFAULTBENDLINEEXTENTVALUE system variable

23.102.1 Bend line extent value

Controls sheet metal bend lines.

Values between -1,000,000 and 1,000,000.0 are accepted.

- Positive value = Stretches past a contour
- Negative value = Does not reach it
- Zero = Just touches

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	-1000000 to 1000000
Default value:	0.25

23.103 SMDEFAULTBENDRADIUSTYPE system variable

23.103.1 Bend radius type

Controls the default sheet metal bend radius.

Absolute value toggles the Thickness ratio. **Override bend radius in SMCONVERT** controls if the bend radius is taken from SMDEFAULTBENDRADIUSVALUE or from the model.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 3



Default value:	2
Possible values:	1: Absolute value 2: Override bend radius in SMCONVERT

23.104 SMDEFAULTBENDRADIUSVALUE system variable

23.104.1 Bend radius value

Controls the default sheet metal bend radius, in drawing units. See also the SMDEFAULTBENDRADIUSTYPE system variable.

Values between 0.0001 and 1,000,000 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1

23.105 SMDEFAULTBENDRELIEFWIDTHTYPE system variable

23.105.1 Bend relief type

Controls if the SMDEFAULTBENDRELIEFWIDTHVALUE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.106 SMDEFAULTBENDRELIEFWIDTHVALUE system variable

23.106.1 Bend relief width value

Controls the default value for a sheet metal bend relief width.



Values between 0.0 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.5

23.107 SMDEFAULTBEVELFEATUREUNFOLDMODE system variable

23.107.1 Bevel unfolding mode

Controls the appearance of bevels in an unfolded part.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	2
Possible values:	0: Keep 1: Remove 2: Annotate

23.108 SMDEFAULTCORNERRELIEFDIAMETERVALUE system variable

23.108.1 Corner relief diameter value

Controls the default diameter for a sheet metal corner relief.

Values between -1.0 and 1,000,000.0 are accepted. Set to -1.0 for automatic determination of least feasible for given corner relief.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	-1.0



23.109 SMDEFAULTFLANGESPLITEXTENSIONTYPE system variable

23.109.1 Miter extension type

Controls if the SMDEFAULTFLANGESPLITEXTENSIONVALUE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.110 SMDEFAULTFLANGESPLITEXTENSIONVALUE system variable

23.110.1 Miter extension value

Controls the default value for a sheet metal miter extension.

Values between 0.0 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1

23.111 SMDEFAULTFLANGESPLITGAPTYPE system variable

23.111.1 Miter gap type

Controls if the SMDEFAULTFLANGESPLITGAPVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing



Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.112 SMDEFAULTFLANGESPLITGAPVALUE system variable

23.112.1 Miter gap value

Controls the default value for sheet metal miter gap size.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1

23.113 SMDEFAULTFORMFEATUREUNFOLDMODE system variable

23.113.1 Form feature unfolding mode

Controls the appearance of form features in an unfolded part.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	4
Possible values:	0: Keep 1: Remove 2: Project 3: Contour 4: Symbol 5: Project without center mark 6: Contour without center mark



23.114 SMDEFAULTGUSSETDEPTHTYPE system variable

23.114.1 Gusset depth type

Controls if the SMDEFAULTGUSSETDEPTHVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.115 SMDEFAULTGUSSETDEPTHVALUE system variable

23.115.1 Gusset height value

Controls the default sheet metal gusset height.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	8

23.116 SMDEFAULTGUSSETFILLETRADIUSTYPE system variable

23.116.1 Gusset fillet radius type

Controls if the SMDEFAULTGUSSETFILLETRADIUSVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.117 SMDEFAULTGUSSETFILLETRADIUSVALUE system variable

23.117.1 Gusset fillet radius value

Controls the default sheet metal gusset radius.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1

23.118 SMDEFAULTGUSSETTYPE system variable

23.118.1 Gusset type

Toggles between a round or flat sheet metal gusset type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	1 to 2
Default value:	1
Possible values:	1: Round 2: Flat



23.119 SMDEFAULTGUSSETWIDTHTYPE system variable

23.119.1 Gusset width type

Controls if the SMDEFAULTGUSSETWIDTHVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.120 SMDEFAULTGUSSETWIDTHVALUE system variable

23.120.1 Gusset width value

Controls the default sheet metal gusset width.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	6

23.121 SMDEFAULTHEMGAPTYPE system variable

23.121.1 Open Hem gap type

Controls if the SMDEFAULTHEMGAPVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only



Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.122 SMDEFAULTHEMGAPVALUE system variable

23.122.1 Open Hem gap value (in addition to the thickness)

Controls the default sheet metal open hem gap size.

Values between 0.001 and 100.0 are accepted.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0.1

23.123 SMDEFAULTHEMRELATIVEBENDDEDUCTION system variable

23.123.1 Hem relative bend deduction value

Sets a bend deduction value, relative to the thickness, used for closed hem unfolding.

Values between 0.0 (hem lengthen) and 10.0 (shorten bend zone by a value equal to 8 times the thickness) are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 10
Default value:	2.4



23.124 SMDEFAULTJOGANGLEVALUE system variable

23.124.1 Jog angle value

Controls the default sheet metal jog angle.

Values between 0.0 and 180.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 180
Default value:	45
Possible values:	0: Bounding box ratio 1: Absolute value

23.125 SMDEFAULTJOGHEIGHTTYPE system variable

23.125.1 Jog height type

Controls if the SMDEFAULTJOGHEIGHTVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.126 SMDEFAULTJOGHEIGHTVALUE system variable

23.126.1 Jog height value

Controls the default sheet metal jog height.

Values between 0.0001 and 1,000,000.0 are accepted.



BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0.0001 to 1,000,000.0
Default value:	1.001

23.127 SMDEFAULTJOGRADIUSTYPE system variable

23.127.1 Jog radius type

Controls if the SMDEFAULTJOGRADIUSVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.128 SMDEFAULTJOGRADIUSVALUE system variable

23.128.1 Jog radius value

Controls the default sheet metal jog radius.

Values between 1.0 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	1.0 to 1,000,000.0



Default value:	1.0
----------------	-----

23.129 SMDEFAULTJUNCTIONALIGNMENTTORELIEF system variable

23.129.1 Junction alignment to relief

Forces sheet metal junction faces to align to adjacent relief faces.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Disabled 1: Enabled

23.130 SMDEFAULTJUNCTIONGAPTYPE system variable

23.130.1 Junction gap type

Controls if the SMDEFAULTJUNCTIONGAPVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.131 SMDEFAULTJUNCTIONGAPVALUE system variable

23.131.1 Junction gap value

Controls the default sheet metal for the open junction gap size.



Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.001

23.132 SMDEFAULTKFACTOR system variable

23.132.1 K-Factor value

Sets the location ratio of the neutral surface (the surface not stretched or squeezed when the sheet is bent) to the material thickness.

Values between 0.00000 (internal bend radius) and 1.00000 (external bend radius) are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Range:	0 to 1
Default value:	0.27324

23.133 SMDEFAULTLOFTEDBENDNUMBERSAMPLES system variable

23.133.1 Lofted bend subdivisions

Controls the default value for sheet metal lofted bend subdivisions.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	10



23.134 SMDEFAULTRELIEFEXTENSIONTYPE system variable

23.134.1 Relief extension type

Controls if the SMDEFAULTRELIEFEXTENSIONTYPE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.135 SMDEFAULTRELIEFEXTENSIONVALUE system variable

23.135.1 Relief extension value

Controls the default value for a sheet metal relief extension.

Values between 0.0 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1

23.136 SMDEFAULTTRIBILLETRADIUSTYPE system variable

23.136.1 Bead fillet radius type

Controls if the SMDEFAULTTRIBILLETRADIUSVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing



Default value:	0
Possible values:	0: Profile radius ratio 1: Absolute value

23.137 SMDEFALTRIBFILLETRADIUSVALUE system variable

23.137.1 Bead fillet radius value

Controls the default radius for a sheet metal bead fillet.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	5

23.138 SMDEFALTRIBPROFILERADIUSTYPE system variable

23.138.1 Bead profile radius type

Controls if the SMDEFALTRIBPROFILERADIUSVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.139 SMDEFALTRIBPROFILERADIUSVALUE system variable

23.139.1 Bead profile radius value

Controls the default radius for a sheet metal bead profile.

Values between -1.0 and 1,000,000.0 are accepted.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	2

23.140 SMDEFALTRIBROUNDRAJUDTYPE system variable

23.140.1 Bead round radius type

Controls if the SMDEFALTRIBROUNDRAJUSVALUE system variable is a ratio to the thickness or an absolute value.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.141 SMDEFALTRIBROUNDRAJUSVALUE system variable

23.141.1 Bead round radius value

Controls the default radius for a sheet metal bead, round.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1

23.142 SMDEFAULTSHARPBENDRAJUSLIMITRATIO system variable

23.142.1 Sharp bend radius limit ratio

Controls the default sheet metal sharp bend radius limit, as a ratio to the thickness.

Values between 0.0 and 1,000,000.0 are accepted



BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	5

23.143 SMDEFAULTTABCHAMFERDISTANCETYPE system variable

23.143.1 Tab chamfer distance type

Controls if the SMDEFAULTTABCHAMFERDISTANCEVALUE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.144 SMDEFAULTTABCHAMFERDISTANCEVALUE system variable

23.144.1 Tab chamfer distance value

Controls the default chamfer distance of sheet metal tabs.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1



23.145 SMDEFAULTTABCLEARANCETYPE system variable

23.145.1 Tab clearance type

Controls if the SMDEFAULTTABCLEARANCEVALUE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.146 SMDEFAULTTABCLEARANCEVALUE system variable

23.146.1 Tab clearance value

Controls the default clearance of sheet metal tabs.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1

23.147 SMDEFAULTTABDISTANCETYPE system variable

23.147.1 Tab distance type

Controls if the SMDEFAULTTABDISTANCEVALUE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1



Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.148 SMDEFAULTTABDISTANCEVALUE system variable

23.148.1 Tab distance value

Controls the default distance of sheet metal tabs.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	20

23.149 SMDEFAULTTABEDGE TYPE system variable

23.149.1 Tab edge type

Controls if sheet metal tabs have sharp, round or chamfered edges.

BricsCAD only

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Sharp edges 1: Fillet edges 2: Chamfer edges



23.150 SMDEFAULTTABFILLETRADIUSTYPE system variable

23.150.1 Tab fillet radius type

Controls if the SMDEFAULTTABFILLETRADIUSVALUE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.151 SMDEFAULTTABFILLETRADIUSVALUE system variable

23.151.1 Tab fillet radius value

Controls the default fillet radius of sheet metal tabs.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.1

23.152 SMDEFAULTTABHEIGHTTYPE system variable

23.152.1 Tab height type

Controls if the SMDEFAULTTABHEIGHTVALUE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1



Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.153 SMDEFAULTTABHEIGHTVALUE system variable

23.153.1 Tab height value

Controls the default height of sheet metal tab slots.

Values between 0.0001 and 1,000,000.0 are accepted.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	1

23.154 SMDEFAULTTABLENGTHTYPE system variable

23.154.1 Tab length type

Controls if the SMDEFAULTTABLENGTHTYPE system variable is a ratio to the thickness or an absolute value.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	0: Thickness ratio 1: Absolute value

23.155 SMDEFAULTTABLENGTHVALUE system variable

23.155.1 Tab length value

Controls the default length of sheet metal tabs.

Values between 0.0001 and 1,000,000.0 are accepted.



BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	4

23.156 SMDEFAULTTABSLOTNUMBER system variable

23.156.1 Tab slot number

Controls the default number of sheet metal tab slots.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	2

23.157 SMDEFAULTTHICKNESS system variable

23.157.1 Thickness value

Controls the default sheet metal thickness, in drawing units.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	2.0 for INSUNITS=4 0.07874 for INSUNITS=1

23.158 SMEXPORTOSMAPPROXIMATIONACCURACY system variable

23.158.1 Accuracy of the approximation

Controls absolute deviation between the smooth edge geometry of 3D part and its .osm representation with lines and arcs, during the SMEXPORTOSM command, in drawing units. The lower the value, the better the precision.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	0.01 - If MEASUREMENT=1 and INSUNITS=4 0.000393701 - If MEASUREMENT=0 and INSUNITS=1

23.159 SMEXPORTOSMMINIMALEDGELENGTH system variable

23.159.1 Minimal edge length

Controls the minimal edge length for the SMEXPORTOSM command, in drawing units.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.05 - If MEASUREMENT=1 and INSUNITS=4 0.001968505 - If MEASUREMENT=0 and INSUNITS=1

23.160 SMFORMFEATURESDOWNCOLOR system variable

23.160.1 Color of the form features down layer

Controls the color of the 'Form Features Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	6

23.161 SMFORMFEATURESDOWNLAYERLINETYPE system variable

23.161.1 Linetype of the form features down layer

Controls the linetype of the 'Form Features Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.



BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

23.162 SMFORMFEATURESDOWNLAYERLINEWEIGHT system variable

23.162.1 Lineweight of the form features down layer

Controls the lineweight of the 'Form Features Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.

Values between -3 and 211 are accepted.

- 1=ByLayer
- 2=ByBlock
- 3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

23.163 SMFORMFEATURESUPCOLOR system variable

23.163.1 Color of the form features up layer

Controls the color of the 'Form Features Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255



Default value:	6
----------------	---

23.164 SMFORMFEATURESUPAYERLINETYPE system variable

23.164.1 Linetype of the form features up layer

Controls the linetype of the 'Form Features Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

23.165 SMFORMFEATURESUPAYERLINEWEIGHT system variable

23.165.1 Lineweight of the form features up layer

Controls the linewidth of the 'Form Features Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.

Values between -3 and 211 are accepted.

- 1=ByLayer
- 2=ByBlock
- 3=Default

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

23.166 SMHEMCREATECLOSEDHEMGAP system variable

23.166.1 Closed Hem, Teardrop, and Round gap value

Controls the bend radius of a Closed hem and the gap between the base Flange and a Teardrop or Round hem, for the SMHEM command.



BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0.02

23.167 SMJUNCTIONCREATEHEALCOINCIDENT system variable

23.167.1 Heal coincident junction faces

Controls how junctions with coincident faces are recognized and converted to regular junctions, during the SMJUNCTIONCREATE command.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off

23.168 SMOOTHMESHCONVERT system variable

23.168.1 Mesh conversion mode

Controls the conversion mode of meshes to 3D solids or surfaces, with the CONVTOSOLID or CONVTOSURFACE commands.

Type:	Short
Saved in:	Not saved
Range:	1 to 3
Default value:	2
Possible values:	1: Conversion result is smooth and not optimized 2: Conversion result is faceted and optimized 3: Conversion result is faceted and not optimized



23.169 SMOVERALLANNOTATIONSAYERCOLOR system variable

23.169.1 Color of the overall dimensions annotations layer

Controls the color of the 'Overall Dimensions' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	3

23.170 SMOVERALLANNOTATIONSAYERLINETYPE system variable

23.170.1 Linetype of the overall annotation layer

Controls the linetype of the 'Overall Dimensions' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	CONTINUOUS

23.171 SMOVERALLANNOTATIONSAYERLINEWEIGHT system variable

23.171.1 Lineweight of the overall annotation layer

Controls the linewidth of the 'Overall Dimensions' layer, created by the SMUNFOLD and SMEXPORT2D commands.

Values between -3 and 211 are accepted.

- 1=ByLayer
- 2=ByBlock
- 3=Default

BricsCAD only



Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

23.172 SMPARAMETRIZEHOLESPARAMETRIZATION system variable

23.172.1 Hole parametrization

Controls how straight holes are converted, during the SMPARAMETRIZE command.

If **Convert holes to array** is on, holes on flanges are converted into parametric, rectangular arrays. If **Parametrize holes** is on, holes, not already included in arrays, are constrained.

BricsCAD only

Type:	Short
Saved in:	Drawing
	0 to 3
Default value:	3
Possible values:	0: Does not parametrize holes 1: Parametrize holes 2: Convert holes to array

23.173 SMREPAIRLOFTEDBENDMERGE system variable

23.173.1 Merge lofted bends

Merges lofted bends that touch into a single lofted bend, during the SMREPAIR command.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off



23.174 SMROLLEDGEANNOTATIONSLAYERCOLOR system variable

23.174.1 Color of the rolled edge annotations text layer

Controls the color of the 'Rolled Edge Annotations' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	5

23.175 SMROLLEDGEANNOTATIONSLAYERTEXTHEIGHT system variable

23.175.1 Height of the text

Controls the text height of the 'Rolled Edge Annotations' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Real
Saved in:	Registry
Possible values:	0 or greater
Default value:	0.01

23.176 SMROLLEDGEANNOTATIONSLAYERTEXTHEIGHTTYPE system variable

23.176.1 Type of the text height

Controls the text height type for the 'Rolled Edge Annotations' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry



Range:	0 to 1
Default value:	0
Possible values:	0: Bounding box ratio 1: Absolute value

23.177 SMROLLEDGEDLINESDOWNLAYERCOLOR system variable

23.177.1 Color of the rolled edge down lines layer

Controls the color of the 'Rolled Edge Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	1

23.178 SMROLLEDGEDLINESDOWNLAYERLINETYPE system variable

23.178.1 Linetype of the rolled edge down lines layer

Controls the linetype of the 'Rolled Edge Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	Continuous

23.179 SMROLLEDGEDLINESDOWNLAYERLINEWEIGHT system variable

23.179.1 Lineweight of the rolled edge down layer

Controls the linewidth of the 'Rolled Edge Down' layer, created by the SMUNFOLD and SMEXPORT2D commands.



Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

23.180 SMROLLEDGELINESUPLAYERCOLOR system variable

23.180.1 Color of the rolled edge up lines layer

Controls the color of the 'Rolled Edge Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.
BricsCAD only

Type:	Short
Saved in:	Registry
Range:	1 to 255
Default value:	1

23.181 SMROLLEDGELINESUPLAYERLINETYPE system variable

23.181.1 Linetype of the rolled edge up lines layer

Controls the linetype of the 'Rolled Edge Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.
BricsCAD only

Type:	String
Saved in:	Registry
Default value:	Continuous

23.182 SMROLLEDGELINESUPLAYERLINEWEIGHT system variable

23.182.1 Lineweight of the rolled edge up layer

Controls the linewidth of the 'Rolled Edge Up' layer, created by the SMUNFOLD and SMEXPORT2D commands.



Type:	Short
Saved in:	Registry
Range:	-3 to 211
Default value:	-3

23.183 SMSMARTFEATURES system variable

23.183.1 Automatic update features after sheet metal commands

Controls how sheet metal features are rebuilt after sheet metal commands.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	3
Possible options:	<ul style="list-style-type: none">1: Allow the rebuild of sheet metal features2: Allow automatic edges to imprint after rebuild4: Allow the automatic creation of junctions after bends are created

23.184 SMSPLITAMBIGUOUSINPUT system variable

23.184.1 Ambiguous input behavior

Controls how the SMSPLIT command resolves issues when it can not detect a face, entity, point or 2D curve that it relates to.

BricsCAD only

Type:	Short
Saved in:	Drawing
	0 to 1
Default value:	0



Possible values:	0: Prompt user 1: Command fail
------------------	-----------------------------------

23.185 SMSPLITCONVERTBENDTOJUNCTION system variable

23.185.1 Convert bend to junction

Controls how a split that passes through a bend is solved with the SMSPLIT command.

If on, the shortest side of the bend is automatically converted to a junction. If off, a split through a bend will retain the bend geometry on both sides of the split.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	On

23.186 SMSPLITHEALCOINCIDENT system variable

23.186.1 Heal coincident miter faces

Enables the **Heal coincident miter faces** option for the SMSPLIT command.

BricsCAD only

Type:	Boolean
Saved in:	Drawing
Default value:	Off

23.187 SMSPLITORTHOGONALBENDSPLIT system variable

23.187.1 Orthogonal bend split

Controls how a split that touches a bend is solved with the SMSPLIT command.

If on, the split direction for a bend is orthogonal to the bend axis (changes to a 90° angle as it passes through the bend). If off, the split direction is tangential to the split curve (does not change direction as it passes through the bend).

BricsCAD only

Type:	Boolean
-------	---------



Saved in:	Drawing
Default value:	Off

23.188 SMTARGETCAM system variable

23.188.1 Target CAM

Controls the target CAM system, for sheet metal parts unfolded with SMUNFOLD command.

BricsCAD only

Type:	String
Saved in:	Registry

23.189 SMUNFOLDAPEARANCE system variable

23.189.1 Unfold appearance

Controls the text height for the SMUNFOLD command.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	1: Text height for annotations is managed by current text, dimension and mleader styles

23.190 SNAPANG system variable

23.190.1 Snap angle

Controls the rotation of snap, the grid, and the crosshair, for the current viewport, relative to the current UCS.

Type:	Real
Saved in:	Drawing
Default value:	0.0



23.191 SNAPBASE system variable

23.191.1 Snap base

Controls the origin point of snap and the grid, in the current viewport, relative to the current UCS.

Type:	2D point
Saved in:	Drawing
Default value:	0,0


23.192 SNAPISOPAIR system variable

23.192.1 Snap isometric pair

Controls the current viewport's isometric plane (left, top or right), if the SNAPSTYL system variable is set to **isometric**.

Press **F5** function key to set the appropriate drawing plane: **Left**, **Top** or **Right**.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	0
Possible values:	0: Left 1: Top 2: Right



23.193 SNAPMARKERCOLOR system variable

23.193.1 Snap marker color

Controls the color of snap markers.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	1 to 255
Default value:	122

23.194 SNAPMARKERSIZE system variable

23.194.1 Snap marker size

Controls the size of snap markers.

BricsCAD only

Type:	Short
Saved in:	Preference



Default value:	8
----------------	---

23.195 SNAPMARKERTHICKNESS system variable

23.195.1 Snap marker thickness

Controls the thickness of the snap marker.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	2

23.196 SNAPMODE system variable

23.196.1 Snap mode

Toggles snap On or Off for the current viewport.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Snap off (for current viewport) On (1): Snap on (for current viewport)

23.197 SNAPSTYL system variable

23.197.1 Snap style

Controls the snap style for the current viewport - rectangular or isometric.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0



Possible values:	0: Rectangular snap 1: Isometric snap
------------------	--

23.198 SNAPTYPE system variable

23.198.1 Snap type

Controls the snap type for the current viewport.

For **Adaptive Grid Snap**, see also the ADAPTIVEGRIDSTEPSENSE system variable.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Grid snap 1: Polar snap 2: Adaptive Grid Snap

23.199 SNAPUNIT system variable

23.199.1 Snap unit

Controls the current viewport's snap spacing. Adjusts itself automatically to reflect the isometric snap, if SNAPSTYL is set to **Isometric snap** (1).

Note: There is no snap in the Z direction.

Type:	2D point
Saved in:	Drawing
Default value:	0.5,0.5 - If MEASUREMENT=0 and INSUNITS=inches 10.0,10.0 - If MEASUREMENT=1 and INSUNITS=millimeters

23.200 SOLIDCHECK system variable

23.200.1 Solid check

Toggles the 3D solid validation for the current application session.



Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Solid validation off On (1): Solid validation on

23.201 SORTENTS system variable

23.201.1 Sort entities

Controls the entity display sort order.

Type:	Short
Saved in:	Drawing
Range:	0 to 127
Default value:	127
Possible options:	0: Off 1: Entity selection 2: Entity snap 4: Redraws 8: Mslide slide creation 16: Regens 32: Plotting 64: PostScript output

23.202 SPAADJUSTMODE system variable

23.202.1 Adjust mode

Controls the adjustment mode used for triangle smoothing. Ignored if FACETRES is used.

Adjust mode identifies which facet nodes are to be adjusted (smoothed) to other than their initial grid positions.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only



Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	0
Possible values:	<p>0: None - No changes 1: Non-grid - Move nodes in the center of surrounding nodes to adjust points surrounded by triangles 2: All - Also adjust grid nodes</p>

23.203 SPACHECKLEVEL system variable

23.203.1 Check level

Check level used in AUDIT and SOLIDEDIT for checking ACIS entities.

Audit is used to repair drawings that are open. The SOLIDEDIT command edits the faces, edges and bodies of 3D solids and 2D regions.

Value 10 is the lowest, used for fast checking. Value 70 is the maximum, used for comprehensive time consuming check.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 70
Default value:	10



Possible values:	0: Basic transformation consistency - basic pointer and fatal topology check 10: Basic geometry check - cellular topology check 20: Data sharing check, face area and loop orientation check, medium check of curved geometry 30: General surface check - check for sliver faces 40: Degenerate spline surface check, compatibility check between surface and pcurve surface, and check that a COEDGE has a partner on a single-sided face 50: Body containment check - compatibility check between pcurve location and (non-tolerant) coedge location 60: Convexity points check 70: Lump and shell containment check - face-face intersection check, and curve parametrization check
------------------	---

23.204 SPAGRIDASPECTRATIO system variable

23.204.1 Grid aspect ratio

Controls the aspect ratio of each cell in a grid. Ignored if the FACETRES system variable is in use.

A value of 1 is square.

This does not guarantee the aspect ratio of the facet, which may consist of only a part of a cell.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

23.205 SPAGRIDMODE system variable

23.205.1 Grid mode

Controls how grids are used in the mesh process. This variable is ignored if FACETRES is used.

The grid mode specifies whether a grid is used and whether the points where the grid cuts the edges should be inserted into the edge discretization.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Preference
Range:	0 to 3
Default value:	1
Possible values:	0: Do not subdivide faces with a grid 1: Use a grid but do not add model edge intersection points 2: Allow grid to divide model edges 3: Grid only in one direction, u or v

23.206 SPAMAXFACETEDGELENGTH system variable

23.206.1 Maximum facet edge length

Controls the maximum length of a facet side. Ignored if the FACETRES system variable is used.

A value of zero means uses defaults (recommend).

CAUTION: Lengths that are too small cause high memory consumption and poor performance.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

23.207 SPAMAXNUMGRIDLINES system variable

23.207.1 Maximum number of grid lines

Controls the maximum number of grid subdivisions, this limits the face facet data size. Does not apply if the FACETRES system variable is in use.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Long
Saved in:	Preference
Default value:	3000



23.208 SPAMINUGRIDLINES system variable

23.208.1 Minimum number of U grid lines

Controls the minimum number of U grid lines - the minimum number of grid lines generated in the U direction. Ignored if the FACETRES system variable is in use.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Long
Saved in:	Preference
Default value:	0

23.209 SPAMINVGRIDLINES system variable

23.209.1 Minimum number of V grid lines

Controls the minimum number of V grid lines - the minimum number of grid lines generated in the V direction. Ignored if the FACETRES system variable is in use.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Long
Saved in:	Preference
Default value:	0

23.210 SPANORMALTOL system variable

23.210.1 Normal tolerance

Controls the maximum deviation allowed between two normals on two adjacent facet nodes, in degrees.

This value is independent of the model size. This variable is ignored if the FACETRES system variable is on (1).

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Real
-------	------



Saved in:	Preference
Default value:	15.0

23.211 SPASURFACETOL system variable

23.211.1 Surface tolerance

Controls the maximum distance between a facet edge and the true surface. The value is dependent on the model size.

This variable is ignored for output to STL and PDF if the FACETRES system variable is in use.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	-1.0

23.212 SPATRIANGMODE system variable

23.212.1 Triangulation mode

Identifies what portion of a mesh is triangulated. Ignored if the FACETRES system variable is in use.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 5
Default value:	1



Possible values:	0: No triangulation 1: Triangulate everywhere 2: Triangulate against the boundary 3: Also triangulate first grid level 4: Triangulate to 3 levels of fringe 5: Triangulate to 4 levels of fringe
------------------	---

23.213 SPAUSEFACETRES system variable

23.213.1 Use FACETRES system variable

Use the FACETRES system variable in place of normal tolerances.

Note: Spa is short for Spatial, the maker of ACIS.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On

23.214 SPLFRAME system variable

23.214.1 Spline frame

Displays control polygons for splines and spline-fit polylines.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't display control polygon for splines and spline-fit polylines On (1): Display control polygon for splines and spline-fit polylines

23.215 SPLINESEGS system variable

23.215.1 Spline segments

Controls how many line segments are generated when a spline is converted to a polyline with the PEDIT command.

Values between -32768 and 32767 are accepted.



For negative values, a fit-type curve is applied, composed of arc-segments, yields a smoother curve, but it takes longer to generate.


Type:	Short
Saved in:	Drawing
Range:	-32768 to 32767
Default value:	8

23.216 SPLINETYPE system variable

23.216.1 Spline type

Controls the curve type generated by the **Spline** option of the PEDIT command: Quadratic B-spline or Cubic B-spline.

Type:	Short
Saved in:	Drawing
Range:	5 to 6
Default value:	6
Possible values:	5: Quadratic B-spline 6: Cubic B-spline



23.217 SRCHPATH system variable

23.217.1 Support file search path

The file path for text fonts, customization files, plugins, drawings to insert, linetypes, and hatch patterns, not in the current folder.

Separate file paths with semicolons (;).

BricsCAD only



Type:	String Standard
Saved in:	Registry

23.218 SSFOUND system variable

23.218.1 Sheet Set found (Read Only)

Displays the sheet set file name and path that is associated with the current drawing file.

Type:	String
Saved in:	Not saved

23.219 SSLOCATE system variable

23.219.1 Sheet Set locate

Opens any associated sheets sets when a drawing is opened.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't open a drawing's Sheet Set with the drawing On (1): Open a drawing's Sheet Set with the drawing

23.220 SSMAUTOOPEN system variable

23.220.1 Sheet Set manager auto open

Opens **Sheet Set** panel automatically when a drawing is opened that is associated with a Sheet Set. The SSMAUTOOPEN and SSLOCATE system variables must both be switched on to display the Sheet Set automatically.

Type:	Boolean
Saved in:	Workspace
Default value:	On



Possible values:	Off (0): Don't open Sheet Set panel automatically On (1): Open Sheet Set panel automatically
------------------	---

23.221 SSMPOLLTIME system variable

23.221.1 Sheet Set manager poll time

Controls the time interval between automatic refreshes of the status data in a Sheet Set. The SSMSHEETSTATUS system variable must be set to 2 for the timer to operate.

Values between 10 and 600 are accepted.

Type:	Short
Saved in:	Registry
Range:	10 to 600
Default value:	15

23.222 SSMSHEETSTATUS system variable

23.222.1 Sheet Set manager status

Controls how the status data in a Sheet Set is refreshed.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Don't automatically refresh status 1: Refresh status when Sheet Set is loaded or updated 2: Refresh status when Sheet Set is loaded or updated, and at time interval by SSMPOLLTIME

23.223 SSMSTATE system variable

23.223.1 Sheet Set manager state (Read Only)

Controls if the Sheet Set Manager is active or not.



Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Sheet Set Manager is not active 1: Sheet Set Manager is active

23.224 STACKPANELTYPE system variable

23.224.1 Stack panel type

The style of stacked docking panel containers.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	2
Possible values:	0: Tabbed - horizontal textual tabs, resizes drawing space 1: Flyout - vertical icon tab buttons, does not resize drawing space 2: Collapsible - vertical icon tab buttons, resizes drawing space

23.225 STAMPFONTSIZE system variable

23.225.1 Font Size

Controls the font size for the plot stamp. See also the INCLUDEPLOTSTAMP system variable.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.2



23.226 STAMPFONTSTYLE system variable

23.226.1 Font Style

Controls the font style for the plot stamp. See also the INCLUDEPLOTSTAMP system variable.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	Arial

23.227 STAMPFOOTER system variable

23.227.1 Footer

Controls the footer for the plot stamp.

BricsCAD only

Type:	String
Saved in:	Preference

23.228 STAMPFOOTEROFFSETX system variable

23.228.1 Stamp footer X offset

Controls the offset of the plot stamp footer from the bottom of the printable area. See also the INCLUDEPLOTSTAMP system variable.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

23.229 STAMPFOOTEROFFSETY system variable

23.229.1 Stamp footer Y offset

Controls the offset of the plot stamp footer from the bottom of the printable area. See also the INCLUDEPLOTSTAMP system variable.



BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

23.230 STAMPHEADER system variable

23.230.1 Header

Controls the header for the plot stamp.

BricsCAD only

Type:	String
Saved in:	Preference

23.231 STAMPHEADEROFFSETX system variable

23.231.1 Stamp header X offset

Controls the offset of the plot stamp header from the top of the printable area. See also the INCLUDEPLOTTSTAMP system variable.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

23.232 STAMPHEADEROFFSETY system variable

23.232.1 Stamp header Y offset

Controls the offset of the plot stamp header from the top of the printable area. See also the INCLUDEPLOTTSTAMP system variable.

BricsCAD only

Type:	Real
-------	------



Saved in:	Preference
Default value:	0.0

23.233 STAMPUNITS system variable

23.233.1 Units

Controls the units for the font size of the plot stamp.

See the INCLUDEPLOTTSTAMP system variable.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 1
Default value:	0
Possible values:	0: Inches 1: Millimeters

23.234 STANDARDOPTIONS system variable

23.234.1 Standards validation options

Options to control the standards check procedure.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible options:	1: Fix non-standard entity properties automatically 2: Show ignored problems



23.235 STANDARDSVIOLATION system variable

23.235.1 Standards Violation Notification

Controls how a user is notified of standards violations.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	2
Possible options:	0: Notification is off 1: An alert dialog is displayed 2: An icon is displayed in the Status bar

23.236 STARTUP system variable

23.236.1 Startup

Controls the display of the **Create New Drawing** and **Startup** dialog boxes.

Type:	Short
Saved in:	Registry
Range:	0 to 4
Default value:	3
Possible values:	0: Display the Select Template dialog box, or use a default drawing template file. See also the BASEFILE system variable 1: Display the Startup and the Create New Drawing dialog boxes 2: Display the Start page 3: Display the Start page (with the Ribbon preloaded but not displayed) 4: Display the Start page (with the Ribbon preloaded but not displayed) except if a file is passed on command line

23.237 STATUSBAR system variable

23.237.1 Window Status bar

Controls the display of the Status bar.



Note: The only reason to turn off the status bar is to gain a bit more drawing area. It is far more useful to leave it on

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't show Status bar On (1): Show Status bar

23.238 STEPSIZE system variable

23.238.1 Step size

Controls the size of each step, in drawing units, when in walk or fly mode.

Type:	Real
Saved in:	Drawing
Range:	1e-6 to 1e+6
Default value:	2.0

23.239 STEPSPERSEC system variable

23.239.1 Steps per second

Controls the number of steps per second, when in walk or fly mode.

Values between 1.0 and 30.0 are accepted.

Type:	Real
Saved in:	Drawing
Range:	1.0 to 30.0
Default value:	24.0



23.240 STLPOSITIVEQUADRANT system variable

23.240.1 STL export coordinates adjustment

Moves coordinates to all-positive values during an STL export.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	1
Possible values:	0: Off 1: On

23.241 STORYBAR system variable

23.241.1 Display Story Bar

Controls the visibility and position of the **Story Bar**.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	Off
Possible values:	0: Off - turns off the Story bar 1: Right - turns the story bar visible on the right side of the model space 2: Left - turns the story bar visible on the left side of the model space

23.242 STRUCTURETREECONFIG system variable

23.242.1 Structure Tree Configuration

Displays the name of the active **Structure Tree Configuration** file used by the **Structure** panel. Type SRCHPATH in the Command line to find the file.

Loading a different CST file than the default file changes the way that the STRUCTUREPANEL command presents drawing data.

BricsCAD only



Type:	String
Saved in:	Workspace
Default value:	default.cst

23.243 SURFTAB1 system variable

23.243.1 Surface tabulation 1

Controls the number of tabulations to be created for RULESURF and TABSURF commands. Also controls the mesh density in the M direction for REVSURF and EDGESURF commands.

When extruding entities with arc segments: the SURFTAB1 system variable divides them in a number of equal length intervals.

When revolving entities: the SURFTAB1 variable controls the number of segments of the revolution surface.

Type:	Short
Saved in:	Drawing
Default value:	6

23.244 SURFTAB2 system variable

23.244.1 Surface tabulation 2

Controls the mesh density in the N direction for REVSURF and EDGESURF commands.

The SURFTAB2 variable controls the number of segments of each arc segment in the revolved entity.

Type:	Short
Saved in:	Drawing
Default value:	6

23.245 SURFTYPE system variable

23.245.1 Surface-fitting type

Controls the surface-fitting type used with the **Desmooth** option of the PEDIT command.



Type:	Short
Saved in:	Drawing
Range:	5 to 8
Default value:	6
Possible values:	5: Quadratic B-spline surface 6: Cubic B-spline surface 8: Bezier surface

23.246 SURFU system variable

23.246.1 Surface U

Controls the surface density in the M direction and the U isolines density on surface entities for the **Smooth** option of the PEDIT command.

Type:	Short
Saved in:	Drawing
Default value:	6

23.247 SURFV system variable

23.247.1 Surface V

Controls the surface density in the N direction and the V isolines density on surface entities for the **Smooth** option of the PEDIT command.

Type:	Short
Saved in:	Drawing
Default value:	6

23.248 SVGBLENDEDGRADIENTS system variable

23.248.1 SVG Blended Gradients

Toggles the use of blended gradients for complex gradient fills for SVG export.



The use of complex gradient fills makes the file size larger.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: Yes 1: No

23.249 SVGCOLORPOLICY system variable

23.249.1 SVG Color Policy

Color policy for an SVG export.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	1
Possible values:	0: Colorful 1: Monochrome 2: Grayscale

23.250 SVGDEFAULTIMAGEEXTENSION system variable

23.250.1 SVG Default Image Extension

Controls the default image extension type.

BricsCAD only

Type:	String
Saved in:	Preference
Default value:	.png



23.251 SVGGENERICFONTFAMILY system variable

23.251.1 SVG Generic Font Family

Substitute font to use if the font is missing for SVG export.

The following generic font families are supported in SVG: **serif, sans-serif, cursive, fantasy, monospace**.

- Sans-serif - fonts without serifs, like Arial
- Serif - fonts with serifs, like Times Roman
- Cursive - fonts that look handwritten
- Fantasy - unusual fonts
- Monospace - fonts where each character takes up the same space (non-proportional spacing), such as Courier

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	0
Possible values:	0: Sans-serif 1: Serif 2: Cursive 3: Fantasy 4: Monospace

23.252 SVGIMAGEBASE system variable

23.252.1 SVG Image base path

The image file path for SVG export.

If not set, absolute file paths are written to the SVG.

BricsCAD only

Type:	String Standard
Saved in:	Preference

23.253 SVGIMAGEURL system variable

23.253.1 SVG Image Url

The file path for images for SVG export.



BricsCAD only

Type:	String Standard
Saved in:	Preference

23.254 SVGLINEWEIGHTSCALE system variable

23.254.1 SVG Line Weight Scale

Scales lineweights for an SVG export.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	1.0

23.255 SVGOUTPUTHEIGHT system variable

23.255.1 SVG Output Height

Page height, in pixels, for SVG export.

Valid only if SVGSCALFACTOR system variable is set to zero.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	768

23.256 SVGOUTPUTWIDTH system variable

23.256.1 SVG Output Width

Page width, in pixels, for SVG export.

Valid only if SVGSCALFACTOR system variable is set to zero.

BricsCAD only

Type:	Short
-------	-------



Saved in:	Preference
Default value:	1024

23.257 SVGPRECISION system variable

23.257.1 SVG Floating Point Precision

Number of decimal digits (as in printf("%.9g",...)) - 9 digits) for an SVG export.

BricsCAD only

Type:	Short
Saved in:	Preference
Default value:	6

23.258 SVGSCALEFACTOR system variable

23.258.1 SVG Scale Factor

Scales the SVG during an export. Dependent files need to be converted separately.

1 Drawing unit = X SVG pixel.

- If set to zero, scales the current view to fit within the page size set with the SVGOUTPUTWIDTH and SVGOUTPUTHEIGHT variables.
- If set to a positive value, SVG page size is calculated automatically to correspond to required scale.

For example, 96dpi / 25.4 = 3.7795 - the corresponding scale factor for the conversion of 1 DWG unit into 1 mm SVG.

BricsCAD only

Type:	Real
Saved in:	Preference
Default value:	0.0

23.259 SYSCODEPAGE system variable

23.259.1 System code page (Read Only)

Displays the system code page, determined by the operating system.



Type:	String
Saved in:	Not saved



24. T

24.1 TABCONTROLHEIGHT system variable

24.1.1 Tab control height in pixels (Mac & Linux)

Controls the height of the document control tab, in pixels.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 or greater
Default value:	25

24.2 TABMODE system variable

24.2.1 Tablet mode

Allows the use of a tablet. Use the TABLET command to configure the tablet.

Type:	Boolean
Saved in:	Not saved
Range:	0
Possible values:	0: Command selection mode 1: Digitize mode

24.3 TABSFIXEDWIDTH system variable

24.3.1 Tabs fixed width (Mac & Linux)

Applies the same width to all tabs, in the documents tab.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off



Possible values:	Off (0): All tabs have fixed width off On (1): All tabs have fixed width on
------------------	--

24.4 TANGENTLENGTHTYPE system variable

24.4.1 Tangent Length Type

Sets default flow fitting tangent length type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

24.5 TANGENTLENGTHVALUE system variable

24.5.1 Tangent Length Value

Sets default flow fitting tangent length value.

BricsCAD only

Type:	Real
Saved in:	Drawing
Default value:	0

24.6 TARGET system variable

24.6.1 Target (Read Only)

The coordinates for perspective projection of the current viewport.

Type:	3D point
Saved in:	Drawing



24.7 TDCREATE system variable

24.7.1 Time/Date create (Read only)

The time and date the drawing was created, in Julian Day format.

Type:	Real
Saved in:	Drawing

24.8 TDINDWG system variable

24.8.1 Time/Date in drawing (Read Only)

The total current drawing edit time, in days.

Format: >number of days<. >decimal fraction of a day<

Type:	Real
Saved in:	Drawing

24.9 TDUCREATE system variable

24.9.1 Time/Date universal create (Read Only)

The universal time and date the drawing was created, Julian Day format.

Type:	Real
Saved in:	Drawing

24.10 TDUPDATE system variable

24.10.1 Time/Date update (Read Only)

The local time and date, the drawing was last saved or updated, in Julian Day format.

Type:	Real
Saved in:	Drawing



24.11 TDUSRTIMER system variable

24.11.1 Time/Date user timer (Read Only)

The user-elapsed timer value.

Start, stop and reset the timer with the TIME command.

Type:	Real
Saved in:	Drawing

24.12 TDUUPDATE system variable

24.12.1 Time/Date universal update (Read Only)

The universal time and date the drawing was last saved or updated - in Julian Day format.

Type:	Real
Saved in:	Drawing

24.13 TEETANGENTLENGTHTYPE system variable

24.13.1 Tee Length Type

Sets default tee tangent length type.

BricsCAD only

Type:	Short
Saved in:	Drawing
Default value:	0
Possible values:	(0): Profile Width Ratio (1): Absolute Value

24.14 TEETANGENTLENGTHVALUE system variable

24.14.1 Tee Length Value

Sets default tee tangent length value.

BricsCAD only



Type:	Real
Saved in:	Drawing
Default value:	0.5

24.15 TEMPLATEPATH system variable

24.15.1 Template path

Specifies the file path used for the Templates folder.

BricsCAD only

Type:	String Standard
Saved in:	Preference

24.16 TEMPPREFIX system variable

24.16.1 Temporary prefix

The folder name for temporary files.

Type:	String Standard
Saved in:	Registry

24.17 TEXTANGLE system variable

24.17.1 Text angle

The angle of the last added text entity.

BricsCAD only

Type:	Real
Saved in:	Not saved

24.18 TEXTED system variable

24.18.1 Text editor for single line text entities

Controls the editor type used for single line text entities.



Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2
Possible values:	0: Edit in-place editor 1: Edit in pop up dialog 2: Edit in-place editor with repeated input

24.19 TEXTEDITMODE system variable

24.19.1 Text edit mode

Controls if DDEDIT command automatically repeats entity selections or not.

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	0
Possible values:	0: Multiple edit mode (command repeats until canceled) 1: Single edit mode (command ends after editing a text entity) 2: Automatic edit mode (single if to edit preselected text, otherwise multiple)

24.20 TEXTEVAL system variable

24.20.1 Text evaluation

Controls the interpretation of Command line text strings.

When the TEXTEVAL system variable is set to 1, this command evaluates LISP expressions:

Text: (* pi 2)

The result of the equation ($\pi \times 2$) is placed as text: 6.283185

Type:	Short
-------	-------



Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: All responses to prompts for text strings and attribute values are taken literally 1: Text starting with '(' or ')' is evaluated as an LISP expression, as for non-textual input

24.21 TEXTFILL system variable

24.21.1 Text fill

Controls if TrueType fonts are filled or outlined for renders and the PSOUT command.

Type:	Short
Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Display text as outlines 1: Display text as filled images



24.22 TEXTQLTY system variable

24.22.1 Text quality (Mac & Linux)

Controls the smoothness of TrueType fonts for plot and render.

Values between 0 and 100 are accepted.

- A value of zero means no smoothing.
- A value of 100 is maximum smoothing.



Type:	Short
Saved in:	Not saved
Range:	0 to 100
Default value:	50
Possible values:	0: No smoothing 100: Maximum smoothing

24.23 TEXTSIZE system variable

24.23.1 Text size

The default height for new text entities, has no effect if the current text style has a fixed height.

Type:	Real
Saved in:	Drawing
Default value:	2.5

24.24 TEXTSTYLE system variable

24.24.1 Text style

The current text style.

Type:	String
Saved in:	Drawing
Default value:	Standard

24.25 TEXTUREMAPPATH system variable

24.25.1 Texture map path

The file paths for texture maps.

BricsCAD only

Type:	String Standard
-------	-----------------



Saved in:	Preference
-----------	------------

24.26 THICKNESS system variable

24.26.1 Thickness

The default thickness for 2D entities.

Type:	Real
Saved in:	Drawing
Default value:	0.0

24.27 THREADDISPLAY system variable

24.27.1 Thread representation

Controls the thread display for part created, during the -BMHARDWARE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): Turn off Thread Display On (1): Thread Display

24.28 THUMBSIZE system variable

24.28.1 Thumbnail preview image size

Controls the maximum generated size for thumbnail previews, in pixels.

Type:	Short
Saved in:	Registry
Range:	0 to 8
Default value:	3



Possible values:	0: 64x64 1: 128x128 2: 256x256 3: 512x512 4: 1024x1024 5: 1440x1440 6: 1600x1600 7: 1920x1920 8: 2560x2560
------------------	--

24.29 TILEMODE system variable

24.29.1 Tile mode

Switches the active tab, model or paper space.

Type:	Short
Saved in:	Drawing
Default value:	1
Possible values:	0: Last active layout tab (paper space) 1: Model tab

24.30 TILEMODELIGHTSYNCH system variable

24.30.1 Tile mode light synch

Synchronizes lighting in all model space viewports (Internal use only).

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't synchronize lighting On (1): Synchronize lighting



24.31 TIMEZONE system variable

24.31.1 Timezone

Controls the time zone for the sun.

Note: Setting a geographic location also controls the time zone.

Type:	Short
Saved in:	Drawing
Range:	-12000 to 13000
Default value:	-8000



Possible values:	-12000: (GMT-12:00) International Date Line West -11000: (GMT-11:00) Midway Island, Samoa -10000: (GMT-10:00) Hawaii -9000: (GMT-09:00) Alaska -8000: (GMT-08:00) Pacific Time (US & Canada); Tijuana -7000: (GMT-07:00) Mountain Time (US & Canada) -7001: (GMT-07:00) Arizona -7002: (GMT-07:00) Chihuahua, La Paz, Mazatlan -6000: (GMT-06:00) Central Time (US & Canada) -6001: (GMT-06:00) Central America -6002: (GMT-06:00) Guadalajara, Mexico City, Monterrey -6003: (GMT-06:00) Saskatchewan -5000: (GMT-05:00) Eastern Time (US & Canada) -5001: (GMT-05:00) Indiana (East) -5002: (GMT-05:00) Bogota, Lima, Quito -4000: (GMT-04:00) Atlantic Time (Canada) -4001: (GMT-04:00) Caracas, La Paz -4002: (GMT-04:00) Santiago -3300: (GMT-03:30) Newfoundland -3000: (GMT-03:00) Brasilia -3001: (GMT-03:00) Buenos Aires, Georgetown -3002: (GMT-03:00) Greenland -2000: (GMT-02:00) Mid-Atlantic -1000: (GMT-01:00) Azores -1001: (GMT-01:00) Cape Verde Is. 0: (UTC) Universal Coordinated Time 1: (GMT) Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London 2: (GMT) Casablanca, Monrovia 1000: (GMT+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna 1001: (GMT+01:00) Brussels, Copenhagen, Madrid, Paris 1002: (GMT+01:00) Belgrade, Bratislava, Budapest, Ljubljana, Prague 1003: (GMT+01:00) Sarajevo, Skopje, Warsaw, Zagreb 1004: (GMT+01:00) West Central Africa 2000: (GMT+02:00) Athens, Beirut, Istanbul, Minsk 2001: (GMT+02:00) Bucharest 2002: (GMT+02:00) Cairo 2003: (GMT+02:00) Harare, Pretoria 2004: (GMT+02:00) Helsinki, Kyiv, Riga, Sofia, Tallinn, Vilnius 2005: (GMT+02:00) Jerusalem 3000: (GMT+03:00) Moscow, St. Petersburg, Volgograd 3001: (GMT+03:00) Kuwait, Riyadh 3002: (GMT+03:00) Baghdad 3003: (GMT+03:00) Nairobi 3300: (GMT+03:30) Tehran 4000: (GMT+04:00) Abu Dhabi, Muscat 4001: (GMT+04:00) Baku, Tbilisi, Yerevan 4300: (GMT+04:30) Kabul 5000: (GMT+05:00) Ekaterinburg 5001: (GMT+05:00) Islamabad, Karachi, Tashkent 5300: (GMT+05:30) Chennai, Kolkata, Mumbai, New Delhi 5450: (GMT+05:45) Kathmandu 6000: (GMT+06:00) Almaty, Novosibirsk 6001: (GMT+06:00) Astana, Dhaka 6002: (GMT+06:00) Sri Jayawardenepura 6200: (GMT+06:30) Bangkok
------------------	---



24.32 TOOLBARMARGIN system variable

24.32.1 Toolbar margin

Controls the toolbar row margin size, in pixels.

Values between 0 and 63 are accepted.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 63
Default value:	0

24.33 TOOLBUTTONSIZE system variable

24.33.1 Tool button size

Controls size of Toolbar buttons and icons.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 2
Default value:	0
Possible values:	0: Small buttons 1: Large buttons 2: Extra-large buttons

Small:



Large:



Extra Large:



24.34 TOOLICONPADDING system variable

24.34.1 Tool icon padding

Controls the size of toolbar buttons. Changes the spacing, in pixels, does not change the size of the icons.

Values between 0 and 15 are accepted.

BricsCAD only

Type:	Short
Saved in:	Workspace
Range:	0 to 15
Default value:	4

24.35 TOOLPALETTEPATH system variable

24.35.1 Tool palettes path

Specify the path(s) to the Tool Palettes.

Type:	String Standard
Saved in:	Registry

24.36 TOOLTIPDELAY system variable

24.36.1 Tooltip delay

Controls the delay for tooltips (hover tips) to appear, in milliseconds. Applies only if tooltips are enabled in the TOOLTIPS system variable.

Values between 0 and 500 are accepted.

BricsCAD only

Type:	Short
Saved in:	Registry



Range:	0 or greater
Default value:	500

24.37 TOOLTIPS system variable

24.37.1 Tooltips

Toggles the display of tooltips for toolbars, the Ribbon, the Quad and the Properties.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display tooltips On (1): Display tooltips

24.38 TPSTATE system variable

24.38.1 Tool Palettes Panel state (Read Only)

The status of the Tool Palettes panel.

Type:	Short
Saved in:	Not saved
Range:	0 to 1
Default value:	0
Possible values:	0: Tool Palettes bar is invisible 1: Tool Palettes bar is visible

24.39 TRACEWID system variable

24.39.1 Trace width

Controls the default width for new traces, for the TRACE command.

Type:	Real
-------	------



Saved in:	Drawing
Default value:	1.0

24.40 TRACKPATH system variable

24.40.1 Track path

Controls the display of polar and entity snap tracking paths.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible values:	0: Display full-screen entity snap tracking path 1: Display entity snap tracking path only between the alignment point and the From point to the cursor location 2: Do not display polar tracking path 3: Do not display polar or entity snap tracking paths

24.41 TRANSPARENCYDISPLAY system variable

24.41.1 Transparency display

Displays transparencies.

Type:	Boolean
Saved in:	Registry
Default value:	On

24.42 TRAYICONS system variable

24.42.1 Tray icons

Toggles the display of notification icons in the Status bar.

Type:	Boolean
-------	---------



Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display tray On (1): Display tray

24.43 TRAYNOTIFY system variable

24.43.1 Tray notify

Toggles the display of notification balloons.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't display notifications On (1): Display notifications

24.44 TRAYTIMEOUT system variable

24.44.1 Tray timeout

Controls the display time for service notifications, in seconds. Applies only if the TRAYNOTIFY system variable is on.

Values between 0 and 60 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 60
Default value:	0

24.45 TREEDEPTH system variable

24.45.1 Tree depth

Controls the maximum number of times an index can be divided into branches.



A value of zero suppresses the spatial index entirely, entities are always processed in database order. Positive numbers turn on spatial indexing, an integer, five digits maximum, the first three digits refer to model space, the remaining digits refer to paper space. For negative numbers Z coordinate is ignored in model space, recommended for 2D drawings.

Type:	Short
Saved in:	Drawing
Default value:	3020
Possible values:	0: Suppress spatial indexing >0: Apply spatial indexing <0: Ignore Z coordinates

24.46 TREEMAX system variable

24.46.1 Tree maximum

Limits the use of memory, limits the number of nodes in the spatial index (oct-tree) when a drawing is regenerated.

By imposing a fixed limit with TREEMAX, you can load drawings created on systems with more memory than your system and with a larger TREEDEPTH than your system can handle. These drawings, if left unchecked, have an oct-tree large enough to eventually consume more memory than is available to your computer. TREEMAX also provides a safeguard against experimentation with inappropriately high TREEDEPTH values.

Type:	Long
Saved in:	Registry
Default value:	10000000

24.47 TRIMEDGES system variable

24.47.1 TRIM and EXTEND to hatches

Controls whether hatch patterns are considered when trimming and extending in Quick mode.

Type:	Boolean
Saved in:	Registry



Default value:	1
Possible values:	0: Uses hatch patterns as boundaries 1: Uses hatch edges only

24.48 TRIMEXTENDMODE system variable

24.48.1 TRIM and EXTEND mode

Controls how TRIM and EXTEND commands use streamlined inputs.


Type:	Boolean
Saved in:	Registry
Default value:	1
Possible values:	0: Standard mode, cutting and boundary edges need to be specified firstly 1: Quick mode, all objects in the drawing are automatically specified as cutting and boundary edges

24.49 TRIMMODE system variable

24.49.1 Trim mode

Controls if the length of selected entities or polyline segments for chamfers and fillets are adjusted (trimmed or lengthened).

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't trim selected edges to the endpoints of chamfer lines and fillet arcs On (1): Trim selected edges to the endpoints of chamfer lines and fillet arcs



24.50 TRUSTEDPATHS system variable

24.50.1 Trusted executable file locations (Read Only)

File path(s) to use to load executable files.

Separate file paths with semicolons (;

Type:	String
Saved in:	Not saved

24.51 TSPACEFAC system variable

24.51.1 Text space factor

Controls the line spacing distance of multiline text, measured as a multiplier of text height.

Values between 0.25 and 4.0 are accepted.

Type:	Real
Saved in:	Not saved
Range:	0.25 to 4.0
Default value:	1.0

24.52 TSPACETYPE system variable

24.52.1 Text space type

Controls the type of line spacing used for multiline text.

- At least: adjusts line spacing based on the tallest character(s) in a line
- Exactly: uses the specified line spacing, regardless of individual character sizes

Note: The mtexts created with the MLEADER command are also influenced by this system variable's value.



Type:	Short
Saved in:	Registry
Range:	1 to 2
Default value:	1
Possible values:	1: At least 2: Exactly

24.53 TSTACKALIGN system variable

24.53.1 Text stack align

Controls the vertical alignment of stacked text.

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Align bottom 1: Align center 2: Align top

24.54 TSTACKSIZE system variable

24.54.1 Text stack size

Controls the stacked text height, as a percentage, relative to the height of the selected text.

Values between 25 and 125 are accepted.

Type:	Short
Saved in:	Drawing
Range:	25 to 125
Default value:	70



24.55 TTFASTTEXT system variable

24.55.1 TrueType Text displaying mode

Controls if TrueType text is drawn as vectorized graphics or as text.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Displays text as vectorized graphics On (1): Displays text as text

24.56 TUTORIALSONSTARTPAGE system variable

24.56.1 Tutorials on start page

Switch to control whether tutorials can be accessed from the start page.

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Does not display the Discover hands-on tutorials button on the start page On (1): Displays the Discover hands-on tutorials button on the start page



25. U

25.1 UCSAXISANG system variable

25.1.1 UCS axis angle

Controls the default rotation angle around the X, Y, or Z axis, for the UCS command.

Values between 5 and 180 are accepted.

Type:	Real
Saved in:	Registry
Range:	5 to 180
Default value:	90

25.2 UCSBASE system variable

25.2.1 UCS base

The name of the UCS that defines the orthographic UCS.

Type:	String
Saved in:	Drawing
Default value:	WORLD

25.3 UCSDETECT system variable

25.3.1 UCS detect

Controls the dynamic UCS behavior. Dynamic UCS is a temporary UCS that activates automatically when the cursor hovers over a face, region or 2D entity.

A negative value is the same as 0, but helps in storing the earlier value.

Type:	Short
Saved in:	Registry
Range:	-3 to 3



Default value:	1
Possible options:	negative: Disable dynamic UCS 1: Enable for faces of 3D solid and regions 2: Enable for 2D entities

25.4 UCSFOLLOW system variable

25.4.1 UCS follow

Controls if a plan view (a top view zoomed to extents) is generated automatically whenever the UCS changes.

If on, turn off the UCSDETECT system variable.

Type:	Boolean
Saved in:	Drawing
Default value:	Off
Possible values:	Off (0): Don't show plan view when UCS is changed On (1): Show plan view when UCS is changed

25.5 UCSICON system variable

25.5.1 UCS icon

Controls the display and position of the UCS icon for the current viewport.

Type:	Short
Saved in:	Drawing
Default value:	3
Possible options:	0: No icon 1: Show icon 2: At origin

25.6 UCSICONPOS system variable

25.6.1 UCS icon position

Controls the location of the UCS icon when the origin point is not visible.



BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	1
Possible values:	0: Lower right 1: Lower left 2: Upper right 3: Upper left

25.7 UCSNAME system variable

25.7.1 UCS name (Read Only)

The name of the UCS for the current viewport, in the current workspace.

Type:	String
Saved in:	Drawing

25.8 UCSORG system variable

25.8.1 UCS origin (Read Only)

The current coordinate system's origin point for the current viewport.

Type:	3D point
Saved in:	Drawing
Default value:	0,0,0

25.9 UCSORTHO system variable

25.9.1 UCS orthographic

Sets the UCS to follow the current view, automatically switches the drawing plane to match the current view plane.

Only works if an orthographic view is selected with the -VIEW command or the LookFrom widget.



Does not work if the NAVVCUBEORIENT system variable is set to UCS.

Type:	Boolean
Saved in:	Registry
Default value:	Off
Possible values:	Off (0): When an orthographic view is selected, don't automatically activate the related orthographic UCS On (1): When an orthographic view is selected, automatically activate the related orthographic UCS

25.10 UCSVIEW system variable

25.10.1 UCS view

Controls if the current UCS is saved with a named view.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't save current UCS with named view On (1): Save current UCS with named view

25.11 UCSVP system variable

25.11.1 UCS viewports

Controls if the UCS in all viewports is fixed, or changes to reflect the currently active viewport's UCS.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Not locked (UCS not stored in viewport) On (1): Locked (UCS stored in viewport)



25.12 UCSXDIR system variable

25.12.1 UCS X direction (Read Only)

The X direction for the current viewport.

Type:	3D point
Saved in:	Drawing
Default value:	1,0,0

25.13 UCSYDIR system variable

25.13.1 UCS Y direction (Read Only)

The Y direction for the current viewport.

Type:	3D point
Saved in:	Drawing
Default value:	0,1,0

25.14 UNDOCTL system variable

25.14.1 Undo control (Read Only)

Controls the behavior of the UNDO command.

Type:	Short
Saved in:	Not saved
Default value:	5
Possible options:	0: Undo off 1: Undo on 2: Only one command can be undone 4: Auto is turned on 8: A group is currently active



25.15 UNDOMARKS system variable

25.15.1 Undo marks (Read Only)

Shows the current number of marks placed in the Undo control using the MARK option.

The MARK and BACK options are not available if a group is currently active.

Type:	Short
Saved in:	Not saved

25.16 UNITESURFACES system variable

Unite adjacent surfaces.

25.16.1 Unite adjacent surfaces

Unites extruded/revolved surfaces that touch.

The UNITESURFACES system variable is one of the four system variables found under the **Extrude mode** group.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Default value:	0
Possible options:	Off (0): Unite adjacent surfaces On (1): Do not unite adjacent surfaces

25.17 UNITMODE system variable

25.17.1 Unit mode

Controls how Imperial units are displayed.

Type:	Boolean
Saved in:	Drawing
Default value:	Off



Possible values:	Off (0): Don't remove spaces when distances or angles are converted to text On (1): Remove spaces when distances or angles are converted to text
------------------	---

25.18 USECOMMUNICATOR system variable

25.18.1 Use Communicator

Shows if the Communicator for BricsCAD® is in use. If active, also shows the license type.

- 0: no license, Communicator for BricsCAD® import and export formats are not available.
- 1: trial, runs Communicator for BricsCAD® in trial mode, expiring after 30 days.
- 2: full, runs the full Communicator for BricsCAD® import-export set.

If the license is changed, the new level comes into effect after restarting the program.

BricsCAD only

Type:	Short
Saved in:	Preference
Range:	0 to 2
Default value:	1
Possible values:	0: Not using Communicator 1: Communicator in use - on trial 2: Communicator in use - fully licensed

25.19 USENEWSTATUSBAR system variable

25.19.1 Status Bar Preview

Determines the type of status bar that is displayed.

BricsCAD only

Type:	Short
Saved in:	Registry
Default value:	0



Possible values:	Off (0): Show WX status bar On (1): Show Qt status bar
------------------	---

25.20 USERI1 system variable

25.20.1 User integer 1

First of 5 variables that can be used to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

25.21 USERI2 system variable

25.21.1 User integer 2

Second of 5 variables that can be used to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

25.22 USERI3 system variable

25.22.1 User integer 3

Third of 5 variables that can be used to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

25.23 USERI4 system variable

25.23.1 User integer 4

Fourth of 5 variables that can be used to store integer values.



Type:	Short
Saved in:	Drawing
Default value:	0

25.24 USERI5 system variable

25.24.1 User integer 5

Fifth of 5 variables that can be used to store integer values.

Type:	Short
Saved in:	Drawing
Default value:	0

25.25 USERR1 system variable

25.25.1 User real 1

First of 5 variables that can be used to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0

25.26 USERR2 system variable

25.26.1 User real 2

Second of 5 variables that can be used to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0



25.27 USERR3 system variable

25.27.1 User real 3

Third of 5 variables that can be used to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0

25.28 USERR4 system variable

25.28.1 User real 4

Fourth of 5 variables that can be used to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0

25.29 USERR5 system variable

25.29.1 User real 5

Fifth of 5 variables that can be used to store real numerical values.

Type:	Real
Saved in:	Drawing
Default value:	0.0

25.30 USERS1 system variable

25.30.1 User string 1

First of 5 variables that can be used to store string values.

Type:	String
Saved in:	Not saved



25.31 USERS2 system variable

25.31.1 User string 2

Second of 5 variables that can be used to store string values.

Type:	String
Saved in:	Not saved

25.32 USERS3 system variable

25.32.1 User string 3

Third of 5 variables that can be used to store string values.

Type:	String
Saved in:	Not saved

25.33 USERS4 system variable

25.33.1 User string 4

Fourth of 5 variables that can be used to store string values.

Type:	String
Saved in:	Not saved

25.34 USERS5 system variable

25.34.1 User string 5

Fifth of 5 variables that can be used to store string values.

Type:	String
Saved in:	Not saved



25.35 USESTANDARDOPENFILEDIALOG system variable

25.35.1 Use standard open file dialog (Windows)

Uses a standard (non-customizable) dialog for the OPEN, SAVEAS and INSERT commands (Windows only). See also the DRAWINGPATH, BLOCKSPATH and PLACESBARFOLDER system variables.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	Off



26. V

26.1 VBAMACROS system variable

26.1.1 Enable macros

Enables macros when a VBA-project is loaded.

BricsCAD only

Type:	Boolean
Saved in:	Preference
Default value:	On
Possible values:	Off (0): Disable macros on loading VBA-project On (1): Enable macros on loading VBA-project

26.2 VENDORNAME system variable

26.2.1 Vendor name (obsolete)

Shows the vendor name.

BricsCAD only

Read-only

Type:	String
Saved in:	Not saved
Default value:	Bricsys

26.3 VERBOSEBIMSECTIONUPDATE system variable

26.3.1 Additional diagnostics while section update

Displays additional diagnostics for the BIMSECTIONUPDATE command.

BricsCAD only

Type:	Boolean
Saved in:	Registry



Default value:	On
----------------	----

26.4 VERSIONCONTROLCONFIGPATH system variable

26.4.1 Version Control config path

The file path used to store version control settings.

BricsCAD only

Type:	String
Saved in:	Registry

26.5 VERSIONCONTROLDOWNLOADPATH system variable

26.5.1 Version Control download path

The file path used to store version control projects.

BricsCAD only

Type:	String
Saved in:	Registry

26.6 VERSIONCUSTOMZABLEFILES system variable

26.6.1 Version customizable files (Read Only)

Shows the current version of the CUI and PGP files.

Type:	String
Saved in:	Preference

26.7 VIEWCTR system variable

26.7.1 View center (Read Only)

The coordinates for the center point of the current viewport.

Type:	3D point
Saved in:	Drawing



26.8 VIEWDIR system variable

26.8.1 View direction (Read Only)

Displays the view direction of the current viewport.

Type:	3D point
Saved in:	Drawing

26.9 VIEWMODE system variable

26.9.1 View mode (Read Only)

The current viewport's View mode.

- If off, the front clipping plane passes through the camera point (vectors behind the camera are not displayed) unless front-clipping is off.
- If **Front clip not at eye** is on, the FRONTZ system variable controls the front clipping plane.

Type:	Short
Saved in:	Drawing
Range:	0 to 31
Possible options:	0: Turned off 1: Perspective view active 2: Front clipping on 4: Back clipping on 8: UCS Follow mode on 16: Front clip not at eye

26.10 VIEWSIZE system variable

26.10.1 View size (Read Only)

The height of the current viewport.

Type:	Real
Saved in:	Drawing
Default value:	0.0



26.11 VIEWTWIST system variable

26.11.1 View twist (Read Only)

The view twist angle relative to the WCS for the current viewport.

Type:	Real
Saved in:	Drawing

26.12 VIEWUPDATEAUTO system variable

26.12.1 Automatically update drawing views

Turns on automatic updates to drawing views (in paper space) when the source model changes.

When turned off, the VIEWUPDATE command manually updates the drawing views created by VIEWBASE and VIEWSECTION commands. This only works in paper space.

Type:	Boolean
Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Don't update drawing views automatically On (1): Update drawing views automatically

26.13 VISRETAIN system variable

26.13.1 Visibility retain

Controls the visibility, color, linetype and linewidth of an XRef, and if path changes to nested XRefs are saved. If the PSTYLEPOLICY system variable is off (0), also controls the plotstyles of XRef-dependent layers.

- If Off (0): Changes made to XRefs-dependent layers in the current drawing are valid in the current session only and are not saved with the drawing. When the current drawing is reopened, the layer table is reloaded from the reference drawing and the current drawing reflects those settings. The layer settings affected are On, Off, Freeze, Thaw, Color, Ltype, LWeight, and PStyle (if PSTYLEPOLICY is set to 0).
- If On (1): Layer settings are saved with the current drawing's layer table and persist from session to session.

Type:	Short
-------	-------



Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: Off, the layer table, as stored in the XRef takes precedence 1: On, XRef-dependent layer changes made in the current drawing take precedence

26.14 VOLUMEPREC system variable

26.14.1 Volume precision

Controls the number of decimal places displayed for volumes, if volume properties are formatted with the PROPUNITS system variable.

If negative, LUPREC (Linear Unit Precision) is used.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	-1 to 8
Default value:	-1
Possible values:	-1: Use the LUPREC system variable 0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000 5: 0.00000 6: 0.000000 7: 0.0000000 8: 0.00000000



26.15 VOLUMEUNITS system variable

26.15.1 Volume units

Controls a list of units used to display volume, if volume properties are formatted with the PROPUNITS system variable.

If empty, all volumes match the drawing.

Note: The string contains a space-separated list of unit abbreviations.

BricsCAD only

Type:	String
Saved in:	Registry
Default value:	in ft mi µm mm cm m km

26.16 VP MAXIMIZED STATE system variable

26.16.1 Viewport maximized (Read Only)

Displays a value to indicate if the viewport is maximized.

Note: You cannot plot or publish when the viewport is maximized.

This system variable is available only at the Command line.

Type:	Boolean
Saved in:	Not saved
Default value:	Off
Possible values:	Off (0): Viewport is not maximized On (1): Viewport is maximized

26.17 VPROTATEASSOC system variable

26.17.1 Rotate view

Rotates a view with the viewport, in paper space.

Type:	Boolean
Saved in:	Registry



Default value:	On
Possible values:	Off (0): Rotate view off On (1): Rotate view on

26.18 VSMAX system variable

26.18.1 Virtual screen maximum (Read Only)

The current viewport's upper-right corner coordinates.

Type:	3D point
Saved in:	Drawing

26.19 VSMIN system variable

26.19.1 Virtual screen minimum (Read Only)

The current viewport's lower-left corner coordinates.

Type:	3D point
Saved in:	Drawing

26.20 VTDURATION system variable

26.20.1 View transition duration

Controls the duration of animated view transitions in milliseconds.

Values between 0 and 5000 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 5000
Default value:	750



26.21 VTENABLE system variable

26.21.1 Enable view transitions

Enables animation transitions during pan, zoom and rotation view actions in model space. See also, the VTFPS system variable.

Type:	Short
Saved in:	Registry
Range:	0 to 7
Default value:	3
Possible options:	1: For zoom/pan 2: For rotation 4: For unattended mode

26.22 VTFPS system variable

26.22.1 View transition minimum FPS

Controls the minimum FPS required to enable animated view transitions.

Values between 1 and 30 are accepted.

The default value is 7, which means that the redraw time should take less than 143 (=1000/7) milliseconds. If the computer is not capable to redraw the view fast enough, no animation will be available.

Type:	Short
Saved in:	Registry
Range:	1 to 30
Default value:	7



27. W

27.1 WARNINGMESSAGES system variable

27.1.1 Warning messages

Controls which warning messages are displayed.

BricsCAD only

Type:	Long
Saved in:	Preference
Default value:	1048575
Possible options:	<p>1: When 3D context with hardware rendering switched off is selected 2: When tool property are modified in the Customize dialog box 4: When sheet custom properties are deleted 8: When entities are moved to frozen or off layer 16: When saving to previous version that does not support certain entities 32: When a drawing is opened and modified attachments are detected 64: When a new layer, that does not match the current layer filter, is created 128: Render: Tile sizes between 4 and 127 are processed as 128 256: When a category mass is expanded in the Properties panel 512: When an item in the Customize dialog box is deleted 1024: On publish: Save sheet list 2048: When layouts in Page Setup Explorer are deleted 4096: When mass property calculations will take a long time 8192: When entering the Array Edit mode 16384: When there are incompatible units 32768: When a block definition modification will cause all related block references to update 65536: When a Data Link has changed - tables that use this link may need to be updated 131072: When VIEWBASE is used for architectural drawings 262144: When a closed category in the Properties panel is expanded 524288: When an empty category in the Properties panel is removed</p>

27.2 WHIPARC system variable

27.2.1 Whip arcs

Controls if circles and circular arcs display as true (smooth) circles or as a series of angular lines.

Type:	Short
-------	-------



Saved in:	Registry
Range:	0 to 1
Default value:	1
Possible values:	0: Display circles and arcs as a series of angular lines 1: Display as true circles and arcs

27.3 WHIPTHREAD system variable

27.3.1 Whip thread

Controls if the REGEN and REDRAW commands use multithreading, if the machine has multiple processors (Not yet supported).

When multithreaded processing is used for redraw operations (value 2 or 3), the order of entities specified with the DRAWORDER command is not guaranteed to be preserved for display but is preserved for plotting.

Type:	Short
Saved in:	Registry
Range:	0 to 3
Default value:	0
Possible options:	0: No multithreading 1: Regenerative multithreading 2: Redraw multithreading

27.4 WINDOWAREACOLOR system variable

27.4.1 Window area color

Controls the color for window selection areas (left-right).

It has effect only when SELECTIONAREA system variable is on.

Type:	Short
Saved in:	Registry
Range:	1 to 255



Default value:	150
----------------	-----

27.5 WIPEOUTFRAME system variable

27.5.1 Wipeout frame

Controls the display of frames for wipeout entities, if the FRAME system variable is set to **Use individual system variables** (3).

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	1
Possible values:	0: Hide wipeout frames 1: Display and plot wipeout frames 2: Display but do not plot wipeout frames

27.6 WMFBKGND system variable

27.6.1 Windows Meta File background

Controls how the background of a WMF (Windows Meta File) or Copy Clip is created and displayed in other applications.

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Transparent background; foreground set with the WMFFOREGND system variable On (1): Current background color; foreground remains unchanged

27.7 WMFFOREGND system variable

27.7.1 Windows Meta File foreground

Controls how the foreground of a WMF (Windows Meta File) or Copy Clip is created and displayed in other applications.



WMFFOREGND applies only when WMFBKGND is set to 0.

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Ensure foreground color is darker than background color On (1): Ensure foreground color is lighter than background color

27.8 WMFTTFASTEXT system variable

27.8.1 TrueType Text mode for Windows Meta File

Controls if TrueType text is exported as vectorized graphics or as text to a WMF (Windows Meta File).

BricsCAD only

Type:	Boolean
Saved in:	Registry
Default value:	0
Possible values:	Off (0): Export TrueType text as vectorized graphics On (1): Export TrueType text as text

27.9 WNDLMAIN system variable

27.9.1 Main window state

The state of the main graphics window.

BricsCAD only

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	2



Possible values:	0: Normal 1: Minimized 2: Maximized
------------------	---

27.10 WNDLSCRL system variable

27.10.1 Window scrollbars (Windows)

Controls the display of scrollbars on the main graphics window.

BricsCAD only

Type:	Boolean
Saved in:	Workspace
Default value:	Off
Possible values:	Off (0): Don't show scrollbars On (1): Show scrollbars

27.11 WNDLTEXT system variable

27.11.1 Text window state

The text window status.

BricsCAD only

Type:	Short
Saved in:	Registry
Possible values:	0: Hidden 1: Normal 2: Minimized 3: Maximized

27.12 WNDPMAIN system variable

27.12.1 Main window top-left

The top-left position of the main graphics window.

BricsCAD only



Type:	2D point
Saved in:	Registry

27.13 WNDPTEXT system variable

27.13.1 Text window top left

The top-left position of the text window.

BricsCAD only

Type:	2D point
Saved in:	Registry

27.14 WNDSMAIN system variable

27.14.1 Main window size

The size of the main graphics window.

BricsCAD only

Type:	2D point
Saved in:	Registry

27.15 WNDSTEXT system variable

27.15.1 Text window size

The size of the text window.

BricsCAD only

Type:	2D point
Saved in:	Registry

27.16 WORLDUCS system variable

27.16.1 World UCS (Read Only)

Displays if the UCS matches the WCS or not.



Type:	Boolean
Saved in:	Not saved
Possible values:	Off (0): UCS doesn't match the WCS On (1): UCS matches the WCS

27.17 WORLDVIEW system variable

27.17.1 World view

Controls if the DVIEW or VPOINT commands change the current UCS to the WCS.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	1
Possible values:	0: UCS remains unchanged 1: UCS changes to the WCS for the duration of the command; the command input is relative to the current UCS

27.18 WRITESTAT system variable

27.18.1 Write status (Read Only)

The state of the open drawing - read-only or writable.

Used in LISP to determine the write status of drawing.

Type:	Boolean
Saved in:	Not saved
Default value:	On
Possible values:	Off (0): Can't write to the drawing On (1): Can write to the drawing



27.19 WSAUTOSAVE system variable

27.19.1 Workspace autosave

Automatically saves workspace changes.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Don't save automatically On (1): Save automatically

27.20 WSCURRENT system variable

27.20.1 Current workspace

The name of the current workspace.

Type:	String
Saved in:	Registry



28. X

28.1 XCLIPFRAME system variable

28.1.1 Xref clipping frame

Controls the display of XRef clipping boundaries, if the FRAME system variable is set to **Use individual system variables** (3).

Type:	Short
Saved in:	Drawing
Range:	0 to 2
Default value:	2
Possible values:	0: Hide clipping boundaries 1: Display and plot clipping boundaries 2: Display but do not plot clipping boundaries

28.2 XDWGFADECTL system variable

28.2.1 XRef database fade control

Controls the transparency for XRefs.

Values between -90 and 90 are accepted. Negative values disable fading.

Type:	Short
Saved in:	Registry
Range:	-90 to 90
Default value:	70

28.3 XEDIT system variable

28.3.1 XRef editable

Allows in-place editing on the current drawing, if it is referenced in another drawing.

Type:	Boolean
-------	---------



Saved in:	Drawing
Default value:	On
Possible values:	Off (0): Can't use in-place reference editing On (1): Can use in-place reference editing

28.4 XFADECTL system variable

28.4.1 Reference editing fade control

Controls the transparency for XRefs during edit mode.

This system variable affects only the entities that are not being edited in the reference.

Values between 0 and 90 are accepted.

- A value of zero means fully opaque.
- A value of 90 means maximum transparency.

Type:	Short
Saved in:	Registry
Range:	0 to 90
Default value:	50

28.5 XLOADCTL system variable

28.5.1 XRef load control

Controls XRef demand loading and if a copy or the original drawing is opened (Not yet supported).

Type:	Short
Saved in:	Registry
Range:	0 to 2
Default value:	1



Possible values:	0: Turn off demand-loading; the entire drawing is loaded 1: Turn on demand-loading; referenced drawings are kept open and locked 2: Turn on demand-loading; copies of referenced drawings are opened and locked; referenced drawings are not locked
------------------	---

28.6 XLOADPATH system variable

28.6.1 XRef load path

Controls a path to store temporary copies of demand-loaded XRefs. See also the XREFCTL system variable.

Type:	String Standard
Saved in:	Registry

28.7 XNOTIFYTIME system variable

28.7.1 Xnotify time

Controls how often the program checks for modified XRefs, images and PDF documents, in minutes.

This is if XREFNOTIFY, IMAGENOTIFY and/or PDFNOTIFY is ON.

Values between 0 and 10,080 are accepted.

Type:	Short
Saved in:	Registry
Range:	0 to 10080
Default value:	5

28.8 XREFCTL system variable

28.8.1 XRef control

Creates XRef log files (XLG).

Type:	Boolean
Saved in:	Registry
Range:	Off



Possible values:	Off (0): Don't write log files On (1): Write log files
------------------	---

28.9 XREFNOTIFY system variable

28.9.1 XRef notify

Displays a warning, when a drawing is opened, if there are missing XRefs.

Type:	Boolean
Saved in:	Registry
Default value:	On
Possible values:	Off (0): Disable Xref notification On (1): Enable Xref notification

28.10 XREFOVERRIDE system variable

28.10.1 XRef override

Controls the display of entity visual properties (such as color, linetype, linewidth, transparency, or plot style) on referenced layers.

- If 0: When the properties of the entities on the XREF drawing are set to ByLayer, any changes to the xref layer properties are displayed in the current drawing.
- If 1: When the properties of the entities on the XREF drawing are not set to ByLayer, entities on xref layers are treated as if their properties are set to ByLayer. And every external reference layer can have its own set of layer overrides.

Type:	Short
Saved in:	Drawing
Range:	0 to 1
Default value:	0
Possible values:	(0): Off, only ByLayer properties of the entities in the XREF drawing can be changed (1): On, all properties of entities in the XREF drawing can be changed by its original layer property



29. Y



30. Z

30.1 ZOOMFACTOR system variable

30.1.1 Zoom factor

Controls the incremental zoom change with respect to the mouse-wheel.

When zooming in, the incremental step decreases gradually allowing to focus on a particularly detail easily.

Values between 3 and 100 are accepted.

Type:	Short
Saved in:	Registry
Range:	3 to 100
Default value:	40

30.2 ZOOMWHEEL system variable

30.2.1 Mouse wheel zoom direction

Toggles the mouse wheel zoom direction.

Type:	Short
Saved in:	Registry
Default value:	0
Possible values:	0: Forward zooms in, backward zooms out 1: Forward zooms out, backward zooms in